

# MODEL H6140 1/2" TWIN HAMMER AIR IMPACT WRENCH INSTRUCTION SHEET

#### **WARNING** EYE/EAR INJURY HAZARD! Wear safety glasses and hearing protection during use of this tool! **INJURY HAZARD!** Always disconnect tool from air to prevent unexpected operation during service! **DO NOT EXCEED 150 PSI!** Personal injury could occur. SHATTERING HAZARD! Use sockets rated for impact wrench use only.

#### Introduction

Twin hammer design means enough power for the toughest bolts. ½" Drive accepts all ½" standard and metric sockets. Features include pistol grip with trigger switch, forward/reverse switch, six clutch settings and a ¼" NPT male quick connect fitting. Sockets not included.

#### **Inventory**

Α.	½" Twin Hammer Air Impact Wrench 1
B.	1/4" NPT Air Fitting 1

### **Operation**

Install any ½" drive socket onto your air impact wrench. Choose from clockwise (R) to tighten, or counterclockwise (L) to loosen by pushing the direction valve (**Ref # 16**) in or out. Turn the direction valve knob to 1 to add or to 6 to subtract torque. Operate between 85 to 114 PSI. Draws approximately 3.5 CFM.



Figure 1. Model H6140

The impact wrench MUST have 3-4 drops of air tool oil directly dropped into the air fitting before each use. For best results, use the setup shown in **Figure 2**. Add 3-4 drops SAE#30 oil to the ball oil fitting on the back if the tool with daily use.





Figure 2. Installing your tool.

If you need help with your new pneumatic tool, call our Tech Support at: (570) 546-9663.

COPYRIGHT © JUNE, 2006 BY GRIZZLY INDUSTRIAL, INC.
WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE
OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.
#PC8328 PRINTED IN CHINA

## **H6140 Parts Breakdown and List**



REF	PART #	DESCRIPTION
1	PH6140001	MOTOR HOUSING
2	PH6140002	WARNING LABEL
3	PH6140003	GREASE FITTING
4	PH6140004	REVERSE VALVE BUSHING
5	PH6140005	REVERSE VALVE BUSHING SEAL
6	PH6140006	THROTTLE VALVE ASSEMBLY
7	PH6140007	THROTTLE VALVE FACE
8	PH6140008	THROTTLE VALVE SPRING
9	PH6140009	THROTTLE VALVE STEM
10	PH6140010	AIR STRAINER ASSEMBLY
11	PH6140011	TRIGGER
11-1	PH6140011-1	PLUG
12	PH6140012	TRIGGER PIN
13	PH6140013	REVERSE VALVE
14	PH6140014	REVERSE VALVE DETENT BALL
15	PH6140015	REVERSE VALVE DETENT SPRING
16	PH6140016	REVERSE VALVE KNOB
17	PH6140017	REVERSE VALVE KNOB SCREW
18	PH6140018	NAMEPLATE
22	PH6140022	ROTOR
23	PH6140023	REAR ROTOR BEARING
24	PH6140024	FRONT ROTOR BEARING

REF	PART #	DESCRIPTION			
25	PH6140025	REAR ROTOR BEARING RETAINER			
26	PH6140026	CYLINDER			
27	PH6140027	CYILINDER DOWEL			
29	PH6140029	VANE PACKET			
30	PH6140030	FRONT END PLATE			
31	PH6140031	REAR END PLATE			
32	PH6140032	END PLATE GASKET			
33	PH6140033	MOTOR CLAMP WASHER			
34	PH6140034	HAMMER FRAME ASSEMBLY			
35	PH6140035	HAMMER PIN			
36	PH6140036	HAMMER FRAME REAR WASHER			
37	PH6140037	HAMMER			
38	PH6140038	HAMMER CASE			
38-1	PH6140038-1	HAMMER CASE PILOT			
39	PH6140039	HAMMER CASE GASKET			
40	PH6140040	HAMMER CASE BUSHING			
41	PH6140041	HAMMER CASE CAP SCREW			
43	PH6140043	ANVIL			
44	PH6140044	SOCKET RETAINER			
45	PH6140045	RETAINER O-RING			
46*	PH6140046	1/4" NPT AIR FITTING			
* NOT	* NOT SHOWN IN PARTS BREAKDOWN				

NOT SHOWN IN PARTS BREAKDOWN

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com