


9" QUICK RELEASE WOODWORKING VISE



OPERATING INSTRUCTIONS



Due to continuing improvements, actual product may differ slightly from the product described herein.



3491 Mission Oaks Blvd., Camarillo, CA 93011

Visit our Web site at http://www.harborfreight.com

Copyright[©] 2006 by Harbor Freight Tools[®]. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

For technical questions or replacement parts, please call 1-800-444-3353

SPECIFICATIONS

Jaw Width	9 Inches
Throat Depth	3 Inches
Maximum Jaw Opening	10-5/16 Inches
Jaw Hardness	25-30 HRC
Rear Mounting Hole Dimensions	.435" Diameter x 2 and .420"W x .714"H x 2
Overeall Dimension	6.0"L X 9.0"W X 18.0"H
Net Weight	24 Lbs.

SAVE THIS MANUAL

You will need the manual for the safety warnings and precautions, operating and maintenance procedures, parts list and diagram. Keep your invoice with this manual. Write the invoice number on the inside of the front cover. Keep the manual and invoice in a safe and dry place for future reference.

SAFETY WARNINGS AND PRECAUTIONS

- 1. **KEEP PRODUCT USAGE AREA CLEAN.** Cluttered areas invite injuries.
- 2. **KEEP CHILDREN AWAY FROM PRODUCT USAGE AREA.** Do not allow children to handle this product.
- 3. **DO NOT USE THIS PRODUCT IF UNDER THE INFLUENCE OF ALCOHOL OR DRUGS.** Read warning labels on prescriptions to determine if your judgement or reflexes are impaired while taking drugs. If there is any doubt, do not use this product.
- 4. **USE EYE PROTECTION.** Wear ANSI approved safety impact goggles. Goggles are available from Harbor Freight Tools.
- 5. **DRESS SAFELY.** Do not wear loose clothing or jewelry as they can become caught in moving parts. Wear a protective hair covering to prevent long hair from becoming caught in the moving parts.
- 6. **DO NOT OVERREACH.** Keep proper footing and balance at all times.
- 7. **STAY ALERT.** Watch what you are doing at all times. Use common sense. Do not operate this product when you are tired or distracted from the job at hand.

- 8. **CHECK FOR DAMAGED PARTS.** Before using this product, carefully check that it will operate properly and perform its intended function. Check for damaged parts and any other conditions that may affect its operation. Replace or repair damaged or worn parts immediately.
- 9. **MAINTAIN PRODUCT WITH CARE.** Keep this product clean and dry, and moving parts lightly lubricated for better performance. Keep the Handle dry, clean and free from oil, grease, and solvents.
- 10. **USE THE RIGHT PRODUCT FOR THE RIGHT JOB.** Do not attempt to force a small tool or attachment to do the work of a larger industrial tool. There are certain applications for which this tool was designed. It will do the job better and more safely at the rate for which it was intended. Do not modify this tool and do not use this tool for any purpose other than which it was intended.

UNPACKING

When unpacking, check to make sure all parts shown on the Parts List (page 5) are included. If any parts are missing or broken, please call Harbor Freight Tools at the number shown on the cover of this manual as soon as possible.

NOTE: Always mount the vise to a level workbench that is capable of supporting the weight of the vise and all work-pieces.

NOTE: All parts below refer to the parts listed on page 5 of this manual.

Setting Up The Vise:

- 1. Use the mounting holes on the Vise Plate (1) as a template. Lift the Vise against the workbench and, with a pencil, mark the points at which to fasten the Vise to the workbench. Set the Vise aside. *See Figure 1 next page.*
- 2. Drill the holes of the appropriate size (where previously marked with a pencil) into the workbench. *Caution:* Before drilling holes, always check to make sure that no hidden electrical wires or cords are in the drilling path.
- 3. Carefully set the Vise into place against the workbench with the mounting holes corresponding to the holes previously drilled through the top of the workbench.
- 4. Insert hardened steel bolts (not provided), of the appropriate diameter through the Vise Plate (1) and into the workbench. The length mounting bolts will vary, depending on the thickness of workbench the Vise it is to be attached to.

5. From the underside of the workbench, put the appropriate size washers, lock washers and nuts on the bolts (not provided). Tighten all the nuts, securing the Vise Plate (1) to the workbench. Be sure the Vise is securely attached to the workbench before working with the Vise.





Figure 1

OPERATING INSTRUCTIONS

Note: By pushing down on the Quick Release Lever (4), you can release the Jaws so the Jaws can be easily and quickly slid open or closed.

- Slide the Jaws (2) open by either turning the Handle (3) or using the Quck Release Lever. Place the workpiece you are working on inside the Jaws. Tighten the Jaws (2) against the workpiece by turning the Handle (3) clockwise until your workpiece is held securely.
 Caution: Damage could occur if you over-tighten the Handle (3). Avoid marring the workpiece surface. See Figure 2.
- 2. To remove the object you are working on, turn the Handle (3) counterclockwise two to three times, opening the Jaws (2). Remove your workpiece.



PART #	DESCRIPTION	QTY
1	Vise Plate	1
2	Jaws	2
3	Handle	1
4	Quick Release Lever	1
5	Lead Screw	1

PARTS LIST

Note: No replacement parts are available for this product.

PARTS DESCRIPTION

Part 2 Part 3

PLEASE READ THE FOLLOWING CAREFULLY


THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER NOR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACE-MENT PARTS THERETO.

SKU 94386

For technical questions please call 1-800-444-3353.

Page 5

Part (4)



Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com