

# 6" OFF ROAD LIGHT BAR LOUD SPEAKER

**Model 95953** 

## SET UP AND OPERATING INSTRUCTIONS



Diagrams within this manual may not be drawn proportionally.

Due to continuing improvements, actual product may differ slightly from the product described herein.

# Distributed exclusively by Harbor Freight Tools<sup>®</sup>.

3491 Mission Oaks Blvd., Camarillo, CA 93011

Visit our website at: http://www.harborfreight.com



Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

Copyright<sup>©</sup> 2007 by Harbor Freight Tools<sup>®</sup>. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

For technical questions or replacement parts, please call 1-800-444-3353.

#### **SAVE THIS MANUAL**

Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.



WARNING! Read all instructions

Failure to follow all instructions listed below may result in serious injury.

#### **SAVE THESE INSTRUCTIONS**

#### **WORK AREA SAFETY**

- 1. Keep children and bystanders away while installing. Distractions can cause you to lose control.
- 2. Keep work area clean and well lit. Cluttered or dark areas invite accidents.

# **PERSONAL SAFETY**

- 1. Wear ANSI-approved safety goggles.
- 2. Stay alert and use common sense when operating. Do not use when tired or under the influence of drugs, alcohol or medication.
- 3. Dress properly. Do not wear loose clothing or jewelry when installing. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry or long hair can be caught in moving parts.

## PRODUCT USE AND CARE

- 1. This product is not a toy. Keep it out of reach of children.
- 2. Use the correct product for your application. The correct product will do the job better and safer at the rate for which it was designed. Do not modify this product or use it for a purpose for which it is not intended.
- 3. Check for broken parts and any other condition that may affect the product's operation.

# **SERVICE**

 Maintain labels and nameplates on the product. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.

# **MISCELLANEOUS**

- 1. Exposure to noise levels above 85 dB is hazardous to hearing.
- 2. The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.



## **SPECIFICATIONS**

Rated Power	15RMS (Watts)
Maximum Input Power	30 Watts
Frequency Response	80 - 20,000 Hz
Impedance	4 ohms
Decibel Sensitivity	86 dB

## **UNPACKING**

When unpacking, check to make sure that the item is intact and undamaged. If any parts are missing or broken, please call Harbor Freight Tools at the number shown on the cover of this manual as soon as possible.

#### **SET UP INSTRUCTIONS**



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

**Note:** For additional information regarding the parts listed in the following pages, refer to the Assembly Diagram near the end of this manual.

## **Mounting**

- 1. If you are not completely comfortable doing this type of mounting and wiring project, seek help from a qualified service technician.
- 2. Consult the vehicle owner's manual and the manual for the stereo system prior to installing this device.
- 3. Turn the vehicle off and disconnect the negative battery terminal.
- 4. Select a proper location to mount the Speaker and mark it. Keep in mind that the Wires from the Speaker must be able to reach a pre-existing speaker terminal. The Speaker can be top or bottom mounted. If there is no hole for mounting the Speaker, then a hole must be drilled at the point selected.
- 5. The speaker and power lines must be protected at contact points with the vehicle's body to prevent possible shorting.
- 6. Installation may require that a hole be drilled through which to insert the wiring.
- 7. The black wire with the white stripe is the positive connection and must be connected to the positive terminal on the pre-existing speaker. The solid black wire connects to the ground or negative terminal.
- 8. Properly insulate and cap off all wires.
- 9. The unit will now broadcast whenever the pre-existing speaker does.

#### MAINTENANCE AND SERVICING

# **ACAUTION**

Damaged products can fail, causing personal injury. Do not use a damaged product. If abnormal noise or vibration occurs, have the problem corrected before further use.

#### Cleaning, maintenance, and lubrication

- 1. **BEFORE EACH USE**, inspect the general condition of the product. Check for loose screws, misalignment or binding of moving parts, cracked or broken parts, damaged electrical wiring, and any other condition that may affect its safe operation.
- 2. **AFTER USE**, clean external surfaces of the product with clean, moist cloth.

#### **LIMITED 90 DAY WARRANTY**

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

3491 Mission Oaks Blvd. • PO Box 6009 • Camarillo, CA 93011 • (800) 444-3353

Record Product's Serial Number Here	

**Note:** If product has no serial number, record month and year of purchase instead.

**Note:** Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts.

SKU 95953 For technical questions, please call 1-800-444-3353.


Page 5

#### PLEASE READ THE FOLLOWING CAREFULLY


THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.


#### **PARTS LIST**

Part	Description	Qty
1	Cover	1
2	Speaker Cover	1
3	Speaker	1
4	Wiring Kit	1
5	Housing	1
6	Ring	2
7	Gasket	1









SKU 95953

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com