


# TRANSFORMERS

## CYBERTRON

ROBOTS IN DISGUISE



AGES 5+

80315/80285 Asst.

TRANSFORMERS.COM

NOTE: Some parts are made to detach if excessive force is applied and are designed to be re-attached if separation occurs. Adult supervision may be necessary for younger children.

### CHANGING TO ROBOT

1

5

6

ROBOT MODE

KEY ACTIVATED

1

2

1. Insert missile into launcher.  
2. Insert key to launch missile.

Reverse order of instructions to convert back into vehicle.

INSERT KEY TO ACTIVATE FEATURES!

Cyber Planet Key launches weapon blast!

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>