

**Continuous Ink Supply System  
for  
HP1200  
Installation Instruction**

**For AT Prefilled Version**

**With Auto Reset Chips**

**This Version of the Continuous Ink Flow System comes with Prefilled Cartridges and Auto Reset Chips. You just need to fill the Reservoir bottles and print! The whole operation is very easy. It's really an effective tool to save your money.**

# HP Business Inkjet 1200

Welcome to use our Continuous Ink Supply System. It will largely reduce your printing cost. It is really the perfect compatible products for Inkjet printers .In order to insure you the easy and safe operation, please kindly to read our instruction carefully before using the CISS.

## 1、 General Guide:

### 1、 Components

A、 CIS system 1 set

D、 Refill Kit 4pcs

B、 Air filters 4pcs

E、 Instruction CD 1pc

C、 Support Arm 1 set



## 2、 Opening box inspection

- Check whether all the accessories are ready.
- Check whether there's leakage of CIS System, whether some tubes have been separated from CISS. If there is, please kindly to contact the local dealer.
- Check whether there is air space in the tube. If the length of air space is more than 20cm, please clean the printer head for 2 or 3 times before printing.

## 2、 Printer testing:

- Check whether the printer is all in normal, like mechanical status, lubrication status, broken or not.
- Print testing lines, insure the printing head is in gear.
- Print pictures, to see whether the printing image is ok.

## 3、 Installing steps:

### (1)、 First step



Put the CISS on the left side of the printer, in the same time order all the tubes in the correct position.



Pull up the rubber plug in the air hole.



Place the 4pcs air filters ready in the air holes, the thicker side is the assembly part.

### (2)、 The second step: Set up the Continuous Ink Supply System



Open the cover for the cartridges



Remove out the original cartridges



Place the cartridges of our CISS correctly



Slightly press every cartridges to check all the cartridges are in the correct position. And Please be care about the tubes which out through the box .Then stick the Support Arm on the Position which show in the third picture.



Clip the tube clamp



Finished

(3)The third step: Checking the printing head



Enter in the Printer Services Item

If there show breaks, please clean your printing head. It is possible that the wispy air have entered into the printing head. If it is still show little breaks specially show in one color, it is no need to repeatedly continue to clean. Just keep the printer silent for about one hour, it may disappear. If after testing, it still abnormal, please kindly to contact with local dealer.

#### 4、Reset:



If the indicator light flashing when printing, it show that you need to reset the chip to refill the ink. Then please power off your printer for about 1 minute, then turn on. It will be reset to full ink.

#### 5.Refill Ink:



Please pay attention to the ink level in the reservoirs; if the ink level is below 1CM as the above picture shown, please use refill kits to fill ink into Reservoir bottles. Carefully pull out the rubber plugs from the refill holes.(there is possibility of ink spattering. Be careful!) Refill ink according to the color in short supply. Then put the rubber back. **(Please keep the printer and the reservoir at the same horizontal line during the process of refilling ink.)**

#### 6、Attention for maintenance:

Take out the CISS including the inner cartridges and other components. Then remove support arm from printer, and place the original cartridges in. Please inquire local dealer before sending to maintenance.

#### 7.Notice:

1. Please don't take out cartridge at random after installing the CIS system. Keep the reservoir bottles on the same level with the printer.
2. Try to keep at least 1/2 inch of ink in the bottles, as you don't want to run out of ink and draw air into the cartridge.
3. Don't place the Reservoir Bottles higher or lower much than the printer.
4. To be used in a dry place between 15 and 35 degree. Avoid exposure to direct sunlight.
5. Don't put the continuous ink supply systems reversed or leaning during the shipment. Please make sure all the ink filling holes and Ventilation holes are closed tightly during the transportation. Otherwise, the ink shall leak out.
6. Don't sway the cartridge frequently. It may cause ink leakage.

7. Don't pull out the connector of cartridge and don't tear off adhesive tape at the bottom of cartridge.

**8.Warning:**

1. Not drinkable; keep it out reach of children.
2. Avoid exposure to direct sunshine and don't keep it in high or freezing temperature.
3. Avoid collision and fallen down.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>