


Hardware

(Drawn to Scale)



x 1




x 2




x 2




x 4




x 3



x 4




x 1




x 4



x 11



x 16




x 16



x 1

Balancing Kit





x 4

Wire Connector

- Low Profile Washer
- 3" Wood Screw
- Flat Washer
- 1.5" Wood Screw
- Screw, Low Profile
- Canopy Screw
- Setscrew
- Mounting Isolator
- Screw, Blade Iron Armature
- Screw, Blade Assembly
- Blade Grommet
- Screw, Switch Housing Assembly
- Screw, Machine, 6-32

Fan Parts

(Not Drawn to Scale)




Hunter

Using this Parts Guide, make sure all parts are included in the box. If parts are missing, DO NOT RETURN

THIS ITEM TO THE STORE, call 888-830-1326 for assistance.

THIS PARTS GUIDE IS FOR REFERENCE ONLY. REFER TO THE INSTALLATION MANUAL FOR FULL ASSEMBLY INSTRUCTIONS.




Parts List

Item Name	Qty	Part #
* Hanging System Kit		
Ceiling Plate		98848-01
Canopy		98848-01
Canopy Trim Ring		98848-01
Hanger Ball / Downrod Assembly		98135-19
Setscrew		
Low Profile Washer		
Canopy Screw		
Wood Screw		
Flat Washer		
Mounting Isolator		
Screw, Low Profile		
Switch Housing Assembly	1	98865-19
Blade Iron Set	1	98403-05
Blade Set	1	G0253-67
Screw, Blade Iron Armature	11	63755-06
Light Kit Assembly	1	98866-01
Hardware Kit	1	98848-00-860
Blade Grommet		
Blade Assembly Screw		
Screw, Machine, 6-32		
Wire Connector		
Screw, Switch Housing Assembly		
Globe/Shade	1	98874-01
Pull Chain Pendant	1	G0090-01
Pull Chain Pendant	1	G0091-01
Pull Chain	1	63756-35
Pull Chain	2	63756-60
Bottom Cap	1	64349-07
Finial	1	74758-03
Light bulb / Bulb	2	77646-04
Dummy Terminal, Male	1	08198-01
Dummy Terminal, Female	1	08200-01
Cap, Switch Housing	1	73853-01
Plug Button	1	73854-01
Balancing Kit	1	65666-01


Materiales

(no dibujados a escala)



Piezas del ventilador

(no dibujadas a escala)




GUÍA DE PIEZAS

Hunter

ALTO

Consulte esta Guía de partes para asegurarse de que todas las partes estén incluidas en la caja.



Si falta alguna parte, NO DEVUELVA ESTE PRODUCTO A LA TIENDA. Solicite ayuda al 888-830-1326. ESTA GUÍA DE PARTES SOLAMENTE ES REFERENCIAL. CONSULTE LAS INSTRUCCIONES COMPLETAS DE ENSAMBLAJE EN EL MANUAL DE INSTALACIÓN

Lista de piezas		No. del modelo	21317
		No. del dibujo de ensamblaje	98848-01
		Acabado	Bronce Nuevo
Nombre del ítem	Cantidad	No. de la pieza	
Kit del sistema de suspensión		98135-19	
Placa de techo			
Campana			
Anillo de la moldura de campana			
Bola de suspensión / Conjunto de varilla			
Tornillo prisionero			
Roseta de perfil bajo			
Tornillo, de campana			
Tornillo, de madera			
Arandela, plana			
Aislador de montaje			
Tornillo, de roseta de perfil bajo			
Conjunto del interruptor	1	98865-19	
Juego de soporte de paletas	1	98403-05	
Juego de paletas	1	G0253-67	
Tornillo, de armadura de soporte de paleta	11	63755-06	
Conjunto del kit de luz	1	98866-01	
Kit de materiales	1	98848-00-860	
Arandela de caucho, de paleta			
Tornillo, de conjunto de paleta			
Tornillo, mecánico, 6-32			
Empalme plástico			
Tornillo, del conjunto de la caja del interruptor			
Globo / Pantalla	1	98874-01	
Pendiente del tirador de cadena	1	G0090-01	
Pendiente del tirador de cadena	1	G0091-01	
Tirador de cadena	1	63756-35	
Tirador de cadena	2	63756-60	
Tope inferior	1	64349-07	
Cubierta ornamental	1	74758-03	
Bombilla	2	77646-04	
Terminal simulado, macho	1	08198-01	
Terminal simulado, hembra	1	08200-01	
Tapa, Caja del interruptor	1	73853-01	
Botón taponador	1	73854-01	
Kit de equilibrado	1	65666-01	

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>