



Inspection Instructions

SmartLink Software Update

GS-2669 DC

GS-3369 DC

GS-4069 DC

Part No. 1253604
Rev A

Introduction



Observe and Obey:

- This procedure shall be completed by a person trained and qualified on the repair of this machine.
- Immediately tag and remove from service a damaged or malfunctioning machine.
- Repair any machine damage or malfunction before operating the machine.

Before Starting Installation:

- Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual.
- Be sure that all necessary tools and parts are available and ready for use.
- Read this procedure completely and adhere to the instructions. Attempting shortcuts may produce hazardous conditions.
- Indicates that a specific result is expected after performing a series of steps.
- Indicates that an incorrect result has occurred after performing a series of steps.

Note: These installation instructions only apply to the Genie models listed on the front cover, as required by Safety Notice 130010.

Tools Required:

Laptop or desktop computer with an Ethernet Port and Internet Browser

Torx T10 screw driver

CAT5 Ethernet cable of suitable length

Glossary of Terms

ECM - Electronic Control Module

GCON - Ground Controller. This ECM is located at the ground controls.

PCON - Platform Controller. This ECM is located at the platform controls.

CAT5 Cable - Standard Ethernet cable used for networking purposes.

Components of Kit 1253597

Printing Instructions
Genie part number 1255048
Qty. 1

Thumb drive
Genie part number 1253598
Qty. 1

Includes:

Software, SL1000, APP
Genie part number 137641
Qty. 1

SmartLink Software Update Installation Instructions
Genie part number 1253604
Qty. 1

Procedure

Updating Machine Software

- 1 Turn on the computer.


Using a thumb drive:

- 2 Insert the thumb drive into the USB port. Genie part number 1253598.
- 3 Copy the .gff file onto your hard disk or desktop.

All applications:

Note: Disable all external internet or network connections before continuing.

- 4 At the GCON, turn the key switch to the GCON position.
 - 5 At the PCON, pull out the red Emergency Stop button to the on position.
 - 6 At the GCON, press and hold the **Enter** and **Escape** buttons. Pull out the red Emergency Stop button to the on position.
- ⦿ Result: The GCON LCD will display the following screen.



- 1 LCD
- 2 ESCAPE button
- 3 ENTER button

- 7 Locate the diagnostic port on the side of the GCON.



- 1 Diagnostic Port


- 8 Remove one of the fasteners securing the cover and set aside. Loosen the other fastener. Do not remove it.
 - 9 Connect one end of a CAT5 Ethernet cable into the diagnostic port. Connect the other end into a PC or laptop.
- ⦿ Result: The GCON LCD will display the following screen.



- 10 Read and record the IP address.


Procedure

- 11 Launch a web browser such as Internet Explorer® or Firefox® on your PC or laptop. Type in the IP address from steps 8 and 9 into the web browser address bar and press Enter.
- ⦿ Result: The following screen will be displayed.



- 12 Select the **Browse** button. Navigate to the firmware file located on your hard disk or desktop and select the file. Firmware number 137641Y.gff (rev Y or above).

Note: Depending on your web browser, this button may be shown as **Choose File**. 137641Y.gff (rev Y or above).



- 13 Select the **Load Flash File** button.

Note: Verify it is the correct flash file.

- ⦿ Result: The following screen will be displayed.

Note: This process may take 1 to 2 minutes.




- 14 Select the **Reprogram Device (s)** button to start the ECM software update.
- ⦿ Result: The following screen will be displayed after the software update is complete.

Note: Do not turn off power while the ECM is being reprogrammed. This process may take up to 5 minutes.



Note: Verify that the firmware number is displayed in the box marked "**Current:**". Firmware number 137641Y (rev Y or above).



- 15 Select the **Run application** button to exit the software update mode.
- 16 Push in the red Emergency Stop button at the GCON and disconnect the CAT5 cable. Remove the thumb drive if installed.
- 17 Secure the diagnostic port cover using the retaining fasteners removed in step 5. Do not over tighten.

Procedure

- 18 Perform function test. Refer to the Operator's Manual on your machine.
- 19 Return the machine to service.
- 20 Fill out and sign the attached completion form and fax or email to Terex AWP Warranty Department. This will serve as verification that you have completed Safety Notice 130010.

If you have any further questions regarding these instructions or need assistance, please contact Genie Product Support at one of the following telephone numbers:

United States:		800-536-1800
Canada:		425-881-1800
Europe:	UK	0044 1476 584 333
	France	0033 237 260 986
	Germany	0049 4221 491 821
	Iberica	0034 935 725 090
	Italy	0039 075 941 8132
	Scandinavia	0046 3157 5154
	Other locations	0031 653 221 908
Middle East:		0097 143 391 800 or 0097 150 459 7937
Australia:		61 7 3456 4444
All other locations		001-425-881-1800

This page intentionally left blank.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>