

# Owner's Manual Mode d'emploi ND-BC1

**PIONEER CORPORATION**  
4-1, MEGURO 1-CHOME, MEGURO-KU, TOKYO 153-8654, JAPAN  
**PIONEER ELECTRONICS (USA) INC.**  
P.O. Box 1540, Long Beach, California 90801-1540, U.S.A.  
TEL: (800) 421-1404  
**PIONEER EUROPE NV**  
Haven 1087, Keetberglaan 1, B-9120 Melsele, Belgium  
TEL: (0) 3/570.05.11  
**PIONEER ELECTRONICS ASIACENTRE PTE. LTD.**  
253 Alexandra Road, #04-01, Singapore 159936  
TEL: 65-6472-1111  
**PIONEER ELECTRONICS AUSTRALIA PTY. LTD.**  
178-184 Boundary Road, Braeside, Victoria 3195, Australia  
TEL: (03) 9586-6300  
**PIONEER ELECTRONICS OF CANADA, INC.**  
300 Allstate Parkway, Markham, Ontario L3R 0P2, Canada  
TEL: 1-877-283-5901  
**PIONEER ELECTRONICS DE MEXICO, S.A. de C.V.**  
Blvd. Manuel Avila Camacho 138 10 piso  
Col. Lomas de Chapultepec, Mexico, D.F. 11000  
TEL: 55-9178-4270















先鋒股份有限公司  
總公司: 台北市中山北路二段44號13樓  
電話: (02) 2521-3588  
先鋒電子(香港)有限公司  
香港九龍尖沙咀海港城世界商業中心9樓901-6室  
電話: (0852) 2848-6488

<KNKNN> <04C00000>

Published by Pioneer Corporation.  
Copyright © 2004 by Pioneer Corporation.  
All rights reserved.

Publication de Pioneer Corporation.  
Copyright © 2004 Pioneer Corporation.  
Tous droits de reproduction et de traduction réservés.

Printed in Japan  
Imprimé au Japon  
<CZR5019-A> E



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Information to User  
Alteration or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment.

#### WARNING:

Handling the cord on this product or cords associated with accessories sold with the product will expose you to lead, a chemical known to the State of California and other governmental entities to cause cancer and birth defects or other reproductive harm. *Wash hands after handling.*

### IMPORTANT SAFEGUARDS

- Installation and wiring of this product require specialist skill and experience. To assure your safety, please request a specialist technician to install the unit.
- This product is a rear view camera for checking the view at the rear of a car. A rear view camera is a camera that provides symmetrical images in the same way as rear and side view mirrors.
- Connection to a TV with an RCA video input is possible, but confirm whether the TV you use has a reverse gear connection function.
- Direct sunlight or strong light (sunlight reflected from a bumper etc) on the camera may result in smear above and below the location where the light strikes, but this is not a malfunction.
- This product is designed to supplement the driver's rear view, but the camera images do not show all dangers and obstacles. Be sure to look behind you when reversing to confirm the view.
- This product features a wide-angle lens, so the rear view is wide and the far view is narrow, which may create a false sense of distance. Be sure to look behind you when reversing to confirm the view.
- Do not wash your car with an automatic car wash or high-pressure water as it may result in water entering the camera or the camera falling off.
- Check camera stand installation before driving. Are the screws loose?
  - Is the camera stand firmly secured?
  - If the rear view camera comes loose while you are driving it may cause an accident.

### Installation

#### Parts supplied

- Ⓐ Rear view camera × 1
- Ⓑ Power supply unit × 1
- Ⓒ RCA cable × 1
- Ⓓ Rear view camera stand × 1
- Ⓔ Hexagon wrench × 1
- Ⓕ Velcro tape (soft type) × 1
- Ⓖ Velcro tape (hard type) × 1
- Ⓗ Installation screws (3 × 4 mm) × 2
- ① Waterproof pad × 1
- Ⓙ Clamp × 10
- Ⓚ Double-sided tape × 1
- Ⓛ Lock tie × 1

#### Installation example (Fig. 1)

- ① Glass surface
- ② Make sure it doesn't touch the wiper
- ③ Install on the center part

#### Changing the orientation of camera stand installation (Fig. 2)

Changing the orientation of camera stand installation bracket Ⓐ enables a variety of installation possibilities. Change to match your car's shape or the installation site.

- Use the hexagon wrench to remove the screws securing camera stand brackets Ⓐ and Ⓑ.
- Change the orientation of installation bracket Ⓐ, and then secure with the screws again.

#### Note:

- Before finally installing the unit, connect the wiring temporarily, making sure it is all connected up properly, and the unit and the system work properly.
- Use only the parts included with the unit to ensure proper installation. The use of unauthorized parts can cause malfunctions.
- Consult with your nearest dealer if installation requires the drilling of holes or other modifications of the vehicle.
- Install the unit where it does not get in the driver's way and cannot injure the passenger if there is a sudden stop, like an emergency stop.
- When mounting this unit, make sure none of the leads are trapped between this unit and the surrounding metalwork or fittings.
- Do not mount this unit near the heater outlet, where it would be affected by heat, or near the doors, where rainwater might splash onto it. (Never install in locations such as the above because of the danger of malfunction due to high temperatures.)

- Before drilling any mounting holes always check behind where you want to drill the holes. Do not drill into the gas line, brake line, electrical wiring or other important parts.
- If this unit is installed in the passenger compartment, anchor it securely so it does not break free while the car is moving, and cause injury or an accident.
- If this unit is installed under a front seat, make sure it does not obstruct seat movement. Route all leads and cords carefully around the sliding mechanism so they do not get caught or pinched in the mechanism and cause a short circuit.
- Locate in the position you want to install the rear view camera. Adjust the angle of the rear view camera, and install so that the camera doesn't touch the car.
- When sticking to a glass surface, stick it on in a position that assures the camera doesn't touch the rear window.
- Install so that it does not obstruct the rear field of view.
- Install so that it does not protrude from the side of the car.
- Do not perform installation in rain or fog.
- When humidity is high, dry the surface to which the unit is to be attached before installing. Moisture on the attachment surface reduces adhesive strength which may lead to the unit coming off.
- If the temperature of the attachment surface is low, warm with a hair dryer of other means before installing to improve adhesive strength.
- Do not attach the camera stand to areas on the car body treated with fluorocarbon resin, or glass. This may result in the rear view camera falling off.
- During the 24-hour period after installing:
  - Do not apply water to the unit.
  - Do not expose the unit to rain.
  - Do not subject the camera to unnecessary force.
- Thoroughly clean where tape is used for sticking on the unit.

#### 1. Clean the surface to which the rear view camera is to be installed. (Fig. 3)

Use a cloth or other item to wipe oil, wax, dust and any other dirt from the installation surface.

#### 2. Align the camera stand with the installation surface. (Fig. 4)

Adjust the camera stand so that there is no space between it and the installation surface.

- ① Turn
- ② Twist
- ③ Camera stand

#### 3. Attach the rear view camera to the camera stand with the installation screws. (Fig. 6)

Depending on the side you want the cable to come out of, pass it through the groove.

- ① Top
- ② Rear view camera
- ③ Bottom
- ④ Installation screw
- ⑤ Camera stand

#### 4. Peel off the sheet on the back of the camera stand and stick it on. (Fig. 5, Fig. 7)

Press the camera stand with your fingers to stick it to the installation surface. Touching the adhesive surface or sticking the unit on a second time reduces adhesive power which may result in the unit coming off.

- ① Camera stand
- ② Stick in the center

#### 5. Adjust the angle so that the bumper or rear edge of the car is displayed at the bottom of the TV screen. (Fig. 8, Fig. 9, Fig. 10)

- ① Angle of view  
Horizontal: 112°
- ② Angle of view  
Vertical: 82°
- ③ Bumper or rear edge of car

#### 6. Install the power supply unit. (Fig. 11)

Stick Velcro tape (hard type) to the bottom of the power supply unit, and stick Velcro tape (soft type) to the installation site.

- You can use Velcro tape (hard type) to attach directly to a carpet, but do not use the soft type.
- Install the power supply unit close enough for the rear view camera cable to reach.

### <ENGLISH>

### PRECAUCIONES DE SEGURIDAD IMPORTANTES

- La instalación y cableado de este producto requiere la habilidad y experiencia de un especialista. Para asegurar la seguridad, solicite un técnico especialista para instalar la unidad.
- Este producto es una cámara de vista posterior para verificar la vista en la parte trasera de un coche. Una cámara de vista posterior es una cámara que provee imágenes simétricas de la misma manera que los espejos retrovisores o laterales.
- Se puede hacer la conexión a un televisor con entrada de vídeo RCA, pero compruebe si el televisor tiene una función de conexión de marcha atrás.
- La luz directa del sol o luz fuerte (luz del sol reflejada de un parachoques, etc.) en la cámara puede producir una mancha por encima y por debajo de la ubicación donde la luz radia, pero esto no es un fallo de funcionamiento.
- Este producto ha sido diseñado para complementar la vista trasera del conductor, pero las imágenes de la cámara no muestran todos los peligros y obstáculos. Asegúrese de mirar atrás cuando vaya de marcha atrás para comprobar la vista.
- Este producto tiene una lente de gran angular y, por lo tanto, la vista cercana es amplia y la vista distante es estrecha, lo que puede crear una sensación falsa de la distancia. Asegúrese de mirar atrás cuando vaya de marcha atrás para comprobar la vista.
- No lave su coche en un túnel de lavado automático o agua de alta presión, ya que esto puede resultar en la entrada de agua en la cámara o caída de la cámara.
- Verifique la instalación del soporte de la cámara antes de conducir el coche.
  - ¿No están flojos los tornillos?
  - ¿Está firmemente fijo el soporte de la cámara?
  - Si la cámara de vista posterior se afloja mientras está conduciendo, esto puede causar un accidente.

### Instalación

#### Piezas suministradas

- Ⓐ Cámara de vista posterior × 1
- Ⓑ Unidad de suministro de energía × 1
- Ⓒ Cable RCA × 1
- Ⓓ Soporte de la cámara de vista posterior × 1
- Ⓔ Llave hexagonal × 1
- Ⓕ Cinta velcro (tipo blanda) × 1
- Ⓖ Cinta velcro (tipo dura) × 1
- Ⓗ Tornillos de instalación (3 × 4 mm) × 2
- ① Almohadilla impermeable × 1
- Ⓙ Abrazadera × 10
- Ⓚ Cinta de doble cara × 1
- Ⓛ Enlace de fijación × 1

#### Ejemplo de instalación (Fig. 1)

- ① Superficie de vidrio
- ② Asegúrese de que no toque el limpiador
- ③ Instale en la pieza central

#### Cambio de la orientación de la instalación del soporte de la cámara (Fig. 2)

Cambiar la orientación de la ménsula Ⓐ de la instalación del soporte de la cámara permite una gran variedad de posibilidades de instalación. Cambie de acuerdo con la forma de su coche o sitio de instalación.

- Utilice la llave hexagonal para sacar los tornillos que fijan las ménsulas Ⓐ y Ⓑ del soporte de la cámara.
- Cambie la orientación de la ménsula Ⓐ de instalación y, a continuación, fijela nuevamente con los tornillos.

#### Nota:

- Antes de finalizar la instalación de la unidad, conecte el cableado temporariamente, asegurándose de que todo se encuentra conectado apropiadamente, y la unidad y el sistema funcionan apropiadamente.
- Utilice solamente las partes incluídas con la unidad para asegurar una instalación adecuada. El uso de partes no autorizadas puede ocasionar fallas de funcionamiento.
- Si la instalación requiere del taladrado de orificios u otras modificaciones del vehículo, consulte con su agente o concesionario más cercano a su domicilio.
- Instale la unidad en donde no interfiera con el conductor y no pueda lesionar al pasajero en caso de una parada repentina, tal como una frenada de emergencia.
- Cuando monte esta unidad, cerciórese que ninguno de los cables queda aprisionado entre esta unidad y accesorios o partes metálicas circundantes.
- No monte esta unidad cerca de la salida del calefactor, en donde podría ser afectado por el calor o cerca de las puertas, en donde la lluvia

### <ESPAÑOL>

#### 2. Alinee el soporte de la cámara con la superficie de instalación. (Fig. 4)

Ajuste el soporte de la cámara de modo que no quede ningún espacio entre ello y la superficie de instalación.

- ① Gire
- ② Retuerza
- ③ Soporte de la cámara

#### 3. Fije la cámara de vista posterior al soporte de la cámara con los tornillos de instalación. (Fig. 6)

Dependiendo del lado que desea que el cable salga, páselo a través de la ranura.

- ① Parte superior
- ② Cámara de vista posterior
- ③ Parte inferior
- ④ Tornillo de instalación
- ⑤ Soporte de la cámara

#### 4. Quite la hoja de la parte posterior del soporte de la cámara y fije. (Fig. 5, Fig. 7)

Presione el soporte de la cámara con los dedos para fijarlo en la superficie de instalación. Tocar la superficie adhesiva o fijar la unidad una segunda vez reduce la resistencia de adherencia, lo que puede resultar en el despegamiento de la unidad.

- ① Soporte de la cámara
- ② Fije en el centro

#### 5. Ajuste el ángulo de modo que el parachoques o borde trasero del coche se visualice en la parte inferior de la pantalla de TV. (Fig. 8, Fig. 9, Fig. 10)

- ① Ángulo de visión  
Horizontal: 112°
- ② Ángulo de visión  
Vertical: 82°
- ③ Parachoques o borde trasero del coche

#### 6. Instale la unidad de suministro de energía. (Fig. 11)

Fije la cinta velcro (tipo dura) en la parte inferior de la unidad de suministro de energía, y fije la cinta velcro (tipo blanda) en el sitio de instalación.

- Puede utilizar la cinta velcro (tipo dura) para fijar directamente a una alfombra, pero no utilice el tipo de cinta blanda.
- Instale la unidad de suministro de energía lo suficiente cercano para que el cable de la cámara de vista posterior la alcance.








Fig. 12  
 Abb. 12




Fig. 13  
 Abb. 13




Fig. 14  
 Abb. 14




Fig. 15  
 Abb. 15




Fig. 16  
 Abb. 16




Fig. 17  
 Abb. 17









## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>