Kramer Electronics, Ltd.



USER MANUAL

Model:

VS-30FW

FireWire 800/1394b Repeater / HUB

Contents

Contents

1	Introduction	1			
2	Getting Started	1			
3	Overview	2			
3.1	About the VS-30FW FireWire 800/1394b Repeater / HUB	2			
3.2	FireWire Compliance	4			
4	Defining the VS-30FW FireWire 800/1394b Repeater / HUB	5			
5	Using the VS-30FW FireWire 800/1394b Repeater / HUB	6			
5.1	Powering the FireWire Devices	6			
6	Technical Specifications	7			
Figu	ires				
Figure	e 1: VS-30FW FireWire 800/1394b Repeater / HUB	5			
Figur	e 2: Connecting the VS-30FW FireWire 800/1394b Repeater / HUB	6			
Tab	les				
Table	Γable 1: VS-30FW FireWire 800/1394b Repeater / HUB Features				
Table	Table 2: Technical Specifications of the VS-30FW FireWire 800/1394b Repeater / HUB				



1 Introduction

Welcome to Kramer Electronics (since 1981): a world of unique, creative and affordable solutions to the infinite range of problems that confront the video, audio and presentation professional on a daily basis. In recent years, we have redesigned and upgraded most of our line, making the best even better! Our 350-plus different models now appear in 8 Groups¹, which are clearly defined by function.

Congratulations on purchasing your Kramer TOOLS VS-30FW which is ideal for:

- High-speed external disk drives
- Professional scanners and printers
- Portable storage devices
- Digital audio and video
- Home entertainment components

The package includes the following items:

- VS-30FW FireWire 800/1394b Repeater / HUB
- Power adapter (12V DC Input)
- This user manual²

2 Getting Started

We recommend that you:

- Unpack the equipment carefully and save the original box and packaging materials for possible future shipment
 - Review the contents of this user manual
 - Use Kramer high performance high resolution cables³

³ The complete list of Kramer cables is on our Web site at http://www.kramerelectronics.com (click "Cables and Connectors" in the Products section)



¹ GROUP 1: Distribution Amplifiers; GROUP 2: Video and Audio Switchers, Matrix Switchers and Controllers; GROUP 3: Video, Audio, VGA/XGA Processors; GROUP 4: Interfaces and Sync Processors; GROUP 5: Twisted Pair Interfaces; GROUP 6: Accessories and Rack Adapters; GROUP 7: Scan Converters and Scalers; and GROUP 8: Cables and Connectors 2 Download up-to-date Kramer user manuals from the Internet at this URL: http://www.kramerelectronics.com/manuals.html

3 Overview

The Kramer TOOLS VS-30FW FireWire 800/1394b Repeater / HUB:

- Is a 3 Port IEEE 1394b 800Mbps (S800) Hub that also supports legacy FireWire speeds of 400Mbps, 200Mbps, and 100Mbps (S400, S200, S100). In fact, you can connect several devices with different speeds, and the **VS-30FW** will bridge the gaps!
- Does not require any setup, and also supports hot swapping
- Has 3 Bilingual IEEE 1394b connectors¹
- Is powered by an external 12VDC power supply, or via a FireWire connection from a PC

The **VS-30FW** is based on FireWire which:

- Is a serial bus standard² that enables quick universal interfacing between video and computer hardware items³
- Is simple to use and operates independently of the host system, letting you connect more items than you otherwise could (as a computer only has limited ports available), and for extended distances. Several can be cascaded to create up to a 63 port FireWire Repeater / HUB
- Supports Plug and Play⁴, and isochronous⁵ and asynchronous applications

Achieving the best performance means:

- Connecting only good quality connection cables, thus avoiding interference, deterioration in signal quality due to poor matching, and elevated noise levels (often associated with low quality cables)
- Avoiding interference from neighboring electrical appliances and positioning your **VS-30FW** away from moisture, excessive sunlight and dust

3.1 About the VS-30FW FireWire 800/1394b Repeater / HUB

Many computers today come with one or more FireWire ports on the rear panel. These ports let you attach many devices to your computer quickly and easily. The operating system also supports FireWire, so the installation of the device drivers is also quick and easy. Compared to other ways of connecting devices to your computer (including parallel ports, serial ports and special

KRAMER: SIMPLE CREATIVE TECHNOLOGY

¹ Adapting cables are available

² Originally developed by Apple™ and published as IEEE 1394 by the Institute of Electrical and Electronics Engineers

³ Hardware items include digital cameras, computers, printers, VCRs, CD-ROMs, hard disks, scanners and graphic cards

⁴ Configures automatically. Whenever a device is added or removed the 1394 bus re-enumerates

⁵ Video / audio applications require constant transfer rates, which the serial bus provides by supporting isochronous transfers

cards that you install inside the computer's case), FireWire devices are simple. Many peripheral devices (including: DV Camcorders, Digital still cameras, Storage devices such as External Hard Drives and Disk Arrays, Network connections, and scanners and printers) now come in a FireWire version.

Connecting a FireWire device to a computer is easy – you just plug it into the port. If it is an uninstalled FireWire device, the operating system auto-detects it and installs software support for it automatically. If the device has already been installed, the computer activates it and starts talking to it.

With so many FireWire devices on the market today, you easily run out of ports very quickly. The simple solution to the problem is an inexpensive FireWire hub. The FireWire standard supports up to 63 devices, and FireWire hubs are a part of the standard. You plug the hub into your computer, and then plug your devices (or other hubs) into the hub. By chaining hubs together, you can build up dozens of available FireWire ports on a single computer.

A FireWire hub is like a network, with bi-directional signals. The standard defines FireWire as Peer-to-Peer connection; that is why two devices, or a device and a computer can talk to each other.

It is important to note that everything depends on your computer's software, and the firmware of the devices. Sometimes, it is possible that a computer can work with many FireWire devices simultaneously (like a distributor), sometimes it can work with many devices in time-sharing mode (like a switcher). But most often it is possible to work one-to-one. In this case, you have to disconnect all the devices that are unnecessary at this time and leave only two of them. Since the FireWire is hot-plug standard, you can connect/disconnect devices at any time.

Hubs can be powered or unpowered. The FireWire standard lets devices draw their power from their FireWire connection. Obviously, a high-power device, like a professional DV camcorder, will have its own power supply, but low-power devices like a Webcam derive their power from the bus in order to simplify them. The power for this (up to 1 amp at 12 volts) comes from the computer.

If you have several self-powered devices, then your hub does not need to be powered, as none of the devices connecting to the hub needs additional power, and the hub itself can derive power from the computer. If you have many unpowered devices, you probably need a powered hub. The hub has to be powered from an AC adapter, which supplies power to the bus. The **VS-30FW** can supply up to 2.1A to the bus (each port can provide up to 1A).



3.2 FireWire Compliance

In particular, the **VS-30FW** *FireWire 800/1394b Repeater / HUB*:

- Fully supports the provisions of the IEEE P1394b Revision 1.33+ at 1-Gigabit signaling rates
- Fully supports the provisions of the IEEE 1394-1995 Standard for High Performance Serial Bus and the P1394a Supplement
- Is fully interoperable with FireWire™ and i.LINK™ implementation of IEEE Std 1394
- Provides three fully backward compatible (1394a-2000 fully compliant) bilingual P1394b cable ports at up to 800 Megabits per second (Mbits/s)
- Is fully compliant with OpenHCI requirements
- Provides P1394a Fully Compliant Cable Ports at 100/200/400 Megabits per Second (Mbits/s)
- Includes full P1394a support, that is, Connection Debounce, Arbitrated Short Reset, Multispeed Concatenation, Arbitration Acceleration, Fly-By Concatenation, Port Disable/Suspend/Resume
- Includes Extended Resume Signaling for Compatibility with Legacy DV Devices

4 Defining the VS-30FW FireWire 800/1394b Repeater / HUB

Figure 1 and Table 1 define the VS-30FW FireWire 800/1394b Repeater / HUB:




Figure 1: VS-30FW FireWire 800/1394b Repeater / HUB

Table 1: VS-30FW FireWire 800/1394b Repeater / HUB Features

#	Feature	Function
1	12V DC	+12V DC connector for powering the unit
2	PORT 1	Connects to the FireWire device 1
3	PORT 2	Connects to the FireWire device 2
4	PORT 3	Connects to the FireWire device 3
5	ON LED	Illuminates when receiving power
6	ACTIVE LED	Lights when a connection between 2 FireWire devices is established

5 Using the VS-30FW FireWire 800/1394b Repeater / HUB

To use the **VS-30FW** *FireWire 800/1394b Repeater / HUB*, as the example in Figure 2 illustrates, do the following:

- 1. Connect up to 3 FireWire devices to up to 3 ports¹, for example: PORT 1 to a video camcorder, PORT 2 to a hard drive, and PORT 3 to a computer.
- Connect the 12V DC power adapter (see section 5.1) to the power socket and connect the adapter to the mains electricity (not shown in Figure 2). The ON red LED lights.
- Be sure that the power on each device is turned ON (see section 5.1).The ACTIVE green LED lights indicating that there is data present on a port.

5.1 Powering the FireWire Devices

Each FireWire device can derive its power in one of 2 ways:

- Independently, by connecting each FireWire device to its own power supply, while the **VS-30FW** is connected to the external 12VDC (12V, 500mA) power supply (supplied with the **VS-30FW**)
- Via the **VS-30FW** that is connected to an external powerful power supply: the 12VDC (12V, 2.1A) (optional with the **VS-30FW**). In this case, each of the (up to) 3 FireWire devices can derive its power (up to 1A per port) from the respective **VS-30FW** FireWire port




Figure 2: Connecting the VS-30FW FireWire 800/1394b Repeater / HUB

¹ Not all ports need to be connected. Any unused port should simply be left unconnected

6 Technical Specifications

Table 2 includes the technical specifications:

Table 2: Technical Specifications¹ of the VS-30FW FireWire 800/1394b Repeater / HUB

TRANSFER RATE: 100/200/400 Mbps² (S400, S200, S100) STANDARDS: Fully supports the provisions of the IEEE P1394b Revision 1.33+ at 1 Gigabit signaling rates; Fully supports the provisions of the IEEE 1394-1995 Standard for High Performance Serial Bus and the P1394a Supplement; Fully interoperable with FireWire™ and i.LINK™ implementation of IEEE Std 1394; Provides three fully backward compatible (1394a 2000 fully compliant) bilingual P1394b cable ports at up to 800 Megabits per second (Mbits/s); Fully compliant with OpenHCI requirements; Provides three P1394b Fully Compliant Cable Ports at 100/200/400/800 Megabits per Second (Mbits/s); Full P1394a support includes: Connection Debounce, Arbitrated Short Reset, Multispeed Concatenation, Arbitration Acceleration, Fly-By Concatenation, Port Disable/Suspend/Resume; Extended Resume Signaling for Compatibility with Legacy DV Devices; POWER SOURCE: 12 VDC, 500mA DIMENSIONS: 12cm x 7.5cm x 2.5cm (4.7" x 2.95" x 0.98", W, D, H) WEIGHT: 0.3 kg. (0.67 lbs.) approx. ACCESSORIES: Power supply (12V, 500mA), mounting bracket		
Fully supports the provisions of the IEEE P1394b Revision 1.33+ at 1 Gigabit signaling rates; Fully supports the provisions of the IEEE 1394-1995 Standard for High Performance Serial Bus and the P1394a Supplement; Fully interoperable with FireWire™ and i.LINK™ implementation of IEEE Std 1394; Provides three fully backward compatible (1394a 2000 fully compliant) bilingual P1394b cable ports at up to 800 Megabits per second (Mbits/s); Fully compliant with OpenHCI requirements; Provides three P1394b Fully Compliant Cable Ports at 100/200/400/800 Megabits per Second (Mbits/s); Full P1394a support includes: Connection Debounce, Arbitrated Short Reset, Multispeed Concatenation, Arbitration Acceleration, Fly-By Concatenation, Port Disable/Suspend/Resume; Extended Resume Signaling for Compatibility with Legacy DV Devices; POWER SOURCE: 12 VDC, 500mA DIMENSIONS: 12cm x 7.5cm x 2.5cm (4.7" x 2.95" x 0.98", W, D, H) WEIGHT: 0.3 kg. (0.67 lbs.) approx. ACCESSORIES: Power supply (12V, 500mA), mounting bracket	PORTS:	Three Bilingual IEEE 1394b 800Mbps (S800) Ports
signaling rates; Fully supports the provisions of the IEEE 1394-1995 Standard for High Performance Serial Bus and the P1394a Supplement; Fully interoperable with FireWire™ and i.LINK™ implementation of IEEE Std 1394; Provides three fully backward compatible (1394a 2000 fully compliant) bilingual P1394b cable ports at up to 800 Megabits per second (Mbits/s); Fully compliant with OpenHCI requirements; Provides three P1394b Fully Compliant Cable Ports at 100/200/400/800 Megabits per Second (Mbits/s); Full P1394a support includes: Connection Debounce, Arbitrated Short Reset, Multispeed Concatenation, Arbitration Acceleration, Fly-By Concatenation, Port Disable/Suspend/Resume; Extended Resume Signaling for Compatibility with Legacy DV Devices; POWER SOURCE: 12 VDC, 500mA DIMENSIONS: 12cm x 7.5cm x 2.5cm (4.7" x 2.95" x 0.98", W, D, H) WEIGHT: 0.3 kg. (0.67 lbs.) approx. ACCESSORIES: Power supply (12V, 500mA), mounting bracket	TRANSFER RATE:	100/200/400 Mbps ² (S400, S200, S100)
Performance Serial Bus and the P1394a Supplement; Fully interoperable with FireWire™ and i.LINK™ implementation of IEEE Std 1394; Provides three fully backward compatible (1394a 2000 fully compliant) bilingual P1394b cable ports at up to 800 Megabits per second (Mbits/s); Fully compliant with OpenHCI requirements; Provides three P1394b Fully Compliant Cable Ports at 100/200/400/800 Megabits per Second (Mbits/s); Full P1394a support includes: Connection Debounce, Arbitrated Short Reset, Multispeed Concatenation, Arbitration Acceleration, Fly-By Concatenation, Port Disable/Suspend/Resume; Extended Resume Signaling for Compatibility with Legacy DV Devices; POWER SOURCE: 12 VDC, 500mA DIMENSIONS: 12cm x 7.5cm x 2.5cm (4.7" x 2.95" x 0.98", W, D, H) WEIGHT: 0.3 kg. (0.67 lbs.) approx. ACCESSORIES: Power supply (12V, 500mA), mounting bracket	STANDARDS:	
Provides three fully backward compatible (1394a 2000 fully compliant) bilingual P1394b cable ports at up to 800 Megabits per second (Mbits/s); Fully compliant with OpenHCI requirements; Provides three P1394b Fully Compliant Cable Ports at 100/200/400/800 Megabits per Second (Mbits/s); Full P1394a support includes: Connection Debounce, Arbitrated Short Reset, Multispeed Concatenation, Arbitration Acceleration, Fly-By Concatenation, Port Disable/Suspend/Resume; Extended Resume Signaling for Compatibility with Legacy DV Devices; POWER SOURCE: 12 VDC, 500mA DIMENSIONS: 12cm x 7.5cm x 2.5cm (4.7" x 2.95" x 0.98", W, D, H) WEIGHT: 0.3 kg. (0.67 lbs.) approx. ACCESSORIES: Power supply (12V, 500mA), mounting bracket		, , , , ,
Provides three P1394b Fully Compliant Cable Ports at 100/200/400/800 Megabits per Second (Mbits/s); Full P1394a support includes: Connection Debounce, Arbitrated Short Reset, Multispeed Concatenation, Arbitration Acceleration, Fly-By Concatenation, Port Disable/Suspend/Resume; Extended Resume Signaling for Compatibility with Legacy DV Devices; POWER SOURCE: 12 VDC, 500mA DIMENSIONS: 12cm x 7.5cm x 2.5cm (4.7" x 2.95" x 0.98", W, D, H) WEIGHT: 0.3 kg. (0.67 lbs.) approx. ACCESSORIES: Power supply (12V, 500mA), mounting bracket		Provides three fully backward compatible (1394a 2000 fully compliant) bilingual P1394b cable ports at up to 800 Megabits per second (Mbits/s);
Multispeed Concatenation, Arbitration Acceleration, Fly-By Concatenation, Port Disable/Suspend/Resume; Extended Resume Signaling for Compatibility with Legacy DV Devices; POWER SOURCE: 12 VDC, 500mA DIMENSIONS: 12cm x 7.5cm x 2.5cm (4.7" x 2.95" x 0.98", W, D, H) WEIGHT: 0.3 kg. (0.67 lbs.) approx. ACCESSORIES: Power supply (12V, 500mA), mounting bracket		Provides three P1394b Fully Compliant Cable Ports at 100/200/400/800 Megabits
POWER SOURCE: 12 VDC, 500mA DIMENSIONS: 12cm x 7.5cm x 2.5cm (4.7" x 2.95" x 0.98", W, D, H) WEIGHT: 0.3 kg. (0.67 lbs.) approx. ACCESSORIES: Power supply (12V, 500mA), mounting bracket		Multispeed Concatenation, Arbitration Acceleration, Fly-By Concatenation, Port
DIMENSIONS: 12cm x 7.5cm x 2.5cm (4.7" x 2.95" x 0.98", W, D, H) WEIGHT: 0.3 kg. (0.67 lbs.) approx. ACCESSORIES: Power supply (12V, 500mA), mounting bracket		Extended Resume Signaling for Compatibility with Legacy DV Devices;
WEIGHT: 0.3 kg. (0.67 lbs.) approx. ACCESSORIES: Power supply (12V, 500mA), mounting bracket	POWER SOURCE:	12 VDC, 500mA
ACCESSORIES: Power supply (12V, 500mA), mounting bracket	DIMENSIONS:	12cm x 7.5cm x 2.5cm (4.7" x 2.95" x 0.98", W, D, H)
,, ,, ,,	WEIGHT:	0.3 kg. (0.67 lbs.) approx.
OPTIONS: Adapting cables ³ , Powerful Power supply (12V, 2.1A) ^{3,4}	ACCESSORIES:	Power supply (12V, 500mA), mounting bracket
	OPTIONS:	Adapting cables ³ , Powerful Power supply (12V, 2.1A) ^{3,4}

⁴ Kramer P/N: 2535-025120 (P.S SW PPS25W-13 12V/2.1A EUR)



¹ Specifications are subject to change without notice

² Legacy FireWire speeds

³ For details, refer to our Web site at http://www.kramerelectronics.com

LIMITED WARRANTY

Kramer Electronics (hereafter Kramer) warrants this product free from defects in material and workmanship under the following terms.

HOW LONG IS THE WARRANTY

Labor and parts are warranted for three years from the date of the first customer purchase.

WHO IS PROTECTED?

Only the first purchase customer may enforce this warranty.

WHAT IS COVERED AND WHAT IS NOT COVERED

Except as below, this warranty covers all defects in material or workmanship in this product. The following are not covered by the warranty:

- Any product which is not distributed by Kramer, or which is not purchased from an authorized Kramer dealer. If you are uncertain as to whether a dealer is authorized, please contact Kramer at one of the agents listed in the web site www.kramerelectronics.com.
- 2 Any product, on which the serial number has been defaced, modified or removed.
- Damage, deterioration or malfunction resulting from: 3
 - Accident, misuse, abuse, neglect, fire, water, lightning or other acts of nature
 - Product modification, or failure to follow instructions supplied with the product ii)
 - (iii Repair or attempted repair by anyone not authorized by Kramer
 - iv) Any shipment of the product (claims must be presented to the carrier)
 - v) Removal or installation of the product
 - vi) Any other cause, which does not relate to a product defect
 - vii) Cartons, equipment enclosures, cables or accessories used in conjunction with the product

WHAT WE WILL PAY FOR AND WHAT WE WILL NOT PAY FOR

We will pay labor and material expenses for covered items. We will not pay for the following:

- Removal or installations charges.
- 2. Costs of initial technical adjustments (set-up), including adjustment of user controls or programming. These costs are the responsibility of the Kramer dealer from whom the product was purchased.
- 3. Shipping charges.

HOW YOU CAN GET WARRANTY SERVICE

- To obtain service on you product, you must take or ship it prepaid to any authorized Kramer service center.
- Whenever warranty service is required, the original dated invoice (or a copy) must be presented as proof of warranty coverage, 2. and should be included in any shipment of the product. Please also include in any mailing a contact name, company, address, and a description of the problem(s).
- For the name of the nearest Kramer authorized service center, consult your authorized dealer.

LIMITATION OF IMPLIED WARRANTIES

All implied warranties, including warranties of merchantability and fitness for a particular purpose, are limited in duration to the length of this warranty.

EXCLUSION OF DAMAGES

The liability of Kramer for any effective products is limited to the repair or replacement of the product at our option. Kramer shall not be liable for:

- Damage to other property caused by defects in this product, damages based upon inconvenience, loss of use of the product, loss of time, commercial loss; or:
- 2. Any other damages, whether incidental, consequential or otherwise. Some countries may not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from place to place.

NOTE: All products returned to Kramer for service must have prior approval. This may be obtained from your dealer.

This equipment has been tested to determine compliance with the requirements of: EN-50081:

"Electromagnetic compatibility (EMC);

generic emission standard.

Part 1: Residential, commercial and light industry"

EN-50082: "Electromagnetic compatibility (EMC) generic immunity standard.

Part 1: Residential, commercial and light industry environment".

CFR-47: FCC Rules and Regulations:

Part 15: "Radio frequency devices

Subpart B - Unintentional radiators"

CAUTION!

- 🖾 Servicing the machines can only be done by an authorized Kramer technician. Any user who makes changes or modifications to the unit without the expressed approval of the manufacturer will void user authority to operate the equipment.



For the latest information on our products and a list of Kramer distributors, visit our Web site: www.kramerelectronics.com.

Updates to this user manual may be found at http://www.kramerelectronics.com/manuals.html.

We welcome your questions, comments and feedback.





Kramer Electronics, Ltd.

Web site: www.kramerelectronics.com E-mail: info@kramerel.com P/N: 2900-000014 REV 1 Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com