Bluetooth™ Wireless USB Adapter

User Manual (GBU221/321)

IOGEAR®

Thank you for purchasing one of the most feature-rich Bluetooth™ to USB adapters available. IOGEAR's Bluetooth™ to USB adapters are first-rate wireless connectivity accessories designed to help reduce the frustration of dealing with cable glut in your home or office. These adapters allow computers with USB connections to become Bluetooth™ enabled computers. They comply to Bluetooth 2.0 and USB 1.1 specifications, and provide users with a 2.1Mbps data rate. They also enable wireless Personal Area Network (PAN) connectivity to Bluetooth™ enabled devices such as PDA's, printers, cellular phones, computers, etc.

We hope you enjoy using your IOGEAR Bluetooth™ to USB adapter, another connectivity solution from IOGEAR.

Table of Contents

This package contains:

GBU221/321
1 Bluetooth to USB adapter
1 Driver CD
1 User Manual
1 Warranty/Registration card

The Bluetooth™ Installation CD contains the following:

• Bluetooth drivers for Windows 2000/XP/Vista
• User Manual for IOGEAR Bluetooth Adapter

If any items are damaged or missing please contact your dealer.

Overview

Bluetooth™ is a low-power wireless networking standard which uses short radio waves to allow electronic devices to communicate with each other without using cables.

The following applications are supported by Bluetooth™ technology:

- Synchronize your Bluetooth™ PDA with your computer.
- Send your business card to anyone who has a Bluetooth™ device.
- Send or receive files to or from anyone who has a Bluetooth™ enabled device.
- Chat with anyone who has a Bluetooth™ enabled computer.
- Play a one-on-one serial game without a cable.
- Send an e-mail without being wired to the network.
- Dial up to the Internet on your computer over your Bluetooth cellular phone.
- Send a fax from your computer over your Bluetooth™ cellular phone.
- Transfer data between your cell phone and PC.

Most Bluetooth-enabled devices have the capability to act as:

- A **Bluetooth server** - these devices provide one or more services, such as access to the Internet, or to other Bluetooth devices.

- A **Bluetooth client** - these devices use the service(s) provided by Bluetooth servers.

Most Bluetooth devices that can act as both server and client, and can often do both at the same time.

Overview Continued

Bluetooth™ technology is supported under the following operating systems.

• Windows 2000
• Windows XP
• Windows Vista

• Mac OS X 10.3.9 or greater

Features

- Eliminates cables between your computers
- Controls and communicates with Bluetooth™ enabled devices
- Enables wireless Personal Area Network (PAN) connectivity
- Bluetooth™ specification 2.0 compliant
- USB specification 1.1 compliant
- Up to 20 meter (66 feet) wireless working distance for GBU221, up to 100 meter (330 feet) for GBU321
- Up to 2.1 Mbps data rate
- Small form factor makes it easy to carry and place
- Crisp, easy, and fast installation and setup
- Built-in security to assure the privacy of your communication – Pairing, Encryption, and Authentication
- PC and Mac compatible

System Requirement:

Hardware Requirement:
· Available USB port

Operating System:

For PCs: Windows 2000/XP/Vista
For Macs: OS X v10.3.9 or later

Introduction

IOGEAR®'s Wireless Bluetooth™ to USB Adapter is a Class 1 (for GBU321) device with a wireless working distance of up 330 feet (100 meters), and Class 2 (for GBU221) device with a wireless working distance of up to 66 feet (20 meters). This device allows any computer with USB connections to become a Bluetooth™ enabled computer. It complies with Bluetooth 2.0 and USB 1.1 specifications, and provides users with a 2.1 Mbps data transfer rate at ranges up to 330 feet. It also enables wireless Personal Area Network (PAN) connectivity to Bluetooth™ enabled devices such as PDA's, printers, cellular phones, computers, etc.

The Wireless Bluetooth™ to USB adapter is compatible with both PC and Mac. It is easy to install and use, and very portable. Another great solution from IOGEAR® for home and mobile networking needs.

GBU221 is a class 2 device with a wireless working distance of 60 feet (20 meters).

Windows XP Service Pack 2
The Microsoft Bluetooth stack comes included with
Service Pack 2 for Windows XP. If you already have
Service Pack 2 installed, you may choose not to
install drivers from the installation CD and instead
use the Microsoft Bluetooth drivers. Please see
Page 34 on the manual for more details.

1. Make sure that the IOGEAR Bluetooth adapter
   is **NOT** plugged into the computer before
   installing the software. Insert the IOGEAR
   installation CD into your CD-ROM drive. The
   auto-start feature will bring up the installation
   window to begin the driver installation. If the
   installation CD does not auto-start, simply
   browse to your CD drive and run the setup file.
   Please follow the on-screen instructions to
   install the drivers.

11

2. If you accept the license agreement, click **Next.**

3. When you approach the end of the installation process, the Driver Signature Notice may appear. Simply click OK to proceed with the installation.

4. During the install, a "Bluetooth Device not Found" window will appear. **DO NOT** plug in the Bluetooth adapter at this time, simply click **Cancel** to proceed with the driver installation without connecting the Bluetooth device.

5. Once the driver installation has completed, click Finish and **RESTART** your computer

6. After restarting the computer, proceed to plug in the Bluetooth USB Adapter, and wait a few seconds while Windows recognizes the device.


13

Windows Vista

1. Make sure the IOGEAR Bluetooth adapter is plugged into the computer before installing the software. Insert the IOGEAR installation CD into your CD-ROM drive. The auto-start feature will bring up the auto play options for the installation CD. Simply click on Open folder to view files to browse the CD.

2. A Window will bring up the files that are in the installation CD. Simply double click on the setup.exe file to start the driver installation.

3. If your IOGEAR Bluetooth adapter was not plugged into the computer before you begin the setup, a window will popup and ask you to plug in the IOGEAR adapter to continue installation.

15

4. The Driver Signature Notice may appear before getting into the installation window. Simply click Install this driver software anyway to proceed with the installation.

5. Installation window will be brought up and simply click Next to begin the driver installation.

6. If you accept the agreement, click Next.

7. Choose your destination folder to be installed to, and then click Next.

8. Click Next to being the installation.

9. Once installation has completed, click Finish and RESTART your computer.

10. After restarting the computer, the IOGEAR Bluetooth adapter will be recognized and will function correctly.

1. Now double click the Bluetooth™ icon in the system tray. This will start the "Initial Bluetooth-Configuration Wizard."

2. Once the Initial Bluetooth™ Configuration Wizard has started, click **Next.**

3. Next, enter a unique name for this computer. This name will be displayed to other Bluetooth™ devices. Select a computer type from the drop-down menu and click **Next.**

4. Click **Next** to configure the services this computer will offer to other Bluetooth™ devices.

5. Choose the services that this computer will offer to other Bluetooth™ devices by placing a check in the box. To display the properties, click on the configure button. Click **Next** to proceed.

6. At this point, Windows will install the software necessary for the services you selected.

7. Once Windows is finished installing the software, the following window will appear. This window will allow you to configure your computer to use the service of another Bluetooth Device.

   If you do not have any additional devices you wish to connect to at this time, click **Skip,** click **Finish** on the final screen.

Windows XP Service Pack 2

1. First, unplug the IOGEAR USB Bluetooth adapter from your computer
2. Go to Control Panel (Start > Settings > Control Panel)
3. Click on *Add or Remove Programs*
4. Click on **IOGEAR Bluetooth Software** and click on [Remove]
5. When the uninstall is complete, restart your computer

Windows Vista

1. First, unplug the IOGEAR USB Bluetooth adapter from your computer
2. Go to Control Panel (Start > Control Panel)
3. Click on Uninstall a program under Programs or Click on Programs and Features (Control Panel Classic View)
4. Click on **Widcomm Bluetooth Software** and click on [Remove]
5. When the uninstall is complete, restart your computer

Installation – MAC OS X

1. Use of the IOGEAR Bluetooth adapter requires MAC OS X v10.3.9 or later. There is no need to install any additional drivers, as Apple provides all required Bluetooth drivers under MAC OS X v10.3.9.

Simply plug in your Bluetooth adapter into an available USB port on your computer, and go to *System Preferences*.

2. Double-click on the Bluetooth icon and under the Settings tab, make sure Bluetooth Power is ON and that the box next to *Discoverable* is checked.

24

3. To begin setting up your Bluetooth device, select the *Devices* tab and click on **Set Up New Device**.

4. This will initiate the Bluetooth Setup Assistant; click **Continue** to proceed.

5. On this window, you can select what type of Bluetooth device you want to setup. Please make your choice below and then click **Continue.**

6. Your computer will search Bluetooth devices in your area and display them under the window below. Select the device you wish to communicate with and then click **Continue** to pair/connect to your device.

7. Please refer to the Apple website for further information on Apple Bluetooth support at www.apple.com.

**How to connect to a Cellular Phone (Bluetooth Enabled)**

For Window XP

1. Double-click on the IOGEAR® Bluetooth ™ iconin the system tray.

2. Next, click on Search for devices in range. As illustrated below, the Bluetooth-enabled cell phone is detected.

27

Connect to a Cellular Phone

3. Right-click on the cell phone, and select Pair Device. When prompted for passkey, simply type any four digits and click OK. On the phone, you will also be prompted to enter a passkey. Make sure you enter the same passkey as on the computer. Your devices should now be paired.

4. In our example, we used a Nokia 3650 cell phone. Double-click on the phone to see the available services. The services offered by your cell phone may depend on the features supported by your specific model and may or may not require additional software by the phone manufacturer.

In the case of Nokia phones, you can take full advantage of your Bluetooth phone by using the Nokia PC Suite software. Please check www.nokia.com to see the version of the software supported by your Nokia phone. Once you have the Nokia PC Suite software installed on your system, please proceed with the instructions below.

For Window Vista

1. Right-click on the Bluetooth TM icon in the system tray and select Add a Bluetooth Device.

2. Make sure to set your Bluetooth cellular phone in "discoverable" mode and check the box as shown on the picture.

Connect to a Cellular Phone

3. Your computer will search for all the Bluetooth devices in your area and list them. Select the desired cellular phone, and click Next.

4. Please consult the user manual for your cellular phone to see if you need a passkey to pair/establish a connection.

Add Bluetooth Device Wizard

Do you need a passkey to add your device?

To answer this question, refer to the "Bluetooth" section of the documentation that came with your device. If the documentation specifies a passkey, use that one.

○ Choose a passkey for me

○ Use the passkey found in the documentation:

○ Let me choose my own passkey:

○ Don't use a passkey

ⓘ You should always use a passkey, unless your device does not support one. We recommend using a passkey that is 8 to 16 digits long. The longer the passkey, the more secure it will be.

[< Back] [Next >] [Cancel]

Connect to a Cellular Phone

5. Your Bluetooth cellular phone will then connect to the IOGEAR Bluetooth adapter. To finish the process, simply click Finish.

Add Bluetooth Device Wizard

Completing the Add Bluetooth Device Wizard

The Bluetooth device was successfully connected to your computer. Your computer and the device can communicate whenever they are near each other.

To close this wizard, click Finish.

< Back   **Finish**   Cancel

How to Connect to Network Access (Bluetooth - Enabled Computer)

For Window XP

1. Double-click on the IOGEAR Bluetooth Icon in the system tray.

2. Next, click on Search for devices in range. As illustrated below, the Bluetooth-enabled computer is found.

Connect to Network Access

3. Double click on the device to display a list of its services. To establish a network connection, right click on Network Access and select Connect to Network Access Point.

4. When the connection is being established, you will be prompted to accept/deny the connection on your other computer. To allow access, click OK.

5. Once you establish the connection, the Network Access icon will turn green and say "Connected." Your device will be able to share its Internet connection (if the device has Internet access) and files. If a passkey has been set by either device, the passkey is required to connect both Bluetooth™ enabled devices.

6. At any time, when service requests are made from or to another Bluetooth™ device (e.g. File Transfer, Network Access, Serial Port Connection, etc.), a passkey is required to connect the devices. This authentication is not required once devices are paired (see *Chapter: What's Pairing?*).

Connect to Network Access

For Window Vista

1. Right-click on the Bluetooth TM icon in the system tray and select Join a Personal Area Network.

2. Click Add to add a new network device.

3. Make sure to set your Bluetooth enabled computer in "discoverable" mode and check the box as shown on the picture.

4. Your computer will search for all the Bluetooth devices in your area and list them. Select the desired computer, and click Next.

5. Decide if you use a passkey to add your device. Then click Next to proceed.

6. When the connection is being established, you will be prompted to accept/deny the connection on your other computer. To allow access, click on the message.

7. Enter the passkey that you have created or provided by the wizard to confirm the connection.

8. Your Bluetooth enabled computer will then connect to the IOGEAR Bluetooth adapter. To finish the process, simply click Finish.

9. When you return to the Bluetooth Personal Area Network Device window by right-clicking on the Bluetooth TM icon in the system tray and select Join a Personal Area Network, now you can see the connection that has been established. Simply choose the desired connection and click Connect.

10. Window will be closed automatically after the connection has successfully been connected.


40

11. A Bluetooth connection is shown when you open Computer from the start menu. Now your device will be able to share its internet connection, printers, and files. (Make sure the desired share options' checkboxes are checked under Bluetooth setting by right-clicking on the Bluetooth TM icon in the system tray.)

How to connect to a Bluetooth™ Enabled Printer

1. Double-click on the IOGEAR® Bluetooth™ icon in the system tray.

2. Next double click on "**Find Bluetooth™ Devices**".

3. Double click on the printer you wish to connect to.

4. Click OK to install the printer. If your printer is already installed, the printer properties window will appear.

43

5. If your printer is already installed, the printer properties window will appear. Click on **Print Test Page** to print a test page.

44

How to connect to a PDA (Personal Digital Assistant)

For Window XP

1. Double-click on the IOGEAR® Bluetooth™ icon in the system tray.

2. Next double click on "Find Bluetooth™ Devices"

Connect to a PDA

3. Once the search is finished, double click on the PDA to view the services it offers.

4. At any time, when service requests are made from or to another Bluetooth™ device (e.g. File Transfer, Network Access, Serial Port Connection, etc.), a pass key is required to connect the devices. This authentication is not required once devices are paired (see *Chapter: What's Pairing?*).

For Window Vista

1. Right-click on the Bluetooth TM icon in the system tray and select Add a Bluetooth Device.

2. Make sure to set your Bluetooth enabled PDA in "discoverable" mode and check the box as shown on the picture.

47

3. Your computer will search for all the Bluetooth devices in your area and list them. Select the desired PDA, and click **Next**.

4. Please consult the user manual for your PDA to see if you need a passkey to pair/establish a connection.

5. Your Bluetooth PDA will then connect to the IOGEAR Bluetooth adapter. To finish the process, simply click **Finish**.

Pairing

What is "Pairing ?"

Pairing is a Bluetooth™ function that enables Bluetooth™ devices to remain permanently linked to another.

What "Pairing" means in terms of security?

Pairing is a Bluetooth™ function that enables Bluetooth™ devices to remain permanently linked to another.

What "Pairing" means in terms of security?

As mentioned, Pairing allows devices to permanently link with each other. The pass key authentication will also be perpetuated in Pairing, meaning that devices will not ask for a pass key once they are paired. Paired devices will remain linked, even if other paired devices are turned off. Once a paired device turns back on, it is ready to be used and service requests will not ask for the pass key again. The built-in 128 bit security encryption of Bluetooth™ assures the privacy of your paired devices. Note: If devices are unpaired, it is necessary to enter a pass key each time a service request is made from or to another Bluetooth™ device.

Pairing Devices

1. Right-click on the Bluetooth™ device and select on "Pair device".

2. Enter a **Pass Key** when asked.

   Note: **The Pass Key on both devices must be the same!**

   Example: If Device 1 tries to pair with Device 2, Device 1 will prompt for a Pass Key. Enter any Pass Key. Device 2 will then ask for a Pass Key. Enter the Pass Key, which has been set for Device 1. Done!

3. The device is now paired with your computer.

Unpairing Devices

1. Right-click on the paired Bluetooth™ device in the list and select on "Unpair Device".

2. The device is now unpaired

Windows XP Service Pack 2 - Bluetooth Stack

If you are running Windows XP with Service Pack 2, you may use the Bluetooth drivers provided by Microsoft. Keep in mind, however, that this Bluetooth stack has limited Bluetooth profiles support. For more information, please visit the Microsoft website at www.microsoft.com.

1. To use the Microsoft Bluetooth stack, simply plug in your IOGEAR Bluetooth adapter into an available USB port on your computer. Windows will automatically detect the Bluetooth device and install all necessary drivers.

2. You will then see a Bluetooth icon on your traybar that allows you to perform all Bluetooth operations, as shown below:

52

3. Optionally, you can find this in *Control Panel > Bluetooth Devices*.

4. To connect with your Bluetooth device, simply right-click on the Bluetooth icon on the traybar and select *Add a Bluetooth Device*.

**5.** Make sure to set your Bluetooth device in "discoverable" mode and check the box as shown on the picture.

**6.** Your computer will search for all the Bluetooth devices in your area and list them. Select the desired device, and click **Next.**

54

7. Please consult the user manual for your Bluetooth device to see if you need a Passkey to pair/establish a connection.

8. Your Bluetooth device will then connect to the IOGEAR Bluetooth adapter. To finish the process, simply click **Finish**.

Specification

Function	GBU221/GBU321
Connectors	USB Type A 1
Data Rate	2.1 Mbps
Frenquency Band	2.402 GHz - 2.4835 GHz Unlicensed ISM band
Humidity	10% - 90% non-condensing
Interface	USB
Modulation	GFSK (Gaussian Frenquency Shift Keying)
Operating Temperature	0˚C - 50˚C
Security	Pairing, Encryption, Authentication
Sensitivity	Minimum - 76dB
Transmission Power	20 dBm max with power control (Class 1)
Weight	0.4 oz.

If you need technical support, please check out our IOGEAR® Tech Info Library (T.I.L.) at **www.iogear.com/support** for the latest tips, tricks, and troubleshooting. The IOGEAR® T.I.L. was designed to provide you with the latest technical information about our products. Most of the answers to your questions can be found here, so please try it out before contacting technical support.

Technical support is available Monday through Friday from 8:00 am to 5:00 pm PST and can be reached at (949) 453-8782 and (866) 946-4327 or by email **support@iogear.com**.

Radio & TV Interference Statement

WARNING!!! This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause interference to radio communications. This equipment has been tested and found to comply with the limits for a Class B computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

IN NO EVENT SHALL THE DIRECT VENDOR'S LIABILITY FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, DISK OR ITS DOCUMENTATION EXCEED THE PRICE PAID FOR THE PRODUCT.

The direct vendor makes no warranty or representation, expressed, implied, or statutory with respect to the contents or use of this documentation, and especially disclaims its quality, performance, merchantability, or fitness for any particular purpose.

The direct vendor also reserves the right to revise or update the device or documentation without obligation to notify any individual or entity of such revisions, or updates. For further inquires please contact your direct vendor.

IOGEAR®

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com