



Installation Guide

USB Auto Printer Sharing Switch

GUB211
PART NO. M1327



Table of Contents

Introduction	04
Features	05
Package Contents	06
System Requirements	07
Windows Installation	08
Mac Installation	13
Set Up the Control Center Application	18
Connect to other USB device	22
Troubleshooting	24
Federal Communications Commission (FCC) Statement	25
CE Safety Statement	27
Limited Warranty	28
Contact	29

Introduction

Thank you for purchasing the LOGEAR GUB211 USB Printer Auto Sharing Switch (hereafter referred to as "Switch"). This Switch is designed to enable two computers to share your All-In-One/Multifunction devices, standard printers, automatically processing print jobs from the two connected computers to send print jobs.

Features

- Automatically switch between two computers when connecting to USB printer or multi-function printer
- Print jobs on first come first serve basis, no need to switch manually
- USB 2.0 - supports Hi-speed (up to 480 Mbps) and USB 1.1 backward compatible.
- Bus Powered - No external power supply needed.
- USB devices hot pluggable.
- Software enable manual switch
- Share different USB devices between two computers
- LED Lights indicate active connection

Package Contents

Verify that nothing is missing from the package by using the checklist below. Please contact your dealer if anything is missing or damaged. All packing materials are recyclable. Please confirm the items in the package below:

- 1 x 2-to-1 USB2.0 Peripheral Sharing Switch
- 2x 5 ft USB A-B Cable
- Application CD
- Quick Start Guide

System Requirements

PC users

- Win 2000, XP and Vista Compatible
- Available USB Port

Mac Users

- Mac OS X 10.3.9 or greater
- Requires OS 10.3 or greater for USB 2.0 support
- Available USB 2.0 Port

Windows Installation

NOTE: Please ensure your printer driver is installed PRIOR to installing the drivers for IOGEAR Auto Printer Sharing Switch.


For Vista

Upon inserting the software CD into the CD-ROM of your computer, the auto-run screen will appear with a menu of options. Click on "Install Auto Printer Sharing Software" to begin the setup of the control center software. Vista will prompt a "User Account Control" window, and click on Allow to continue. The installation wizard will start the installation process, click on Next to continue.



The rest of the installation will be the same as the XP/2K installation, just follow procedures starting from Step 2.

For XP/2K


1. Insert the software CD into the CD-ROM of your computer. An auto-run screen should appear with a menu of options. Click on "Install Auto Printer Sharing Software" to begin the setup of the control center software. The installation wizard will start the installation process, click on Next to continue.




2. The installation wizard will guide you through the installation process. Click on Next to continue.



3. The installation wizard will place a shortcut icon on the desktop. Make sure the “Create a desktop icon” box is checked and click on Next to continue.



4. Click on Install to install the application, then Finish to complete the setup



5. Once the installation is completed, you will see a GREEN bubble showing up on your task bar to indicate the software is ready and correctly installed.




Mac Installation

NOTE: Please ensure your printer driver is installed **PRIOR** to installing the drivers for IOGEAR Auto Printer Sharing Switch.


1. After inserting the installation CD, browse to the content of the CD and double click on “IOGEAR Printer Sharing Switch” to begin the installation.




2. Click on Continue to proceed with the installation.




3. Please select the preferred location to install the application. We recommend installing the application to your hard driver for optimal performance




4. Click on Install to continue.



5. You may be prompted by the Authenticate window to ask for password to continue. Type in your password of the account that you used for this computer and click on OK to continue.



6. When the installation finishes, click on Close to complete the installation process.



Hardware Installation

1. Connect a USB printer to the USB port shown as above, and turn on the power of your USB printer.
2. Connect any two computers (Windows or Mac) to one of the USB ports shown below with the included USB cable.




Set Up the Control Center Application

Important Note:

The IOGEAR Auto Printer Sharing Switch application needs to be activated on your computer in order for the switch to function.

Windows

1. After installation, you will see an icon "IOGEAR Auto Printer Sharing Switch" placed on your desktop. Double click on the icon to launch the application.



2. When the application window shows up, you will be able to select the printer that's already setup on your computer from the drop-down list by clicking on the down arrow. Click on OK to confirm your selection. Make sure you select the correct printer on both computers that are connected to the GUB211.



NOTE:

If you see a YELLOW bubble on the task bar, that means the printer is currently occupied by another computer. You may still send your print job without having the printer connected back to the computer that you are trying to print, or you may click on Switch to manually connect to the printer.

If you see a RED bubble on the task bar, that means the printer is busy. You may send your print job and the switch will automatically queue the print job and finish the print job momentarily.




Mac

1. After installation, you will see the GREEN bubble showing up on the task bar at the bottom. Click on the GREEN bubble to launch the application.



2. You can select and set the printer that is going to be used through the printer sharing switch by selecting the printer from the drop down list. Click on OK to confirm. Now the printer sharing switch will automatically determine the printing order on first come first serve basis.



NOTE:

If you see a YELLOW bubble on the task bar, that means the printer is currently occupied by another computer. You may still send your print job without

having the printer connected back to the computer that you are trying to print, or you may click on Switch to manually connect to the printer.

If you see a RED bubble on the task bar, that means the printer is busy. You may send your print job and the switch will automatically queue the print job and finish the print job momentarily.


Connecting to other USB device

You may choose to use GUB211 to share different types of USB devices between two computers, such as USB external storage or multimedia device with USB connection.

1. For instance, simply connect the USB external storage to the GUB211.



2. On Windows or Mac OS, launch the application and click on Switch to manually connect to the USB external storage device.



3. Once it is connected, you will see GREEN bubble showing up on the task bar, and now you should be able to access the USB external storage device.



Troubleshooting

Problems	Solutions
The Switch does not detect my computer	<ol style="list-style-type: none">1. Check the cable between the Switch and the computer is securely connected2. Try to connect the computer to a different USB port on the Switch
My USB device is not detected by the Switch application	<ol style="list-style-type: none">1. Make sure the application is properly installed and the USB device supports the operation system2. Make sure the connected computer and the USB device is no further than 15 feet away
The USB device is not working properly	Remove and re-install the application
The USB device can not be switched to another computer	Unplug and re-plug the USB cable between the Switch and the host computer.

Federal Communications Commission (FCC) Statement

15.21

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

15.105(b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Operation is subject to the following two conditions:

- 1) this device may not cause interference and
- 2) this device must accept any interference, including interference that may cause undesired operation of the device.

FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

CE Safety Statement

This device has been tested and found to comply with the requirements set up in the council directive on the approximation of the law of member states relating to EMC Directive 89/336/EEC, Low Voltage Directive 73/23/EEC and R&TTE Directive 99/5/EC.

The product has been approved for LVD and covered the following countries:

Belgium, Denmark, France, Germany, Italy, Portugal, U.K., Spain, Sweden

Limited Warranty

IN NO EVENT SHALL THE DIRECT VENDOR'S LIABILITY FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, DISK OR ITS DOCUMENTATION EXCEED THE PRICE PAID FOR THE PRODUCT.

The direct vendor makes no warranty or representation, expressed, implied, or statutory with respect to the contents or use of this documentation, and especially disclaims its quality, performance, merchantability, or fitness for any particular purpose.

The direct vendor also reserves the right to revise or update the device or documentation without obligation to notify any individual or entity of such revisions, or updates. For further inquires please contact your direct vendor.

Contact

IOGEAR, INC.

23 Hubble
Irvine, CA 92618

P 949.453.8782

F 949.453.8785

Visit us at: **www.iogear.com**

©2007 IOGEAR. All Rights Reserved. M0060

IOGEAR, the IOGEAR logo, are trademarks or registered trademarks of IOGEAR, Inc. Microsoft and Windows are registered trademarks of Microsoft Corporation. IBM is a registered trademark of International Business Machines, Inc. Macintosh, G3/G4 and iMac are registered trademarks of Apple Computer, Inc. All other brand and product names are trademarks or registered trademarks of their respective holders. IOGEAR makes no warranty of any kind with regards to the information presented in this document. All information furnished here is for informational purposes only and is subject to change without notice. IOGEAR, Inc. assumes no responsibility for any inaccuracies or errors that may appear in this document.



About Us



FUN

IOGEAR offers connectivity solutions that are innovative, fun, and stylish, helping people enjoy daily life using our high technology products.



GREEN

IOGEAR is an environmentally conscious company that emphasizes the importance of conserving natural resources. The use of our technology solutions helps reduce electronic waste.



HEALTH

IOGEAR supports healthy and fit lifestyles. By integrating products with the latest scientific developments, IOGEAR's solutions enhance the life of end-users.

© 2008 IOGEAR, INC.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>