

# Installation

NETGEAR®


## N300 WiFi Router

Model WNR2000v5


## Package Contents



N300 WiFi Router



Ethernet cable



Power adapter  
(varies by region)


### 1. Prepare your modem.


Unplug your modem's power. If it has a battery backup, remove the battery.

### 2. Connect your modem.

Plug in your modem. Put the battery back in. Then cable the modem to the router's yellow Internet port.

### 3. Power on the router.

The Power LED  lights green. If the Power LED does not light, press the **Power On/Off** button.



### 4. Connect a computer.

Use an Ethernet cable to connect your computer to the Ethernet port on the router.

You can also use WiFi to connect. To connect with WiFi, use the WiFi network name (SSID) and password on the router labels on the bottom of the router.

### 5. Log in to the router.

Launch a web browser.

NETGEAR genie displays.

If you do not see genie, enter **www.routerlogin.net** in the address field of the web browser. When prompted, enter **admin** for the user name and **password** for the password.

Follow the genie steps to connect to the web.

### 6. Get the genie app.

Download the free genie app from [www.NETGEAR.com/genie](http://www.NETGEAR.com/genie).

Easily share media, files, and printers on the network from your smartphone, tablet, or laptop.

## Join the WiFi Network

To connect your computer or WiFi device (such as a smartphone or gaming device) to your router's WiFi network, you can use either the manual method or the Wi-Fi Protected Setup (WPS) method.



### Manual Method

1. Open the software utility that manages your WiFi connections on the computer or WiFi device that you want to connect to your router.  
This utility scans for all wireless networks in your area.
2. Find and select your modem router's WiFi network name (SSID).  
The SSID is on the product label.
3. Enter the router's password (or your custom password if you changed it) and click the **Connect** button.  
The password is on the product label.
4. Repeat Step 1 through Step 3 to add other computers or WiFi devices

### WPS Method

If your computer or WiFi device supports WPS, you can use WPS to join the modem router's WiFi network. For help with the WPS button on your computer or WiFi device, check the instructions or online help that came with that computer or WiFi device. Some older equipment cannot use WPS.

**Note:** WPS does not support WEP security. If you are using WEP security, use the manual method.

1. Press the **WPS** button  on the router.
2. Within two minutes, on your computer or WiFi device, press its **WPS** button or click its onscreen **WPS** button.  
The WiFi LED  blinks green during the WPS process.  
The computer or WiFi device connects to your router's WiFi network.
3. Repeat this process to add other computers or WiFi devices to the network.

## View or Change the Router Settings


After you use genie to set up the router, you can log in to the router to view or change its settings.

1. Connect a computer or wireless device to the router.  
You can use a wired or WiFi connection:
  - For a wired connection, use an Ethernet cable (not included) to connect your computer to a black Ethernet LAN port on your router.
  - To connect with WiFi, use the WiFi network name (SSID) and password on the router labels on the bottom of the router.
2. Launch a web browser.
3. Type **www.routerlogin.net** in the address field of the browser.  
A login screen displays.
4. Enter **admin** for the user name and **password** for the password.  
The router BASIC Home screen displays.

## Restore Factory Settings

You can return the router to its factory default settings.

1. Locate the round hole in the bottom of the router.  
The Reset button is inside of this hole.
2. Use a paperclip or sharp object to press and hold the **Reset** button for at least seven seconds.  
The router resets and returns to its factory settings.



## Support

Thank you for purchasing this NETGEAR product.

After installing your device, locate the serial number on the label of your product and use it to register your product at <https://my.netgear.com>.

You must register your product before you can use NETGEAR telephone support. NETGEAR recommends registering your product through the NETGEAR website. For product updates and web support, visit <http://support.netgear.com>.

NETGEAR recommends that you use only the official NETGEAR support resources.

For the current EU Declaration of Conformity, visit [http://support.netgear.com/app/answers/detail/a\\_id/11621/](http://support.netgear.com/app/answers/detail/a_id/11621/).

For regulatory compliance information, visit <http://www.netgear.com/about/regulatory/>.  
See the regulatory compliance document before connecting the power supply.

You can get the user manual online at <http://downloadcenter.netgear.com> or through a link in the product's user interface.



June 2014

NETGEAR, Inc.  
350 East Plumeria Drive  
San Jose, CA 95134, USA

Download from [Www.Somanuals.com](http://www.Somanuals.com). All Manuals Search And Download.

NETGEAR, the NETGEAR logo, and Connect with Innovation are trademarks and/or registered trademarks of NETGEAR, Inc. and/or its subsidiaries in the United States and/or other countries. Information is subject to change without notice. © NETGEAR, Inc. All rights reserved.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>