

**GeForce FX 5900 XT Series** 

VGA Card

User's Guide

Download from Www.Somanuals.com. All Manuals Search And Download.

#### Disclaimer

The information in this document is subject to change without notice and does not represent a commitment on the part of the vendor. No warranty or representation, either expressed or implied, is made with respect to the quality, accuracy or fitness for any particular purpose of this document. The manufacturer reserves the right to make changes to the content of this document and/or the products associated with it at any time without obligation to notify any person or organization of such changes. In no event will the manufacturer be liable for direct, indirect, special, incidental or consequential damages arising out of the use or inability to use this product or documentation, even if advised of the possibility of such damages. This document contains materials protected by copyright. All rights are reserved. No part of this manual may be reproduced or transmitted in any form, by any means or for any purpose without express written consent. Product names appearing in this document are mentioned for identification purposes only. All trademarks, product names or brand names appearing in this document are registered property of their respective owners.

Printed in Taiwan


#### **FCC Compliance Statement**

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television equipment reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Move the equipment away from the receiver.
- Plug the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for additional suggestions.

Only equipment certified to comply with Class B should be attached to this equipment, and must have shielded interface cables. You are cautioned that any change or modifications to the equipment not expressly approved by the party responsible for compliance could void your authority to operate such equipment. This device complies with Part 15 of the FCC rule. Operation is subjected to the following two conditions:

- 1) This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.



## **CONTENTS**

Chapter 1 Introduction1
Product Specifications
8
System Requirements 2
Chapter 2 Hardware Setup
Installing the Hardware
硬體安裝4
Installation du matériel 5
하드웨어 설치
Installation der Hardware7
Chapter 3 Driver Setup8
Introduction
DirectX 9.0
Display Drivers Setup
Display Drivers Secup
Chapter 4 Display properties12
nView Display Setup
Performance and Quality Settings
Direct 3D Settings
OpenGL Settings
Overlay Controls
TroubleShooting
NVRotate
Temperature Setting (For specific products only)
Refresh Rate Override
Change Resolutions
Change Resolutions
Desktop Management
Desktop Management
Desktop Management

## Chapter 1 Introduction

#### **Product Specifications**

#### Interface

AGP 4x/8x and AGP texturing support

Chipset

NVIDIA GeForce FX5900 XT Series

## **Memory Interface**

Supports 128 MB DDR SDRAM

## Features

- 256-bit advanced memory interface
- 256-bit graphics architecture
- 400 MHz internal RAMDAC
- 22.4 GB/sec memory bandwidth
- 8 pixels per clock rendering engine
- 16 texels per pixel with 8 textures applied per clock
- NVIDIA CineFX 2.0 Engine
- Advanced Display Pipeline with full nView Capabilities
- High-performance, high-precision 3D rendering engine
- High-Performance 2D rendering engine
- UltraShadow technology
- Intellisample HCT Performance Technology
- Digital Vibrance Control (DVC) 3.0
- NVIDIA nView multi-display technology
- Unified Driver Architecture (UDA)

## High quality video playback

- Dual, 400MHz RAMDACs for display resolutions up to and including 2048x1536 @ 85Hz
- Integrated NTSC/PAL TV encoder support resolutions up to 1024x768 without the need for panning with built-in Macrovision copy protection
- DVD and HDTV-ready MPEG-2 decoding up to 1920x1080i resolutions
- Support for dual-link DVI for compatibility with next-generation flat panel displays with resolutions greater than 1600x1200 without the need for reduced blanking

## **Full Software Support**

- Microsoft DirectX optimizations and support
- Full OpenGL 1.4 and lower support
- Complete support DirectX 9.0 and lower
- WHQL-certified Windows 2000 / XP (for Windows 9x / ME versions please visit NVIDIA's website for the latest update on drivers)

### Chapter 1

## Others

- TV-out
- DVI-I (Optional)
- VIVO (Optional)

## **Package Contents**

- 1. GeForce FX5900 XT Series VGA card
- 2. User's Guide
- 3. Driver Pack
  - Windows 2000/XP drivers (for Windows 9x / ME versions please visit NVIDIA's website or see later update on drivers)
  - 3Deep (Optional)
  - WinDVD 6 Channel
  - WinDVD Creator
  - WinRip
- 4. WinProducer 3.0 (Optional)
- 5. MDK2
- 6. Game Pack (5 in 1)
  - Age of Wonders2
  - Serious Sam2
  - Rally Trophy
  - Max Panye
  - Tropico
- 7. S-Video to S-Video cable
- 8. S-Video to AV cable (Optional)
- 9. DVI I to VGA Adapter
- 10. Composite Cable (Optional)
- 11. VIVO cable (Optional)

## System Requirements

## **Computer System**

- Intel Pentium® II or newer compatible CPU (Intel Pentium® III or AMD Athlon® or newer CPU's recommended)
- VGA/Super VGA monitor, supporting minimum 640x480 resolution.
- 64MB RAM or higher.
- 15MB HDD space.
- CD-ROM or DVD-ROM Driver.
- DirectX 9.0 and lower.
- Windows 2000 / XP operation system (for Windows 9x / ME versions please visit NVIDIA's website or see later update on drivers)

User's Guide


## Chapter 2 Hardware Setup

## **Installing the Hardware**

- 1. **Turn off** the computer's **power** and make sure the system is properly grounded (leave the power cord connected). Then disconnect the monitor signal cable.
- 2. Remove the computer chassis cover. Be sure to discharge your body's static electricity by touching the metal area of the computer each time before touching both the old and new VGA cards.



- 3. Remove the old card, if it exists.
- 4. Grasp the edge or bracket of the card, align your card with an empty AGP expansion slot and slide it into place.
- 5. Replace the screw to fasten the card onto the chassis, and replace the computer chassis cover.
- 6. Plug the monitor cable into your card, and then turn on the computer and the monitor.




User's Guide

4


User's Guide

## 硬體安裝

- 1. 關掉電腦的電源,並且確定拔掉電源線,然後拔除螢幕的訊號線。
- 2. 移開電腦的外殼蓋。在每次安裝新的和舊的顯示卡前,請觸摸電腦的金 屬部位,以確保排出身體中之多餘靜電。




- 3. 假如你有舊的顯示卡請先移除。
- 4. 握緊你的顯示卡,小心地將顯示卡插入空的 AGP 插槽中。
- 5. 用螺絲將顯示卡固定於機設中,並且將電腦的外殼蓋放回原處,並用螺 絲栓緊。
- 6. 連接螢幕的排線於顯示卡上,並且打開電腦和螢幕的電源開闢。




#### Chapter 2

#### Installation du matériel

- 1. Eteignez votre ordinateur et déconnecté votre écran.
- 2. Enlevez le couvercle ou les panneaux de côté de votre ordinateur (consultez le manuel d'instructions de votre ordinateur pour les instructions de montage et de démontage).



- 3. Enlevez la carte graphique AGP présente -o u enlevez la languette de métal qui recouvre l'emplacement du connecteur AGP.
- 4. Alignez le côté de votre carte où se trouvent les connecteurs avec l'emplacement du connecteur AGP et appuyez fermement jusqu'à ce qu'elle soit complètement mise ne place (ne SURTOUT PAS forcer la carte dans son emplacement - appliquez une poussée uniforme de chaque côté de la carte).
- Visez la carte au châssis, et remonté le couvercle du boîtier. 5.
- Branchez le cordon VGA à la carte graphique et reconnectez votre moniteur 6. ainsi que le reste des câbles.




하드웨어 설치

- 1. 먼저 컴퓨터의 전원을 차단하고 전원이 완전히 차단되었는지 확인한 후에 모니터 시그널 케이블을 분리해 주십시오.
- 2. 컴퓨터 케이스의 덮개를 열고 VGA 카드를 장착하기에 앞서 컴퓨터를 전자기로부터 보호하기 위해 전자기로부터 안전한 복장 및 도구를 착용하거나 이용해 주십시오.



- 3. 만약 구형카드가 시스템에 장착되어 있다면 먼저 구형카드를 시스템에서 분리해 주십시오.
- 4. 케이스 뒷면 브라켓 장착 부분과 PCI 확장 슬롯에 수직이 되도록 하여 카드를 조심스럽게 PCI 확장 슬롯에 장착해 주십시오.
- 5. VGA 카드를 장착한 후 컴퓨터 케이스 덮개를 씌워 주십시오.
- 6. VGA 카드에 모니터 케이블을 연결한 후 컴퓨터 본체와 모니터의 전원을 켜주십시오.




6


User's Guide

#### Installation der Hardware

- Schalten Sie den Computer aus, und stellen Sie sicher, dass das Gerät richtig geerdet ist (lassen Sie das Netzkabel sowohl am PC als auch an der Netzsteckdose angeschlossen). Trennen Sie jetzt das Signalkabel des Monitors vom VGA-Anschluß.
- 2. Entfernen Sie die Abdeckung des PC-Gehäuses. Stellen Sie sicher, dass Sie sich jedes mal durch Berührung des Metallgehäuses von statischer Elektrizität befreien, bevor Sie die alte oder neue VGA-Karte anfassen!



- 3. Remove the old card, if it exists.
- 4. Grasp the edge or bracket of the card, align your card with an empty AGP expansion slot and slide it into place.
- 5. Replace the screw to fasten the card onto the chassis, and replace the computer chassis cover.
- 6. Plug the monitor cable into your card, and then turn on the computer and the monitor.



User's Guide

Chapter 3


## **Chapter 3 Driver Setup**

#### Introduction

This chapter explains how to install AGP VGA card drivers using the VGA Driver Setup tool that is included in the CD-ROM that came with your AGP VGA card.

## DirectX 9.0

1. If an older version of DirectX has been installed in the system, please click on [**DIRECTX 9.0**] to upgrade to the latest version.




2. After reading the license agreement, please click [Next >] to continue.



8

Chapter 3

3. Please click [**Next** >] to continue.



4. Please click **[Finish**] to complete the setup process.



#### Chapter 3

## **Display Drivers Setup**

For Driver setup in Win98se/ME/2000/XP mode, please follow the steps below.

- 1. Insert VGA Driver Package CD into CD-ROM driver.
- 2. Click on [Display Drivers] to begin driver installations.



3. Please click [Next >] to continue.



4. Please select **[Yes]** to restart computer now or **[No]** for restart later, then click **[Finish]** to complete the installation.



**Chapter 4 Display properties** 

In order to open **Display Properties** window, select from [**Start**] -> [**Settings**] -> [**Control Panel**] ->[**Display Properties**]. Otherwise, you may simply right-click the blank Windows<sup>®</sup> desktop area and choose [**Properties**] in the pop-up menu. The **Display Properties** window below will show on your screen:

	Desktop	Screen Saver	Appearance	Settings	
		000			
			Ψŝ		
		_	-	0	
Display Default		NVIDIA GeFord	e FX 5900KT		
Scien	n resolution		Color que	, and a second	
	-0		Highest	(32 bit)	~
Less	1024 by 7	po beau			

Please click the [Advanced] button to enter the advanced setup for your display card.

Choose [GeForce FX5900XT] series tab in the pop-up menu to access further settings on VGA card feature.

## nView Display Setup

In order to open **Display Properties** window, select from [**Start**] ->[**Settings**] -> [**Control Panel**] -> [**Display Properties**] to open the submenu. From [**Display Properties**] -> [**Settings**] -> [**Advanced**] -> [**GeForce FX5900XT**] tab we can select the various functions of this VGA card.

		L Tindentori af See Fit 1900(1
March 190000     March 29499 Mich     Petersance & Guide     Petersance & Guide     Deect0 Setting     Operitor Statistic     Deads Potence     Tradis Provide     Theorematic Settings     Petersance     Deeling Management     Tameen Remain	CAPERCIAL POST	AND
	Filmmen         Terretailun           rud.,dec.dl         Trable dirut           rud.,dec.dl         Trable dirut           rud.glt.dl         Trable dirut           ruccid         Trable dirut	Varian 6.14 Victor 6.14 Victor 6.14 Victor 6.14 Victor 6.14 Victor
		Canad

Please click on **nView Display Mode** to enter its submenu that allows you to setup the various nView options.



13

#### 1) nView Modes

a) Single display

Selects the standard, single display mode. Use this mode if you have only one display device attached to your NVIDIA graphics adapter.

b) Clone

This mode outputs an exact copy of the primary display on the secondary device.

c) Horizontal Span

This mode allows you to extend the Windows desktop across two display devices horizontally. In this mode the two displays combine to form a wide, spanned display surface, which is useful when viewing items that are wider than a single display.

d) Vertical Span

This mode allows you to extend the Windows desktop across two display devices vertically. In this mode the two displays combine to form a tall, spanned display surface, which is useful when viewing items that are larger than a single display.

#### 2) Current Display

If more than one device is connected and you have switched to a mode other than the Standard one, you can select the current display of your choice.

You can also click on the monitor image directly above the display control to select it as the current display.

Notes:

nView Display Devices select:

First Display	$\rightarrow$ D-Sub Connector
Second Display	→ DVI-I Connector
Third Display	$\rightarrow$ TV-out

#### 3) Make this the primary display

Use this option to select which display contains the top left corner of the desktop. The most obvious effect of this option is that it swaps the positions of the monitor images.

#### 4) Disable auto-panning on secondary device (viewport lock)

Turning on this feature locks the current pan position on the secondary clone display. This lets you effectively freeze the virtual desktop at a certain position, which is useful for presentations or fine-detailed work in applications.

#### Chapter 4

#### 5) Detect Displays


Click to detect all displays connected to this video adapter. Use this feature if you have plugged in any displays after the control panel was opened.

#### 6) Device Setting >>

Click this button to set up or change settings related to the output device used for the current display.



#### a) Color Correction:



The slider control allows you to adjust the brightness, contrast or gamma values for the selected color channel.

The color correction controls help you to compensate for variations in luminance between a source image and its output on a display device. When you are working with image processing applications, this helps provide more accurate color reproduction of images (such as photographs) that are displayed on your monitor.

Also, many 3D-accelerated games may appear too dark to play. Increasing the brightness and/or the gamma value equally across all channels makes these games appear brighter and more playable. Chapter 4

#### b) Device Adjustments

#### i) Screen Adjustment

This will access the Screen Adjustment panel as below.



This allows you to adjust the center of your screen, to adjust the screen position, move the mouse over the monitor image and drag the desktop to the desired position while holding down the primary mouse button. Use the arrow positioning buttons for fine adjustments. You can also click the [Default] button to return to its original state. Click [OK] when you finish adjusting the screen.

ii) Display Timing



This option allows users to select the various timing mode for the monitor. Click [**Restore Defaults**] to restore the default timing mode of the monitor.

17

18

User's Guide

Performance a	and Qu	iality Se	ettings
---------------	--------	-----------	---------

	General Color Mar	Adapt	les .	Monitor Gel	Teo Force FX 50	tionical toget
<ul> <li>SeForce RX52004T         <ul> <li>shiev Display Mode</li> <li>Portonumer &amp; Guality *                  Deec00 Settings                 OpenGL Settings                 Orestar/Castol                 Toublechooling                 MrRinzel                 Temperature Settings                 Refeatil Rate Overvide:                 </li> </ul> </li> </ul>	Isage retirg		• •		NVII NVII	DIA.
	High pertons Antisilaring no Application	inge		mance		Quelly
- Change Resolutions Desktop Management Screen Manus	Cr Anisotropio (B	- 10 C	24	, AL	ŝ.	
	Applicate	on-controlle	4			_
٩	dis.		6	4		14
1				fie .	they show	h

#### 1) Performance

Drag the slider to select the performance setting (as described below) for quality enhancements in Direct3D and OpenGL applications.

#### 2) Antialiasing

Antialiasing is a technique used to minimize the "stairstep" effect sometimes seen along the edges of 3D objects. This option automatically enables the optimal antialiasing settings for those 3D applications that support antialiasing.

#### 3) Anisotropic Filtering

Availability of options described below may depend on the NVIDIA GPU you are using.Use this slider by dragging it to set the degree of anisotropic filtering for improved image quality. Enabling this option improves image quality at the cost of performance.

#### 4) Texture Sharpening

To improve image quality, select this option to sharpen textures when running 3D applications with antialiasing enabled.

Download from Www.Somanuals.com. All Manuals Search And Download.

## **Direct 3D Settings**

This tab allows you to adjust the values of **Performance and Compatibility**, **Mipmapping** and **PCI Texture Memory Size** for 3D games.

		eitor Troubleshoot 1 GeForce FX 5900XT
GeForce FX 5900/T     r/Vew Display Mode	Direct3D	WVIDIA.
E Performance & Quality *	Petranence and compatibility options Migroup detail level	
Overlay Controls	Best image quality	
Troubleshooling M/Rotale Temperature Settings Rotech Rate Direndes Change Resolutions Deliktop Management Screen Menus	Maximum system memory for PC1 mode ter 53      HE Enable log table enviration	date
	Custim direct3D settings	
	- <u>See</u>	Az
٢		Notes delate
0	OK.	Cancel Apple

#### 1) Performance and Compatibility Options

This option contains items that allow you to set up the options influencing the performance and compatibility in 3D games.

#### 2) Mipmap Detail Level

This option allows you to set up the mipmap level for a higher performance or better image effects.

#### 3) PCI Texture Memory Size

This option allows you to adjust the size of the PCI texture memory. For some applications using the Direct3D technology, typing a higher value in this spin box may significantly increase the performance. However, this option does not work on display adapter using an AGP bus.

#### 4) Custom Direct3D Settings:

This option allows you to save your settings for future reference.

#### Chapter 4

## **OpenGL Settings**

This tab allows you to adjust the **Performance and Compatibility Options** for your OpenGL application.

	General Adapter Estor Hanagement	Montor Troubleshoot
■ GeForce FX 5900-0 riview Doplay Mode	OpenGL	WVIDIA.
	Fefomence and	compatibility options
Direct3D Settings Elsericit, 1 atrings O verlag Controls Troubleshooting	Disable support for enhanced I Enable conformant OpenGL ter	
NVRotate Temperature Settings	Multi-deploy fractivities accordination	Tangle Unitsy multi-
Fielseith Rate Overides Change Resolutions	Default color depth (for testures)	Use desktop color depth
Decktop Hanagement	Buller lipping wode:	Auto-select
Screen Menuz	Vetical pro:	ûn by default 🖉
	Custom OpenSiL settings:	
0		Save As. Deter
		Prenture delavite
1	0	Carcel / risky

#### 1) Performance and Compatibility Options

This feature allows you to set up the various options influencing the performance and compatibility in your OpenGL applications.

#### 2) Default Color Depth for Textures

This option determines the default textures of a specific color depth in OpenGL applications.

#### 3) Buffer Flipping Mode

When running the OpenGL application under Full-Screen mode, turning on the page- flipping function may significantly increase the performance.

4) Vertical Sync

This option allows you to choose the type of vertical sync.

## **Overlay Controls**

Use these controls to adjust the quality of video or DVD playback on your monitor. You can independently control the **Brightness**, **Contrast**, **Hue** and **Saturation** to achieve optimal image quality during video or DVD movie playback on your computer.

	General Adapter Color Management	Monitor Ti Seferce PK	publeshoot 5900-07
GeForce FX 5900/0 r/View Diglay Mode	۲	<b>N</b> V	IDIA.
E Petomence & Qualty 1 Direct3D Settings	Uverlay zoon controls. Select screen region to zoon	Zoon cont	d
OpenGL Settings		Video Overlag	
Dividia/Controls Troublechooting		Dut	in
NyRotate Temperature Settings Rehech Plate Oversider		Ū.	
Change Flecolutions Deuktop Management Screen Menus	Diverting color controls	Hie	0%
	Adjurt Colors	Salaration	1143
0		- 0	
		Bestore de	(esite

Zoom control: Let you zoom in on or out of the selected portion of the video playback screen.

#### Chapter 4

## TroubleShooting

	General Adap Color Management	and the second s	ikor Troubleshoot GeForce FX 9900KT
GeFace FX 1900KT     Niew Display Mode     Performance & Quality     Operator Scheinigs     Operator Scheinigs     Operator Scheinigs     Operator Scheinigs     Operator Scheinigs     Nietotale     Temperature Scheinigs     Desklap Management     Screen Menus	The Invitors and passing hands features and passing pourly the Windows taskbas	i configured in the	

## 1) Display the Media Center icon in the taskbar:

Adds the NVIDIA Media icon to the Windows taskbar by checking the appropriate box on the screen. The icon allows you to apply any of the custom Direct3D, OpenGL or color settings **on the fly** from a convenient pop-up menu. The menu also contains items for restoring default settings and accessing the Display Properties dialog box.

#### 2) Detect Display

Click this button to allow detection of any new displays added for the nView Display Mode.

#### 3) Restore Defaults

Click [Restore defaults] to restore the default timing mode of the monitor.

#### Chapter 4

#### **NVRotate**

The NVRotate feature lets you view your Windows desktop in **Landscape** or **Portrait** mode. You can rotate desktop by 90, 180 or 270 degrees.



#### 1) Landscape (0 degree rotation)



This is the default setting that will leave the screen in its original state.

#### 2) Portrait (90 degree rotation)




This will rotate the display screen 90 degrees to the right.

User's Guide

23

24

User's Guide





This will rotate the display screen 180 degrees upside down.

#### 4) Portrait (90 degree rotation)

This will rotate the display screen 270 degrees (i.e. 90 degrees to the left).



## **Temperature Setting (For specific products only)**

This gives an indication of the current status of the GPU temperature setting.



Download from Www.Somanuals.com. All Manuals Search And Download.

### **Refresh Rate Override**

This tab allows you to select Refresh Rate Override to be used in Direct3D applications.

**Adata** 16.484 Denklar Teres 4.2 Define PLNDDO Distantion of the local distance of the loca E. 2 Gallistia Ph 19900-1 WVIDIA. (Water Digital Annie Performance & Station City U-mids where says to many measures over the constraint of the size of P Dep/100 Series Ineria intro C Application Loopled values when Overlag Deninds CO-wilds alled uses nudded-colleg waai 130 + 200 220 + 240 400 + 360 Column Designed Woman and 400 + 303 Completion of States 512 x 384 545 x 488 545 x 488 721+40 721+55 801+60 941+40 0 Dr. Internet

#### **Change Resolutions**

	Color Management Color Management Color Management
Galf year FN 20007     New Disate Heat     Polace Disate Heat     Polace Disate Service     Tradictioning     Notice Constit     Tradictioning     Polace Marcine     Doublics Haragement     Soversities	
	E [ Levil ]

This option gives the details of the screen resolution and allows users to change screen resolution, color quality and refresh rates for the monitor. In Custom Resolutions and Refresh Rates, users can customize their own resolutions and refresh rates by clicking [Add] or [Remove] button. When checking the [Only show custom modes] box only custom modes are shown.

## **Desktop Management**



#### **Enables the NVIDIA Desktop Manager:**

The NVIDIA Desktop Manager enables additional functions such as hot keys for window management, re-centering of dialog boxes, and zooming in when nView's multi-monitor configurations are in use. The Desktop Manager also adds support for multiple desktops to help you better organize your application workspace.

## **Screen Menus**

This gives an indication of the current status of the GPU temperature setting.

	Cales Hanagement Staff Coal Cr State Fr
Gef use FX 50001     ridee Exploy Flade     Politanese 15 Guilty     Dec33 Setting     Ovelas Central     Wilate     Wilate     Setting Headware     Setting Headware     Setting Headware	Control of the second second of the second sec
	Termi stale
1	DK CAVAL

User's Guid

## Appendix

## WinCinema

1. Enter personal information on boxes below to register the product.

Please enter po	u nano, the	company for	where you a	rok and the p	roduct.
send marden.					_
Ngrae					
Economic [					-
Senat [		 			_

 Choose [Select All] to select all the products, in this case WINDVD, WinDVDCreator and WINRIP, and [Clear All] to deselect them. Click [Next >] to proceed.

Appendix	C

## 1) WinDVD

It is a simple-to-use software DVD player combining all the features of a standard consumer DVD player with some very advanced functionality only possible on a software DVD player.





/inCinema Setup	
Select the products you with I	a motal.
Vivi0//DCealor	
S. witho	
	Select All Dear All
	(jack Seat) Cancel

User's Guide

1. Please click [Next >] to begin the setup process.




2. After reading the license agreement, please click [Yes] to continue.


InterVideo WinDVD 4 Setup Hulti-Channel Support	8
License Agreement Please read the following license agreement carefully	ter <mark>/fan</mark>
Press the PAGE DOWN key to see the rest of the agreement.	
SINGLE END/USER LICENSE AGREEMENT FOR INTERVIDED WIND/OTH SOFTWARE	<u>e</u>
MPORTANT READ CAREFULLY.	
This intel/ideo WeDVD End-ILaeruse Ageeneet (TEULA') is a legal AGRED between you and interhideo inc. for the line/ideo WeDVD universe product ide above: which product includes compares rollwave and nav include encoursed or printed materials, and "univer" or electronic documentation ("SDFTWARE PRODU By installing, copying, or offerwise using the SDFTWARE PRODUCT, you agree	eda. UCT 1
Do you accept all the terms of the preceding License Agreement? If you choose to setup will close. To install Wind/VD, you must accept this agreement.	lo, the
relative i	
(Back Yes	30

#### Appendix

3. Please select a folder where the program will be installed and click [Next >] to proceed.



 Please select one folder name from existing folders list and click [Next >] to proceed.



 Please select the default player by checking the specific boxes and click [Next>] to proceed.

File Types Association	int	er <mark>i</mark> Ate
Select the file types for which you	ward InterVideo WinDVD Player to be the obfault	player.
P DVD Video - autoplay DVD III	9	
P Movie File - includes: ropeg ro	pg extensions	
dullhili		

6. Click on [Finish] to complete the installation process.

InterVideo WinDVD 4 Set	ap: Multi-Channel Support
Inter <mark>liAtens</mark>	Setup Complete Setup has triched installing WirDVD on your computer.
	Click Finish to complete Secup
	- Jack Freih

## 2) WinDVD Creator Setup

WinDVD Creator's storyboard interface makes the entire DVD-making process as easy as moving pictures around on your screen.

There are four Easy Steps to make your DVD: Capture, Edit, Author & Make Movie.



1. Please click [Next >] to begin the setup process.



2. After reading the license agreement, please click [Yes] to continue.



3. Please select a folder where the program will be installed and click [Next >] to proceed.

lease use the default Destination path	inter <b>/</b> ide
WinDVD Creator Install has detected anoth it is highly recommended to install WinDVD	ter IntelVideo product installed on your syntem. I Dealer to WinDVD Creater.
Dedination Folder	Breen
Dedination Folder CrYPtogram Files/InterVideo/W/Deator	Byone
<ul> <li>Manager Manager and Statements</li> </ul>	Byoinit

4. Please select one folder name from existing list of folders and click [Next >] to proceed.


intext Program Folder	
Please onlect a program folder.	Inter
Estap will add program score to the it name, or milect one host the eathing	
Dogwin Falder:	
TRANSPORT OF LODGE	
Equitry Folder:	
Alleitter	
Administrative Tools Servers Inden'sdes WinDVO & Startup	
a hada	

 Please check the box to install the required third party product and click [Next >] to proceed.



Appendix

6. Click on [Finish] to complete the installation process.



#### 3) WinRip 2.1 Setup


WinRip lets you record, store, organize, and enjoy you music collection - on your PC, CD player, and portable player. WinRip's IDI technology adds synchronized lyrics to your songs, then use the Karaoke and other DSP effects for a great party.

V	
-	Aller Contane Cantered to barries to:
inte	Envideo. Intervation(R)/WinRig(R) (c) 2000, http://dec.inc. All Rights/Reparted
	ED induted data through the interval from the CDER <sup>W</sup> May is CD Database, (1) 1988, 2080 CEDRUM EDDID Card Televane, Councign 1988, 2080 CEDRU, Inc. CEDRU Enabled, CEDRU, CEDRU and the CDID Carp are trademarks of CEDRU, Inc. See Second End Service and OFD are involve marks of CEDRU, Inc. MPRO Large V2 and/o counting technology feasored by Frazebote Institu Integrate Schattangen Mightlewarks the following
1.0	Particle Land upon Misraelf Windows Moda Technologies (c) 9000 Misraelf Carposition, All Palific Facework Microsoft, Windows Media, and the Windows Lap are registrated Labertails of Misraelf Carposation in the United Tables and/or other monthle
Single I	ED/EVD searching an Boarts down legiod under lawson from Paulat, Iro.

User's Guide

35







Next >

Cancel


3. Please select a folder where the program will be installed and click [Next >] to proceed.

	inter/id
WinFig Install has detected another IntelVideo product insta recommended to install WinFig to CVProgram Files/IntelVide	
Destination Folder	
Destination Folder C/Program Film/Unter/Video/WrinFigs	- Bysens.

4. Please select one folder name from existing list of folders and click [Next >] to proceed.

elect Program Folder		100 M
Please select a program folder.		interVic
Setup will add program icons to the Pri name, or othert one from the existing for		
Program Foldett		
Intelliget Walking		
Egisting Folders		
Accession		
Administrative Tools Games InterVideo WinDVD 4 InterVideo WinDVD Cleator Startup		
citil		
	(Back	Next> Cancel

5. Click on [Start >] to begin WinRip Configuration Wizard.



 Choose [Select All] to select all file extension types for WinRip and click [Next >] to continue.



User's Guide

37

38

User's Guide

Appendix

7. Click on [Next >] to continue.

Setting Record Path	8
The is used to set your default peth for serving your reco	rded songs.
Pecoding Path	
	NAL AND DECIDENT
	Browse
< Back 1	Eext) Cancel

8. Select the type of recording format and click [Next >] to continue.



- 9. Click on [Finish] to complete the configuration process.

Be sure that all your settings are conrect. Prease the "Back" button to receit previous settings, of press "Finish" to end this wisered.
< Back Finish Cancel

## 10. Click on [Finish] to complete the setup.



39

**3Deep E-color (Optional)** 

3Deep ensures that your monitor displays 3D games with accurate lighting and shading exactly the way the creator intended. 3Deep delivers the precise imagery that the developer spent months working to achieve.

1. Please click [Next >] to continue.



2. After reading the license agreement, please click [Yes] to continue.



3. Please click [Next >] to continue.

COLOR	Teriup rell sustal E-Color Software in the following tokes To install to this hidee, click Newt. To noted to a different folder, click Browce and select another folder You can choose not to install E-Color Software by clicking Cancel to eail Selup.		
Color You Can Trust*	Destination Folds C1Program File/E Cole	Basse	

4. Please click **[OK]** to allow the 3Deep E-color to tune up your display.



 Choose your screen to be either CRT or FLAT PANEL and then press [Next >] to continue.



42

User's Guide

Please follow the setup procedure below to tune up your Display.

6. Please click [**Next** >] to continue installing 3Deep E-color.



 Please check the box for the required files and then click [Next >] to end the installation process.



We recommend that you Tune-Up your monitor every three to six months.

#### Appendix

#### **Tuning Up Instruction**

Double-click on the E-Color icon in your system tray and then click on the 'Tune-Up' tab.

- 1. Click on the 'Tune-up' button.
- 2. Complete the quick and easy E-Color Wizard, and then connect to the Internet.
- 3. When connected, 3Deep will complete the process enabling you to see E-Color Corrected images.

#### For Your Best Result

- 1. Let your monitor warm up for at least 30 minutes before beginning the E-Color Wizard (TM). This process allows the colors to stabilize.
- If you have a third-party monitor calibration system installed (e.g., EFIcolor, AGFA FotoTune, or another), use either that system or 3Deep. Do not use both calibration systems. Using both systems will mis-calibrate the monitor. Search 3Deep Help for instructions for your application.
- 3. If your monitor has some type of color adjustment controls, adjust them to your liking first, before running 3Deep.
- 4. If your monitor has a degauss button press it before running the E-Color Wizard. If you don't have one, then your monitor has an automatic degauss cycle that works when you turn your monitor off and then on again, even if there is no outward indication of it.

#### Note:

See the Readme.txt file in the CD-ROM's root directory for installation instructions of this software.

3Deep V3 **does not** operate properly in **256 color** mode on Microsoft® Windows® NT4 or 2000 systems. Please use a higher color Depth (16-bit or higher).

3. Enter personal information on spaces below to register the product.



4. Please select a folder where the program will be installed and click on [Next >] to proceed.



## WinProducer3 (Optional)

1. Please click [Next >] to continue installing WinProducer3.



2. Please click [Yes] to continue installing WinProducer3.



5. Please select one folder from existing list of folders and click on [Next >] to proceed.

Select Program Folder		intervid
Please select a program folder.		intervid
Setup will add program icons to the P mane, or unlect one from the electrop		
Program Folders:	The second second second second	
InterVideo WerPochare 1		
Existing Folders		
Accessoles		
Administrative Tools C Media Audio		
E-Color		
Ganes Intel/ideo winDVD 4		
Stafiag		
1000 CON		
Alter		
	( Back	New Cancel
	< 8-90%	rade Lance

6. Please click [**Next** >] to continue installing WinProducer 3.

erVideo WinProducer Setup		
ed Party Application Setup		inter <b>V</b> ide
WirProducer Setup recommends to install to performance.	he followings: application(s) for ma	simure
🖉 Mercenti MCML Heip	2001 Instal Microso view HTML D karvat (chrief)	
Space Required on C Space Available on C	720 K 26998736 K	Owge,
altan)	Next Next >	Cancel

7. Please click [Finish] to complete the WinProducer 3 installation program.





WinProducer 3 CD, or WinProducer 3 DVD These InterVideo applications let you combine your personal video, digital images, and audio into exciting, professional-quality movies. Whether you are editing your first movie or looking for a program that will let you take your productions to the next level, your WinProducer application's straightforward drag-and-drop editing style combined

User's Guide

47

NOTE

# NOTE

with its comprehensive editing capabilities will meet your needs today and tomorrow.

With your WinProducer application, you can:

- Record and capture video, image, and audio content for your movie.
- Import video, image, and audio files in a wide variety of popular formats including: MPEG1, MPEG2, AVI, BMP, GIF, JPEG, MP3, and WAV.
- Use simple drag-and-drop operations to turn the clips into a compelling movie.
- Enhance you movie with professional-quality special effects.
- Perform DVD-authoring tasks. (only WinProducer3 CD and WinProducer 2 DVD support this feature.)

Save your finished movie in a variety of formats. As the following table indicates, the format you can use to save your movie depends on which WinProducer product you are using.

Application	Format				
	MPEG or AVI File	CD-RW	DVD Rewritable	DV Camera	
WinProducer 3	•			•	
WinProducer 3 CD	•	•		•	
WinProducer 3 DVD	•	•	•	•	

For further details on confirmations and operation instructions, please refer to the Help topics under the Help tool bar.

All rights are reserved for the products and corporate names/logos that appear in this manual to their original owners.

All rights are reserved for changing this manual and all the information/ content is subject to change without notice.

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com