



DF5HD Series Heavy-Duty Fixed-Mount Dome

**Installation Manual** 

C2432M-A (12/03)

Pelco • 3500 Pelco Way • Clovis, CA 93612-5699 USA • www.pelco.com In North America and Canada: Tel (800) 289-9100 • FAX (800) 289-9150 International Customers: Tel +1(559) 292-1981 • FAX +1(559) 348-1120

# **CONTENTS**

IMPOF	RTANT SAFEGUARDS AND WARNINGS	3
DESCI	RIPTION	Q
M	DDELS	3
INSTA	LLATION IN-CEILING MODEL	4
	REPARE CEILING	
	STALL THE MOUNTING PLATES	
IN	STALL THE BACK BOX	4
INSTA	LLATION PENDANT MODELS	5
	DUNT AND INSTALL THE BACK BOX	
CAME	RA AND LENS INSTALLATION	.6
LOWE	R DOME INSTALLATION	. 6
IN	-CEILING MODEL	6
PE	NDANT MODELS	6
SPECI	FICATIONS	.7
WARR	ANTY AND RETURN INFORMATION	8
ST OF	TABLES	
Α	Video Coaxial Cable Requirements	5
В	24 VAC Wiring Distances	

# **IMPORTANT SAFEGUARDS AND WARNINGS**

Prior to installation and use of this product, the following WARNINGS should be observed.

- 1. Installation and servicing should only be done by qualified service personnel and conform to all local codes.
- 2. Unless the unit is specifically marked as a NEMA Type 3, 3R, 3S, 4, 4X, 6, or 6P enclosure, it is designed for indoor use only and it must not be installed where exposed to rain and moisture.
- 3. Only use replacement parts recommended by Pelco.
- 4. The installation method and materials should be capable of supporting four times the weight of the enclosure, pan/tilt, camera and lens combination.

The product and/or manual may bear the following marks:



This symbol indicates that dangerous voltage constituting a risk of electric shock is present within this unit.



This symbol indicates that there are important operating and maintenance instructions in the literature accompanying this unit.

### **CAUTION:**

RISK OF ELECTRIC SHOCK. DO NOT OPEN.

Please thoroughly familiarize yourself with the information in this manual prior to installation and operation.

# **DESCRIPTION**

The Heavy-duty DF5HD Series dome is perfect for fixed camera installations where structural integrity and vandalism are a priority. The system features barrel key locks, heavy-duty construction and a thick injection-molded plastic lower dome. The in-ceiling model has a reinforced bracket mounting system for installation in a fixed ceiling. Pendant models can be mounted to a pole or wall using the IWM wall mount.

## **MODELS**

DF5HD-1 In-ceiling back box with reinforced bracket-mounting system and clear dome
DF5HD-PG-1 Indoor, pendant style back box with reinforced sun shroud and clear dome

DF5HD-PG-E1 Environmental, pendant style back box with heater, fan, reinforced sun shroud and clear dome

# **INSTALLATION IN-CEILING MODEL**


## **PREPARE CEILING**



 a. Locate the center point of the mounting location. Drill a hole in the ceiling using a 3/32-inch drill.



Insert the compass tool into the hole.
 Draw a circle on the ceiling using the compass tool and a pencil. Cut the circle out of the ceiling.




 Use the mounting ring as a template and mark the hole pattern onto the mounting surface. Prepare the holes.


# **INSTALL THE MOUNTING PLATES**

Use the eight 10-32 x 3-inch screws (supplied) and install the mounting ring and two back mounting plates.


- a. Line up the mounting ring with the eight fastener holes.
- Feed one back mounting plate through the hole in the ceiling and line up with four fastener holes.
- Install fasteners through the mounting ring, ceiling, and out the back mounting plate.
- d. Install second back mounting plate.



# **INSTALL THE BACK BOX**



- Attach the conduit fitting, lock nut, and safety chain bracket.
   Install a safety chain/cable (not supplied) that will support up to 16 pounds (7.3 kg).
- Turn the thumbscrew and open the hinged door to the back box. Pull wiring into the back box through the conduit fitting.
   Refer to Tables A and B for cable requirements and wiring distances.





c. Compress the spring clips on the back box and push it through the hole, until the clips spring back. Tighten the screws until you hear a clicking noise. Insert the two 8-32 x .250-inch screws to secure the back box to the mounting ring.

# **INSTALLATION PENDANT MODELS**

# **MOUNT AND INSTALL THE BACK BOX**

NOTE: If installing outdoors make sure the installation is properly sealed to keep moisture out.





- a. Install the mount for the pendant dome. Refer to the instructions supplied with the mount. Bring the wiring for the dome through the mount. Refer to Tables A and B for cable requirements and wiring distances.
- b. Pull wiring from the mount into the back box.

 Screw the back box into the mount. If outdoors, apply thread compound (provided) to the threads on the back box.

Table A. Video Coaxial Cable Requirements

Cable Type*	Maximum Distance			
RG59/U	750 ft (229 m)			
RG6/U	1,000 ft (305 m)			
RG11/U	1,500 ft (457 m)			

<sup>\*</sup> Minimum cable requirements:

75 ohms impedance

All-copper center conductor

All-copper braided shield with 95% braid coverage

Table B. 24 VAC Wiring Distances

The following are the recommended maximum distances for 24 VAC applications and are calculated with a 10-percent voltage drop. (Ten percent is generally the maximum allowable voltage drop for AC-powered devices.)

**EXAMPLE:** An enclosure that requires 80 vA and is installed 35 feet (10 m) from the transformer would require a minimum wire gauge of 20 AWG.

**NOTE:** Distances are calculated in feet; values in parentheses are meters.

### Wire Gauge

		20	18	16	14	12	10
Total vA consumed	10	283 (86)	451(137)	716 (218)	1142 (348)	1811 (551)	2880 (877)
	20	141 (42)	225 (68)	358 (109)	571 (174)	905 (275)	1440 (438)
	30	94 (28)	150 (45)	238 (72)	380 (115)	603 (183)	960 (292)
	40	70 (21)	112 (34)	179 (54)	285 (86)	452 (137)	720 (219)
	50	56 (17)	90 (27)	143 (43)	228 (69)	362 (110)	576 (175)
	60	47 (14)	75 (22)	119 (36)	190 (57)	301 (91)	480 (146)
	70	40 (12)	64 (19)	102 (31)	163 (49)	258 (78)	411 (125)
	80	35 (10)	56 (17)	89 (27)	142 (43)	226 (68)	360 (109)
-							

Maximum distance from transformer to load

# **CAMERA AND LENS INSTALLATION**

To install the camera and lens:


- 1. Extend the lens to the maximum length before installing in the back box.
- 2. Attach the camera to the tilt table with the 1/4-20 screw and washers (supplied).
- 3. To ensure that the lens will not hit the lower dome:
  - · Place the lower dome over the back box with the camera and lens installed (do not attach dome)
  - · If the lens touches the lower dome, adjust the tilt table assembly.
- 4. Refer to the manual supplied with the camera and lens for the following information:
  - How to connect power and video wiring
  - · How to make camera and lens adjustments

**NOTE:** The torque applied to the camera mounting bracket nut should not exceed 40 pound-inches.


# LOWER DOME INSTALLATION

# **IN-CEILING MODEL**

- a. Attach the lower dome trim leash to one of the 8-32  $\times$  .250-inch screws that secure the back box to the mounting ring.
- Insert both keys in the barrel locks. Turn keys clockwise to the unlocked position. Keys can not be removed from lock in the unlocked position.
- Align pegs (located on the mounting ring) with the peg receptacles (located on the inside of the lower dome).
- d. Place lower dome over back box. Hold and turn both keys to the locked position.




## **PENDANT MODELS**



a. Lightly apply O-ring lubricant to the O-ring. Install the O-ring in the groove on the trim ring of the lower dome.

Attach the back box trim leash to a retainer screw inside the lower dome.

**Environmental Model only:** Plug the two-pin heater connection in the lower dome into the mating connector in the back box.



 Align barrel locks in lower dome with the holes located on each side of the back box. Push lower dome onto back box. Press the pins of the barrel locks IN to secure the lower dome.

# **SPECIFICATIONS**

### **ELECTRICAL**

Input Voltage: 24 VAC (outdoor models only)

Input Power: 62 vA (for heater)

### **MECHANICAL**

Construction

Back Box: Aluminum Mounting Bracket: Steel

Lower Dome: Clear polycarbonate, 0.090 inch thick

Dimensions: See dimension drawing

# **GENERAL**

Environment

In-Ceiling: Indoor only

Pendant: Indoor/outdoor, NEMA 4X, IP66 Rated

**Operating Range** 

In-Ceiling: 32 to 140°F (0 to 60°C) intermittent operation; 32 to 122°F (0 to 50°C) continuous operation

Pendant

Without Heater: 32 to 140°F (0 to 60°C) absolute maximum operating temperature;

32 to 122°F (0 to 50°C) sustained maximum operating temperature

With Heater: (Assumes no wind chill factor; for detailed test conditions, contact Pelco.)

Maximum operating

temperature: 140°F (60°C) absolute maximum; 122°F (50°C) sustained maximum

Minimum operating

temperature: -60°F (-51.11°C) absolute minimum; minimal icing at -50°F (-45.56°C) sustained minimum;

prevents icing at -40°F (-40°C) sustained minimum; de-ices. 1 inch (2.5 mm) within 3 hours after power-up

Weight

Back Box Unit

(without camera)

| In-ceiling: 2.17 lb (.98 kg) | Pendant Indoor: 4.45 lb (2.02 kg) | Outdoor Pendant: 4.75 lb (2.15 kg)

Lower Dome


In-ceiling: 1.6 lb (.73 kg)
Pendant: 1.83 lb (.83 kg)

## **CAMERA**

Maximum Camera and

Lens Size: 5.00 (L) x 2.75 (W) x 2.75 (H) (12.70 x 6.99 x 6.99 cm)

(Design and product specifications subject to change without notice.)



 $\underline{\mathsf{NOTE}} : \mathsf{VALUES}$  IN PARENTHESES ARE CENTIMETERS; ALL OTHERS ARE INCHES

### PRODUCT WARRANTY AND RETURN INFORMATION

#### WARRANTY

Pelco will repair or replace, without charge, any merchandise proved defective in material or workmanship **for a period of one year** after the date of shipment.

Exceptions to this warranty are as noted below:

- · Five years on FT/FR8000 Series fiber optic products.
- Three years on Genex® Series products (multiplexers, server, and keyboard).
- Three years on Camclosure® and fixed camera models, except the CC3701H-2, CC3701H-2X, CC3751H-2, CC3651H-2X, MC3651H-2, and MC3651H-2X camera models, which have a five-year warranty.
- · Two years on standard motorized or fixed focal length lenses.
- Two years on Legacy®, CM6700/CM6800/CM9700 Series matrix, and DF5/DF8 Series fixed dome products.
- Two years on Spectra®, Esprit®, ExSite™, and PS20 scanners, including when used in continuous motion applications.
- Two years on Esprit® and WW5700 Series window wiper (excluding wiper blades).
- Eighteen months on DX Series digital video recorders, NVR300 Series network video recorders, and Endura™ Series distributed network-based video products.
- One year (except video heads) on video cassette recorders (VCRs). Video heads will be covered for a period of six months.
- Six months on all pan and tilts, scanners or preset lenses used in continuous motion
  applications (that is, preset scan, tour and auto scan modes).

Pelco will warrant all replacement parts and repairs for 90 days from the date of Pelco shipment. All goods requiring warranty repair shall be sent freight prepaid to Pelco, Clovis, California. Repairs made necessary by reason of misuse, alteration, normal wear, or accident are not covered under this warranty.

Pelco assumes no risk and shall be subject to no liability for damages or loss resulting from the specific use or application made of the Products. Pelco's liability for any claim, whether based on breach of contract, negligence, infringement of any rights of any party or product liability, relating to the Products shall not exceed the price paid by the Dealer to Pelco for such Products. In no event will Pelco be liable for any special, incidental or consequential damages (including loss of use, loss of profit and claims of third parties) however caused, whether by the negligence of Pelco or otherwise.

The above warranty provides the Dealer with specific legal rights. The Dealer may also have additional rights, which are subject to variation from state to state.

If a warranty repair is required, the Dealer must contact Pelco at (800) 289-9100 or (559) 292-1981 to obtain a Repair Authorization number (RA), and provide the following information:

- 1. Model and serial numbe
- 2. Date of shipment, P.O. number, Sales Order number, or Pelco invoice number
- 3. Details of the defect or problem

If there is a dispute regarding the warranty of a product which does not fall under the warranty conditions stated above, please include a written explanation with the product when returned.

Method of return shipment shall be the same or equal to the method by which the item was received by Pelco.

### RETURNS

In order to expedite parts returned to the factory for repair or credit, please call the factory at (800) 289-9100 or (559) 292-1981 to obtain an authorization number (CA number if returned for credit, and RA number if returned for repair).

All merchandise returned for credit may be subject to a 20% restocking and refurbishing charge.

Goods returned for repair or credit should be clearly identified with the assigned CA or RA number and freight should be prepaid. Ship to the appropriate address below.

If you are located within the continental U.S., Alaska, Hawaii or Puerto Rico, send goods to:

Service Department Pelco 3500 Pelco Way Clovis, CA 93612-5699

If you are located outside the continental U.S., Alaska, Hawaii or Puerto Rico and are instructed to return goods to the USA, you may do one of the following:

If the goods are to be sent by a COURIER SERVICE, send the goods to:

Pelco 3500 Pelco Way Clovis, CA 93612-5699 USA

If the goods are to be sent by a FREIGHT FORWARDER, send the goods to:

Pelco c/o Expeditors 473 Eccles Avenue South San Francisco, CA 94080 USA Phone: 650-737-1700 Fax: 650-737-1933

Pelco, the Pelco logo, Camclosure, Esprit, Genex, Legacy, and Spectra are registered trademarks of Pelco.

Endura and ExSite are trademarks of Pelco.

Loctite is a registered trademark of Loctite Corporation.

©Copyright 2003, Pelco. All rights reserved.

### **REVISION HISTORY**

**Manual # Date Comments**C2432M 7/01 Original version.

C2432M-A 12/03 Per ECO #03-9442, changed dome material description from acrylic to clear polycarbonate.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com