


**NETWORK COLOR CAMERA**
**N-CC2360**

**TABLE OF CONTENTS**

<b>1. SAFETY PRECAUTIONS</b> .....	2	<b>8. ADJUSTMENT</b> .....	9
<b>2. LIST OF INCLUDED COMPONENTS AND PARTS</b> .....	3	<b>9. ABOUT THE MODE SWITCH</b> .....	11
<b>3. GENERAL DESCRIPTION</b> .....	4	<b>10. ABOUT THE CONTACT INPUT/ OUTPUT TERMINAL</b> .....	12
<b>4. HANDLING PRECAUTIONS</b> .....	4	<b>11. SETTING INITIALIZATION</b> .....	13
<b>5. NOMENCLATURE</b> .....	5	<b>12. TROUBLESHOOTING</b> .....	14
<b>6. INSTALLATION</b> .....	6	<b>13. SPECIFICATIONS</b> .....	15
<b>7. CONNECTIONS</b>		System Requirements	
7.1. Connection Example .....	8	(for Software decoder) .....	18

Thank you for purchasing TOA's Network Color Camera. Please carefully follow the instructions in this manual to ensure long, trouble-free use of your equipment.

**TOA Corporation**

# 1. SAFETY PRECAUTIONS

- Before installation or use, be sure to carefully read all the instructions in this section for correct and safe operation.
- Be sure to follow all the precautionary instructions in this section, which contain important warnings and/or cautions regarding safety.
- Keep this instruction manual handy for future reference.

## Safety Symbol and Message Conventions

Safety symbols and messages described below are used in this manual to prevent bodily injury and property damage which could result from mishandling. Before operating your product, read this manual first and understand the safety symbols and messages so you are thoroughly aware of the potential safety hazards.



### **WARNING**

Do not expose the unit to rain or an environment where it may be splashed by water or other liquids, as doing so may result in fire or electric shock.



### **WARNING**

Indicates a potentially hazardous situation which, if mishandled, could result in death or serious personal injury.

### When Installing the Unit

- This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
- Install the unit only in a location that can structurally support the weight of the unit and the mounting bracket. Doing otherwise may result in the unit falling down and causing personal injury and/or property damage.
- Since the unit is designed for in-door use, do not install it outdoors. If installed outdoors, the aging of parts causes the unit to fall off, resulting in personal injury. Also, when it gets wet with rain, there is a danger of electric shock.

### When the Unit is in Use

- Should the following irregularity be found during use, immediately switch off the power, disconnect the power supply plug from the AC outlet and contact your nearest TOA dealer. Make no further attempt to operate the unit in this condition as this may cause fire or electric shock.
  - If you detect smoke or a strange smell coming from the unit.
  - If water or any metallic object gets into the unit
  - If the unit falls, or the unit case breaks
  - If the connection cable is damaged (exposure of the core, disconnection, etc.)
  - No sound output
  - If no camera images are displayed on the monitor TV
- To prevent a fire or electric shock, never open nor remove the unit case as there are high voltage components inside the unit. Refer all servicing to your nearest TOA dealer.
- Do not insert nor drop metallic objects or flammable materials in the unit, as this may result in fire or electric shock.
- Be sure to inspect the unit periodically for safety use. Deterioration of the installed part may cause dropping of the unit, resulting in personal injury and/or property damage. Contact your TOA dealer as to the periodical inspection.



## **CAUTION**

Indicates a potentially hazardous situation which, if mishandled, could result in moderate or minor personal injury, and/or property damage.

### **When Installing the Unit**

- Avoid installing the unit in humid or dusty locations, in locations exposed to the direct sunlight, near the heaters, or in locations generating sooty smoke or steam as doing otherwise may result in fire or electric shock.
- Leave the installation of the unit to your TOA dealer because the installation requires expert experience and skills. If the unit falls, this could cause personal injuries.

### **When the Unit is in Use**

- Do not hang down from the unit as this may cause it to fall down or drop, resulting in personal injury and/or property damage.

CU version complies with Part 15 of the FCC Rules.

#### **Note**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

#### **Modifications**

Any modifications made to this device that are not approved by TOA Corporation may void the authority granted to the user by the FCC to operate this equipment.

## **2. LIST OF INCLUDED COMPONENTS AND PARTS**

Check to be sure that the following components and parts are contained in the package:

Power conversion cable .....	1
CD-ROM ( Software Decoder: N-SD2000, Manuals (PDF)) .....	1
Network Color Camera Instruction Manual .....	1
Software license agreement .....	1
Network Camera System Installation Guide .....	1

#### **Note**

The CD-ROM contains Software Decoder, Software Decoder Instruction Manual, Setting Manual, Adobe Reader, and DirectX.

### 3. GENERAL DESCRIPTION

The N-CC2360 Network Color Camera can be connected directly to a LAN (10BASE-T/100BASE-TX). Since it can simultaneously transmit MPEG-4 and JPEG data, smooth moving images can be monitored and high-definition still images monitored and recorded. The N-CC2360 can transmit bi-directional sub-band ADPCM or PCM quality voice. Its power supply features PoE compatibility in addition to 24V AC or 24V DC operation, permitting simplified wiring work and cable savings during construction by supplying power via the network. The supplied software decoder permits the system to be remotely monitored and easily configured on a personal computer. Since it is equipped with a Day-Night function that increases sensitivity by automatically switching color images to monochrome under poor lighting conditions, and a 64x Electronic Sensitivity Boost function as well as a Wide Dynamic function, the camera enables monitoring even in dark or backlight locations. Camera functions can be easily set, and color and brightness remotely adjusted from distant locations using a network browser.

### 4. HANDLING PRECAUTIONS

- Do not direct the camera lens to the sun or strong lighting or light reflection. Exposure to direct sunlight could cause the CCD's color filter to deteriorate, leading to image discoloration.
- Do not give the camera a great shock or vibration, as this will damage the camera.
- It is recommended that the camera be always used in locations where the ambient temperature ranges from  $-10^{\circ}\text{C}$  to  $+50^{\circ}\text{C}$  (continuous active for operation at temperature below  $0^{\circ}\text{C}$ ) and the humidity is under 90% to ensure that no condensation is formed.
- To clean, wipe with a dry soft cloth. Never use benzene, thinner or chemically processed towel as the camera's plastic or other parts may be deformed or discolored.
- When dust has settled on the camera's lens, lightly clean using a commercial camera blower or cleaning paper.
- Installing the LAN cables in close proximity to fluorescent lamps or other electrical appliances can downgrade the picture quality. In such cases, change the wiring.
- If there is a strong electric or magnetic field near the camera, such as television transmission antennas, motors or transformers, this may distort or roll the monitor picture. In such cases, run the entire wiring route through metal conduit tubing.
- Shielded (STP) network cables must be used with this unit to ensure compliance with EMC standards.
- If the Day/Night mode is used, the subject may go out of focus when the display is switched between color and B&W modes. In such cases, use a lens designed for visible light of up to the near-infrared region.
- Install cables so as to prevent their damage and provide ample cable slack if they need to be stretched taut.
- The IP address, subnet mask, and gateway IP address must be set.
- Transmission to multiple receivers using the unicast function could result in a reduction in the frame rate.
- When using the multicast function, the network must be compatible with the multicast system.
- When a connection is established between the transmitter and multiple receivers, if the data rate requested by each receiver differs, the transmission will be limited to the minimum set data rate.
- In transmission streaming mode, data is constantly transmitted from camera to network even when no communications are performed between the two.
- Personal computers running Microsoft Windows XP are required when performing initial settings for the network color camera.
- TOA's software decoder does not support Macintosh or Unix operating systems.

#### • MPEG-4 visual patent portfolio license


With respect to a Licensee offering MPEG-4 Video Decoders and/or Encoders the following notice shall be given:

THIS PRODUCT IS LICENSED UNDER THE MPEG-4 VISUAL PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER FOR (1) ENCODING VIDEO IN COMPLIANCE WITH THE MPEG-4 VISUAL STANDARD ("MPEG-4 VIDEO") AND/OR (2) DECODING MPEG-4 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSE BY MPEG LA TO PROVIDE MPEG-4 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION INCLUDING THAT RELATING TO PROMOTIONAL, INTERNAL AND COMMERCIAL USES AND LICENSING MAY BE OBTAINED FROM MPEG LA, LLC.


SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com).

## 5. NOMENCLATURE


[ Top panel ]




[ N-CC2360 Rear panel ]



[ Side panel ]



[ Front panel ]



**(1) Power Input Terminal [24 V AC, 24 V DC]**

Connect this terminal to the 24 V AC or 24 V DC power supply.

**Note** Do not connect 24 V AC or 24 V DC power when using a PoE-compatible hub.

**(2) Indicators [RDY BUSY ERR]**

RDY (green): Remains lit during normal operation.  
 BUSY (yellow): Lights continuously during communications.  
 ERR (red): Lights when an error occurs.

**(3) Network Terminal [10BASE-T, 100BASE-TX]**

Connect this terminal to a network.

• LINK/ACT indicator:

Lights when the network is correctly connected and flashes while data is being transmitted or received.

• FD/COL indicator:

Lights continuously while the camera is operating in full-duplex mode, and remains unlit while the camera is in half-duplex mode. The indicator flashes when a data collision occurs over the network.

**(4) Audio Output Terminal (RCA pin jack)**

Outputs audio signals received via a network.

**(5) Monitor Output Terminal (RCA pin jack)**

Connect a monitor to this terminal.

**(6) Contact Input/Output Terminal**

• Contact input terminal:

Used to receive alarm signals from sensors, etc. Setting the terminal to a Day-Night function places the camera in monochrome mode.

• Contact output terminal:

Connect external equipment to this terminal for its control.

**(7) Back Focal Length Adjustment Ring Fixing Screw**

Used to fix the back focal length adjustment ring.

**(8) Camera Mount**

**(9) Initialization Key**

Returns camera settings to initial factory-preset status.

**(10) Reset Key**

Restarts the camera.

**(11) Lens Connector**

Connect the connector of the lens to this connector.

**(12) Mode Setting Switch**


Changes camera settings.

**(13) Back Focal Length Adjustment Ring**


**(14) Microphone**

## 6. INSTALLATION

### [Ceiling Mounting Example]



### [Wall Mounting Example]



## WARNING

Install the unit only in a location that can structurally support the weight of the unit and the mounting bracket. Doing otherwise may result in the unit falling down and causing personal injury and/or property damage.



- Select the lens type on the Camera menu screen.  
Select the lens for the best possible picture reproduction. (Refer to Setup Manual)

Lens type	Camera Menu
DC input type, Automatic aperture control lens	DC
Manual-iris or fixed iris lens	Manual

### Notes

- Video lens is also displayed on the camera menu, however it cannot be used with the N-CC2360 camera.
- When using the flicker-reduction function outdoors or under the fluorescent lighting, select the auto-iris lens. When the manual-iris lens is selected, the flicker-reduction function cannot be used.


- Attach the lens to the camera.
  - Tighten the lens fully onto a camera's lens mount to secure it.
  - Insert the connector from the lens into the lens connector.



Lens connector pin No.	DC input type
1	Damping coil (-)
2	Damping coil (+)
3	Driving coil (+)
4	Driving coil (-)

#### Notes

- To avoid damaging the internal sections of the camera's lens mount, be sure that the lens flange is 6 mm or less thick as illustrated on the right.
- C-mount lenses must be used in conjunction with the Lens Mounting Adapter CF-5 (optional).



3. Mount the optional Camera Mounting Bracket to the ceiling or wall.  
The bracket must be fixed securely using an electrical box and screws supplied with the bracket. When securing, be sure to run the LAN cable through the hole in the bracket.
4. Rotating the bracket's pedestal, fully insert it into the threaded hole in the camera mount.

#### Note

The mount can be attached on either the top or bottom panel of the camera, Change the position depending on the installation site. (factory default: The camera mount is attached on the top panel.)


5. Determine the camera direction and fix it.  
Set the camera's direction, then fix the camera by rotating the lock lever on the Camera Mounting Bracket.

## 7. CONNECTIONS

### 7.1. Connection Example

By connecting a network video receiver and PC to a hub and performing each equipment settings at the PC, camera images can be viewed at the monitor. Installing the supplied software decoder in the PC permits camera settings to be performed and camera images to be viewed at the pc with the software decoder installed. When connecting the N-CC2360 network color camera to the hub, use CAT 5 or greater straight cable fitted with RJ45 connectors.

For each equipment setting, refer to the Setup Manual.



#### Notes

- Do not connect the 24V AC or 24V DC power when using a PoE-compatible hub since the power is supplied from the hub.
- Connect the 24V AC or 24V DC power when not using a PoE-compatible hub since no power is supplied from the hub.
- The distance between camera and hub must be shorter than 100 meters using CAT 5 or greater cable.
- Shielded (STP) network cables must be used with this unit to ensure compliance with EMC standards.



## 8. ADJUSTMENT

1. The RDY indicator lights when the power is supplied to the network camera.
2. Connect the monitor output terminal to the monitor so that the picture may be displayed on the monitor.
3. Set the Flicker-reduction switch of the mode switch to "ON" position if flicker is annoying.  
Flickering of the picture may interfere with the view under fluorescent lamps in the area where power frequency is 50 Hz (CU) or 60 Hz (PL). In such cases, set the Flicker-reduction switch to "ON" position, and the image free from flickering can be obtained.

### Note

Setting the Flicker-reduction switch to "ON" makes the sensitivity lower than when set to "OFF." Set to the "OFF" position when flicker is not annoying or when the camera is used in locations with poor lighting conditions.

4. Determine the camera orientation.  
Loosen the lock lever on the Camera Mounting Bracket, set the camera to the desired direction, then securely fix the camera by rotating the lock lever on the bracket.
5. Adjust the angle of view with the zoom ring and focus on with the focal ring to get the best possible picture reproduction.

### • When focusing


The object that was brought into focus in bright locations could be out of focus in dark conditions. In such cases, focus the lens after turning the Focus adjustment switch of mode switch to "ON" position.

**Note:** After focus adjustment completion, turn the switch to "OFF" position.

### • Adjusting back focal length

When the distance to an object is shorter than the lens' shortest focusing distance, if the object is out of focus, adjust the camera with the below procedures.

- (1) Attach a lens to the camera.
- (2) Loosen the back focal length adjustment ring fixing screw.
- (3) Rotating the back focal length adjustment ring, adjust it to the optimum position.
- (4) Retighten the back focal length adjustment ring fixing screw.



6. Adjust the iris level

- When using the DC input type lens

Adjust the iris level on the Camera menu screen's "IRIS" item.

6-1 Check to confirm that Camera menu setting items are selected as follows.

Lens selection: "DC"

Backlight compensation: "OFF" (factory default: OFF)


6-2 Moving the bar toward "HIGH" side makes the image brighter, and moving it toward "LOW" side makes the image darker.

6-3 Set backlight compensation of a Camera menu screen according to the object condition.

**Note:** For the Camera Menu setting, refer to the Setup Manual.


## 9. ABOUT THE MODE SWITCH

Set each switch to the position that provides the best picture reproduction.




### • Focus adjustment switch

Set this switch when adjusting the focus of a lens. (This setting provides the same effect as when using an ND filter.)



Normal:

After focus adjustment completion, turn the switch to "OFF" position. Normally, use this mode.



Adjustment (At the time of Adjustment):


Set the switch when focusing the lens. The object that was brought into focus in bright locations could be out of focus in dark conditions. In such cases, turn the Focus adjustment switch to "ON" position only when adjusting focus.

#### Note

When the Focus adjustment switch is set to the "ON" position, the color of the screen may change periodically if the camera is used under fluorescent lighting. Further, the screen may flicker in areas where the electrical frequency is 50 Hz.


### • Flicker-reduction switch

Set the switch when flicker is annoying.



Normal:

Normally, use this mode.



Flicker-reduction:

Flickering of the picture may interfere with the view under fluorescent lamps in the area where the electrical frequency is 50 Hz (CU) or 60 Hz (PL). In such cases, set the Flicker-reduction switch to "ON" position, and the image free from flickering can be obtained.

#### Note

Setting the Flicker-reduction switch to "ON" makes the sensitivity lower than when set to "OFF." Set to the "OFF" position when flicker is not annoying or when the camera is used in locations with poor lighting conditions.

## 10. ABOUT THE CONTACT INPUT/ OUTPUT TERMINAL

### • Contact Input

There are two no-voltage contact inputs for connection of sensor trigger signals, etc. A contact can be automatically established between the transmitter and the network video receiver or network digital recorder when a signal enters the contact.

Setting the contact input to Day & Night mode forcibly, shorting (making) the Day/Night input terminal forcibly switches the display to B&W mode, which increases the camera's sensitivity. For details, refer to the Setup Manual.

#### Note

The Day & Night function can also be set using the camera menu. If "Normal," "Motion," or "Color" has been selected for the Day & Night function, the display could repetitively switch between color and black-and-white modes when the camera is used under phototransmitter. In such cases, select "Day & Night" in the "Contact Input" settings, and synchronize the phototransmitter power supply with the switch to black-and-white mode.


The display mode changes as follows if the Contact Input has been set to "NO" (Normally Open):

Infrared phototransmitter power "ON" : B&W mode (close)

Infrared phototransmitter power "OFF" : Color mode (open)

### • Contact Output

There are two contact outputs, allowing external connected device control and contact bridging between video network system devices. For details, refer to the Setup Manual.



#### Applicable cables

Solid cable: AWG28 (ø 0.32) – AWG22 (ø 0.65)

Stranded cable: AWG28 (0.08 mm<sup>2</sup>) – AWG22 (0.32 mm<sup>2</sup>)

**Note:** Strip the cable sheath approximately 10 mm, then insert the cable while pushing down the button on the terminal with a screwdriver.

## 11. SETTING INITIALIZATION

Network settings can be reset to their factory defaults.

1. Either press the Reset key or switch on the power again while holding down the INITIALIZE key.
2. Continue to press the INITIALIZE key until the Ready indicator has switched from flashing to steady-on mode.

### **Note**

To return camera settings other than those used for network settings to default conditions, use the camera menu. For the camera menu settings, refer to the Setup Manual.

## 12. TROUBLESHOOTING

Symptom	Possible cause	Remedy
Camera does not start. (RDY does not light.)	Power is not supplied. [ When using a PoE-compatible hub for power supply ] <ul style="list-style-type: none"> <li>• Camera not connected to the PoE-compatible hub.</li> <li>• PoE-compatible hub's PoE function is not made valid.</li> <li>• Camera is connected to the PoE-compatible hub's port not supporting PoE.</li> <li>• Power requirement exceeds the PoE-compatible hub's supply capability.</li> </ul> [ When using 24V AC or 24V DC for power supply ] <ul style="list-style-type: none"> <li>• Incorrect terminal connections.</li> </ul>	Supply power independently to the Camera.
LINK/ACT does not light.	Cable is not correctly connected to the Camera's network terminal.	Confirm that the cable type (category, null modem or straight) is appropriate for the connected port, then connect correctly.
Rough noise appears when the subject becomes dark at night.	Camera's AGC function has been activated and noise is amplified	If the rough noise is annoying and distracting, lower the AGC level.
After image appears when the subject becomes dark at night.	Camera's Slow Shutter function has been activated.	If the after image is annoying and distracting, decrease the Slow Shutter magnification.
Mode frequently switches between color and black-and-white.	Phototransmitter is operating.	If an phototransmitter is used, take any one of the following actions: <ul style="list-style-type: none"> <li>• If a phototransmitter is used, connect it to the external Day &amp; Night selection input so that the Day &amp; Night function is operated as the phototransmitter is activated.</li> <li>• Manually set the Day &amp; Night function to ON using the software decoder while the infrared projector remains lit.</li> <li>• Reduce infrared floodlighting amount by changing the infrared projector's angle.</li> </ul>

### 13. SPECIFICATIONS

[N-CC2360 CU]

\* 0 dB = 1V

Power Source	24 V AC, 50/60 Hz or 24 V DC or PoE (IEEE802.3af)
Power Consumption	13 W (at 24 V AC), (8 W: PoE, 350mA: 24 V DC)
Power Terminal	Screwless connector (Solid cable: $\varnothing$ 0.4– $\varnothing$ 1.2 mm (AWG 26 – 16), Stranded cable: 0.3–1.25 mm <sup>2</sup> (AWG 22 – 16)
Monitor Output	VBS 1.0 V(p-p), 75 $\Omega$ , RCA pin jack, NTSC
Microphone	Omnidirectional, electret condenser microphone
Audio Output	1channel, –10 dB *, low impedance, unbalanced, RCA pin jack
Contact Input	2 channels (Color/B&W Switching Input included), no-voltage contact input, open voltage: 9 V DC, short-circuit current: Under 10 mA, loop resistance: Under 200 $\Omega$ , screwless connector
Contact Output	2 channels, open collector output, withstand voltage: 30 V DC, control current: 50 mA screwless connector
<b>Camera</b>	
Image Device	1/ 3 type IT-CCD
Number of Effective Pixels	768 (H) x 494 (V) (380,000 pixels)
Scanning System	2:1 interlace
Scanning Frequency	Horizontal: 15.734 kHz , Vertical: 59.94 Hz
Synchronizing System	Internal
Minimum Required Illumination	0.5 lx (50 IRE), 0.1 lx (20 IRE) (F1.0) (sensitivity up: OFF) (color mode) 0.01 lx (F1.0) (sensitivity up: ON) (B&W mode, incandescent lamp)
Automatic Electric Shutter Range	1: 2000 (F1.4 – 63)
Dynamic Range	46 dB (backlight compensation: wide dynamic: ON)
Backlight Compensation	WIDE DYNAMIC/ ON/ OFF
Shutter Speed	1/60, 1/100, 1/125, 1/250, 1/500, 1/1000, 1/2000, 1/4000, 1/10000
AGC	Auto/ Fixed/ OFF
Sensitivity Up	OFF, 2, 4, 6, 8, 10, 16, 24, 32, 64 times
White Balance Mode	ATW/ AWB/ Manual
Lens Mount	CS mount
Auto-Iris Lens Output	DC input type (4 pin connector)
Character Display	Up to 16 characters (alphanumeric and symbols)
Other Functions	Privacy masking (up to 4), Electronic Zoom (2x), Horizontal/Vertical reverse, Flickering reduction (DIP switch), Focus adjustment switch (DIP switch), Chroma level: Normal/Manual (MIN – MAX), Enhancer: Normal/Manual (soft – sharp)
<b>Network</b>	
Network I/F	10BASE-T/100BASE-TX, Auto-Nego/Manual: RJ45 connector
Network Protocol	TCP, UDP, SIP, RTP, IGMP, HTTP, ARP, DHCP, DNS, SNMP
Video Compression/ Resolution	MPEG-4: D1 (720 x 480), Half D1 (720 x 240), QVGA (320 x 240) JPEG: D1 (720 x 480), Half D1 (720 x 240), VGA (640 x 480) QVGA (320 x 240), QQVGA (160 x 120)
Frame Rate	MPEG-4 (D1, max. 30 fps) + JPEG (D1, max. 5 fps)
Audio Compression/ Decompression	Sub-band ADPCM, PCM (non-compression)
Audio Sampling Frequency	8 kHz, 32 kHz

Network	
Image Transfer Rate	MPEG-4: max. 4 Mbps
Simultaneous Connected Number	5 (MPEG-4: 4, JPEG: 1) In streaming mode: No limit (MPEG-4 only)
Other Functions	Password authentication, Motion detection
Operating Temperature	-10°C to +50°C (continuously active for operation at temperature below 0°C) 14°F to 122°F (continuously active for operation at temperature below 32°F)
Operating Humidity	Under 90 % RH (no condensation)
Application	Indoor use
Finish	Case: Surface-treated steel plate, sand gray, paint
Dimensions	69.3 (W) x 64.8 (H) x 157.3 (D) mm (2.73" x 2.55" x 6.19")
Weight	670 g (1.48 lb)

**Note:** The design and specification are subject to change without notice for improvement.



Power Source	24 V AC, 50/60 Hz or 24 V DC or PoE (IEEE802.3af)
Power Consumption	13 W (at 24 V AC), (8 W: PoE, 350mA: 24 V DC)
Power Terminal	Screwless connector (Solid cable: $\varnothing$ 0.4– $\varnothing$ 1.2 mm (AWG 26 – 16), Stranded cable: 0.3–1.25 mm <sup>2</sup> (AWG 22 – 16)
Monitor Output	VBS 1.0 V(p-p), 75 $\Omega$ , RCA pin jack, PAL
Microphone	Omnidirectional, electret condenser microphone
Audio Output	1channel, –10 dB *, low impedance, unbalanced, RCA pin jack
Contact Input	2 channels (Color/B&W Switching Input included), no-voltage contact input, open voltage: 9 V DC, short-circuit current: Under 10 mA, loop resistance: Under 200 $\Omega$ , screwless connector
Contact Output	2 channels, open collector output, withstand voltage: 30 V DC, control current: 50 mA screwless connector
<b>Camera</b>	
Image Device	1/ 3 type IT-CCD
Number of Effective Pixels	768 (H) x 582 (V) (440,000 pixels)
Scanning System	2:1 interlace
Scanning Frequency	Horizontal: 15.734 kHz , Vertical: 50.00 Hz
Synchronizing System	Internal
Minimum Required Illumination	0.5 lx (350 mV), 0.1 lx (140 mV) (F1.0) (sensitivity up: OFF) (color mode) 0.01 lx (F1.0) (sensitivity up: ON) (B&W mode, incandescent lamp)
Automatic Electric Shutter Range	1:2400 (F1.4 – 63)
Dynamic Range	46 dB (backlight compensation: wide dynamic: ON)
Backlight Compensation	WIDE DYNAMIC/ ON/ OFF
Shutter Speed	1/50, 1/100, 1/125, 1/250, 1/500, 1/1000, 1/2000, 1/4000, 1/10000
AGC	Auto/ Fixed/ OFF
Sensitivity Up	OFF, 2, 4, 6, 8, 10, 16, 24, 32, 64 times
White Balance Mode	ATW/ AWB/ Manual
Lens Mount	CS mount
Auto-Iris Lens Output	DC input type (4 pin connector)
Character Display	Up to 16 characters (alphanumeric and symbols)
Other Functions	Privacy masking (up to 4), Electronic Zoom (2x), Horizontal/Vertical reverse, Flickering reduction (DIP switch), Focus adjustment switch (DIP switch), Chroma level: Normal/Manual (MIN – MAX), Enhancer: Normal/Manual (soft – sharp)
<b>Network</b>	
Network I/F	10BASE-T/100BASE-TX, Auto-Nego/Manual: RJ45 connector
Network Protocol	TCP, UDP, SIP, RTP, IGMP, HTTP, ARP, DHCP, DNS, SNTP
Video Compression/ Resolution	MPEG-4: D1 (720 x 576), Half D1 (720 x 288), CIF (352 x 288) JPEG: D1 (720 x 576), Half D1 (720 x 288), CIF (352 x 288), VGA (640 x 480), QVGA (320 x 240), QQVGA (160 x 120)
Frame Rate	MPEG-4 (D1, max. 25 fps) + JPEG (D1, max. 5 fps)
Audio Compression/ Decompression	Sub-band ADPCM, PCM (non-compression)
Audio Sampling Frequency	8 kHz, 32 kHz

Network	
Image Transfer Rate	MPEG-4: max. 4 Mbps
Simultaneous Connected Number	5 (MPEG-4: 4, JPEG: 1) In streaming mode: No limit (MPEG-4 only)
Other Functions	Password authentication, Motion detection
Operating Temperature	-10°C to +50°C (continuously active for operation at temperature below 0°C) 14°F to 122°F (continuously active for operation at temperature below 32°F)
Operating Humidity	Under 90 % RH (no condensation)
Application	Indoor use
Finish	Case: Surface-treated steel plate, sand gray, paint
Dimensions	69.3 (W) x 64.8 (H) x 157.3 (D) mm (2.73" x 2.55" x 6.19")
Weight	670 g (1.48 lb)

**Note:** The design and specification are subject to change without notice for improvement.

• **System Requirements (for Software decoder)**

Personal Computer	PC/AT compatible
Main Specifications	CPU: Pentium 4, over 3 GHz Memory: Over 512 MB Display adapter: XGA (1024 x 768 pixels), Intel Chipset (Recommended) Usable on DirectX 9.0a or later Sound controller: Usable over DirectX 9.0a or later Network adapter: Over 100BASE-TX
OS	Windows XP Professional
Required Web Browser	Internet Explorer 6.0 or later

**Notes**

- Pentium and Intel are trademark of Intel Corporation.
- Windows is a trademark of Microsoft Corporation.





URL: <http://www.toa.jp/>

133-12-993-90

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>