

High Resolution CMOS camera CSB1100F **Operation Manual**

Thank you for purchasing our CSB1100F CMOS camera.

This operation manual includes some important information such as how to use this equipment correctly and safely. Please read through this manual carefully. After reading, keep this manual by the side of your equipment for your future reference.

TOSHIBA TELI CORPORATION

Printed On Recycled Paper

BEFORE USE – GENERAL SAFETY INSTRUCTIONS

This instruction manual contains important information for the operator (user) and/or people in the vicinity to avoid personal injury, or property damage.

Prior to use, read this operation manual carefully to fully understand its instructions for correct use. After reading, keep this manual near the equipment for future reference. The meaning of each mark used in this instruction manual is given below.

[Definition of marking	s]
WARNIN	This mark warns the user that improper use may cause death or severe personal injury (*1) of the user or people in the vicinity.
	This mark warns the user that improper use may cause personal injuries (*2) or material damages (*3) against the user or people in the vicinity.
** • • • • • • • • • • • • • • • • • •	

*1: Severe personal injury means wounds, blindness, physical injury, burns(low temperature high temperature), electric shocks, fracture, addictive and others for which have aftereffects and hospitalization or long term care are required.

*2: Personal injury means wounds, burns, electric shocks, and others for which hospitalization or long term care are not required.

*3: Material damage means any consequential damage related to premise, possession, domestic animals and pet.

[Definition of markings]

\bigcirc	This mark indicates what the user SHOULD NOT DO . The details are given adjacent the mark.
	This mark indicates what the user MUST DO . The detail are given adjacent the mark.

Handling Precaution

Avoid

 \bigcirc

Avoid

 \bigcirc

Immediately cease of the equipment in the event of abnormality or malfunction. If abnormal conditions are present, such as smoke, a burning smell, ingr of water or foreign matter, or if the equipment is dropped or malfunctions, or electric shock may result. Unplug If such abnormalities occur, disconnect the power plug from the outlet contact your sales representative.
Do not get wet Do not use the equipment in locations subject to water splashes. Otherwise, fire or electric shock may result.
Never pull apart Do not disassemble, repair, or modify the equipment. Otherwise, fire or electric shock may result. For internal repair, inspection, or cleaning, contact your sales representat
Do not place anything on the equipment. If metallic objects, liquid, or other foreign matter enters the equipment, fire electric shock may result.
Do not install the equipment in an unstable or inclined location or locations subject to vibration or impact. Avoid Otherwise, the equipment may topple over and cause personal injury.
Do not touch During an electrical storm, do not touch the power cord or connection cable. Otherwise, an electric shock may result.
Use the specified power supply. Use of an unspecified power supply may result in fire or electric shock.
Avoid Do not be handled roughly, damaged, fabricated, bent forcefully, pulled, twisted, bundled, places under heavy objects or heated the power cord, connection cable. Otherwise, fire or electric shock may result.

Observe the following when installing the equipment

• Do not cover the equipment with a cloth, etc. 0 • Do not place the equipment in a narrow location where heat is likely to accumulate. Otherwise, heat will accumulate inside the equipment, possibly Instruction resulting in a fire.

> Do not place the equipment in locations subject to high moisture, oil fumes, stream. or dust.

Otherwise, fire or electric shock may result Do not install the equipment in locations exposed to direct sunlight or

humidity. Otherwise, the internal temperature of the equipment will rise, which may cause a fire

Use only specified DC power cables and connection cables. Otherwise, fire or electric shock may result.



Avoid giving a strong shock against the camera body.



 \bigcirc

Avoid

fix a camera cable in the place near the camera, and do not transmit a shock to the camera connector. Contact your sales representative to request periodic inspection and

cleaning (every approx. five years). A Accumulation of dust inside the equipment may result in fire or electric

Instruction For inspection and cleaning costs, contact your sales representative

CASE FOR INDEMNITY(LIMITED WARRANTY) We shall be exempted from taking responsibility and held harmless for damage or losses incurred by the user in the following cases

- In the case damage or losses are caused by fire, earthquake, or other acts of God, acts by a third party, deliberate or accidental misuse by the user, or use under extreme operating conditions
- In the case of indirect, additional, consequential damages (loss of business interests, suspension of business activities) are incurred as result of malfunction or non-function of the equipment, we shall be exempted from responsibility for such damages.
- In the case damage or losses are caused by failure to observe the information contained in the instructions in this instruction manual and specifications.
- In the case damage or losses are caused by use contrary to the instructions in this instruction manual and specifications.
- In the case damage or losses are caused by malfunction or other problems resulting from use f equipment or software that is not specified.
- In the case damage or losses are caused by repair or modification conducted by the customer or any unauthorized third party(such as an unauthorized service representative).
 Expenses we bear on this product shall be limited to the individual price of the product
- About the item which does not have a publication in the specifications and manual of this
 product, it considers as the outside for a guarantee.

RESTRICTION FOR USE

- Should the equipment be used in the following conditions or environments, give consideration to safety measures and inform us of such usage:
- 1. Use of the equipment in the conditions or environment contrary to those specified, or use outdoors.
- Use of the equipment in applications expected to cause potential hazard to people or property, which require special safety measures to be adopted.
- This product can be used under diverse operating conditions. Determination of applicability of
 equipment or devices concerned shall be determined after analysis or testing as necessary by the designer of such equipment or devices, or personal related to the specifications. Such
- designer or personal shall assure the performance and safety of the equipment or devices.
 This product is not designed or manufactured to be used for control of equipment directly services/functions involving factors of safety(*2). Therefore, the product shall not be used for such applications.
- (*1): Equipment directly concerned with human life refers to:
- · Medical equipment such as life-support systems, equipment for operating theaters
- · Exhaust control equipment for exhaust gases such as toxic fumes or smoke. Equipment mandatory to be installed by various laws and regulations such as the Fire Act or Building Standard Law.
- Equipment related to the above
- (*2): Equipment relating to maintenance of public services/functions involving factors of safety
- Traffic control systems for air transportation, railways, roads, or marine transportation Equipment for nuclear power generation.
- Equipment related to the above.

Usage Precautions

Handle carefully

Do not drop the equipment or allow it to be subject to strong impact or vibration, as such action may cause malfunctions. Further, do not damage the connection cable, since this may cause wire breakage.

Environmental operating conditions

Do not use the product in locations where the ambient temperature or humidity exceeds specifications. Otherwise, image quality may be degraded or internal components may be adversely affected. In particular, do not use the product in areas exposed to direct sunlight. More over, during shooting under high temperatures, vertical stripes or white spots (noise) may be produced, depending on the subject or camera conditions (such as increased gain). However, such phenomena are not malfunctions.

Do not shoot under intense light

Avoid intense light such as spotlights on part of the screen because it may cause blooming or smears. If intense light falls on the screen, vertical stripes may appear on the screen, but this is not a malfunction Occurrence of moiré

- If you shoot thin stripe patterns, moiré patterns (interference fringes) may appear. This is not malfunction.
- Occurrence of noise on the screen
- If an intense magnetic or electromagnetic field is generated near the camera or connection cable, noise may be generated on the screen. If this occurs, move the camera or the cable.
- Handling of the protective cap If the camera is not in use, attach the lens cap to the camera to protect the image pickup
- If the equipment is not to be used for a long duration Turn off power to the camera for safety.
- Maintenance

Turn off power to the equipment and wipe it with a dry cloth. If it becomes severely contaminated, gently wipe the affected areas with a soft cloth dampened with diluted neutral detergent. Never use alcohol, benzene, thinner, or other chemicals because such chemicals may damage or discolor the paint and indications. If the image pickup surface becomes dusty, contaminated, or scratched, consult your sales representative

 Disposal When disposing of the camera, it may be necessary to disassemble it into separate parts, in accordance with the laws and regulations of your country and/or municipality concerning

CMOS sensor characteristics

Defective pixels

A CMOS image sensor is composed of photo sensor pixels in a square grid array. Due to the characteristics of CMOS image sensors, over- or under-driving of the pixels results in temporary white or black areas (as if these are noises) appearing on the screen. This phenomenon, which is not a defect is exacerbated under higher temperatures and long exposure times.

Image shading

Under global shutter operation, the brightness of the upper part of the screen may differ from the lower part. And, the brightness of the left part on the screen may differ from the right part. However, this does not mean the CMOS image sensor is defective.

This phenomenon occurs under short exposure times and high illumination

To counteract this phenomenon, reduce the illumination by setting a longer exposure time, or adjust the lens aperture.

It may be blurred by this phenomenon when fast-moving subject captured.

1. Product Description

Model CSB1100F is a high-resolution B/W CMOS camera achieving high-speed image processing by a random access

2. Features

(1) Ultra-high resolution

The CSB1100F features a high-pixel CMOS sensor (Total pixel count: 1.30 Mega pixels), enabling high-density images (i.e., significantly reduced moiré and beat) to be obtained

- (2) Global shutter mode This model features a Global shutter mode, which means that clear images of a fast-moving
- subject with little blurring are obtained. (3) Random trigger shutter mode
- This feature starts light-exposure in synchronization with external trigger signal, and enables image capture at any given timing.
- (4) WOI (Window Of Interest)
- WOI is a feature enabling high-speed image processing.
- By designating horizontal and vertical addresses, user-defined areas only are read out. (5) High-dynamic range
- This model features a high-dynamic range with multi slope integration mode, both high-and low-intensity subjects can be captured at the same time despite the high difference in contrast.

3. Configuration

(1) Camera body (2) Operation Manual --

4. Optional parts

- (1) IEEE1394 cable (Recommended harness HSB-HCC-***)
- (2) Camera mounting kit (Model name: CPT1100CL)
- (3) TFL lens mount adapter (Model name: TCAR)
- *NOTE: Application software is not supplied as a standard item.

5. Designation and Operation of each Part



6. Mounting the camera

into the camera body

screw(M3)

Download from Www.Somanuals.com. All Manuals Search And Download.

(1) Option 1: Using a camera tripod fixing kit.

(2) Option 2: Using the mounting holes

(1) IEEE1394 Connector Digital data IN/OUT terminal The VIDEO signal and the command are sent and received. This connects to IEEE1394 interface board.

tripod

(2) Trigger connector It is an input terminal of the trigger pulse

There are various methods of fixing the camera. Choose from among the following options.

screws to affix tripod-mounting hardware to your camera. (See the figure below)

Use an optional tripod fixing kit (1/4-20UNC) to fix the camera onto the tripod. Use attached

If not using the tripod fixing kit, make sure that the M3 screws do not penetrate more than 6 mm

7. Connection (1) IEEE1394

Connector (Camera side): 67430-001 (Manufactured by MOLEX) Plug (Cable side): HSB-HCC-*** (Manufactured by DDK)

PIN No.	Signal name	I/O
1	POWER	I
2	POWER(GND)	I
3	TPB-	I/O
4	TPB+	I/O
5	TPA-	I/O
6	TPA+	I/O

(2) DATA IN/OUT

Connector (Camera side): 10226-2210VE (Manufactured by 3M) Connector (Cable side): 10126-6000 (Manufactured by 3M)

PIN No.	Signal name	I/O	Notes
1	TRIG	I	
2	TRIG(GND)		
3	N.C.	-	Be sure use in open
4	S.G.	1	

8. Function

Electronic shutte

The shutter-speed of CSB1100F is also manually adjustable. By manipulating the internal register setting value of CSB1100F, you can change the shutter-speed by user-defines setting value of 62.5 micro sec step.

*The longer a user sets the exposure time, the more defective pixels on the image is outstanding. When you attach importance to image quality, it is recommendable to set the shutter speed at 30 msec or less.

(2) Random trigger shutter

Under the RTS mode, the camera can capture image at any user-defined timing with external trigger signal. Under FIX mode, shutter speed can be set with the internal resister setting value. Under pulse mode, shutter speed can be set with the trigger pulse width. You can change the polarity of trigger pulse with the internal resister setting value

(3) Multi slope function

By changing a slope position with internal resister setting value, you can set the sensitivity matching to the subject luminance

Refer to the interface specifications for the detail of the setting method separately

(4) WOI (Window Of Interest)

Only user-defined area can be captured by designating of the horizontal and the vertical address. Up to 16 areas can be set in 1 screen

This function can increase a frame rate because the area other than designated is not captured. The minimum area size is 50 dot(H) x 50 dot(V).

Horizontal address can set up only even number

• The placement is available up to 16 windows in all active pixel area.



• The setting of readout address is available up to 8 types













In the case of only one readout area A readout area can be designated by the start

address (X1, Y1) and the end address (X2, Y2). The camera can read out the user-defined area through this function. The each address is designated by the start address and lengths (pixel numbers) of "X" and "Y" directions

In the case of more than two readout areas The area designated by the start address (X1, Y1) and the end address (X2, Y2) is read out first (A-block in the left figure).

After reading out of A-block, the next area designated by (X3, Y3) and (X4, Y4) is read out (B-block in the left figure)

In the case of more than two readout areas and including the same readout lines with each other The designated areas are read out in order of address from the start (X1, Y1) to the end (X4, Y4).

The designated areas are read out in order of

address from start (X1, Y1) to the end (X8, Y8).

In the case of four readout areas



9. Specification

CMOS image sensor		
1280(H) x 1024(V)		
1240(H) x 1024(V)		
6.7(H) x 6.7(V) micro m		
8.308mm(H) x 6.854mm(V)		
39.3216 MHz		
1024 lines		
Progressive		
16 fps (Exposure time: 62.5 micro sec)		
Internal		
5:4		
2600lx, F5.6 (3100K) (Exposure time: Approx 16 msec)		
Approx. 62.2 msec		
Conforms to IEEE Std. 1394a-2000		
400Mbps		
Format7/Special format (in WOI) Mono 8bit		
Conforms to 1394-based Digital Camera Specification ver.1.3		
TRIG (Shutter Trigger) 3.3V CMOS level		
Falling edge detection		
Minimum : 5 micro sec		
Max : no limit		
Shutter speed (preset inside the camera) selection via communication command 1 through 4000 (approx. 62.5 micro sec through 1 sec)		
Global shutter		
RTS operation is available by external trigger input. Shutter speed		
preset or shutter speed control by pulse width is available.		
Shutter speed preset mode (preset inside camera)		
Shutter speed can be controlled via shutter trigger pulse width.		
The camera starts light-exposure at the falling edge timing and ends it at		
the rising edge timing.		
DC+8V through DC+30V (IEEE1394 cable power supply)		
Approx. 1.5W (at +30V)		
Approx. 1.4W (at +12V)		
Approx. 1.4W (at +8V)		

[Mechanical Specification]

(1) External dimension	$44(W) \times 29(H) \times 52(D) \text{ mm}$ (Without	projection)
(2) Weight	Approx. 120 g	
(3) Lens mount	C-mount	
(4) Flange back	17.526 mm	
(5) Chassis grounding	Between Connector shell and FG	Continuity provided
/insulation	Between FG and SG	Continuity not provided

[Use environmental conditions]

Ambient condition	
Temperature:	
Performance guaranteed	From 0 through 40 degrees Celsius
Operation guaranteed	From –5 through 45 degrees Celsius
Preservation	From –20 through 60 degrees Celsius
Humidity:	
Performance guaranteed	From 20 through 80 % (No condensing)
Operation guaranteed	From 20 through 80 % (No condensing)
Preservation	From 20 through 95 % (No condensing)

[Interface specification]

Please contact our sales person about interface specification.

10. Timing Chart

(1) Normal shutter mode (Format 7 mode 0)







Shutter speed depends on the internal resister setting value. After trigger IN, next trigger signal is not acceptable until the readout is completed.







Trigger disable time

Exposure time Depends on trigger pulse width

Approx. 41.6us

Image A

**ms

455us

-

Approx

125us

(7) WOI mode (Pulse width control, Format X)

(5) Scalable (Pulse width control, Format 7 mode 1)

Approx 455us

TRIG

(EXTERNAL)

EXPOSURE

(CAMERA INTERANAL)

VIDEO DATA



Shutter speed depends on the trigger pulse width. After trigger IN, next trigger signal is acceptable until the readout is completed.



Download from Www.Somanuals.com. All Manuals Search And Download.











Following information is only for EU-member states:

The use of the symbol indicates that this product may not be treated as household waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the take-back and recycling of this product, please contact your supplier where you purchased the product.



Ŕ

"This symbol is applicable for EU member states only"

TOSHIBA TELI CORPORATION

Head Office: 7-1, 4 chome, Asahigaoka, Hino-shi, Tokyo, 191-0065, Japan (Overseas Sales Department) Phone: +81-42-589-8771 Fax: +81-42-589-8774

URL: <u>http://www.toshiba-teli.co.jp</u>

Free Manuals Download Website http://myh66.com http://www.somanuals.us http://www.somanuals.com http://www.4manuals.com http://www.404manual.com http://www.404manual.com http://www.luxmanual.com Golf course search by state

http://golfingnear.com Email search by domain http://emailbydomain.com Auto manuals search http://auto.somanuals.com TV manuals search

<u>http://tv.somanuals.com</u>