

# SIRMarine DUAL MOUNT MARINE SIRIUS SATELLITE RADIO ANTENNA



مرونا والملمون المراجع

#### **Table of Contents**

### **About Installation**

Installation of marine audio components can require extensive experience with a variety of mechanical and electrical procedures. Although the instructions in this guide explain how to install the TERK SIRMarine Satellite Radio Antenna in a general sense, they do not show the exact installation methods for your particular boat.

IMPORTANT: If you are not comfortable performing a complex installation, ask your local marine audio dealer about professional installation options.

## Introduction

The TERK SIRMarine Satellite Radio Antenna is a high-performance antenna designed specifically for Sirius Satellite Radio reception on recreational marine craft such as fishing boats, sport boats, yachts, and sailboats. Its features include:

- Rugged antenna to withstand high-vibration salt-water environment
- Dual mounting options:
  - Through hole mounting for deck mount or mounting on any flat surface. Perfect for use on small vessels.
  - Bracket or mast mounting when used with the supplied threaded flange adaptor with the standard 1"-14 marine thread. Perfect for larger vessels and sail boats. (Mounting bracket and mast not included)
- Antenna supplied with 6 inch cable and gold plated TNC connector for ease of mounting. Also includes 25 feet of RG174 coax cable terminated with gold plated TNC and SMB connectors
- Meets or exceeds all Sirius Satellite Radio mobile-antenna specifications
- Shock- and vibration-proof design

The TERK SIRMarine Satellite Radio Antenna is easy to install on most recreational marine craft. Remember to save your sales receipt and this guide so both are available for future reference.

NOTE: To achieve best Sirius Satellite Radio reception, also refer to your SIRIUS radio's owner's manual.

2 Table Of Contents Introduction 3

# **Applications**

The TERK SIRMarine Satellite Radio Antenna can be installed on a variety of recreational marine craft, as shown below. For details, see Installation starting on page 6.



Figure 1. The TERK SIRMarine is shown installed on the fishing boat's fly bridge, both with a bracket and a mast mount




Figure 2. The TERK SIRMarine is shown mounted on the electronics arch of a sports boat.




Figure 3. The TERK SIRMarine is shown mounted on a deck or flat surface of a small boat.

#### Sailboats




Figure 4. The TERK SIRMarine is shown installed on an antenna extension on the stern of a sailboat.

NOTE: When mounted in this configuration, the mast and sails may interfere with reception when the craft is at certain angles to the satellite.

4 Applications 5

## Installation




Figure 5. Verify that your TERK SIRMarine package includes the above items.

## **Recommended Tools and Supplies**

- Any electric drill and a 9/16 inch drill bit
- A 24mm open end or adjustable wrench to tighten hex nut when deck mounting
- Any tool to help cable routing (e.g., flat dental pick, screwdriver, etc.)
- Grommet and silicone sealer (for cable routes)
- (Optional) Antenna Extension with 1"-14 threads
- (Optional) Any mounting bracket with 1"-14 threads

## **Installation Precautions and Tips**

- When selecting an antenna location, make sure the antenna is not enclosed by any metal material.
   If a metal fly bridge is to be used, the antenna must protrude at least 5 inches above the bridge's top edge. Consider using an antenna extension to increase the height above the boat.
- Also, at the proposed site, verify that there is at least a 20-degree clearance from any metallic obstruction on all sides, as shown in figure 6 (on the next page).
- Prior to installation, turn off all audio systems and other electrical devices. Disconnect the (–)
  negative lead from the boat's battery.
- At the installation site, locate and make a note of all fuel lines, cables, and electrical wiring.
   Use extreme caution when cutting or drilling in and around these areas. Always wear protective eye wear when using tools.
- When drilling fiberglass surfaces, use a small backup block of wood to help control splintering.




Figure 6. Correct and incorrect TERK SIRMarine locations on a fishing boat.

- As you plan the cable route, avoid running the cable through any component that may cause
  excessive chafing. Doing so may erode the jacket and break signal continuity. Also, avoid
  kinking, pinching, excessive bending, or twisting of the cable during a run.
- Do not trim the cable length. It is optimized for best signal reception. Coil and store any excess cable behind the Sirius receiver.
- Do not remove the connectors from the cables.

## **Installing the TERK SIRMarine Satellite Radio Antenna**

#### **Deck or Flat Surface Mounting**


- At the chosen site, drill a 9/16 inch mounting hole. For mounting surfaces thicker then 1/4 inch
  you will need to attach the supplied slotted extension adapter to the SIRMarine antenna. Simply
  route the 6 inch long antenna cable through the slot and thread the extension adapter onto the
  existing antenna shaft and tighten.
- 2. Pass the TNC connector and the 6 inch antenna cable through the hole in the mounting surface.
- 3. Install the lock washer and hex nut onto the antenna shaft and tighten securely assuring that the antenna is seated properly.
- Attach the 25 foot coax cable to the 6 inch antenna cable by connecting the TNC connectors securely. See figures 7 and 8 on the next page.

Continue to the "Connecting To Your Sirius Radio" section on the next page.

Continued on next page.



## **Installation** (continued)



#### **Mast or Bracket Mounting**

The Terk SIRMarine Satellite Radio Antenna is easy to install on any standard mast or brackets that have a 1"-14 thread.


- Attach the Threaded Flange Adapter to the SIRMarine by first passing the TNC connector on the 6 inch antenna cable lead through the adapter as shown in Figure 9 on the next page. Next thread the adapter on to the threaded extension of the SIRMarine and tighten securely. (Note: do not use the supplied Slotted Threaded Adaptor in this application.
- 2. Connect the TNC connector on the 6 inch antenna cable lead to the mating TNC connector on the 25 foot cable and tighten securely. The 25 foot cable can be routed through the provided access holes and grommet that are located on the mast or bracket. Since the SMB connector has a much smaller diameter it is recommended that you route this connector through any access hole necessary. Many masts have grommets that can be removed which makes it easier to route the cable through the access hole. The grommet can be placed over the SMB connector and put back in place for a neat install.
- Secure the SIRMarine antenna and adapter to the mast or bracket by tightening onto the 1"-14 thread securely. All mast and brackets should be installed on the boat per manufacturers specifications. If needed, adjust the tilt so that the antenna is perpendicular to the horizon.

#### **Connecting to your Sirius Radio**

- Connect the SMB connector to the Sirius Satellite Receiver. Turn on the Sirius system and tune
  the radio to channel 184 (i.e., the preview channel) to verify that the antenna is properly
  installed. If there are any problems, review the installation steps and verify that each one was
  performed correctly. Also see *Troubleshooting* on the next page.
- After the system has been tested successfully, continue dressing the cable from the antenna to the receiver for best appearance and complete any remaining installation. Use cable tie wraps where needed to secure cables from flagging in the wind and catching on objects. Seal any holes in the bulkheads with a marine grade RTV or silicon adhesive.

Note: For additional help with cable routing, consult your local marine audio dealer.

Figure 9. SIRMarine Antenna with Threaded Flange Adapter for Mast mounting.



B Installation Installation

#### SIRMarine Owner's Manual

**Use and Care** 

In normal daily use, the TERK SIRMarine Satellite Radio Antenna is a rugged, high-performance antenna that does not require any special attention.

## **Troubleshooting**

Symptom	Solutions
Sirius radio displays "Antenna" or "Check Antenna" message	Check antenna connections to the Sirius receiver.
Sirius radio displays "No Signal" message	<ul> <li>Boat may be in an area where the Sirius signal is obstructed. Move the boat to more open surroundings.</li> </ul>
Other symptoms	<ul> <li>Call TERK for help at 1-800-942-TERK (8375) on any business day, between 9 A.M. and 5:30 P.M., EST and ask for Technical Support.</li> </ul>

## **Specifications**

#### **Electrical**

Frequency	2320.0 to 2332.5 MHz
Gain	4.5 to 7 dBi from 50 to 90 deg.
Bandwidth	12.5 MHz
Imnedance	50 ohms

50 ohms Polarization LHCP (Circular)

LNA for Satellite Signals -

Gain 33.5 dB, typical **Noise Figure** 0.8 dB, maximum

Cable Loss -12.0 dB

**Output VSWR** 1.5:1 Input P1dB -14

Mechanical

**Current Draw** 

**Total Height** Deck Mount -1.08 inches Mast Mount - 3.13 inches

3.75 inches (outside)

160 mA, maximum

Coax Cable 25 ft RG-174

Quality and Performance -

**Max Diameter** 

Temperature -40° to + 185° F (operating) **SIRIUS Approved** Per SIRIUS Satellite Radio Specifications AUDIOVOX Corp. strives to maintain and exceed the highest consumer standards. Due to these on going efforts, modifications may be made from time to time to existing products without any prior notice. Specifications and appearance may differ from those listed or shown in this manual. The Sirius name and related logos are trademarks of Sirius Satellite Radio, Inc. TERK and TERK logo are trademarks of AUDIOVOX Corp.

## **About Sirius Satellite Radio**

For more information about Sirius Satellite Radio service, visit their web site at: www.siriusradio.com

## 12 Month Limited Warranty

AUDIOVOX ELECTRONICS CORPORATION (the Company) warrants to the original retail purchaser of this product that should this product or any part there of, under normal use and conditions, be proven defective in material or workmanship within 12 months from the date of original purchase, such defect(s) will be repaired or replaced with new or reconditioned product (at the Company's option) without charge for parts and repair labor. To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to an approved warranty station or the Company at the address shown below. This Warranty does not extend to the elimination of externally generated static or noise, to costs incurred for installation, removal or reinstallation of the product, damage to speakers, accessories, or vehicle and home electrical systems, malfunction of satellite transmissions, repeater signal or receiver unit. This Warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT. This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HERE UNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 48 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.



For Customer Service Visit Our Website At www.audiovox.com Product Information, Photos, FAQ's, Owner's Manuals

For customer service and technical information:: 1.800.290.6650

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com