

IdeaTab S6000

User Guide v1.0

Please read the safety precautions and important notes in the supplied manual before use.



Chapter 01 IdeaTab S6000 Overview

*Specific models only

- 1-1 IdeaTab Appearance
- 1-2 Buttons
- 1-3 Turning On/Off Your IdeaTab
- 1-4 Activating/Deactivating the Display
- 1-5 Screen Lock/Unlock
- 1-6 Navigation Tips
- 1-7 Home Screen
- 1-8 Switching Home Screens
- 1-9 Status Bar
- 1-10 Recent Apps
- 1-11 Applications Management
- 1-12 Entering Text

1-1 IdeaTab Appearance

Images are for reference purposes only, and may differ from your IdeaTab S6000.

1-2 Buttons

Power Button

- To turn on your IdeaTab, press and hold this button for about 3 seconds, then release it.
- If your IdeaTab is turned on, press this button to deactivate the display. If the display is deactivated, press this button to activate the display.
- To turn off your IdeaTab, press and hold this button for about 1 second, then select **OK** in the **Power off** pop-up window to shut down your IdeaTab.

Volume Controls

• Press the Volume Up or Down button to adjust the volume.

*SIM card slot (3G only)

- The SIM card slot is located on the lower left side of the IdeaTab. To insert a SIM card while turned off, pull up the SIM card slot cover with a fingertip, then insert the SIM card. To remove the SIM card while turned off, push the card into the slot lightly until it pops out.
- For the 3G-enabled version, DO NOT insert or remove the SIM card while your IdeaTab is turned on. Doing so may permanently damage your SIM card or IdeaTab.
- For the Wi-Fi version only, this is not valid.

1-3 Turning On/Off Your IdeaTab

Turning On Your IdeaTab

Press and hold the Power button on your IdeaTab for about 3 seconds, then release it. The Lenovo logo and the startup screen will appear in sequence, indicating your IdeaTab has been turned on.

Turning Off Your IdeaTab

Press and hold the Power button on your IdeaTab for about 1 second. The **Power off** pop-up window will appear. Tap **OK** to turn off your IdeaTab.

NOTE: When connecting to a computer with a USB cable, make sure that the battery power is sufficient for normal operation; otherwise, charge with the AC power adapter before USB connection.

1-4 Activating/Deactivating the Display

Activating the Display

With the display deactivated, press the Power button on the IdeaTab to activate the display. The IdeaTab's display will then illuminate, indicating that it has been activated.

Deactivating the Display

If you do not need to use your IdeaTab temporarily, you can press the Power button to deactivate the display. Your IdeaTab will then enter standby mode to save power.

1-5 Screen Lock/Unlock

Screen Lock

You can set screen timeout by tapping **Sleep** in **Display** under **Settings**. If there is no operation within the preset standby time, the display will automatically deactivate, and your IdeaTab will be locked automatically.




Manual Lock

If you do not need to use your IdeaTab temporarily, you can press the Power button for about 1 second to deactivate the display. Your IdeaTab will then be locked, and will enter standby mode.

Screen Unlock

When in standby mode, press the Power button on your IdeaTab to activate the display. Then, tap and hold the lock icon, and drag the slider over the unlock icon, as shown in the illustration below.



Screen Lock Pattern Setting

You can set the screen lock pattern by tapping Pattern in Screen lock in Security under Settings. After this function has been enabled, you will be required to trace a personalized unlock pattern to unlock the screen before you can use your IdeaTab.

1-6 Navigation Tips

• Back : Return to the previous screen.

- : Return to the Home screen. Home
 - : Display recently used apps. **Recent Apps**
- : Display shortcuts such as Preferences, Manage apps, System Advanced Menu settings, Add more capacity and One touch clear.
- App Menu : Display all available apps.



1-7 Home Screen

This desktop enables you to quickly view and open your most frequently used applications.

In the Home screen, you can add shortcuts and change your wallpaper.

- To add a shortcut to the Home screen, tap and hold the icon of the app in the applications list until it is added to the Home screen.
- To change your wallpaper, tap and press any blank area on the Home screen for about 2 seconds. You can choose a wallpaper in the pop-up window.



• To delete something on the Home screen, tap and hold the selected item for about 2 seconds until appears on the top right corner of the icons, then tap to remove it. Tap "finish edit mode" to complete.



Download from Www.Somanuals.com. All Manuals Search And Download.

Your IdeaTab has multiple desktops.


Move through screens by sliding your finger across the display. Icons can be moved from one panel to another.

1-9 Status Bar

System messages, if any, will be displayed in the status bar.

Information about Wi-Fi connections and reception, power levels, charging status, and other notifications are displayed in the status bar.


Drop down the status bar to display the notification panel, which contains the Airplane mode switch, Wi-Fi setting shortcut, Auto-rotate screen switch, Brightness adjustment toolbar, Notifications switch and Settings shortcut.



1-10 Recent Apps

Your IdeaTab remembers apps you have used recently.

Tap to display a list of your recently used apps. Tap an app to open it.



1-11 Applications Management

Tap on the Home screen to open the applications list.

Tap Apps in DEVICE under



Settings to manage all your apps.

Uninstall

Tap **Apps** to display the list of downloaded apps under the **DOWNLOADED** tab. Then choose the app, and tap **Uninstall** at the top to uninstall the app.

Stop/Change Setting

Tap **RUNNING** or **ALL**, then the app, and tap the option you want.

1-12 Entering Text


You can easily enter text from the virtual keyboard directly on the touch screen, such as when adding contact information in the Contacts application, or typing and editing SMS messages. You can input English letters and numeric symbols directly on the touch screen.

Virtual keyboard

Tab	q ۱	w (•	r	t	у	u	i	0	p 📾
7123	а	s	d	f	g	h	j	k	I	Go
٥	z	x	с	۷	b	n	m	,	•	° ◆
茸	Ŷ	1						-	1	.com
				\rightarrow	\Box	ć	5			

Tap on the bottom bar to hide the virtual keyboard. Tap the text input box to display the virtual keyboard.

Switch Input Method



In number input mode, tap
to input symbols and special characters. Tap
to go back to number input mode.

Input Options

• Tap to open the Input options menu. You can select Input languages or Android keyboard settings in this menu.

*Specific models only





2-1 Browser

Network support is required to access the Internet with the web browser. If you have problems accessing your network, please consult your network operator or service provider directly.

The web browser in your IdeaTab can access the Internet via a Wi-Fi or 3G network, for business and/or personal use.

Тар

Browser in the applications list to open the browser.

The browser supports the following functions:

Entering Web Addresses

Tap the address bar, and input a web address using the pop-up virtual keyboard.

Тар

on the virtual keyboard to open the web page.

Exiting the Browser

Go

Tap on the bottom bar to exit the browser and return to the Home screen.

Managing Browser Web Pages

Tap it open the Browser management interface, where you can manage Bookmarks, Internet visiting history and pages read offline under their corresponding tabs.

BOOKMARKS: Download from Www.Somanuals.com. All Manuals Search And Download.

Displays a list of all the web pages that you have added to **BOOKMARKS**. To

add a bookmark, tap in to add the current web page to **BOOKMARKS**. To edit a bookmark, tap and hold the bookmark to open a pop-up window. From the window, you can open, edit, copy, share or delete the selected website, create a shortcut for it, set it as your homepage, or perform other operations.

HISTORY:

Displays a list of all the web pages you have visited recently.

SAVED PAGES:

Displays a list of all the web pages you have saved for offline reading.

Tabbed Browsing
You can open several web pages in the same window to multiply your web surfing fun. Tap to open a new tab. To switch to another web page, just tap its tab. Tap on the tab to close it.
Additional Functions
Refresh: Tap C to manually refresh a web page.
Backward/Forward: Tap \leftarrow or \rightarrow to return to the previous page or to go to the next page.
Select Text: Select text in the current page for copying, sharing, finding, and web searching.
Add/Edit Bookmarks: Tap to bookmark the current page. Tap to manage your bookmarks.
More Options: Tap

More Options: Tap **I** to display an option list. These options include Refresh, Stop, Home, Close, New tab, New incognito tab, Find on page, Share page, Page info, Request desktop site, Save for offline reading, and Settings.

Zoom Pages In/Out: You can manually fit the page to the screen size, and zoom the page in/out by sliding your finger and thumb apart, or bring them together.



lenovo联想

Chapter 03 Applications

- 3-1 Calculator
- 3-2 Calendar
- 3-3 Camera
- 3-4 Clock
- 3-5 Email
- 3-6 Gallery

Tap **Tap** on the Home screen to open the applications list.

3-1	1 Calci	ulator
Тар	- +	Calculator in the applications list to open the calculator.
3-2	2 Cale	ndar

Tap **Calendar** in the applications list to open the calendar.

New Calendar Event

Tap in the **Calendar** view to create a new event. You can also create a new event by tapping and holding a time in the Week or Day view.

Manage Calendar Events

You can switch between **Day**, **Week**, **Month**, and **Agenda** by tapping the appropriate tab at the top of the page.

Day view: Tap and hold an event in Day view to view, edit or delete the event.

Week view: Tap and hold an event in Week view to view, edit or delete the event.

Month view: Manage events in Week view from Month view by tapping any date in the Month view.

Download from Www.Somanuals.com. All Manuals Search And Download.

Agenda view: Tap to view events across a range of dates.

NOTE: Within any **Calendar** view, you can easily return to the current day/week/month by tapping **TODAY** at the top of the page.

3-3 Camera

Camera in the applications list to open the camera interface. Тар In this interface, you can perform the following operations:

Switch Cameras

Your IdeaTab provides you with front/back camera. In the photo/video to switch between the front and back cameras. interface, tap

Switch Camera Modes

Your IdeaTab provides you with nine camera modes. In the camera interface, -0 and to switch between photo taking, video tap recording and panorama shooting modes. You can also tap other modes to take pictures.

Photos

Taking Photos

In the photo interface, tap



to take a picture.



to set the camera properties.



color effect

Scene mode

White balance

Viewing Photos


Tap the photo preview in the photo interface to open the photo viewing interface. You can set and play photo slideshows.

Photo Saving Location

Any photos you have taken will be saved in the **Gallery** application.



Gallery in the applications list to open a list of all the photos you Тар have taken. You can view photos by Albums, Locations, or Times.



Viewing Videos

A thumbnail image of the latest recorded video will be displayed on the bottom right corner of the video interface. Tap the image to open the video player.

Shooting Panoramas

Capturing Panorama Images



In the panorama interface, tap to start capturing. Move your IdeaTab

to stop capturing. The entire panned scene will be captured in slowly. Tap one photo.

Viewing Photos

Tap the photo preview in the panorama interface to open the photo viewing interface. You can set and play photo slideshows.

Photo Saving Location

Any panoramas you have taken will be saved in the



application. Tap **Gallery** in the applications list to open a list of all the photos you have taken.

3-4 Clock



Clock in the applications list to open the Clock.

editing the alarm, tap \mathbf{OK} and select the check box in front of the alarm time to activate the alarm.

To restart an already set alarm, tap OFF to ON status.

When an alarm sounds, tap to deactivate the alarm, or z^z to delay it for ten minutes.

3-5 Email

Network support is required to use your IdeaTab's mailbox. If you have problems accessing your network, please consult your network operator or service provider directly.

Тар

Email in the applications list.

3-6 Gallery

Tap **Gallery** to open the Photo application and view photos stored on your IdeaTab. In the Photo application homepage, photos are automatically displayed on the top left corner as **Albums**. You can select how to display your photos: **Albums**, **Locations**, **Times**.



	Chapter 04 Settings & Safety Information *Specific mo	dels only
4-1	WIRELESS & NETWORKS	
4-2	DEVICE	
4-3	PERSONAL	
4-4	SYSTEM	
0-0-0	Settings in the applications list to open the Settings interface.	

4-1 WIRELESS & NETWORKS

This setting module includes: Wi-Fi, Bluetooth, Data usage and More... (Airplane mode, VPN, Tethering & portable hotspot, Mobile networks*and USB Internet).

Wi-Fi

This setting allows you to enable/disable Wi-Fi connections.

When Wi-Fi is enabled, your IdeaTab will automatically scan for available wireless networks, displaying them in the Wi-Fi network list.

The network status icon, indicates that the network requires no password, and can be connected to directly. However, indicates that the network has been encrypted, and can be connected to only after the required password is entered.

You can select any network you want from the list. After selecting the network, tap **Connect** to connect directly. Alternatively, select the check box in front of **Show advanced options** to adjust the proxy and IP settings in the pop-up text box, and then tap **Connect** to connect to a network. You

can also select **Add network** to manually add a network. Tap **I**, then **Advanced** for advanced Wi-Fi settings.

- **Network notification:** When activated, the system will notify you if there are any open net works available.
- Keep Wi-Fi on during sleep: You can set Wi-Fi connection policy during sleep mode to Always, Only when plugged in or Never.

Bluetooth

You can establish a wireless connection with any other Bluetooth compatible device using Bluetooth technology. Examples of Bluetooth compatible devices can include stereo earphones, keyboard, etc.

Since a Bluetooth-enabled device communicates with other devices by radio waves, you do not have to position your IdeaTab directly towards the other device. You simply need to make sure that the maximum distance between the two devices does not exceed 10 m (about 32 feet). However, please note that the Bluetooth connection can sometimes be interrupted by obstacles, such as walls, or other electronic devices.

Your IdeaTab supports V4.0 Bluetooth. To ensure effective operation of your IdeaTab and another Bluetooth-enabled device, please use only Lenovo-approved accessories compatible with your IdeaTab. Also, check with the manufacturer of the other device to determine whether the device is compatible with your IdeaTab.

In some cases, the use of Bluetooth may be restricted. Please consult with local authorities or your service provider.

Using applications that require Bluetooth technology or running such applications in the background will consume the battery power of your IdeaTab at a faster rate, and reduce the service life of your battery. You can perform the following in Bluetooth settings:

• **SEARCH FOR DEVICES**: After Bluetooth has been activated, your IdeaTab will automatically display a list of any Bluetooth-enabled devices it can find within the effective range (i.e. scan for devices).

Data usage

You can check your data usage status for a specified period.

More...

Airplane mode: When the Airplane mode is enabled, all wireless connections on your IdeaTab will be disabled.

VPN: These settings allow you to add and set up various types of VPN (Virtual Private Network).

Tethering & portable hotspot: You can share your IdeaTab's mobile data connection through USB, Bluetooth, or act as a Portable Wi-Fi hotspot Configure Wi-Fi hotspot.

Mobile networks*: This setting module includes Data enabled, Data roaming, Network Mode, Access Point Names and Network operators.

· How to enable the 3G function: This section explains how to view or edit the Access Point Names (APN) for cellular data services on your IdeaTab. The APN defines the network path for all cellular data connectivity. Incorrect entries in the fields may disable cellular data connectivity. To verify correct APN information, contact the cellular

You can view the APN settings on your IdeaTab at the following location: Settings > More... under WIRELESS & NETWORKS > Mobile networks > Data enabled > Access Point Names

Setting the Access Point Names


carrier of the SIM card you are using.

Follow the instructions below to complete your 3G settings. Then, your 3G will function normally.

Step 1: Tap




Step 2: Tap Settings.



Step 3: Select More... under WIRELESS & NETWORKS > Mobile networks.

🗉 🕆 ± 👄		0 Z 1 2:59 PM
WIRELESS & NETWORKS	Windess & networks	
♥ Wi-Fi	Airplane mode	
8 Bluetooth		
O Data usage	VPN	
More	Tethering & portable hotspot	
DEVICE		
Sound	Mobile networks	
Display	USB Internet Sharing Windows PC internet via USB cable	
Storage		
Battery		
🖻 Apps		
PERSONAL		
Location access		
Security		

Step 4: Select the check box of Data enabled, and tap Access Point Names.



Step 5: Tap

, and select **New APN**.

APNs .		
	New APN	
	Reset to defau	ilt.

Step 6: Contact your 3G carrier for your APN settings, and type them in the text boxes under **Edit** access point.

Edit ac	ccess point	:
	Name Not set	
	APN Not set	
	Proxy Not set	
	Port Not set	
	Username Not set	
	Password Not set	
	Server Not set	
	MMSC Not set	
	MMS proxy Not set	
	MMS port Not not	

Step 7: Return to the applications list, and launch **Browser** to check if the network function is available.

4-2 DEVICE

Sound

Tap this option to enter the Sound settings interface. Settings include **PREDEFINED PROFILES**

General Silent Meeting Outdoor and **Audio enhancer for earphone**. Tap Settings include **Power audio playback Volumes, NOTIFICATIONS (Default notification)** and **SYSTEM** (Touch sounds, Screen lock sound and Vibrate on touch).

Display

Display settings include **PERSONALIZE(Lock screen notifications,Theme** and **Wallpaper)** and **DISPLAY (Brightness, Daydream, Font size, HDMI settings** and **Sleep)**.

Wallpaper: You can select any pictures from ES File Explorer, Gallery, Live Wallpapers, Video Wallpaper and Wallpapers as your wallpaper.

Brightness: You can manually adjust the brightness or select **Automatic brightness**, which allows your IdeaTab to adjust screen brightness automatically according to ambient light.

Font size: This option allows you to select the font size for text displayed on the screen. You can set the font size to Small, Normal, Large or Huge.

Sleep: This option allows you to select how long your IdeaTab's screen will remain activated without any operation before it is automatically locked to save power. You can set the time to 15 seconds, 30 seconds, 1 minute, 2 minutes, 5 minutes, 10 minutes or 30 minutes.

Storage

This option allows you to view internal storage, SD card storage and USB device storage. Nominal capacity calculation method 1GB=1,000MB=1,000,000KB=1,000,000,000 bytes Operating system calculation method 1GB=1,024MB=1,048,576KB=1,073,741,824 bytes The system itself occupies some space; therefore, available space will be less than that calculated.

The Settings	8	C 💎 / 🗎 10:10 A
WIRELESS & NETWORKS		
🗢 Wi-Fi	DEFAULT WRITE DISK	
8 Bluetooth	USB storage	
O Data usage	INTERNAL STORAGE	
More		
DEVICE		
Sound	Total space 0.9868	
O Display	Available 896MB	
Storage	Apps (app data & media content)	
Battery	172MB	
Apps	Cached data 5.97MB	
PERSONAL	USB STORAGE	
Location access		
Security	Total soace	

Battery

Select this option to check battery usage data, remaining power status, and battery usage history details.



With this option, you can easily manage and delete selected applications.

You can also filter any running applications or applications provided by third-party software developers in the applications list.

After selecting an application, you will then be able to see its details and related information. You will also be able to perform functions such as **Force stop**, **Uninstall**, **Clear cache** and **Clear data**, etc.

4-3 PERSONAL

This setting includes: Location access, Security, Language & input and Backup & reset.

Location access

Select how your IdeaTab determines its location. Use either assisted GPS or GPS.

GPS satellites (3G only): Pinpoint your location using GPS.

Security

Security settings include: SCREEN SECURITY, ENCRYPTION, SIM CARD LOCK (3G version only), PASSWORDS, DEVICE ADMINISTRATION and CREDENTIAL STORAGE.

SCREEN SECURITY: You can set the screen lock method, and owner information to be displayed on the lock screen.

• Screen lock: You can unlock the display in one of four ways: Slide, Face Unlock, Pattern, PIN and Password. You can deactivate the screen lock as well by selecting None as well.

Tap **Pattern**, and use your finger on the screen (as illustrated) to draw an unlock pattern. Once you have set the unlock pattern, you will then be able to toggle **Make pattern visible** on/off.

7 🖳						807	🖉 🛢 10:10 ам
			Patter	n recorded.			
	•	€ °		Retry	Continue		
		÷	\Box	Ū			

After you have set and activated the pattern unlock function, the unlock keypad will be displayed whenever the display is to be unlocked. Use your finger to trace your preset pattern on the keypad. After the preset pattern has been correctly entered, the screen will be unlocked.

Tap **PIN** to input the PIN code (minimum 4 digits) you will use to unlock the display.

Tap **Password** to input the password (minimum 4 characters) you will use to unlock the display.

SIM CARD LOCK*: Set SIM card lock-related settings.

PASSWORDS: Under this option, you can decide whether or not your chosen password will be visible when you input it. If the check box is selected, then the password will be visible. If it is not selected, then your password will only be displayed as ******** when you input it, thereby keeping your password more secure.

DEVICE ADMINISTRATION: Set to administrate your IdeaTab and allow installation of non-market apps.

• **Device administrators:** These functions are not available to ordinary users. Only TsingMail users who have previously set up the appropriate security settings within their organizations can use these functions.

These features work in conjunction with the Enterprise Policy Center (Lenovo Enterprise Policy Manager). The Enterprise Policy Center is the executor of the security policies of the Lenovo enterprise platform. Whenever the user enables the Lenovo enterprise mail and service function, the Enterprise Policy Center will then be enabled automatically. This will allow your IdeaTab to accept security policies as set forth by the IT department of your organization, for example, mandatory screensavers with increased password protection. Enabling these functions also allows your IdeaTab to accept management instructions from your company's IT department, for example, allowing them to erase data remotely and reset your device.

• Unknown sources: Select this option to allow installation of non-Market apps.

CREDENTIAL STORAGE: This function allows your IdeaTab to access web pages and LANs for which a specific security certificate or another certificate is required.

- Trusted credentials: Select this option to display all the trusted CA certificates.
- Install from SD card: Install certificates from SD card.
- Clear credentials: Select this option to delete all your currently saved certificates.

Language & input

Language: Select the language you wish to use to operate your IdeaTab.

Spell checker:Toggle spelling correction on/off.

Personal dictionary: You can add new words or terms here to your IdeaTab's dictionary.

KEYBOARD & INPUT METHODS: This option allows you to select and set the input method (including **Default**, **Android keyboard** and **Google voice typing**).

SPEECH: This option allows you to set the Voice speech and general settings for text-to-speech output.

MOUSE/TRACKPAD: Under this option you can adjust pointer speed.

Backup & reset

This option allows you to reset your IdeaTab to the factory default settings.

4-4 SYSTEM

Date & time

These settings allow you to set a number of time-related options, such as system time.

You can enable automatic time and time zone updates via a network (which requires network support), select a time zone, set a specific date and time, and display format for date and time.

Scheduled power on & off

This setting allows you to set the automatic power on & off time and repetitive mode.

Accessibility

SYSTEM: This option allows you to set a Magnification gestures and a large text, set touch & hold delay time, whether to allow the installation of web scripts or not Auto-rotate screen ON/OFF.

About tablet

Under this option, you can view **System updates**, **Status**, **Legal information**, **Model number**, **Android version**, **Baseband version**, **Kernel version**, **Build number**, **Software version** and **Hardware version**.

*Specific models only

Chapter 03: Applications (



www.lenovo.com



Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com