



FOX TANGO INTERNATIONAL

READ AND SAVE THESE INSTRUCTIONS

WARNING: A risk of fire and electrical shock exists in all electrical appliances and may cause personal injury or death. Please follow all safety instructions.

Automatic Stainless Steel Coffee Urn

USE AND CARE GUIDE FOR
MODEL MEU45



IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs. Use oven mitts or pot holders.
- Close supervision is necessary when any appliance is used near children. This appliance is not for use by children.
- To protect against fire, electric shock and injury to persons, do not immerse cord, plug or base in water or other liquid.
- Do not let cord hang over the edge of table or counter, or touch hot surfaces.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Contact Consumer Service for return authorization, examination, repair or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause fire, electric shock, or injury to persons.
- Do not place on or near hot gas or electric burner, or in a heated oven.
- Always attach the plug to appliance first, then plug the cord into the wall outlet. To disconnect, remove plug from wall outlet, then from appliance. Always hold the plug, but never pull the cord.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Extreme caution must be used when moving coffee urn containing hot liquids.
- Make sure that the cover is securely in place before brewing and when serving coffee. When placing the cover on the body of the coffee urn, make sure the locking tabs are in the front and back of the handles. Grasp the knob carefully and turn the cover clockwise until the locking tabs are fully engaged inside the handles of the coffee urn.
- Scalding may occur if the cover is removed during the brewing cycle. When removing the cover from the body of the coffee urn, grasp the knob carefully and turn the cover counter-clockwise to unlock the lid.

NOTE: During and after brewing, the glass knob will be hot. Always use a pot holder or oven mitt to remove or replace the cover.

- Do not use outdoors.
- Do not use appliance for other than intended use.

SAVE THESE INSTRUCTIONS

FOR COMMERCIAL AND HOUSEHOLD USE

The Melitta® Coffee Urn

It is America's classically styled, fully automatic Coffee Urn. It is crafted of durable stainless steel with a gleaming finish for lasting service and beauty. Its graceful, unique design and high polish make a perfect presentation at the buffet table.

It brews hot rich coffee at a cup-a-minute speed, and automatically keeps it hot and fresh-tasting.


Short Cord Instructions

CAUTION: A short power supply cord is provided to reduce the risk of personal injury resulting from becoming entangled in or tripping over a longer cord. Extension cords are available from local hardware stores and may be used if care is exercised in their use. If an extension cord is required, special care and caution is necessary. Also, (1) the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance, (2) should be a grounding-type 3-wire cord, and (3) the cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

GROUNDING-TYPE PLUG: This appliance has a 3-prong grounded-type plug. This plug will only fit into an electrical outlet made for a 3-prong plug. This is a safety feature. If the plug should fail to fit the outlet, contact a qualified electrician. Do not attempt to defeat this safety feature.

ELECTRIC POWER: If the electric circuit is overloaded with other appliances, your appliance may not operate properly. It should be operated on a separate electrical circuit from other appliances.

Getting to Know Your Coffee Urn



Your product may vary slightly from illustration.

- | | |
|---|--------------------------|
| 1. Cover with Glass Knob
(P/N 30777) | 6. READY Light |
| 2. Basket (P/N 30779) | 7. Power ON Light |
| 3. Pump Tube Assembly
(P/N 30778) | 8. Spigot |
| 4. Handles | 9. Spigot Lever |
| 5. Body | 10. Spring (P/N 30778A) |
| | 11. Spreader (P/N 30780) |
| | 12. Locking Tabs |

Using the Coffee Urn

1. Wash the Coffee Urn thoroughly before using for the first time. (See "Care and Cleaning Instructions" section in this use and care guide.)
2. Remove cover, pump tube, spreader, and basket. Check to see that spigot is closed. Use cold, fresh tap water to fill Coffee Urn. **DO NOT OVERFILL OR UNDERFILL.** Fill according to markings on inside of Urn for number of cups desired. Use cold tap water as the automatic brewing cycle is timed to begin with a cold water start.
NOTE: Do not brew less than 20 cups of coffee.
3. Wet basket to help keep small particles of coffee from sifting through. Add desired amount of regular or percolator grind coffee to basket. (Do not use drip or finely ground coffee.)

The following chart suggests amount of coffee to use for medium brew; amounts can be varied to suit personal taste and particular coffees.

CUPS TO BE BREWED	AMOUNT OF GROUND COFFEE TO USE*
20	2 cups
30	2-1/2 cups
40	3 cups
45	3-1/4 cups

1 cup brewed coffee = 5 fluid ounces

*Use standard measuring cups

4. Place the basket on the pump tube and cover with spreader. (Make sure the spring is on the pump tube.) Then, by holding the top end of the pump tube, place it into the Coffee Urn. Make sure the bottom of the pump tube is properly seated on the perk well in the center.
5. Replace the Urn cover and secure in position by turning cover clockwise until cover tabs fit into handle slots.
6. Plug into 3-slot grounded 120 volt AC wall outlet. The Power ON light will come on. To avoid unnecessary strain on the heating mechanism, **PLUG IN COFFEE URN AFTER THE WATER AND COFFEE ARE ADDED AND THE COVER IS SECURELY IN PLACE. NEVER PLUG IN COFFEE URN WITHOUT WATER INSIDE.**

7. When coffee brewing is complete, percolating will stop and the READY light will come on. The Urn automatically switches to “keep warm” setting to preserve fresh-tasting coffee at hot, ready-to-serve temperature.
For best flavor, remove coffee basket, SPREADER and pump tube when brewing is completed.

REMOVE PARTS CAREFULLY: COFFEE URN AND PARTS WILL BE HOT! ALWAYS USE OVEN MITTS OR POT HOLDERS.

8. The 2-way spigot allows you to pour one cup of coffee at a time by pressing down on the spigot lever. For continuous pouring, extend the spigot lever up.
9. When finished, unplug and allow to cool, see CARE AND CLEANING INSTRUCTIONS.

NOTES:

- To make additional coffee, rinse the coffee urn and parts with cold water and repeat steps 1 through 7.
- To preserve taste it is not recommended to reheat coffee.

Unplug the Urn when only 1 or 2 cups of coffee remain.

Care and Cleaning

1. After each use and before washing, unplug power cord from wall outlet and allow the unit to cool.
2. Remove cover and all internal parts carefully - parts, coffee grounds, and remaining coffee may still be hot.
3. Wash the inside of the coffee urn and the parts with warm, soapy water. Rinse thoroughly and dry. **DO NOT IMMERS** THE BASE OF THE COFFEE URN IN WATER. Pump tube (with spring), basket spreader, and cover with glass knob may be washed in the dishwasher. When washing the pump tube, make sure the WASHER on the bottom remains loose. If coffee grounds are trapped in this area hold the pump tube under running water or use a wooden tooth pick to remove them.
4. It may be necessary to clean the glass knob from time to time. Wash the glass knob and nut using non-abrasive cleanser, rinse and dry with a towel. To replace the glass knob after cleaning, align the tabs on the glass knob with the notches in the hole of the cover and screw on the nut. **NOTE:** Tighten the nut using your hands only. Do not over tighten or place hot

- glass knob in cold water as this may crack or break the knob.
5. Wipe outside with damp cloth and dry with a towel. Remove urn cover before storing.
 6. After repeated use, there may be some coffee stains and accumulation of oils that may cause a bitter taste. Periodically, use a coffee-stain remover or special cleanser (such as "Dip-it") and follow package directions for cleaning. Rinse well after cleaning. Do not use abrasive cleansers or pads on outside, inside or any parts of the coffee urn as scratching will occur.

Any servicing requiring disassembly other than the above cleaning must be performed by a qualified appliance repair technician.

IMPORTANT NOTICE

*If any parts are missing or defective,
DO NOT return this product.*

Please call our Customer Service Department for assistance.

800-233-9054 Monday - Friday 9:00 am - 5:00 pm CST

Thank You

ONE-YEAR LIMITED WARRANTY

This Salton, Inc. product warranty extends to the original consumer purchaser of the product.

Warranty Duration: This product is warranted to the original consumer purchaser for a period of one (1) year from the original purchase date.

Warranty Coverage: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by Salton, Inc., or to units which have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Warranty Disclaimers: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for Salton, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one-year warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at Salton, Inc. option) when the product is returned to the Salton, Inc. facility within the warranty period and an additional one-month period. No charge will be made for such repair or replacement.

Service and Repair

Should the appliance malfunction, you should first call toll-free 1-800-233-9054 between the hours of 9:00 am and 5:00 pm Central Standard Time and ask for CUSTOMER SERVICE stating that you are a consumer with a problem.

In-Warranty Service (USA) for an appliance covered under the warranty period, no charge is made for service or postage.

In-Warranty Service (Canada) for an appliance covered under the warranty period, no charge is made for service or postage. Please return the product insured, packaged with sufficient protection, and postage and insurance prepaid to the address listed below. Customs duty/brokerage fee, if any, must be paid by the consumer.

Out-of-Warranty Service: A flat rate charge by model is made for out-of-warranty service. Include \$15.00 (U.S.) for return shipping and handling.

Salton, Inc. cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem; your full return address and daytime phone number; a note describing the problem you experienced; a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

Return the appliance to:

ATTN: Repair Department, Salton, Inc.
708 South Missouri
Macon, MO 63552
Consumer Service: 1-800-233-9054
E-mail: salton@saltonusa.com
Hours: 9:00 a.m. - 5:00 p.m. CST

For more information on Salton, Inc. products:

visit our website: URL <http://www.salton-maxim.com>

This Melitta product is distributed and serviced by Salton, Inc.

Printed in China

©2001 Salton, Inc.

®Reg. T.M. of a company of the Melitta Group

Part No. 60687

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>