



## Fire alarm system EBL128 4550

- **EBL128**, an intelligent analog addressable fire alarm system for up to 128 addresses
- Auto generation of the Site Specific Data for easier c.i.e. programming

### Analog addressable system

**EBL128** is an intelligent analog addressable fire alarm system, conforming to the EN54-2 and the EN54-4 standards. It meets the most stringent requirements in order to secure real fire alarms and to reduce nuisance alarms.

### Features / functions

A user-friendly PC software **Win128** is used to create, edit, download and upload (backup) the Site Specific Data (SSD).

An **SSD Auto generation function** is included in Win128. The units that are connected to EBL128 can be identified and the SSD can be auto generated with default settings and be edited before the download.

Some other features / functions:

- **Compensation for contamination**, i.e. analog smoke detectors have constant sensitivity in spite of any contamination. A **Service signal** will be given when a detector has to be replaced.
- **Advanced alarm algorithms** are used to filter the nuisance alarms from the real fire alarms and one algorithm is used for detection of smouldering fires.
- **User related functions**, e.g. Test mode, Disablements, Alert annunciation, Fire door closing, Interlocking combinations of outputs & inputs, Time channels, Coincidence alarm, User definable text message for each alarm point, etc.
- **Programmable inputs and outputs**. In the c.i.e. and/or via I/O units on the COM loop. A large number of trigger conditions are available.

- **Outputs for routing equipment**. Fire alarm, Fault and Power supply.
- **Socket** for an optional RS485 transceiver component to provide an interface for up to four ext. Fire Brigade Panels, Ext. Presentation Units and/or Alert Annunciation Units.
- **Interface** (RS232) for a PC (Win128)
- **Interface** (RS232) and power supply for Web-server 1588.

Optional RS485 transceiver 4552, provides an interface for up to four display units.

Optional expansion boards 458x mounted in an exp. board holder 4551 provides 8 zone line inputs and 8 relay outputs respectively.

### Up to 128 addresses

The EBL128 c.i.e. has one COM loop for connection of the loop units (address 001-127). Each loop unit uses one address.

Some **loop units** that can be connected:

- Analog heat & smoke detectors
- Addressable manual call points
- Addressable short circuit isolators
- Addressable input and output units (to which e.g. conventional detectors and manual call points can be connected)
- Addressable sirens & sounder bases
- Addressable external power supply units

### Miscellaneous

The cabinet has a space for two sealed Lead-Acid batteries (2x12 V, 16-18 Ah).

EBL128 is intended for indoor use and in dry premises.

Panasonic Electric Works Fire & Security Technology Europe AB

Citadellsvägen 23, SE-211 18 Malmö, Sweden

Tel: +46 (0)40 697 70 00 • Fax: +46 (0)40 697 70 99

info-fste@eu.pewg.panasonic.com • www.panasonic-fire-security.com



Type numbers	
4550	EBL128 c.i.e. (128 addresses). Batteries are not included.
4552	RS485 transceiver component, for up to four display units, i.e. Ext. Fire Brigade Panels 1826 / 1828, Ext. Presentation Unit 1728 and/or Alert Annunciation Units 1735 / 1736.
4551	Expansion board holder. (For two 4580 and two 4581 expansion boards.)
4580	8 zones expansion board. (Max. two per c.i.e.)
4581	8 relays expansion board. (Max. two per c.i.e.)

The 4580 board can be used to connect *conventional* detectors and manual call points to EBL128. An end-of-line capacitor (470 nF) shall be connected in the last alarm point on each zone line.

More information is available in the EBL128 Planning Instructions & Operating Instructions.

Technical data	
Voltage	
primary (V AC)	230
secondary (V DC)	
normal	24
by battery backup	21 - 30
Current consumption (mA)	Depending on connected units, etc. See EBL128 Planning Instructions.
Ambient temperature (°C)	
Operating	-5 to +40
storage	-40 to +75
Ambient humidity (% RH)	max. 95, non condensing
Ingress Protection rating (estimated)	IP32
Inputs	1 COM loop for 128 addresses
	1 programmable input (NO / NC). $R > 200\Omega$ = open circuit. Max. 2 mA
Outputs	1 programmable supervised voltage output (24 V DC, max. 500 mA) <sup>1</sup>
	1 programmable supervised voltage output (24 V DC, max. 200 mA) <sup>2</sup>
	1 programmable relay output. <sup>3</sup> Default set for routing equipment (Fire brigade tx).
	1 non-programmable relay output. <sup>3</sup> For routing equipment (Fault tx).
	Power supply (24 V DC, max. 200 mA) for routing equipment <sup>2</sup>
	Power supply (24 V DC, max. 500 mA) for external equipment (Web-server, up to 4 ext. FBPs, etc.) Web-server requires approx. 65 mA. <sup>1</sup>
Interfaces	RS232 ("D" connector) for a PC (Win128)
	RS232 for a Web-server 1588
	Socket for an optional RS485 transceiver, for ext. FBPs, EPU's and/or AAUs.
Size H x W x D (mm)	511 x 416 x 123
Weight (kg)	12.2 (Excl. Batteries)
Colour (metal cabinet)	Aluminium & light grey (NCS S1500-N, PMS Cool Grey 2)
Approvals	<b>CE</b> ; <b>EN54 parts 2 &amp; 4</b> . The front is fully <b>SS3654</b> compliant.

**Note!** All voltages are nominal. For more information see EBL128 Planning Instructions MEW00508.

<sup>1</sup> Continuous 500 mA, 620 mA during 30 ms.

<sup>2</sup> Continuous 200 mA, 240 mA during 110 ms.

<sup>3</sup> Relay contacts: max. 1 A @ 30 V DC.

All technical features and data are subject to changes without notice, resulting from continuous development and improvement.

Product Leaflet	Date of issue	Revision / Date of revision
MEW00503	2006-04-04	2 / 2007-01-29

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>