# **GETTING STARTED!**

Follow these steps to become familiar with your server documentation and to complete your installation successfully.

#### 1 Checking the Accessory Box

The accessory box contains:

- Keys for the LOCKED front door\*\*
- EXPRESSBUILDER bootable CD-ROM containing setup utilities, maintenance tools and system documentation.
- Customer Notices,\* Alerts,\* Software Notes,\*\* and System Release Notes
- Network Operating System (NOS) software\*\*
- Application Software\*\*
- Power cord(s), keyboard, and mouse
- Service and Warranty information.


\*If required for your server.

### 2 Your System Documentation

- You may view and print user's guides for your Server, ESMPRO, MWA and EXPRESSBUILDER from the **EXPRESSBUILDER** CD-ROM. To do this, insert the CD-ROM into the CD-ROM device on a system running a Microsoft® Windows® Operating System (Do not boot from the **EXPRESSBUILDER** CD-ROM.) At the main menu, Select Online Document Library. Use the Adobe® Acrobat® PDF viewer to view and print the user's guides. If you do not have Adobe Acrobat PDF viewer, select Setup Adobe Acrobat on the CD-ROM to install the reader.
- ☐ Read the System Release Notes. The System Release Notes provide the latest available system information.
- ☐ Read the Software Notes. The Software Notes provide information on configuring and running software preloaded on your system.

# 3 Installing Your Server

- Follow the Server Setting Up information in your User's Guide to unpack and install your server.
- If your server includes Operating System software preloaded at the factory, it will boot-up to the operating system license agreement screen. Follow the screen prompts and Software Notes to complete loading of your operating system.
- Options ordered with your server are already installed. If you have additional adapter boards and devices for your server, install them before putting the server in the location you have selected. Follow the procedures in the *Upgrades and Options* chapter of the system User's Guide, plus installation inserts and vendor documents that came with the option.



Typical Server Connections

## 4 Running the EXPRESSBUILDER CD-ROM

Note: EXPRESSBUILDER does not support FT Linux installation.

- ☐ Boot the **EXPRESSBUILDER** CD-ROM to:
  - Prepare your server for operating system installation.
  - Re-install Windows 2000 Advanced Server.
  - Run EXPRESS5800 utilities independently of the operating system.
  - Run utilities to ensure correct hardware setup if you installed additional adapter boards or devices in Step 3.
- ☐ Autorun the **EXPRESSBUILDER** CD-ROM under Windows to:
  - Read/print documentation and install Adobe Acrobat Reader.
  - Install ESMPRO, or Management Workstation Application (MWA) or make an OEM diskette.
  - Link to the NEC Express5800 web site.

**Note:** If you received system diskettes with your server, these diskettes provide the latest available system utilities information. Use these diskettes instead of running the system utilities from the **EPRESSBUILDER** CD-ROM.

# 5 Installing Application Software

- Locate application software media and accompanying installation procedures. Install application software following procedures in the applicable installation guide.
- ☐ If your Network Administrator advises, install your server management software using the **EXPRESSBUILDER** CD-ROM.

Your server installation is complete.

#### **Need More Help?**

Please call the Technical Support number included with the Service and Warranty information.

<sup>\*\*</sup>On certain models.

| FCC DECLARATION OF CONFORMITY   |  |  |         |
|---|--|--|---------|
|   | TRADE NAME:  | TYPE:  |         |
|   | 320La (Tower version)  | EXP350E  |         |
|   | 320La-R (Rack version)   | EXP350ER   |         |
| digital device, pursuant to part 15 against harmful interference when generates, uses, and can radiate ra instruction manual, may cause har residential area is likely to cause hinterference at his own expense. | e table has been tested and<br>of the FCC Rules. These I<br>in the equipment is operated<br>adio frequency energy, and<br>rmful interference to radio<br>narmful interference, in wh | found to comply with the limits for a Class A limits are designed to provide reasonable protection in a commercial environment. This equipment if not installed and used in accordance with the communications. Operation of this equipment in thich case the user will be required to correct the computers Inc. could void the user's authority to |         |
| Copyright © 2001, 2002 NEC  | Solutions (America) In   | nc.  |         |
| Trademarks Adobe and Acrobat are trademarks ESMPRO is a registered trader Microsoft and Windows 2000 a Other product and company na   | mark of NEC Corporation<br>re registered trademarks  | n.   | olders. |
| PN: 455-01622-002 12  | 2/2002   |  |         |

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com