

nextar 

Item # N3-507

DIGITAL PHOTO FRAME

See Things Differently™






-  3.5" TFT SCREEN
-  INCLUDES 3 INTERCHANGEABLE FRAMES,
BLACK WOOD, PIANO WHITE & PIANO BLACK
-  STORES UP TO 3000 IMAGES ON 256MB
INTERNAL MEMORY
-  DISPLAYS PHOTOS
-  COMPATIBLE WITH SD, MMC, MS
(MEMORY STICK) MEMORY FORMATS



TABLE OF CONTENTS

Introduction.....	1
Important Safety Precautions	2
Features	3
Location of Controls.....	4
Getting Started.....	6
Playing Photos.....	6
Overview of display.....	6
Viewing thumbnails.....	7
Browsing a single photo.....	7
Running a slideshow.....	8
Managing Files.....	8
Question/Troubleshooting.....	10
Specification	11
FCC Compliance.....	12

Introduction

Congratulations on your purchase of this Digital Photo Frame.

Before operating this unit, please read this manual thoroughly and keep it for future reference.

This manual will help you use all of the exiting features to make your Digital Photo Frame view more enjoyable.

The Digital Photo Frame is compatible with most popular memory card types on the market, including SD, MMC and MS, which enables you to view the digital photo directly from your camera's memory card.

This manual contains important safety information and correct operation instructions. Read the manual carefully before you use the Photo Frame in order to avoid any confusion.

Important Safety Precautions

Always follow these basic safety precautions when using your Digital Photo Key Chain. This will reduce the risk of product damage and personal injury.


- **Warning:** To reduce the risk of electric shock, do not remove the cover or back. There are no user-serviceable parts inside. Refer servicing to qualified personnel.
- **Warning:** To prevent fire or electric shock hazard, do not expose the unit to rain to moisture.
- Keep the Digital Photo Frame away from direct sunlight and heat source such as radiators or stoves.
- Do not block the ventilation openings. Slots and openings on the unit are provided for ventilation. The openings should never be blocked by placing your Digital Photo Frame on a cushion, sofa or other similar surface.
- Do not place the Digital Photo Frame on unstable card, stand, tripod, bracket or table. The unit may fall, resulting in possible damage or injury.
- Never place heavy or sharp objects on the LCD panel or frame.
- Only use the power adapter included with the Digital Photo Frame. Using any other adapter will void your warranty.
- Protect the power cord from being walked on or pinched particularly at plugs, receptacles and the point where the cord attached to the Digital Photo Frame.
- Unplug the power from the outlet when the unit is not in use.

Features


- Shows sharp photos on a 3.5 inch LCD display
- Compatible with SD, MMC and MS memory cards
- Display photos from memory cards
- Renders in a smooth and clear resolution of 320x240 pixels
- 256M SLC Nand Flash memory stores up to 3000 photos
- Offers a variety of display features, including slide show mode and manual mode

Location of Controls

Front View




Top View




1. LCD display screen
2. **M/⏻** - Press once to start slide show; or move the cursor right in thumbnail mode. Press and hold to turn on or turn off the screen.
3. **↓** - Press to move the cursor down in thumbnails mode; or select next photo in single view mode; or move the cursor left in the menu.
4. **↑** - Press to move the cursor up in thumbnails mode; or select previous photo in single view mode; or move the cursor right in the menu.
5. **↶** - Press to return to the previous screen. Press and hold to display the firmware version.
6. **↵** - Press to confirm the selection or zoom in the photo. Press and hold to rotate the photo.

Left Side View



Right Side View



- 7. USB Port - Connects to a computer through a USB cable or to an electronic socket through the power adaptor.
- 8. Memory Card Slot - Used for inserting an SD/MMC/MS card.
- 9. Magnetic Stand - This adjustable arm supports the unit on a stable top or other flat surface.

Getting Started


1. Install the magnetic stand for tabletop display or prepare a mount on the wall.
2. Power on the unit by either:
 - Connecting it to an electronic socket through the provided power adapter
 - Connecting it to a computer through the provided USB cable.
3. If there are photos in the internal memory of the frame, follow the steps below to view a slide show; If there are no photos in the internal memory, please insert a memory card into the card slot on the right side of the unit (with the card's metallic contacts facing towards the display screen).
4. Press the [↑] and [↓] button to select **Play Photos** on the main screen and press the [←] button to enter the photo view mode.

Playing Photos

Overview of display

While viewing the photos, you can press the buttons on the back of unit to display the photos in thumbnails mode, slideshow mode or single show mode.

Note: To turn off the display screen and enter power saving mode, press and hold the [M/O] button.



Viewing thumbnails

1. Press the [▲] and [▼] button to select **Play Photos** on the main screen, and press the [←] button. The photos appear on the screen as thumbnails (3 rows x 3 columns).
2. To navigate through the thumbnails, press the [M/⏻], [▲] and [▼] buttons.
3. To view a single photo, select it and press the [←] button.
4. To return to the main screen, press the [↵] button.

Note: If a memory card (SD/MMC/MS) is inserted into the card slot, the photos on the memory card will be displayed on the screen in thumbnails. If not, the photos on the Nand Flash of the Digital Photo Frame are displayed.

Browsing a single photo

1. In thumbnail mode, select a photo you want to display, and press the [←] button. Or in Slide Show mode, press the [←] button.
 - To display the previous or next photo, press the [▲] and [▼] button.
 - To rotate the photo 90° counter-clockwise, press and hold the [←] button.
 - To zoom in the photo to 2X/3X/4X, press the [←] button repeatedly. When the photo is magnified, press the [M/⏻], [▲], [▼] and [↵] button to roam on the photo.
2. To start slide show from the current photo, press the [M/⏻] button.
3. To return to the main screen, press the [↵] button.

Running a slideshow

While browsing a single photo, press the **[M/C]** button to start slideshow from the current photo.

- To set the interval between slides, press the **[M/C]** button repeatedly. Each time the **[M/C]** button is pressed, the interval settings are changed as follows: TIME 3S, TIME 5S, TIME 10S, TIME 1M, TIME 10M, TIME 30M.
- To stop slideshow and return to the thumbnail mode, press the **[↵]** button.

Managing Files

There is a Nand Flash with 256M memory of the Digital Photo Frame. You can copy the photos from the memory card to the Nand Flash, or delete the photos on the Nand Flash.

Press the **[↑]** and **[↓]** button to select **Manage Files** on the main screen, and press the **[←]** button. The File Manage menu appears.

To copy photos one by one

1. Press the **[↑]** and **[↓]** button to select **Copy One**, and press the **[←]** button. The photos on the memory card appear on the screen in thumbnails.
2. Press the **[M/C]**, **[↑]** and **[↓]** buttons to select a photo you want to copy and press the **[←]** button. Wait for the processing is completed until the "SAVE OK" message appears.
3. To copy more photos one by one, repeat the step 2.

To copy all photos once

Press the [↑] and [↓] button to select **Copy All**, and press the [←] button. Wait for the Digital Photo Frame to complete the processing until "All OK" message appears.

To delete all photos

Press the [↑] and [↓] button to select **Delete All**, and press the [←] button. All photos on the Nand Flash of Digital Photo Frame are deleted.

To delete photos one by one

1. Press the [↑] and [↓] button to select **Delete One**, and press the [←] button. The photos on the Nand Flash appear on the screen in thumbnails.
2. Press the [M/⏻], [↑] and [↓] buttons to select a photo you want to delete and press the [←] button.
3. To delete more photos one by one, repeat the step 2.

Question/Troubleshooting

If you have problems in operating your Digital Photo Frame, try to using the following guidance to solve the problem before sending it to the service center. Even if the problem persists, do not disassemble the unit; just refer the problem to your dealer or service center.

1. What kind of photos does this unit support?
 - The Frame will display digital Photos that are stored in the JPEG format, which is the standard format for nearly all digital cameras. Some cameras allow photos to be stored as TIFF or RAW files as well as JPEG, but only the JPEG format is compatible with the Frame.
2. What should I do if the system does not respond when the unit is turned on?
 - Make sure the unit is properly connected to a power source. If so, turn the unit off, reconnect the power and turn it on again.
3. Why is the memory card not recognized?
 - The memory card might be inserted improperly or not pushed in all the way. If the card is inserted in the right direction and is still not recognized, turn off the unit, remove and reinsert the card, and start again.

Specification

Display	Digital TFT LCD Panel size: 3.5 inches Resolution: 320*240 pixels
SLC Nand Flash	256M
Power Supply	Input: 100~240V AC, 50/60Hz Output: 5V 0.5A DC
Supported peripheral devices	SD™ (Secure Digital Card), MMC™ (MultiMedia Card), MS™ (Memory Stick)
Supported photo format	JPEG
Operating temperature	5°C ~ 35°C
Dimension	115* 99* 20mm
Weight	170 g

This manual was correct and complete at the time of printing. However, specifications and updates can occur at any time without any prior notice. No part of this manual may be copied, republished, reproduced, transmitted, or distributed in any way without the prior written consent of Nextar, Inc. Any unauthorized distribution of this manual is expressly forbidden.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subjected to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
3. Consult the dealer or an experienced radio/TV technician for help.

Nextar™ is a trademark of Nextar (Hong Kong) Limited

Nextar may find it necessary to modify, amend or otherwise change or update this manual. We reserve the right to do this at any time, without any prior notice. All specifications and features are subject to change without notice. All screen shots shown are simulated and may not represent the actual screen on production units sold to consumers.

For instruction manuals, updated drivers or other information, be sure to visit our website at:

www.Nextar.com

Or write us at:

©Nextar, INC.AND ITS AFFILIATES

1661 FAIRPLEX DRIVE.

LA VERNE, CA 91750. USA

All products distributed by Nextar, Inc.unless otherwise indicated

Made in China

© 2005 Nextar (Hong Kong) Limited. Nextar (Hong Kong) Limited claims trademark rights in Nextar™. All other brand names, product names and trademarks are the property of their registered owners.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>