

Part No. 206378-A
June 1999

4401 Great America Parkway
Santa Clara, CA 95054

Installation and Reference for the BayStack 60-12T/60-24T 10/100 Ethernet Hubs

NORTEL
NETWORKS™

Copyright © 1999 Nortel Networks

All rights reserved. Printed in the USA. June 1999.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks NA Inc.

The software described in this document is furnished under a license agreement and may only be used in accordance with the terms of that license. A summary of the Software License is included in this document.

Trademarks

Nortel Networks and BayStack are trademarks of Nortel Networks corporation.

All other trademarks and registered trademarks are the property of their respective owners.

Restricted Rights Legend

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Notwithstanding any other license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government regarding its use, reproduction, and disclosure are as set forth in the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19.

Statement of Conditions

In the interest of improving internal design, operational function, and/or reliability, Nortel Networks NA Inc. reserves the right to make changes to the products described in this document without notice.

Nortel Networks NA Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Portions of the code in this software product are Copyright © 1988, Regents of the University of California. All rights reserved. Redistribution and use in source and binary forms of such portions are permitted, provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that such portions of the software were developed by the University of California, Berkeley. The name of the University may not be used to endorse or promote products derived from such portions of the software without specific prior written permission.

SUCH PORTIONS OF THE SOFTWARE ARE PROVIDED "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

In addition, the program and information contained herein are licensed only pursuant to a license agreement that contains restrictions on use and disclosure (that may incorporate by reference certain limitations and notices imposed by third parties).

Federal Communications Commission (FCC) Compliance Notice: Radio Frequency Notice

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy. If it is not installed and used in accordance with the instruction manual, it may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to take whatever measures may be necessary to correct the interference at their own expense.

EN 55 022 Statement

This is to certify that the Nortel Networks BayStack 60-12T and BayStack 60-24T 10/100 Ethernet Hubs are shielded against the generation of radio interference in accordance with the application of Council Directive 89/336/EEC, Article 4a. Conformity is declared by the application of EN 55 022 Class A (CISPR 22).

Warning: This is a Class A product. In a domestic environment, this product may cause radio interference, in which case, the user may be required to take appropriate measures.

EC Declaration of Conformity

This product conforms (or these products conform) to the provisions of Council Directive 89/336/EEC and 73/23/EEC. The Declaration of Conformity is available on the Nortel Networks World Wide Web site at <http://libra2.corpwest.baynetworks.com/cgi-bin/ndCGI.exe/DocView/>.

Voluntary Control Council for Interference (VCCI) Statement

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

Voluntary Control Council for Interference (VCCI) Statement

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may arise. When such trouble occurs, the user may be required to take corrective actions.

Electromagnetic Interference (EMI) Statement

TAIWANESE BCIQ A Warning

警告使用者

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下使用者會被要求採取某些適當的對策。

Canadian Department of Communications Radio Interference Regulations

This digital apparatus (BayStack 60-12T and BayStack 60-24T 10/100 Ethernet Hubs) do not exceed the Class A limits for radio-noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

Règlement sur le brouillage radioélectrique du ministère des Communications

Cet appareil numérique (BayStack 60-12T and BayStack 60-24T 10/100 Ethernet Hubs) respecte les limites de bruits radioélectriques visant les appareils numériques de classe A prescrites dans le Règlement sur le brouillage radioélectrique du ministère des Communications du Canada.

Wichtige Sicherheitshinweise

1. Bitte lesen Sie diese Hinweise sorgfältig durch.
2. Heben Sie diese Anleitung für den späteren Gebrauch auf.
3. Vor jedem Reinigen ist das Gerät vom Stromnetz zu trennen. Verwenden Sie keine Flüssig- oder Aerosolreiniger. Am besten eignet sich ein angefeuchtetes Tuch zur Reinigung.
4. Die Netzanschlussdose soll nahe dem Gerät angebracht und leicht zugänglich sein.
5. Das Gerät ist vor Feuchtigkeit zu schützen.
6. Bei der Aufstellung des Gerätes ist auf sicheren Stand zu achten. Ein Kippen oder Fallen könnte Beschädigungen hervorrufen.
7. Die Belüftungsöffnungen dienen der Luftzirkulation, die das Gerät vor Überhitzung schützt. Sorgen Sie dafür, daß diese Öffnungen nicht abgedeckt werden.
8. Beachten Sie beim Anschluß an das Stromnetz die Anschlußwerte.
9. Verlegen Sie die Netzanschlußleitung so, daß niemand darüber fallen kann. Es sollte auch nichts auf der Leitung abgestellt werden.
10. Alle Hinweise und Warnungen, die sich am Gerät befinden, sind zu beachten.
11. Wird das Gerät über einen längeren Zeitraum nicht benutzt, sollten Sie es vom Stromnetz trennen. Somit wird im Falle einer Überspannung eine Beschädigung vermieden.
12. Durch die Lüftungsöffnungen dürfen niemals Gegenstände oder Flüssigkeiten in das Gerät gelangen. Dies könnte einen Brand bzw. elektrischen Schlag auslösen.
13. Öffnen Sie niemals das Gerät. Das Gerät darf aus Gründen der elektrischen Sicherheit nur von autorisiertem Servicepersonal geöffnet werden.
14. Wenn folgende Situationen auftreten, ist das Gerät vom Stromnetz zu trennen und von einer qualifizierten Servicestelle zu überprüfen:
 - (a) Netzkabel oder Netzstecker sind beschädigt.
 - (b) Flüssigkeit ist in das Gerät eingedrungen.
 - (c) Das Gerät war Feuchtigkeit ausgesetzt.
 - (d) Wenn das Gerät nicht der Bedienungsanleitung entsprechend funktioniert oder Sie mit Hilfe dieser Anleitung keine Verbesserung erzielen.
 - (e) Das Gerät ist gefallen und/oder das Gehäuse ist beschädigt.
 - (f) Wenn das Gerät deutliche Anzeichen eines Defektes aufweist.
7. Zum Netzanschluß dieses Gerätes ist eine geprüfte Leitung zu verwenden. Für einen Nennstrom bis 6A und einem Gerätegewicht größer 3kg ist eine Leitung nicht leichter als H05VV-F, 3G, 0,75mm² einzusetzen. Der arbeitsplatzbezogene Schalldruckpegel nach DIN 45 635 Teil 1000 beträgt 70dB(A) oder weniger.

Nortel Networks NA Inc. Software License Agreement

NOTICE: Please carefully read this license agreement before copying or using the accompanying software or installing the hardware unit with pre-enabled software (each of which is referred to as “Software” in this Agreement). BY COPYING OR USING THE SOFTWARE, YOU ACCEPT ALL OF THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT. THE TERMS EXPRESSED IN THIS AGREEMENT ARE THE ONLY TERMS UNDER WHICH NORTEL NETWORKS WILL PERMIT YOU TO USE THE SOFTWARE. If you do not accept these terms and conditions, return the product, unused and in the original shipping container, within 30 days of purchase to obtain a credit for the full purchase price.

1. License Grant. Nortel Networks NA Inc. (“Nortel Networks”) grants the end user of the Software (“Licensee”) a personal, nonexclusive license: a) to use the Software either on a single computer or, if applicable, on a single authorized device identified by host ID; b) to copy the Software solely for backup purposes in support of authorized use of the Software; and c) to use and copy the associated user manual solely in support of authorized use of the Software by Licensee. This license applies to the Software only and does not extend to Nortel Networks Agent software or other Nortel Networks software products. Nortel Networks Agent software or other Nortel Networks software products are licensed for use under the terms of the applicable Nortel Networks, Inc. Software License Agreement that accompanies such software and upon payment by the end user of the applicable license fees for such software.

2. Restrictions on use; reservation of rights. The Software and user manuals are protected under copyright laws. Nortel Networks and/or its licensors retain all title and ownership in both the Software and user manuals, including any revisions made by Nortel Networks or its licensors. The copyright notice must be reproduced and included with any copy of any portion of the Software or user manuals. Licensee may not modify, translate, decompile, disassemble, use for any competitive analysis, reverse engineer, distribute, or create derivative works from the Software or user manuals or any copy, in whole or in part. Except as expressly provided in this Agreement, Licensee may not copy or transfer the Software or user manuals, in whole or in part. The Software and user manuals embody Nortel Networks’ and its licensors’ confidential and proprietary intellectual property. Licensee shall not disclose to any third party the Software, or any information about the operation, design, performance, or implementation of the Software and user manuals that is confidential to Nortel Networks and its licensors; however, Licensee may grant permission to its consultants, subcontractors, and agents to use the Software at Licensee’s facility, provided they have agreed to use the Software only in accordance with the terms of this license.

3. Limited warranty. Nortel Networks warrants each item of Software, as delivered by Nortel Networks and properly installed and operated on Nortel Networks hardware or other equipment it is originally licensed for, to function substantially as described in its accompanying user manual during its warranty period, which begins on the date Software is first shipped to Licensee. If any item of Software fails to so function during its warranty period, as the sole remedy Nortel Networks will at its discretion provide a suitable fix, patch, or workaround for the problem that may be included in a future Software release. Nortel Networks further warrants to Licensee that the media on which the Software is provided will be free from defects in materials and workmanship under normal use for a period of 90 days from the date the Software is first shipped to Licensee. Nortel Networks will replace defective media at no charge if it is returned to Nortel Networks during the warranty period along with proof of the date of shipment. This warranty does not apply if the media has been damaged as a result of accident, misuse, or abuse. The Licensee assumes all responsibility for selection of the Software to achieve Licensee’s intended results and for the installation, use, and results obtained from the Software. Nortel Networks does not warrant a) that the functions contained in the software will meet the Licensee’s requirements, b) that the Software will operate in the hardware or software combinations that the Licensee may select, c) that the operation of the Software will be uninterrupted or error free, or d) that all defects in the operation of the Software will be corrected. Nortel Networks is not obligated to remedy any Software defect that cannot be reproduced with the latest Software release. These warranties do not apply to the Software if it has been (i) altered, except by Nortel Networks or in accordance with its instructions; (ii) used in conjunction with another vendor’s product, resulting in the defect; or (iii) damaged by improper environment, abuse, misuse, accident, or negligence. THE FOREGOING WARRANTIES AND LIMITATIONS ARE EXCLUSIVE REMEDIES AND ARE IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Licensee is responsible for the security of its own data and information and for maintaining adequate procedures apart from the Software to reconstruct lost or altered files, data, or programs.

4. Limitation of liability. IN NO EVENT WILL NORTEL NETWORKS OR ITS LICENSORS BE LIABLE FOR ANY COST OF SUBSTITUTE PROCUREMENT; SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES; OR ANY DAMAGES RESULTING FROM INACCURATE OR LOST DATA OR LOSS OF USE OR PROFITS ARISING OUT OF OR IN CONNECTION WITH THE PERFORMANCE OF THE SOFTWARE, EVEN IF NORTEL NETWORKS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL THE LIABILITY OF NORTEL NETWORKS RELATING TO THE SOFTWARE OR THIS AGREEMENT EXCEED THE PRICE PAID TO NORTEL NETWORKS FOR THE SOFTWARE LICENSE.

5. Government Licensees. This provision applies to all Software and documentation acquired directly or indirectly by or on behalf of the United States Government. The Software and documentation are commercial products, licensed on the open market at market prices, and were developed entirely at private expense and without the use of any U.S. Government funds. The license to the U.S. Government is granted only with restricted rights, and use, duplication, or disclosure by the U.S. Government is subject to the restrictions set forth in subparagraph (c)(1) of the Commercial Computer Software—Restricted Rights clause of FAR 52.227-19 and the limitations set out in this license for civilian agencies, and subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause of DFARS 252.227-7013, for agencies of the Department of Defense or their successors, whichever is applicable.

6. Use of Software in the European Community. This provision applies to all Software acquired for use within the European Community. If Licensee uses the Software within a country in the European Community, the Software Directive enacted by the Council of European Communities Directive dated 14 May, 1991, will apply to the examination of the Software to facilitate interoperability. Licensee agrees to notify Nortel Networks of any such intended examination of the Software and may procure support and assistance from Nortel Networks.

7. Term and termination. This license is effective until terminated; however, all of the restrictions with respect to Nortel Networks' copyright in the Software and user manuals will cease being effective at the date of expiration of the Nortel Networks copyright; those restrictions relating to use and disclosure of Nortel Networks' confidential information shall continue in effect. Licensee may terminate this license at any time. The license will automatically terminate if Licensee fails to comply with any of the terms and conditions of the license. Upon termination for any reason, Licensee will immediately destroy or return to Nortel Networks the Software, user manuals, and all copies. Nortel Networks is not liable to Licensee for damages in any form solely by reason of the termination of this license.

8. Export and Re-export. Licensee agrees not to export, directly or indirectly, the Software or related technical data or information without first obtaining any required export licenses or other governmental approvals. Without limiting the foregoing, Licensee, on behalf of itself and its subsidiaries and affiliates, agrees that it will not, without first obtaining all export licenses and approvals required by the U.S. Government: (i) export, re-export, transfer, or divert any such Software or technical data, or any direct product thereof, to any country to which such exports or re-exports are restricted or embargoed under United States export control laws and regulations, or to any national or resident of such restricted or embargoed countries; or (ii) provide the Software or related technical data or information to any military end user or for any military end use, including the design, development, or production of any chemical, nuclear, or biological weapons.

9. General. If any provision of this Agreement is held to be invalid or unenforceable by a court of competent jurisdiction, the remainder of the provisions of this Agreement shall remain in full force and effect. This Agreement will be governed by the laws of the state of California. NORTEL Should you have any questions concerning this Agreement, contact Nortel Networks, 4401 Great America Parkway, P.O. Box 58185, Santa Clara, California 95054-8185.

LICENSEE ACKNOWLEDGES THAT LICENSEE HAS READ THIS AGREEMENT, UNDERSTANDS IT, AND AGREES TO BE BOUND BY ITS TERMS AND CONDITIONS. LICENSEE FURTHER AGREES THAT THIS AGREEMENT IS THE ENTIRE AND EXCLUSIVE AGREEMENT BETWEEN NORTEL NETWORKS AND LICENSEE, WHICH SUPERSEDES ALL PRIOR ORAL AND WRITTEN AGREEMENTS AND COMMUNICATIONS BETWEEN THE PARTIES PERTAINING TO THE SUBJECT MATTER OF THIS AGREEMENT. NO DIFFERENT OR ADDITIONAL TERMS WILL BE ENFORCEABLE AGAINST NORTEL NETWORKS UNLESS NORTEL NETWORKS GIVES ITS EXPRESS WRITTEN CONSENT, INCLUDING AN EXPRESS WAIVER OF THE TERMS OF THIS AGREEMENT.

Contents

Preface

Before You Begin	xv
Hard-Copy Technical Manuals	xvi
How to Get Help	xvi

Chapter 1

Introduction

Product Features	1-1
Product Description	1-2
Autosense Capability	1-2
Front Panel	1-2
LEDs	1-4
Port Functions	1-5
Port Partitioning	1-5
MDI/MDI-X Modes	1-5
MDI/MDI-X Button	1-6
Rear Panel	1-6
Hardware and Environmental Requirements	1-6

Chapter 2

Typical Applications

Mixed 10 Mb/s and 100 Mb/s Environment	2-1
Basic Mixed Network	2-2
Expanded Mixed Network	2-3
Bridging	2-4

Chapter 3 Installation

Package Contents	3-1
Installing the Hub	3-2
Mounting the Hub in a Standard 19" Equipment Rack	3-2
Connecting the Hub To Other Devices	3-3
Cable Types and MDI/MDI-X Modes	3-3
Connecting the Hub Through a RJ-45 Port	3-4
Connecting the Hub Through the MDI Port	3-5
Applying Power to the Hub	3-5
Verifying Port Status	3-6

Chapter 4 Troubleshooting

Verifying System Operations	4-1
Diagnosing Hub Indicators	4-2

Appendix A Technical Specifications

Appendix B Cable and Connector Information

Port Assignments	B-1
RJ-45 Ports	B-1
MDI/MDI-X Ports	B-1
RJ-45 Pin Assignments	B-1
Cable Assignments	B-2

Index

Figures

Figure 1-1.	BayStack 60-12T Front Panel	1-3
Figure 1-2.	BayStack 60-24T Front Panel	1-3
Figure 1-3.	BayStack 60-12T/60-24T Rear Panel	1-6
Figure 2-1.	Example of a Basic Mixed Network	2-2
Figure 2-2.	Example of an Expanded Mixed Network	2-3
Figure 2-3.	Daisy-Chained Hubs	2-4
Figure 3-1.	Rack Mounted Hubs	3-2
Figure 3-2.	Port Status LEDs	3-6
Figure B-1.	RJ-45 Pin Assignments	B-1
Figure B-2.	Cable Schematics	B-2

Tables

Table 1-1.	LED Descriptions	1-4
Table 3-1.	Cables and MDI/MDI-X Modes for the BayStack 60-12T 10/100 Ethernet Hub	3-3
Table 3-2.	Cables and MDI/MDI-X Modes for the BayStack 60-24T 10/100 Ethernet Hub	3-3
Table 3-3.	Port Status LED Descriptions	3-6
Table 4-1.	LED Indicators	4-2
Table A-1.	Product Specifications	A-1
Table B-1.	RJ-45 Pin Descriptions	B-2

Congratulations on your purchase of a BayStack™ 60-12T/60-24T 10/100 Ethernet Hub. The BayStack 60-12T/60-24T 10/100 Ethernet Hubs enable you to migrate easily from Ethernet to Fast Ethernet. You can migrate to Fast Ethernet while maintaining much of your existing Ethernet network and equipment.

In this guide, the BayStack 60-12T and BayStack 60-24T 10/100 Ethernet Hub are referred to collectively as the BayStack 60-12T/60-24T 10/100 Ethernet Hub, or just as the “hubs.” Each model is referred to specifically when features and functions are unique to that particular model.

Before You Begin

This guide is intended for users with the following background:

- Familiarity with network hardware and cable requirements
- Experience in installing rack-mounted network hardware
- Working knowledge of Ethernet (10 Mb/s, or 10BASE-T) and Fast Ethernet (100 Mb/s, or 100BASE-T) operations

Hard-Copy Technical Manuals

You can print selected technical manuals and release notes free, directly from the Internet. Go to support.baynetworks.com/library/tpubs/. Find the product for which you need documentation. Then locate the specific category and model or version for your hardware or software product. Using Adobe Acrobat Reader, you can open the manuals and release notes, search for the sections you need, and print them on most standard printers. You can download Acrobat Reader free from the Adobe Systems Web site, www.adobe.com.

You can purchase selected documentation sets, CDs, and technical publications through the collateral catalog. The catalog is located on the World Wide Web at support.baynetworks.com/catalog.html and is divided into sections arranged alphabetically:

- The “CD ROMs” section lists available CDs.
- The “Guides/Books” section lists books on technical topics.
- The “Technical Manuals” section lists available printed documentation sets.

How to Get Help

If you purchased a service contract for your Nortel Networks product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

If you purchased a Nortel Networks service program, contact one of the following Nortel Networks Technical Solutions Centers:

Technical Solutions Center	Telephone Number
Billerica, MA	800-2LANWAN (800-252-6926)
Santa Clara, CA	800-2LANWAN (800-252-6926)
Valbonne, France	33-4-92-96-69-68
Sydney, Australia	61-2-9927-8800
Tokyo, Japan	81-3-5402-7041

Chapter 1

Introduction

The BayStack 60-12T/60-24T 10/100 Ethernet Hubs provide 12 or 24 RJ-45 ports for 10 Mb/s or 100 Mb/s Ethernet/Fast Ethernet connections. Ten or 100 Mb/s traffic is determined by the autosensing capability of the RJ-45 ports in the BayStack 60-12T/60-24T 10/100 Ethernet Hubs.

Design features of the BayStack 60-12T/60-24T 10/100 Ethernet Hubs provide a user friendly interface, simplifying installation and network troubleshooting.

Product Features

The BayStack 60-12T/60-24T 10/100 Ethernet Hub provides the following features:

- 12/24 autosensing 10/100 Mb/s Ethernet ports with internal switching/bridging hardware
- One MDI/MDI-X port, selected by a push button
- Support for IEEE 802.3 10BASE-T and IEEE 802.3u 100BASE-TX standards
- Transparent bridging between 10 Mb/s and 100 Mb/s segments through an internal switch module
- Support for autopartitioning and reconnection features to facilitate faulty segment isolation
- Polarity autodetection and autocorrection for 10 Mb/s segment UTP/STP ports
- Automatic jabber handling functions
- Extensive front panel LEDs provide all information at a glance
- Plug-and-play connection

- Up to 2 units can be daisy-chained (Class II Repeater)
- Separates network traffic into two network collision domains (10Mb/s, 100Mb/s)
- Store-and-forward packet transmission methods

Product Description

Package contents of the BayStack 60-12T/60-24T 10/100 Ethernet Hub include materials for rack mounting and connecting the hubs, such as a rack mount kit and an AC power cord. Standard Ethernet UTP or STP cables are not provided.

Autosense Capability

BayStack 60-12T/60-24T 10/100 Ethernet Hub ports automatically sense the 10 Mb/s or 100 Mb/s transmission speed of attached devices. Each port automatically sends traffic through the route with the highest available transmission speed, depending on the capability of the connected device. Traffic is forwarded to the 10 or 100 Mb/s segment on the hub, again depending on the incoming speed of the traffic. By confining traffic to its respective segments and only forwarding traffic to the other segment when required, the overall load on the network is significantly reduced.

Front Panel

The BayStack 60-12T/60-24T 10/100 Ethernet Hub includes front panel LEDs and ports for connecting to other devices.

[Figure 1-1](#) and [Figure 1-2](#) show the front panels of the BayStack 60-12T 10/100 Ethernet Hub and BayStack 60-24T 10/100 Ethernet Hub, respectively. [Table 1-1](#) on [page 4](#) provides further details about the LEDs.




Figure 1-1. BayStack 60-12T Front Panel




Figure 1-2. BayStack 60-24T Front Panel

LEDs

This section describes the LEDs on the front panel of the BayStack 60-12T/60-24T 10/100 Ethernet Hub. [Table 1-1](#) describes the LEDs.

Table 1-1. LED Descriptions

LED	Color	Activity	Indication
Power	Green	On	Power is supplied to the hub.
Utilization % 10 Mb/s	Green	On	Data transmission is occurring on a 10 Mb/s network segment at the indicated rate.
100 Mb/s	Green	On	Data transmission is occurring on a 100 Mb/s network segment at the indicated rate.
Collision 10 Mb/s	Yellow	On	Data collision is occurring on a 10 Mb/s network segment.
100 Mb/s	Yellow	On	Data collision is occurring on a 100 Mb/s network segment.
10/100 Link/Activity	Yellow	On	The port is connected to a 10 Mb/s segment.
		Blinking	Data is being received to a 10 Mb/s segment.
	Green	On	The port is connected to a 100 Mb/s segment.
		Blinking	Data is being received to a 100 Mb/s segment.
Partition	Yellow	On	Partitioning has occurred at a port. The Link/Activity LEDs display whether a 10 Mb/s port (yellow) or a 100 Mb/s port (green) is partitioned when the yellow partition LED is lit for a specific port.

Port Functions

This section describes port partitioning and MDI/MDI-X modes. Partitioning is an automatic function of BayStack 60-12T/60-24T 10/100 Ethernet Hub ports. Certain ports can be configured to MDI/MDI-X mode with the MDI/MDI-X button.

Port Partitioning

A port is automatically disabled by the hub when a serious error occurs, such as continuous collisions on a single packet. This process is known as autopartitioning. A partitioned port indicates an overloaded network or a malfunctioning device on the network. When the port receives a valid packet from the connected device, or is able to transmit a packet from the port, it automatically releases the port so that it becomes active again.

- Partitioning occurs at a 100 Mb/s port when there are 61 consecutive collisions.
- Partitioning occurs at a 10 Mb/s port when there are 32 consecutive collisions, or when one collision lasting as long as 575.2us has occurred.

MDI/MDI-X Modes

Adapter cards in computers and workstations usually contain media-dependent interface (MDI) ports, also called uplink ports. Most hub ports are configured as media-dependent interfaces with built-in crossover ports, called MDI-X or normal ports. By default, all BayStack 60-12T/60-24T 10/100 Ethernet Hub ports are set to MDI-X, or normal, mode. You can connect your hub to computers and workstations in MDI-X mode using a standard straight-through cable.

You need a crossover cable to connect your hub to other hubs, switches and routers if you are using a hub port in normal, MDI-X, mode. You can use a straight-through cable to connect to these devices if you configure a port on your hub to the uplink mode.

You can configure port 1 on the BayStack 60-12T/60-24T 10/100 Ethernet Hub from normal to uplink mode with the MDI/MDI-X button.

Refer to [“Cable Types and MDI/MDI-X Modes”](#) on [page 3-3](#) for details regarding which cable or mode to use for specific devices.


MDI/MDI-X Button

The MDI/MDI-X button sets port 1 on the BayStack 60-12T/60-24T 10/100 Ethernet Hub from a normal (MDI-X) port to an uplink (MDI) port. Set the MDI/MDI-X button to uplink (MDI) mode to connect your BayStack 60-12T/60-24T 10/100 Ethernet Hub to another Ethernet hub or switch using a standard straight-through Ethernet cable.

Refer to [“Cable Types and MDI/MDI-X Modes”](#) on [page 3-3](#) for details regarding using straight-through or crossover cables to connect your BayStack 60-12T/60-24T 10/100 Ethernet Hub to various network devices.

Rear Panel

The rear panel ([Figure 1-3](#)) of the BayStack 60-12T/60-24T 10/100 Ethernet Hub includes a standard AC power cord receptacle.



9259EA

Figure 1-3. BayStack 60-12T/60-24T Rear Panel

Hardware and Environmental Requirements

The following environmental and hardware specifications are required for proper installation and function of your hub:

- Power - 100 to 240 V AC (+/- 10 %), 50 to 60 Hz (+/- 3 Hz)
- The hub should be located in a cool, dry place, with at least 10 cm (4 inches) of space in front and behind the hub for ventilation.
- Do not place the hub in direct sunlight. Keep the hub away from heat sources or areas with high amounts of electromagnetic interference.
- If you intend to mount the hub in a rack, make sure you have adequate mounting screws, brackets, bolts, nuts, and appropriate tools.
- Be sure you have all necessary network cables and connectors.

Chapter 2

Typical Applications

The BayStack 60-12T/60-24T 10/100 Ethernet Hubs provide flexibility in configuring your network. You can use the hubs in a standalone configuration, or in multiple hub configurations to utilize your existing Ethernet and Fast Ethernet equipment. You can stack the hubs on top of each other on a flat surface, or mount them in standard 19" equipment racks. In addition to attaching your hub to workstations or printers, you can extend your current local area network (LAN) by connecting a BayStack 60-12T/60-24T 10/100 Ethernet Hub to a collapsed backbone device such as a switch or a router.

This chapter discusses various environments where you can use the BayStack 60-12T/60-24T 10/100 Ethernet Hub, such as environments which have a mixed network of 10 Mb/s and 100 Mb/s devices.

Mixed 10 Mb/s and 100 Mb/s Environment

The BayStack 60-12T/60-24T 10/100 Ethernet Hub runs at both 10 Mb/s and 100 Mb/s simultaneously. Devices running at 10 Mb/s and devices running at 100 Mb/s are located on separate network segments within one BayStack 60-12T/60-24T 10/100 Ethernet Hub. These two segments communicate with the internal switching hardware, which is built in to the hub.

Basic Mixed Network

[Figure 2-1](#) shows a basic use of the BayStack 60-12T/60-24T 10/100 Ethernet Hub in a simple mixed environment network. The hub connects various workstations to each other. Workstations can be operating at 10 Mb/s and/or 100 Mb/s.




Figure 2-1. Example of a Basic Mixed Network

The example shows a BayStack 60-24T 10/100 Ethernet Hub. However, you can use a BayStack 60-12T 10/100 Ethernet Hub instead, depending on the number of devices you need to connect.

Expanded Mixed Network

[Figure 2-2](#) shows an expanded mixed network using two BayStack 60-24T 10/100 Ethernet Hubs connected to each other and to several devices. The devices use 10 Mb/s and 100 Mb/s speeds.




Figure 2-2. Example of an Expanded Mixed Network

The example shows two BayStack 60-24T 10/100 Ethernet Hubs. However, you can use two BayStack 60-12T 10/100 Ethernet Hubs instead, or one 12-port hub and one 24-port hub, depending on the number of devices you need to connect.

[Figure 2-3](#) shows the specific ports used to connect two hubs, as in the expanded network in [Figure 2-2](#). Port 1 on the top hub is set to MDI (uplink) with the MDI/MDI-X button. A UTP/STP Ethernet cable connects port 1 of the top hub to another non-MDI port on the second hub. This type of connection is known as “daisy-chaining.”




Figure 2-3. Daisy-Chained Hubs

Bridging

The internal switching hardware of the hub bridges the two collision domains, the 10 Mb/s and 100 Mb/s segments. The switching hardware handles the bridging, which allows 10 Mb/s and 100 Mb/s segments to talk to each other.

Chapter 3 Installation

You can stack the BayStack 60-12T/60-24T 10/100 Ethernet Hubs on a flat surface, or mount them in a standard 19” equipment rack. This chapter explains how to mount or stack your hubs, how to connect and power up the hub, and how to troubleshoot hub operations. Before installing the hub, be sure your environment meets the requirements defined in [“Hardware and Environmental Requirements”](#) on [page 1-6](#).

Package Contents

The contents of your product package should contain the following items:

- One of the following BayStack 60 Series Hubs:
 - BayStack 60-12T 10/100 Ethernet Hub (12 port 10/100 Mb/s hub)
 - BayStack 60-24T 10/100 Ethernet Hub (24 port 10/100 Mb/s hub)
- One mounting kit, including brackets and screws, for mounting the hub in a standard 19” equipment rack
- Appropriate power cord

Installing the Hub

You can stack hubs on a flat surface or you can mount the hubs in a standard 19" equipment rack.

Mounting the Hub in a Standard 19" Equipment Rack

You can mount BayStack 60-12T/60-24T 10/100 Ethernet Hubs in a rack, such as in a wiring closet or network center.

[Figure 3-1](#) shows three hubs mounted in a standard rack.




Figure 3-1. Rack Mounted Hubs

To mount hubs in a standard EIA 19" equipment rack:

- 1. Gather the brackets and screws included in the package that shipped with your hub.**
- 2. Attach one bracket to each of the front sides of the hub using a cross-head screwdriver.**
- 3. Align the front bracket holes with corresponding holes in the rack.**

4. **Insert the screws into the front of the bracket, through the rack, so that the screws extend past the rack.**
5. **Tighten the screws.**

Connecting the Hub To Other Devices

You can connect hubs to other network devices through the dual-speed MDI/MDI-X RJ-45 port on the front of the hub.

Cable Types and MDI/MDI-X Modes

You can use standard straight through Ethernet cables to connect your hub to PCs, printers, or servers. If you want to connect your BayStack 60-12T/60-24T 10/100 Ethernet Hub to routers, switches, and other hubs you must use a crossover cable unless you set the MDI/MDI-X button to uplink. You can only configure port 1 with the MDI/MDI-X button.

[Table 3-1](#) and [Table 3-2](#) show which cable types and MDI/MDI-X modes to use for various devices when connecting from the BayStack 60-12T 10/100 Ethernet Hub or BayStack 60-24T 10/100 Ethernet Hub, respectively.

Table 3-1. Cables and MDI/MDI-X Modes for the BayStack 60-12T 10/100 Ethernet Hub

Hub Port	Connecting Device	Mode	Cable Type
1 through 12	PC, server	MDI-X (normal)	Straight-through
1 through 12	Hub, router, switch	MDI-X (normal)	Crossover
1	Hub, router, switch	MDI (uplink)	Straight-through

Table 3-2. Cables and MDI/MDI-X Modes for the BayStack 60-24T 10/100 Ethernet Hub

Hub Port	Connecting Device	Mode	Cable Type
1 through 24	PC, server	MDI-X (normal)	Straight-through
1 through 24	Hub, router, switch	MDI-X (normal)	Crossover
1	Hub, router, switch	MDI (uplink)	Straight-through

Connecting the Hub Through a RJ-45 Port

You can connect a BayStack 60-12T/60-24T 10/100 Ethernet Hub to any device that has a standard RJ-45 network interface port. To connect simple devices such as workstations or servers, or more complex devices such as bridges or routers to the hub, use a standard RJ-45 port.

To connect the hub to another device through a RJ-45 Port:

1. **Make sure the devices you want to connect to contain 10BASE-T or 100BASE-T network interface cards.**
2. **Obtain one straight through shielded or unshielded twisted pair cable (STP or UTP) with RJ-45 connectors at each end for each device.**
 - Use 100 Ohm Category 3, 4, or 5 cable for 10 Mb/s Ethernet connections.
 - Use 100 Ohm Category 5 cable for 100 Mb/s Ethernet connections. Category 5 cable is recommended for all connections to avoid confusion between cables, and to provide for easy future migration of all devices to Fast Ethernet.
 - Each cable must be 100 meters long or less.
3. **Connect one RJ-45 connector of the cable to the network interface card of your device.**
4. **Connect the other RJ-45 connector of the cable to any available MDI-X, or normal, port on the hub.**

By default, all ports on the BayStack 60-12T/60-24T 10/100 Ethernet Hub except port 1 are MDI-X. The RJ-45 ports support both 10 Mb/s and 100 Mb/s Ethernet connections.

5. **Be sure the tab on each RJ-45 connector clicks securely into position.**



Warning: Do not connect a phone jack connector to a RJ-45 port. You may damage the hub. Use only twisted pair Ethernet cables with RJ-45 connectors that comply with FCC standards.

Connecting the Hub Through the MDI Port

You can connect BayStack 60-12T/60-24T 10/100 Ethernet Hubs to other compatible hubs or switches through port 1 on the front panel of the hub, setting the MDI/MDI-X button to uplink.

To connect to another device through the MDI port:

1. **Insert an RJ-45 connector of a straight-through twisted pair Ethernet cable into port 1 of your hub.**

You can configure port 1 to uplink or normal mode using the MDI/MDI-X button.

2. **Set the MDI/MDI-X button next to port 1 to MDI, or uplink.**
3. **Insert the other RJ-45 connector in to any MDI-X port on another device.**

You can also connect this RJ-45 connector to a MDI port on another device set up as a daisy-chain configuration.

Applying Power to the Hub

To apply power to your hubs:

1. **Plug the power cord into the power socket in the rear of the hub.**
2. **Plug the other end of the power cord into a standard power outlet.**

The hub will automatically select the setting that matches the connected input voltage. No additional adjustments are necessary when you connect the hub to any input voltage, as long as the voltage range is within the range marked on the rear panel.

3. **Check the Power LED on the front panel.**


The Power LED should be on. The hub will perform a self-diagnostic test during the power on process.



Note: The hub supports a “hot remove” feature which permits you to connect or disconnect cables without powering off the hub. Operation of devices attached to the hub is not disrupted.

Verifying Port Status

You can check the status of each cable connection by viewing the port status indicators shown in [Figure 3-2](#) and described in [Table 3-3](#).



9247EA

Figure 3-2. Port Status LEDs

[Table 3-3](#) describes the light and color indications of port status LEDs.

Table 3-3. Port Status LED Descriptions

LED	State	Indication
Power	On (green)	The hub is receiving power.
Collision	Flashing (yellow)	A packet collision occurred in the 10/100 Mb/s domain.
Activity	Flashing (green)	The port is receiving 10/100 Mb/s traffic.
Partition	On (yellow)	The port has been partitioned from the network.
Link 10/100M	On (green)	The port has established a valid 100 Mb/s network connection.
	On (yellow)	The port has established a valid 10 Mb/s network connection.

Chapter 4

Troubleshooting

This chapter provides common testing methods, possible reasons for problems, and possible steps to take to solve the problems.

Verifying System Operations

You can verify that all attached devices have valid connections. The hub monitors the link status for each port. If a device is properly connected to the hub and if the device is transmitting a link signal, the Link indicator will light up for the corresponding port.

Follow these steps if the Link indicator fails to light when you connect a device to the hub:

- 1. Verify that the twisted-pair cable is properly attached to the connected device and the hub.**
- 2. Verify that the media connector, or RJ-45 connector, snaps securely into place when attached.**
- 3. Verify that your cable is functioning properly. Try attaching the cable to another port on another attached device that appears to be functioning properly.**
- 4. Check the length of each twisted-pair cable.**
 - Each cable should be no longer than 100 meters, or 328 feet, long.
 - If you are using two cascaded Fast Ethernet hubs be sure the cable between the two hubs is no longer than 5 meters, or 16 feet, long.
- 5. Verify that the attached workstation has a functioning adapter card. Try the card in another workstation that is successfully connecting to the network.**

Diagnosing Hub Indicators

You can easily monitor the hub through LED indicators on the front panel. [Table 4-1](#) describes common problems and possible solutions.

Table 4-1. LED Indicators

Symptom	Cause	Solution
The Link 10/100 Mb/s indicator does not light up after making a connection.	A network interface, such as an adapter card on the attached device, a network cable, or the hub port is defective.	<ul style="list-style-type: none">• Verify that the hub and attached device are powered on.• Be sure the cable is securely plugged into the hub and the device.• Verify the proper cable length is being used.• Check the adapter or cable connections for defects. Replace defective parts.
The Power indicator does not light up (green) after powering on.	A power outlet, power cord, or internal power supply is defective.	<ul style="list-style-type: none">• Check the power outlet by plugging in another, properly functioning, device.• Check the power cord by plugging it into another, properly functioning, device.• If you still do not have power, contact Customer Support, as explained in "How to Get Help" on page xvi for assistance.
The hub powers off after running for a time.	Loose connections, or power surges or losses may have occurred.	<ul style="list-style-type: none">• Check for loose power connections. Verify all connections are seated securely.• Determine if power surges or losses occurred at the power outlet.• Verify that the fan on the back of the hub is unobstructed and running.

Appendix A

Technical Specifications

[Table A-1](#) provides technical information regarding product specifications, port and cable assignments, and EMI certification.

Table A-1. Product Specifications

Item	Description
Standards Conformance	IEEE 802.3 Ethernet, IEEE 802.3u Fast Ethernet
Access Method	CSMA/CD, 10 Mb/s, or 100 Mb/s
Communication Rate	10/100 Mb/s on RJ-45 ports
Media Supported	10 BASE-T - 100 Ohm Category 3, 4, 5 twisted pair 100 BASE-TX - 100 Ohm Category 5 twisted pair
Ports	<ul style="list-style-type: none">• 12/24 10/100 Autosensing RJ-45 Ethernet ports• Port 1 can be set to normal (MDI -X) or uplink (MDI) mode
LED indicators	Port status, port link, port partition, collision, activity, 10/100 Mb/s traffic, and power.
Dimensions	482.6 x 204 x 44 mm (19 x 8 x 1.72 inches)
Weight	2.1 kg (4.6 lb)
Input Power	Full range power input: 100 to 240 V AC 50 to 60 Hz
Power Consumption	2.0 A max. @ 100-240 V AC
Heat Dissipation	92.1 BTU/hr max. @ 100-240 V AC
Operating Temperature	0°C to 40°C (32°F to 104°F)
Operating Humidity	80% maximum humidity, noncondensing

Table A-1. Product Specifications (continued)

Item	Description
Certification Emissions Immunity Safety	CE Mark FCC Class A, VCCI Class A, CISPR Class A, BCIQ, AZ/NZS Class A IEC 1000-4-2/3/4/6 CSA/NRTL, TUV/GS, NOM, UL
Internal Switching Specifications	
Network Bridging Function	Filtering, forwarding, and learning
Switching Method	Store-and-forward
Address Table	8K entries
Queue Buffer	512K bytes
Filtering Rate	Line speed
Forwarding Rate	Line speed

Appendix B

Cable and Connector Information

Port Assignments

RJ-45 Ports

This section describes MDI/MDI-X modes and their associated ports, and provides details regarding RJ-45 port pin assignments.

MDI/MDI-X Ports

You can attach the RJ-45 MDI-X ports on the hub to any device, such as routers, servers, or workstations, that uses a standard network interface.

You can daisy-chain RJ-45 MDI ports on the hub to a port on similar networking devices, such as switches or other hubs.

RJ-45 Pin Assignments

[Figure B-1](#) shows the pin assignments in the RJ-45 connector.




Figure B-1. RJ-45 Pin Assignments

[Table B-1](#) describes the pin assignments.

Table B-1. RJ-45 Pin Descriptions

Pin Number	Assignment (Station Ports 1 through 12 or 24)	Assignment (Daisy-Chain Port, other Devices)
1	Input Receive Data +	Output Transmit Data +
2	Input Receive Data -	Output Transmit Data -
3	Output Transmit Data +	Input Receive Data +
6	Output Transmit Data -	Input Receive Data -
4, 5, 7, 8	Not used	Not used

Cable Assignments

You can use unshielded twisted-pair (UTP) or shielded twisted-pair (STP) cable to connect to RJ-45 ports.

Use the following cable categories, depending on the type of Ethernet transmissions on your device.

- 10 BASE-T - 100 Ohm Category 3, 4, 5 twisted pair
- 100 BASE-TX - 100 Ohm Category 5 twisted pair

[Figure B-2](#) shows schematics for straight-through and crossover twisted-pair cables.




Figure B-2. Cable Schematics

A

applications

- 10 or 100 Mb/s only environments, 2-1
- basic mixed network, 2-2
- expanded mixed network, 2-3
- mixed 10 and 100 Mb/s environments, 2-1

autopartitioning, 1-5

autosense capability, overview, 1-2

B

bridging, 2-4

C

cable length, between hubs, 4-1

cable schematics, B-2

cable types

- for 10 Mb/s Ethernet connections, 3-4
- for 100 Mb/s Ethernet connections, 3-4
- using with MDI/MDI-X modes, 3-3

compliance certifications, A-2

connections

- daisy-chaining, 2-4
- power cord, 1-6, 3-5
- with an MDI port, 3-5

customer support, xvi

D

daisy-chain connection, 2-4

E

environmental requirements, 1-6

F

front panel

- BayStack 60-12T 10/100 Ethernet Hub, 1-2
- BayStack 60-24T 10/100 Ethernet Hub, 1-3

I

installation

- connecting to other devices, 3-3
- mounting the hub in a standard equipment rack, 3-2

L

LEDs

- description, 1-4
- diagnosing indicators, 4-2
- indicators, 4-2
- port status descriptions, 3-6
- port status overview, 3-6

M

MDI port, 3-5

MDI/MDI-X button, 1-6

modes

- MDI/MDI-X, 1-5
- normal, 1-5
- uplink, 1-6

N

normal mode, 1-5

P

port partitioning, 1-5

port status LED descriptions, 3-6

ports

- normal, 1-5

- RJ-45, B-1

- uplink, 1-5

power, applying to hub, 3-5

product support, xvi

publications

- hard copy, xvi

R

rear panel, 1-6

RJ-45 ports

- connecting, 3-4

- MDI/MDI-X, B-1

- pin

 - assignments, B-1

 - descriptions, B-2

S

straight-through cable, 1-5

support, Nortel Networks, xvi

T

technical publications, xvi

technical support, xvi

U

uplink mode, 1-6

V

verifying system operations, 4-1

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>