

Start Here


Here's what you'll do with this guide:

- Charge and set up your handheld.
- Install Palm® Desktop software, software for photos, music, and more.
- Synchronize your handheld with your computer.

Important! Already use a Palm OS® handheld?


Before going on to step 1, synchronize your current handheld with your computer so that the information is up-to-date.

For more information on upgrading, go to www.palmOne.com/support/zire72.



1 Connect and charge

- Plug the power adapter into your Zire 72 handheld and into an outlet. Do not connect the HotSync cable to your handheld until later.
- Charge for **three hours**. Be sure to fully charge your handheld before going on to the next step



2 Set up

- (Optional) Unplug the power adapter from your handheld.
- Press the power button.
- Remove the stylus.
- Follow the instructions onscreen.



Problems? See Troubleshooting below.

3 Install software and connect handheld to computer


To install Palm Desktop software and software for other features like photos and music, insert the CD into your computer's CD drive.

Windows:

Follow the installation instructions that appear on your computer screen.

Mac:

Double-click the CD icon, and then double-click the Palm Desktop Installer icon.




Already use a Palm OS handheld?

Want to synchronize with Microsoft Outlook? Select "Change your synchronization method" at the end of the installation process on the CD.

When instructed during installation, connect your handheld to your computer.

- Plug the HotSync cable into a USB port on your computer.
- Plug this cable into your handheld.



Problems? See Troubleshooting below.

Learn More



Learn the basics

- **Start with a tour.** If you haven't done it already, take the Quick Tour on your handheld, and practice Graffiti® 2 writing.
- **Take the interactive tutorial on the CD.** Learn how to create an appointment, set up your handheld's multimedia features, synchronize your info, and much more.



Get more detail

- **Get more with Getting Started.** This guide gives you step-by-step info, tips, and links to more info on the web. Open Palm Desktop software on your computer. Then click the Help menu and select *Getting Started*.
- **Take Getting Started with you.** Go to the Additional Software section on the CD and follow instructions to transfer this guide to your handheld.



Master your handheld

- **Explore the User Guide.** This guide has everything from *Getting Started* and more: all the steps, all the details, all the tips. Follow the links in *Getting Started* on your computer to the *User Guide* on the web. Or go directly to www.palmOne.com/zire72-userguide.



Expand your know-how

- **Visit My Handheld on the palmOne web site.** For great tips, software, accessories, and more, visit www.palmOne.com/myzire72.
- **Find answers to questions.** If you can't solve your problem with *Getting Started* or the *User Guide*, go to www.palmOne.com/support/zire72.

Troubleshooting

► Support information is also available at www.palmOne.com/support/zire72

► Your handheld does not turn on, or does not respond when you tap it

1. Try turning it on by pressing one of the application buttons on the front panel.
2. Do a soft reset: Use the stylus to gently press the reset button inside the hole on the back of the handheld.
3. Make sure the power adapter is firmly connected to the handheld and to a working electric outlet. Charge for another three full hours.

► Palm Desktop Installer does not start when you put the CD into the drive

Windows:

1. Click the Start button and select Run.
2. Click Browse to locate the drive with the Palm Desktop software CD.
3. Double-click autorun.exe on the CD.

Mac:

1. Double-click the CD icon on the Mac desktop.
2. Double-click the Palm Desktop Installer icon.

► Synchronization does not begin

Be sure the HotSync cable is connected to your handheld and to a working USB port on your computer. Follow these steps to check both your computer and your handheld:

Check your computer:


Windows:

1. Make sure the HotSync icon appears in the group of icons in the lower-right part of your screen.



If not:

- Click the Start button and select Programs.
 - Select Palm Desktop, and then select HotSync Manager.
2. Check the connection type:
 - Disconnect and then reconnect the HotSync cable.
 - Make sure there is a checkmark next to Local USB. If not, click Local USB.




Mac:

1. Make sure the HotSync Manager is enabled:
 - Double-click the HotSync Manager icon in the palmOne folder.
 - In the HotSync Controls tab, click Enabled.
2. Make sure the USB connection is working:
 - Disconnect and then reconnect the HotSync cable.
 - Restart your computer.

Check your handheld:

Make sure your handheld is on, and then try the following:

1. Tap Home, and then tap HotSync in the application list.
2. In the HotSync application, make sure of the following:
 - Local is highlighted. If it isn't highlighted, tap Local.
 - The phrase Cradle/Cable appears. If not, tap whatever word is there, and then tap Cradle/Cable in the pick list.



3. To start synchronization, tap the HotSync icon in the middle of the screen.


Already use a Palm OS handheld?

Did you load any third-party applications on your previous Palm OS handheld? You'll have to update them if they are not compatible with your new handheld. If any of the following symptoms occur on your new handheld after you synchronize, remove these applications and contact the vendor for updated versions: handheld freezes or resets when you open an application; slow performance; unusual screen display; difficulties using handheld features; uneven sound quality.

Zire™ 72



palmOne™



palmOne, Inc.
400 N. McCarthy Blvd.
Milpitas, CA 95035

Copyright

© 2003 palmOne, Inc. All rights reserved.

palmOne, the palmOne logo, Zire, the Zire logo, and "Z" (Stylized) are among the trademarks or registered trademarks owned by or exclusively licensed to palmOne, Inc. or its subsidiaries. Palm OS, the Palm logo, Graffiti, HotSync, Palm, the Palm Powered logo, and the HotSync logo are trademarks owned by or licensed to PalmSource, Inc. All other brand and product names are or may be trademarks of, and are used to identify products or services of their respective owners.

Disclaimer and Limitation of Liability

palmOne, Inc. assumes no responsibility for any damage or loss resulting from the use of this guide.

palmOne, Inc. assumes no responsibility for any loss or claims by third parties which may arise through use of this software. palmOne, Inc. assumes no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of all important data on other media to protect against data loss.

IMPORTANT

Please read the End User Software License Agreement with this product before using the accompanying software program(s). Using any part of the software indicates that you accept the terms of the End User Software License Agreement.

Software Download Available

Palm® Desktop software is available on CD. Check www.palmOne.com for updates and new versions of the software.

Agency Compliance Information

Product regulatory and compliance information can be found in the *User Guide* at www.palmOne.com/zire72-userguide.

Zire™ 72

palmOne

Read This First



PN: 405-6297A-US

Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>