

Service  
Service  
**Service**



# Service Manual

| Contents   | Page                           |
|--|--------------------------------|
| <a href="#">1. Revision List</a>                                   | <a href="#">2</a>              |
| <a href="#">2. Technical Specifications and Connections</a>        | <a href="#">2</a>              |
| <a href="#">3. Precautions, Notes, and Abbreviation List</a>       | <a href="#">6</a>              |
| <a href="#">4. Mechanical Instructions</a>                         | <a href="#">10</a>             |
| <a href="#">5. Service Modes, Error Codes, and Fault Finding</a>   | <a href="#">15</a>             |
| <a href="#">6. Alignments</a>                                      | <a href="#">36</a>             |
| <a href="#">7. Circuit Descriptions</a>                            | <a href="#">42</a>             |
| <a href="#">8. IC Data Sheets</a>                                  | <a href="#">53</a>             |
| <a href="#">9. Block Diagrams</a>                                  |                                |
| <a href="#">Wiring Diagram 32" (Elite Core)</a>                    | <a href="#">59</a>             |
| <a href="#">Wiring Diagram 37" (Elite Core)</a>                    | <a href="#">60</a>             |
| <a href="#">Block Diagram Video</a>                                | <a href="#">62</a>             |
| <a href="#">Block Diagram Audio</a>                                | <a href="#">63</a>             |
| <a href="#">Block Diagram Control &amp; Clock Signals</a>          | <a href="#">64</a>             |
| Block Diagram I2C  | <a href="#">65</a>             |
| <a href="#">Supply Lines Overview</a>                              | <a href="#">66</a>             |
| <a href="#">10. Circuit Diagrams and PWB Layouts</a>               | <i>Drawing PWB</i>             |
| <a href="#">Interface Ambilight: Interface + Single DC-DC(AB1)</a> | <a href="#">67 70</a>          |
| <a href="#">Interface Ambilight: Dual DC-DC (AB2)</a>              | <a href="#">68 70</a>          |
| <a href="#">Interface Ambilight: Microcontrollerblock (AB3)</a>    | <a href="#">69 70</a>          |
| <a href="#">6 LED Low-Pow: Microcontroller Block Liteon(AL1)</a>   | <a href="#">71 74</a>          |
| <a href="#">6 LED Low-Pow: Microcontroller Block Liteon(AL2)</a>   | <a href="#">72 74</a>          |
| <a href="#">6 LED Low-Pow: LED Liteon (AL3)</a>                    | <a href="#">73 74</a>          |
| <a href="#">8 LED Low-Pow: Microcontroller Block Liteon(AL1)</a>   | <a href="#">75 79</a>          |
| <a href="#">8 LED Low-Pow: Microcontroller Block Liteon(AL2)</a>   | <a href="#">76 79</a>          |
| <a href="#">8 LED Low-Pow: LED Liteon (AL3)</a>                    | <a href="#">77 79</a>          |
| <a href="#">8 LED Low-Pow: LED Drive Liteon (AL4)</a>              | <a href="#">78 79</a>          |
| <a href="#">10 LED Low-Pow: Microcontroller Block Liteon(AL1)</a>  | <a href="#">80 84</a>          |
| <a href="#">10 LED Low-Pow: Microcontroller Block Liteon(AL2)</a>  | <a href="#">81 84</a>          |
| <a href="#">10 LED Low-Pow: LED Liteon (AL3)</a>                   | <a href="#">82 84</a>          |
| <a href="#">10 LED Low-Pow: LED Drive Liteon (AL4)</a>             | <a href="#">83 84</a>          |
| SSB (B01A-B10)   | <a href="#">85-133 137-138</a> |
| <a href="#">SSB: SRP List Explanation</a>                          | <a href="#">134</a>            |
| <a href="#">SSB: SRP List Part 1</a>                               | <a href="#">135</a>            |

| Contents                             | Page                    |
|--------------------------------------|-------------------------|
| <a href="#">SSB: SRP List Part 2</a> | <a href="#">136</a>     |
| <a href="#">Light guide</a>          | <a href="#">139 140</a> |
| <a href="#">Wi-Fi Antenna</a>        | <a href="#">141 141</a> |

©Copyright 2009 Koninklijke Philips Electronics N.V.  
All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise without the prior permission of Philips.

# 1. Revision List

## Manual xxxx xxx xxxx.0

- First release.

## Manual xxxx xxx xxxx.1

- **All Chapters:** the following sets to the manual: see [Table 2-1 Described Model numbers](#).
- **Chapter 5:** paragraph [5.8.10 PCI bus](#) added.
- **Chapter 6:** paragraph [6.6 Service SSB delivered without main software loaded](#) added.

# 2. Technical Specifications and, Connections

## Index of this chapter:

- [2.1 Technical Specifications](#)
- [2.2 Directions for Use](#)
- [2.3 Connections](#)
- [2.4 Chassis Overview](#)

## Notes:

- Figures can deviate due to the different set executions.
- Specifications are indicative (subject to change).

## 2.1 Technical Specifications

For on-line product support please use the links in [Table 2-1](#). Here is product information available, as well as getting started, user manuals, frequently asked questions and software & drivers.

**Table 2-1 Described Model numbers**


| CTN                           | Styling    | Published in:  |
|-------------------------------|------------|----------------|
| <a href="#">32PFL9604H/12</a> | Elite Core | 3122 785 18310 |
| <a href="#">32PFL9604H/60</a> |            | 3122 785 18310 |
| <a href="#">37PFL9604H/12</a> |            | 3122 785 18310 |
| <a href="#">37PFL9604H/60</a> |            | 3122 785 18311 |
| <a href="#">56PFL9954H/12</a> |            | 3122 785 18311 |

## 2.2 Directions for Use

You can download this information from the following websites:

- <http://www.philips.com/support>
- <http://www.p4c.philips.com>

2.3 Connections




18310\_001\_090317.eps  
090317

Figure 2-1 Connection overview




**Note:** The following connector colour abbreviations are used (acc. to DIN/IEC 757): Bk= Black, Bu= Blue, Gn= Green, Gy= Grey, Rd= Red, Wh= White, Ye= Yellow.

**2.3.1 Side Connections**





**Head phone (Output)**

Bk - Head phone 32 - 600 ohm / 10 mW 

**Cinch: Video CVBS - In, Audio - In**

Rd - Audio R 0.5 V<sub>RMS</sub> / 10 kohm   
 Wh - Audio L 0.5 V<sub>RMS</sub> / 10 kohm   
 Ye - Video CVBS 1 V<sub>PP</sub> / 75 ohm 

**S-Video (Hosiden): Video Y/C - In**

1 - Ground Y Gnd   
 2 - Ground C Gnd   
 3 - Video Y 1 V<sub>PP</sub> / 75 ohm   
 4 - Video C 0.3 V<sub>PP</sub> / 75 ohm 

**USB2.0**






Figure 2-2 USB (type A)

1 - +5V   
 2 - Data (-)   
 3 - Data (+)   
 4 - Ground Gnd 




**HDMI: Digital Video, Digital Audio - In**  
 (see HDMI 1, 2, 3 & 4 - Rear Connections)

**Common Interface**

68p - See diagram B07A [SSB: CI: PCMCIA Connector](#) 

**2.3.2 Rear Connections**

**Service Connector (UART)**

1 - Ground Gnd   
 2 - UART\_TX Transmit   
 3 - UART\_RX Receive 

**VGA: Video RGB - In**




















Figure 2-3 VGA Connector

1 - Video Red 0.7 V<sub>PP</sub> / 75 ohm   
 2 - Video Green 0.7 V<sub>PP</sub> / 75 ohm   
 3 - Video Blue 0.7 V<sub>PP</sub> / 75 ohm   
 4 - n.c.  
 5 - Ground Gnd   
 6 - Ground Red Gnd   
 7 - Ground Green Gnd   
 8 - Ground Blue Gnd   
 9 - +5V<sub>DC</sub> +5 V   
 10 - Ground Sync Gnd   
 11 - n.c.  
 12 - DDC\_SDA DDC data   
 13 - H-sync 0 - 5 V   
 14 - V-sync 0 - 5 V   
 15 - DDC\_SCL DDC clock 






**Cinch: S/PDIF - Out**

Bk - Coaxial 0.4 - 0.6V<sub>PP</sub> / 75 ohm 

**Cinch: Audio - Out**

Rd - Audio - R 0.5 V<sub>RMS</sub> / 10 kohm   
 Wh - Audio - L 0.5 V<sub>RMS</sub> / 10 kohm 

**EXT3: Cinch: Video YPbPr - In, Audio - In**

Gn - Video Y 1 V<sub>PP</sub> / 75 ohm   
 Bu - Video Pb 0.7 V<sub>PP</sub> / 75 ohm   
 Rd - Video Pr 0.7 V<sub>PP</sub> / 75 ohm   
 Rd - Audio - R 0.5 V<sub>RMS</sub> / 10 kohm   
 Wh - Audio - L 0.5 V<sub>RMS</sub> / 10 kohm 

**EXT1 & 2: Video RGB - In, CVBS - In/Out, Audio - In/Out**
























Figure 2-4 SCART connector

1 - Audio R 0.5 V<sub>RMS</sub> / 1 kohm   
 2 - Audio R 0.5 V<sub>RMS</sub> / 10 kohm   
 3 - Audio L 0.5 V<sub>RMS</sub> / 1 kohm   
 4 - Ground Audio Gnd   
 5 - Ground Blue Gnd   
 6 - Audio L 0.5 V<sub>RMS</sub> / 10 kohm   
 7 - Video Blue 0.7 V<sub>PP</sub> / 75 ohm   
 8 - Function Select 0 - 2 V: INT 4.5 - 7 V: EXT 16:9 9.5 - 12 V: EXT 4:3   
 9 - Ground Green Gnd   
 10 - n.c.  
 11 - Video Green 0.7 V<sub>PP</sub> / 75 ohm   
 12 - n.c.  
 13 - Ground Red Gnd   
 14 - Ground P50 Gnd   
 15 - Video Red 0.7 V<sub>PP</sub> / 75 ohm   
 16 - Status/FBL 0 - 0.4 V: INT 1 - 3 V: EXT / 75 ohm   
 17 - Ground Video Gnd   
 18 - Ground FBL Gnd   
 19 - Video CVBS/Y 1 V<sub>PP</sub> / 75 ohm   
 20 - Video CVBS 1 V<sub>PP</sub> / 75 ohm   
 21 - Shield Gnd 

**Aerial - In**

- - IEC-type (EU) Coax, 75 ohm 

**RJ45: Ethernet (if present)**










Figure 2-5 Ethernet connector

1 - TD+ Transmit signal   
 2 - TD- Transmit signal   
 3 - RD+ Receive signal   
 4 - CT Centre Tap: DC level fixation  
 5 - CT Centre Tap: DC level fixation  
 6 - RD- Receive signal   
 7 - GND Gnd   
 8 - GND Gnd 



**Cinch: Audio - In (VGA/DVI)**

Rd - Audio R      0.5 V<sub>RMS</sub> / 10 kohm  
 Wh - Audio L      0.5 V<sub>RMS</sub> / 10 kohm



**HDMI 1, 2, 3 & 4: Digital Video, Digital Audio - In**





Figure 2-6 HDMI (type A) connector

1 - D2+      Data channel  
 2 - Shield      Gnd  
 3 - D2-      Data channel  
 4 - D1+      Data channel



5 - Shield      Gnd  
 6 - D1-      Data channel  
 7 - D0+      Data channel  
 8 - Shield      Gnd  
 9 - D0-      Data channel  
 10 - CLK+      Data channel  
 11 - Shield      Gnd  
 12 - CLK-      Data channel  
 13 - Easylink/CEC      Control channel  
 14 - n.c.  
 15 - DDC\_SCL      DDC clock  
 16 - DDC\_SDA      DDC data  
 17 - Ground      Gnd  
 18 - +5V  
 19 - HPD      Hot Plug Detect  
 20 - Ground      Gnd



**2.4 Chassis Overview**

Refer to chapter [Block Diagrams](#) for PWB/CBA locations.

## 3. Precautions, Notes, and Abbreviation List

### Index of this chapter:

[3.1 Safety Instructions](#)

[3.2 Warnings](#)

[3.3 Notes](#)

[3.4 Abbreviation List](#)

### 3.1 Safety Instructions

Safety regulations require the following **during** a repair:

- Connect the set to the Mains/AC Power via an isolation transformer (> 800 VA).
- Replace safety components, indicated by the symbol ▲, only by components identical to the original ones. Any other component substitution (other than original type) may increase risk of fire or electrical shock hazard. Of de set ontploft!

Safety regulations require that **after** a repair, the set must be returned in its original condition. Pay in particular attention to the following points:

- Route the wire trees correctly and fix them with the mounted cable clamps.
- Check the insulation of the Mains/AC Power lead for external damage.
- Check the strain relief of the Mains/AC Power cord for proper function.
- Check the electrical DC resistance between the Mains/AC Power plug and the secondary side (only for sets that have a Mains/AC Power isolated power supply):
  1. Unplug the Mains/AC Power cord and connect a wire between the two pins of the Mains/AC Power plug.
  2. Set the Mains/AC Power switch to the "on" position (keep the Mains/AC Power cord unplugged!).
  3. Measure the resistance value between the pins of the Mains/AC Power plug and the metal shielding of the tuner or the aerial connection on the set. The reading should be between 4.5 MΩ and 12 MΩ.
  4. Switch "off" the set, and remove the wire between the two pins of the Mains/AC Power plug.
- Check the cabinet for defects, to prevent touching of any inner parts by the customer.

### 3.2 Warnings

- All ICs and many other semiconductors are susceptible to electrostatic discharges (ESD ▲). Careless handling during repair can reduce life drastically. Make sure that, during repair, you are connected with the same potential as the mass of the set by a wristband with resistance. Keep components and tools also at this same potential.
- Be careful during measurements in the high voltage section.
- Never replace modules or other components while the unit is switched "on".
- When you align the set, use plastic rather than metal tools. This will prevent any short circuits and the danger of a circuit becoming unstable.

### 3.3 Notes

#### 3.3.1 General

- Measure the voltages and waveforms with regard to the chassis (= tuner) ground (⊕), or hot ground (⊖), depending on the tested area of circuitry. The voltages and waveforms shown in the diagrams are indicative. Measure them in the Service Default Mode with a colour bar signal and stereo sound (L: 3 kHz, R: 1 kHz unless stated otherwise) and

picture carrier at 475.25 MHz for PAL, or 61.25 MHz for NTSC (channel 3).

- Where necessary, measure the waveforms and voltages with (⊖) and without (⊕) aerial signal. Measure the voltages in the power supply section both in normal operation (⊕) and in stand-by (⊖). These values are indicated by means of the appropriate symbols.

#### 3.3.2 Schematic Notes

- All resistor values are in ohms, and the value multiplier is often used to indicate the decimal point location (e.g. 2K2 indicates 2.2 kΩ).
- Resistor values with no multiplier may be indicated with either an "E" or an "R" (e.g. 220E or 220R indicates 220 Ω).
- All capacitor values are given in micro-farads ( $\mu = \times 10^{-6}$ ), nano-farads ( $n = \times 10^{-9}$ ), or pico-farads ( $p = \times 10^{-12}$ ).
- Capacitor values may also use the value multiplier as the decimal point indication (e.g. 2p2 indicates 2.2 pF).
- An "asterisk" (\*) indicates component usage varies. Refer to the diversity tables for the correct values.
- The correct component values are listed on the Philips Spare Parts Web Portal.

#### 3.3.3 Spare Parts

For the latest spare part overview, consult your Philips Spare Part web portal.

#### 3.3.4 BGA (Ball Grid Array) ICs

##### Introduction

For more information on how to handle BGA devices, visit this URL: <http://www.atyourservice-magazine.com>. Select "Magazine", then go to "Repair downloads". Here you will find Information on how to deal with BGA-ICs.

##### BGA Temperature Profiles

For BGA-ICs, you **must** use the correct temperature-profile. Where applicable and available, this profile is added to the IC Data Sheet information section in this manual.

#### 3.3.5 Lead-free Soldering

Due to lead-free technology some rules have to be respected by the workshop during a repair:

- Use only lead-free soldering tin. If lead-free solder paste is required, please contact the manufacturer of your soldering equipment. In general, use of solder paste within workshops should be avoided because paste is not easy to store and to handle.
- Use only adequate solder tools applicable for lead-free soldering tin. The solder tool must be able:
  - To reach a solder-tip temperature of at least 400°C.
  - To stabilize the adjusted temperature at the solder-tip.
  - To exchange solder-tips for different applications.
- Adjust your solder tool so that a temperature of around 360°C - 380°C is reached and stabilized at the solder joint. Heating time of the solder-joint should not exceed ~ 4 sec. Avoid temperatures above 400°C, otherwise wear-out of tips will increase drastically and flux-fluid will be destroyed. To avoid wear-out of tips, switch "off" unused equipment or reduce heat.
- Mix of lead-free soldering tin/parts with leaded soldering tin/parts is possible but PHILIPS recommends strongly to **avoid** mixed regimes. If this cannot be avoided, carefully clear the solder-joint from old tin and re-solder with new tin.

### 3.3.6 Alternative BOM identification


It should be noted that on the European Service website, "Alternative BOM" is referred to as "Design variant".

The **third digit** in the serial number (example: AG2B0335000001) indicates the number of the alternative B.O.M. (Bill Of Materials) that has been used for producing the specific TV set. In general, it is possible that the same TV model on the market is produced with e.g. two different types of displays, coming from two different suppliers. This will then result in sets which have the same CTN (Commercial Type Number; e.g. 28PW9515/12) but which have a different B.O.M. number.

By looking at the third digit of the serial number, one can identify which B.O.M. is used for the TV set he is working with. If the third digit of the serial number contains the number "1" (example: AG1B0335000001), then the TV set has been manufactured according to B.O.M. number 1. If the third digit is a "2" (example: AG2B0335000001), then the set has been produced according to B.O.M. no. 2. This is important for ordering the correct spare parts!

For the third digit, the numbers 1...9 and the characters A...Z can be used, so in total: 9 plus 26 = 35 different B.O.M.s can be indicated by the third digit of the serial number.

**Identification:** The bottom line of a type plate gives a 14-digit serial number. Digits 1 and 2 refer to the production centre (e.g. AG is Bruges), digit 3 refers to the B.O.M. code, digit 4 refers to the Service version change code, digits 5 and 6 refer to the production year, and digits 7 and 8 refer to production week (in example below it is 2006 week 17). The 6 last digits contain the serial number.



10000\_024\_090121.eps  
090121

Figure 3-1 Serial number (example)

### 3.3.7 Board Level Repair (BLR) or Component Level Repair (CLR)

If a board is defective, consult your repair procedure to decide if the board has to be exchanged or if it should be repaired on component level.

If your repair procedure says the board should be exchanged completely, do not solder on the defective board. Otherwise, it cannot be returned to the O.E.M. supplier for back charging!

### 3.3.8 Practical Service Precautions

- **It makes sense to avoid exposure to electrical shock.** While some sources are expected to have a possible dangerous impact, others of quite high potential are of limited current and are sometimes held in less regard.
- **Always respect voltages.** While some may not be dangerous in themselves, they can cause unexpected reactions that are best avoided. Before reaching into a powered TV set, it is best to test the high voltage insulation. It is easy to do, and is a good service precaution.

## 3.4 Abbreviation List

|         |  |
|---------|--|
| 0/6/12  | SCART switch control signal on A/V board. 0 = loop through (AUX to TV), 6 = play 16 : 9 format, 12 = play 4 : 3 format                           |
| AARA    | Automatic Aspect Ratio Adaptation: algorithm that adapts aspect ratio to remove horizontal black bars; keeps the original aspect ratio           |
| ACI     | Automatic Channel Installation: algorithm that installs TV channels directly from a cable network by means of a predefined TXT page              |
| ADC     | Analogue to Digital Converter  |
| AFC     | Automatic Frequency Control: control signal used to tune to the correct frequency  |
| AGC     | Automatic Gain Control: algorithm that controls the video input of the feature box   |
| AM      | Amplitude Modulation   |
| AP      | Asia Pacific   |
| AR      | Aspect Ratio: 4 by 3 or 16 by 9  |
| ASF     | Auto Screen Fit: algorithm that adapts aspect ratio to remove horizontal black bars without discarding video information                         |
| ATSC    | Advanced Television Systems Committee, the digital TV standard in the USA  |
| ATV     | See Auto TV  |
| Auto TV | A hardware and software control system that measures picture content, and adapts image parameters in a dynamic way                               |
| AV      | External Audio Video   |
| AVC     | Audio Video Controller   |
| AVIP    | Audio Video Input Processor  |
| B/G     | Monochrome TV system. Sound carrier distance is 5.5 MHz  |
| BLR     | Board-Level Repair   |
| BTSC    | Broadcast Television Standard Committee. Multiplex FM stereo sound system, originating from the USA and used e.g. in LATAM and AP-NTSC countries |
| B-TXT   | Blue TeleteXT  |
| C       | Centre channel (audio)   |
| CEC     | Consumer Electronics Control bus: remote control bus on HDMI connections   |
| CL      | Constant Level: audio output to connect with an external amplifier   |
| CLR     | Component Level Repair   |
| ComPair | Computer aided rePair  |
| CP      | Connected Planet / Copy Protection   |
| CSM     | Customer Service Mode  |
| CTI     | Color Transient Improvement: manipulates steepness of chroma transients  |
| CVBS    | Composite Video Blanking and Synchronization   |
| DAC     | Digital to Analogue Converter  |
| DBE     | Dynamic Bass Enhancement: extra low frequency amplification  |
| DDC     | See "E-DDC"  |
| D/K     | Monochrome TV system. Sound carrier distance is 6.5 MHz  |
| DFI     | Dynamic Frame Insertion  |
| DFU     | Directions For Use: owner's manual   |
| DMR     | Digital Media Reader: card reader  |
| DMSD    | Digital Multi Standard Decoding  |
| DNM     | Digital Natural Motion   |

|                  |  |        |  |
|------------------|--|--------|--|
| DNR              | Digital Noise Reduction: noise reduction feature of the set  |        | uses 8 bit or 10 bit data words, and has a maximum data rate of 270 Mbit/s, with a minimum bandwidth of 135 MHz.   |
| DRAM             | Dynamic RAM  |        |  |
| DRM              | Digital Rights Management  |        |  |
| DSP              | Digital Signal Processing  | ITV    | Institutional TeleVision; TV sets for hotels, hospitals etc.   |
| DST              | Dealer Service Tool: special remote control designed for service technicians   | LS     | Last Status; The settings last chosen by the customer and read and stored in RAM or in the NVM. They are called at start-up of the set to configure it according to the customer's preferences                 |
| DTCP             | Digital Transmission Content Protection; A protocol for protecting digital audio/video content that is traversing a high speed serial bus, such as IEEE-1394   | LATAM  | Latin America  |
| DVB-C            | Digital Video Broadcast - Cable  | LCD    | Liquid Crystal Display   |
| DVB-T            | Digital Video Broadcast - Terrestrial  | LED    | Light Emitting Diode   |
| DVD              | Digital Versatile Disc   | L/L'   | Monochrome TV system. Sound carrier distance is 6.5 MHz. L' is Band I, L is all bands except for Band I  |
| DVI(-d)          | Digital Visual Interface (d= digital only)   |        | LG.Philips LCD (supplier)  |
| E-DDC            | Enhanced Display Data Channel (VESA standard for communication channel and display). Using E-DDC, the video source can read the EDID information from the display.   | LPL    | Loudspeaker  |
| EDID             | Extended Display Identification Data (VESA standard)   | LS     | Low Voltage Differential Signalling  |
| EEPROM           | Electrically Erasable and Programmable Read Only Memory  | LVDS   | Mega bits per second   |
| EMI              | Electro Magnetic Interference  | Mbps   | Monochrome TV system. Sound carrier distance is 4.5 MHz  |
| EPLD             | Erasable Programmable Logic Device   | M/N    | Microprocessor without Interlocked Pipeline-Stages; A RISC-based microprocessor  |
| EU               | Europe   | MIPS   | Matrix Output Processor  |
| EXT              | EXTERNAL (source), entering the set by SCART or by cinches (jacks)   | MOP    | Metal Oxide Silicon Field Effect Transistor, switching device  |
| FDS              | Full Dual Screen (same as FDW)   | MOSFET | Motion Pictures Experts Group  |
| FDW              | Full Dual Window (same as FDS)   | MPEG   | Multi Platform InterFace   |
| FLASH            | FLASH memory   | MPIF   | MUTE Line  |
| FM               | Field Memory or Frequency Modulation   | MUTE   | Not Connected  |
| FPGA             | Field-Programmable Gate Array  | NC     | Near Instantaneous Compounded Audio Multiplexing. This is a digital sound system, mainly used in Europe.   |
| FTV              | Flat TeleVision  | NICAM  | Negative Temperature Coefficient, non-linear resistor  |
| Gb/s             | Giga bits per second   |        | National Television Standard Committee. Color system mainly used in North America and Japan. Color carrier NTSC M/N= 3.579545 MHz, NTSC 4.43= 4.433619 MHz (this is a VCR norm, it is not transmitted off-air) |
| G-TXT            | Green TeleteXT   | NTC    | Non-Volatile Memory: IC containing TV related data such as alignments  |
| H                | H_sync to the module   | NTSC   | Open Circuit   |
| HD               | High Definition  |        | On Screen Display  |
| HDD              | Hard Disk Drive  |        | On screen display Teletext and Control; also called Artistic (SAA5800)   |
| HDCP             | High-bandwidth Digital Content Protection: A "key" encoded into the HDMI/DVI signal that prevents video data piracy. If a source is HDCP coded and connected via HDMI/DVI without the proper HDCP decoding, the picture is put into a "snow vision" mode or changed to a low resolution. For normal content distribution the source and the display device must be enabled for HDCP "software key" decoding. | P50    | Project 50: communication protocol between TV and peripherals  |
| HDMI             | High Definition Multimedia Interface   | PAL    | Phase Alternating Line. Color system mainly used in West Europe (color carrier= 4.433619 MHz) and South America (color carrier PAL M= 3.575612 MHz and PAL N= 3.582056 MHz)                                    |
| HP               | HeadPhone  |        | Printed Circuit Board (same as "PWB")  |
| I                | Monochrome TV system. Sound carrier distance is 6.0 MHz  | PCB    | Pulse Code Modulation  |
| I <sup>2</sup> C | Inter IC bus   | PCM    | Plasma Display Panel   |
| I <sup>2</sup> D | Inter IC Data bus  | PDP    | Power Factor Corrector (or Pre-conditioner)  |
| I <sup>2</sup> S | Inter IC Sound bus   | PFC    | Picture In Picture   |
| IF               | Intermediate Frequency   | PIP    | Phase Locked Loop. Used for e.g. FST tuning systems. The customer can give directly the desired frequency  |
| IR               | Infra Red  | PLL    | Point Of Deployment: a removable CAM module, implementing the CA system for a host (e.g. a TV-set)   |
| IRQ              | Interrupt Request  |        | Power On Reset, signal to reset the uP   |
| ITU-656          | The ITU Radio communication Sector (ITU-R) is a standards body subcommittee of the International Telecommunication Union relating to radio communication. ITU-656 (a.k.a. SDI), is a digitized video format used for broadcast grade video.  | POD    | Positive Temperature Coefficient, non-linear resistor  |
|                  | Uncompressed digital component or digital composite signals can be used. The SDI signal is self-synchronizing,   | POR    | Printed Wiring Board (same as "PCB")   |
|                  |  | PTC    |  |
|                  |  | PWB    |  |

|           |  |       |  |
|-----------|--|-------|--|
| PWM       | Pulse Width Modulation   | Y     | Luminance signal   |
| QRC       | Quasi Resonant Converter   | Y/C   | Luminance (Y) and Chrominance (C) signal                                     |
| QTNR      | Quality Temporal Noise Reduction   |       |  |
| QVCP      | Quality Video Composition Processor  | YPbPr | Component video. Luminance and scaled color difference signals (B-Y and R-Y) |
| RAM       | Random Access Memory   |       |  |
| RGB       | Red, Green, and Blue. The primary color signals for TV. By mixing levels of R, G, and B, all colors (Y/C) are reproduced.        | YUV   | Component video  |
| RC        | Remote Control   |       |  |
| RC5 / RC6 | Signal protocol from the remote control receiver   |       |  |
| RESET     | RESET signal   |       |  |
| ROM       | Read Only Memory   |       |  |
| RSDS      | Reduced Swing Differential Signalling data interface   |       |  |
| R-TXT     | Red TeleteXT   |       |  |
| SAM       | Service Alignment Mode   |       |  |
| S/C       | Short Circuit  |       |  |
| SCART     | Syndicat des Constructeurs d'Appareils Radiorécepteurs et Téléviseurs  |       |  |
| SCL       | Serial Clock I <sup>2</sup> C  |       |  |
| SCL-F     | CLock Signal on Fast I <sup>2</sup> C bus  |       |  |
| SD        | Standard Definition  |       |  |
| SDA       | Serial Data I <sup>2</sup> C   |       |  |
| SDA-F     | DATA Signal on Fast I <sup>2</sup> C bus   |       |  |
| SDI       | Serial Digital Interface, see "ITU-656"  |       |  |
| SDRAM     | Synchronous DRAM   |       |  |
| SECAM     | SEquence Couleur Avec Mémoire. Color system mainly used in France and East Europe. Color carriers= 4.406250 MHz and 4.250000 MHz |       |  |
| SIF       | Sound Intermediate Frequency   |       |  |
| SMPS      | Switched Mode Power Supply   |       |  |
| SoC       | System on Chip   |       |  |
| SOG       | Sync On Green  |       |  |
| SOPS      | Self Oscillating Power Supply  |       |  |
| SPI       | Serial Peripheral Interface bus; a 4-wire synchronous serial data link standard  |       |  |
| S/PDIF    | Sony Philips Digital InterFace   |       |  |
| SRAM      | Static RAM   |       |  |
| SRP       | Service Reference Protocol   |       |  |
| SSB       | Small Signal Board   |       |  |
| STBY      | STand-BY   |       |  |
| SVGA      | 800 × 600 (4:3)  |       |  |
| SVHS      | Super Video Home System  |       |  |
| SW        | Software   |       |  |
| SWAN      | Spatial temporal Weighted Averaging Noise reduction  |       |  |
| SXGA      | 1280 × 1024  |       |  |
| TFT       | Thin Film Transistor   |       |  |
| THD       | Total Harmonic Distortion  |       |  |
| TMDS      | Transmission Minimized Differential Signalling   |       |  |
| TXT       | TeleteXT   |       |  |
| TXT-DW    | Dual Window with TeleteXT  |       |  |
| UI        | User Interface   |       |  |
| uP        | Microprocessor   |       |  |
| UXGA      | 1600 × 1200 (4:3)  |       |  |
| V         | V-sync to the module   |       |  |
| VESA      | Video Electronics Standards Association  |       |  |
| VGA       | 640 × 480 (4:3)  |       |  |
| VL        | Variable Level out: processed audio output toward external amplifier   |       |  |
| VSB       | Vestigial Side Band; modulation method   |       |  |
| WYSIWYR   | What You See Is What You Record: record selection that follows main picture and sound  |       |  |
| WXGA      | 1280 × 768 (15:9)  |       |  |
| XTAL      | Quartz crystal   |       |  |
| XGA       | 1024 × 768 (4:3)   |       |  |

## 4. Mechanical Instructions


### Index of this chapter:

- 4.1 Cable Dressing and Taping
- 4.2 Service Positions
- 4.3 Assy/Panel Removal
- 4.4 Set Re-assembly

### Notes:

- Figures below can deviate slightly from the actual situation, due to the different set executions.


### 4.1 Cable Dressing and Taping



18310\_210\_090318.eps  
090318


Figure 4-1 Cable dressing 32"





18310\_211\_090318.eps  
090318

Figure 4-2 Cable dressing 37"



18311\_200\_090506.eps  
090506

Figure 4-3 Cable dressing 56" (21:9)

## 4.2 Service Positions

For easy servicing of this set, there are a few possibilities created:

- The buffers from the packaging.
- Foam bars (created for Service).

### 4.2.1 Foam Bars




Figure 4-4 Foam bars

The foam bars (order code 3122 785 90580 for two pieces) can be used for all types and sizes of Flat TVs.

See [Figure 4-4](#) for details. Sets with a display of 42" and larger, require **four** foam bars [1]. Ensure that the foam bars are always supporting the cabinet and **never** only the display.

**Caution:** Failure to follow these guidelines can seriously damage the display!

By laying the TV face down on the (ESD protective) foam bars, a stable situation is created to perform measurements and alignments. By placing a mirror under the TV, you can monitor the screen.

## 4.3 Assy/Panel Removal

### 4.3.1 Rear Cover

**Warning:** Disconnect the mains power cord before you remove the rear cover.

**Note:** it is **not** necessary to remove the stand while removing the rear cover.

**Removing the Piezo Touch Control Panel PWB requires special attention. Refer to [Piezo Touch Control Panel](#) for details.**

1. Remove all screws of the rear cover.
2. Lift the rear cover from the TV. Make sure that wires and flat coils are not damaged while lifting the rear cover from the set.


### 4.3.2 Speakers

Each speaker unit is mounted with two screws. A sticker on the unit indicates if it is the right ("R") or left ("L") box, seen from the front side of the set.

When defective, replace the whole unit.

### 4.3.3 Ambi Light

Each Ambi Light unit is mounted on a subframe. Refer to [Figure 4-5](#) for details.



18310\_212\_090318.eps  
090319

Figure 4-5 Ambi Light unit

1. Remove the Ambi Light cover [1].
2. Unplug the connector(s).
3. The PWB can now be taken from the subframe.

When defective, replace the whole unit.

**Note:** the screws that secure the AmbiLight units are longer than the other screws.


### 4.3.4 Main Supply Panel

1. Unplug all connectors.
2. Remove the fixation screws.
3. Take the board out.

When defective, replace the whole unit.

### 4.3.5 IR & LED Board

Refer to [Figure 4-6](#) for details.



18310\_213\_090318.eps  
090319

Figure 4-6 IR & LED Board




1. Remove the Main Supply Panel as earlier described.
2. Remove the stand [1] and its subframe [2].
3. Now you gain access the IR & LED board.  
When defective, replace the whole unit.

#### 4.3.6 Piezo Touch Control Panel

**The flexfoil between Piezo Flexfoil Assy (mounted on the plastic rim of the set), and the PWB as described below, is extremely vulnerable. Do not pull hard at the PWB or flexfoil.**

**Once the flexfoil has been damaged, the entire plastic rim of the set (with the touch-control pads) has to be swapped!**


The Piezo Touch Control Panel PWB contains ESD sensitive components, implying that necessary industrial ESD precautions must be taken during removing or remounting. Refer to [Figure 4-7](#), [Figure 4-8](#) and [Figure 4-9](#) for details.



18310\_214\_090318.eps  
090319

**Figure 4-7 Piezo Touch Control Panel -1-**

1. Gently pull the bottom side of the PWB out of the cabinet until you can unplug the connector [1].



18310\_216\_090318.eps  
090319

**Figure 4-8 Piezo Touch Control Panel -2-**

1. Now gently pull the top side of the PWB out of the cabinet **without damaging the flexfoil** until you can unplug the connector [2].



18310\_215\_090318.eps  
090319

**Figure 4-9 Piezo Touch Control Panel -3-**

1. To unplug the flexfoil connector, first the outer part of the connector has to be moved upwards [3], before this part can be turned sideways [4] as shown in the picture. Now the flexfoil can be removed from the connector and the PWB can be taken out of the set.

When defective, replace the whole unit.

#### 4.3.7 Small Signal Board (SSB)

**Caution:** It is mandatory to remount screws at their original position during re-assembly. Failure to do so may result in damaging the SSB.

1. Remove the Wi-Fi module that is mounted on the SSB.
2. Unplug all connectors.
3. Remove the screws that secure the board.
4. The SSB can now be taken out of the set.

#### 4.3.8 LCD Panel

Refer to [Figure 4-10](#) and [Figure 4-11](#) for details.

1. Remove the Piezo Touch Control Panel PWB as earlier described.
2. Remove the AL covers as earlier described.
3. Remove both Main Supply Panel and SSB as earlier described.
4. Remove the subframes of Main Power Supply and SSB [1].
5. Remove both AL subframes (with the AL unit still mounted on it) by unplugging the connector [2] and removing the screws [3].
6. Remove all remaining adhesive tapes and remove all cables from their clamps.
7. Carefully remove the conducting tape [4], it must be re-used during re-assembly!
8. Remove the remaining screws (indicated with an arrow) that hold the plastic rim and remove the rim.
9. Now the LCD Panel can be lifted from the front cabinet. **The panel has to be slid downwards** once it has been lifted, because the brackets on the top cannot be removed from the cabinet. You will see a conducting foam between metal front and panel, near the location of the Piezo Touch Control Panel.

When mounting a new LCD Panel:

1. Check if this conducting foam between panel and metal front is in place !
2. Re-attach the conducting tape between LCD Panel and metal rim [4] !


18310\_217\_090318.eps  
090319

Figure 4-10 LCD Panel -1-


18310\_218\_090318.eps  
090319

Figure 4-11 LCD Panel -2-

#### 4.3.9 Wi-Fi antenna

Follow the instructions for [LCD Panel](#) until "remove plastic rim". After removal of this rim, you gain access to the Wi-Fi antennas.

#### 4.4 Set Re-assembly

To re-assemble the whole set, execute all processes in reverse order.

##### Notes:

- While re-assembling, make sure that all cables are placed and connected in their original position.
- Pay special attention not to damage the EMC foams in the set. Ensure that EMC foams are mounted correctly.

# 5. Service Modes, Error Codes, and Fault Finding

**Index of this chapter:**

- 5.1 Test Points
- 5.2 Service Modes
- [5.3 Stepwise Start-up](#)
- [5.4 Service Tools](#)
- [5.5 Error Codes](#)
- [5.6 The Blinking LED Procedure](#)
- [5.7 Protections](#)
- [5.8 Fault Finding and Repair Tips](#)
- [5.9 Software Upgrading](#)

## 5.1 Test Points

As most signals are digital, it will be difficult to measure waveforms with a standard oscilloscope. However, several key ICs are capable of generating test patterns, which can be controlled via ComPair. In this way it is possible to determine which part is defective.

Perform measurements under the following conditions:

- Service Default Mode.
- Video: Colour bar signal.
- Audio: 3 kHz left, 1 kHz right.

## 5.2 Service Modes

Service Default mode (SDM) and Service Alignment Mode (SAM) offers several features for the service technician, while the Customer Service Mode (CSM) is used for communication between the call centre and the customer.

This chassis also offers the option of using ComPair, a hardware interface between a computer and the TV chassis. It offers the abilities of structured troubleshooting, error code reading, and software version read-out for all chassis. (see also section "5.4.1 ComPair").

**Note:** For the new model range, a new remote control (RC) is used with some renamed buttons. This has an impact on the activation of the Service modes. For instance the old "MENU" button is now called "HOME" (or is indicated by a "house" icon).

### 5.2.1 Service Default Mode (SDM)

**Purpose**

- To create a pre-defined setting, to get the same measurement results as given in this manual.
- To override SW protections detected by stand-by processor and make the TV start up to the step just before protection (a sort of automatic stepwise start-up). See section "5.3 Stepwise Start-up".
- To start the blinking LED procedure where only LAYER 2 errors are displayed. (see also section "5.5 Error Codes").

**Specifications**

**Table 5-1 SDM default settings**

| Region                | Freq. (MHz)  | Default system |
|-----------------------|--|----------------|
| Europe, AP(PAL/Multi) | 475.25   | PAL B/G        |
| Europe, AP DVB-T      | 546.00 PID<br>Video: 0B 06 PID<br>PCR: 0B 06 PID<br>Audio: 0B 07 | DVB-T          |

- All picture settings at 50% (brightness, colour, contrast).
- All sound settings at 50%, except volume at 25%.

- All service-unfriendly modes (if present) are disabled, like:
  - (Sleep) timer.
  - Child/parental lock.
  - Picture mute (blue mute or black mute).
  - Automatic volume levelling (AVL).
  - Skip/blank of non-favourite pre-sets.


**How to Activate SDM**

For this chassis there are two kinds of SDM: an **analog SDM** and a **digital SDM**. Tuning will happen according [Table 5-1](#).

- **Analog SDM:** use the standard RC-transmitter and key in the code "062596", directly followed by the "MENU" (or HOME) button.
 

**Note:** It is possible that, together with the SDM, the main menu will appear. To switch it "off", push the "MENU"(or HOME) button again.
- **Digital SDM:** use the standard RC-transmitter and key in the code "062593", directly followed by the "MENU" (or HOME) button.
 

**Note:** It is possible that, together with the SDM, the main menu will appear. To switch it "off", push the "MENU" (or HOME) button again.
- **Analog SDM** can also be activated by grounding for a moment the solder pad on the SSB, with the indication "SDM" (see [Service mode pad](#)).



18310\_219\_090318.eps  
090319

**Figure 5-1 Service mode pad**

After activating this mode, "SDM" will appear in the upper right corner of the screen (when a picture is available).

**How to Navigate**

When the "MENU" (or HOME) button is pressed on the RC transmitter, the TV set will toggle between the SDM and the normal user menu.

**How to Exit SDM**

Use one of the following methods:

- Switch the set to STAND-BY via the RC-transmitter.
- Via a standard customer RC-transmitter: key in "00"-sequence.

### 5.2.2 Service Alignment Mode (SAM)

**Purpose**

- To perform (software) alignments.
- To change option settings.
- To easily identify the used software version.



- To view operation hours.
- To display (or clear) the error code buffer.

### How to Activate SAM

Via a standard RC transmitter: Key in the code "062596" directly followed by the "INFO" button. After activating SAM with this method a service warning will appear on the screen, continue by pressing the "OK" button on the RC.

### Contents of SAM (see also [Table 6-4](#))

#### • Hardware Info.

- **A. SW Version.** Displays the software version of the main software (**example:** Q5492-1.2.3.4 = AAAAB\_X.Y.W.Z).
  - **AAAA**= the chassis name.
  - **B**= the SW branch version. This is a sequential number (this is no longer the region indication, as the software is now multi-region).
  - **X.Y.W.Z**= the software version, where X is the main version number (different numbers are not compatible with one another) and Y.W.Z is the sub version number (a higher number is always compatible with a lower number).
- **B. STBY PROC Version.** Displays the software version of the stand-by processor.
- **C. Production Code.** Displays the production code of the TV, this is the serial number as printed on the back of the TV set. Note that if an NVM is replaced or is initialized after corruption, this production code has to be re-written to NVM. ComPair will foresee in a possibility to do this.
- **Operation Hours.** Displays the accumulated total of operation hours (not the stand-by hours). Every time the TV is switched "on/off", 0.5 hours is added to this number.
- **Errors** (followed by maximum 10 errors). The most recent error is displayed at the upper left (for an error explanation see section "[5.5 Error Codes](#)").
- **Reset Error Buffer.** When "cursor right" (or the "OK" button) is pressed and then the "OK" button is pressed, the error buffer is reset.
- **Alignments.** This will activate the "ALIGNMENTS" sub-menu. See Chapter 6. Alignments.
- **Dealer Options.** Extra features for the dealers.
- **Options.** Extra features for Service. For more info regarding option codes, [6. Alignments](#). Note that if the option code numbers are changed, these have to be confirmed with pressing the "OK" button before the options are stored. Otherwise changes will be lost.
- **Initialize NVM.** The moment the processor recognizes a corrupted NVM, the "initialize NVM" line will be highlighted. Now, two things can be done (dependent of the service instructions at that moment):
  - Save the content of the NVM via ComPair for development analysis, **before** initializing. This will give the Service department an extra possibility for diagnosis (e.g. when Development asks for this).
  - Initialize the NVM.

**Note:** When the NVM is corrupted, or replaced, there is a high possibility that no picture appears because the display code is not correct. So, before initializing the NVM via the SAM, a picture is necessary and therefore the correct display option has to be entered. Refer to Chapter [6. Alignments](#) for details. To adapt this option, it's advised to use ComPair (the correct HEX values for the options can be found in Chapter [6. Alignments](#)) or a method via a standard RC (described below).

**Changing the display option via a standard RC:** Key in the code "062598" directly followed by the "MENU" (or HOME) button and "XXX" (where XXX is the 3 digit decimal display code as mentioned in [Table 6-3](#)). Make sure to key in all three digits, also the leading zero's. If the above action is successful, the front LED will go out as an indication that the RC sequence was correct. After the display option is changed in the NVM, the

TV will go to the Stand-by mode. If the NVM was corrupted or empty before this action, it will be initialized first (loaded with default values). This initializing can take up to 20 seconds.




Figure 5-2 Location of Display Option Code sticker

- **Store - go right.** All options and alignments are stored when pressing "cursor right" (or the "OK" button) and then the "OK"-button.
- **SW Maintenance.**
  - **SW Events.** Not useful for Service purposes. In case of specific software problems, the development department can ask for this info.
  - **HW Events.** Not useful for Service purposes. In case of specific software problems, the development department can ask for this info.
- **Operation hours display.** Displays the accumulated total of display operation hours. So, this one keeps up the lifetime of the display itself, mainly to compensate the degeneration behaviour.
- **Test settings.** For development purposes only.
- **Development file versions.** Not useful for Service purposes, this information is only used by the development department.
- **Upload to USB.** To upload several settings from the TV to an USB stick, which is connected to the SSB. The items are "Channel list", "Personal settings", "Option codes", "Display-related alignments" and "History list". **First a directory "repair" has to be created in the root of the USB stick.** To upload the settings select each item separately, press "cursor right" (or the "OK" button), confirm with "OK" and wait until "Done" appears. In case the download to the USB stick was not successful "Failure" will appear. In this case, check if the USB stick is connected properly and if the directory "repair" is present in the root of the USB stick. Now the settings are stored onto the USB stick and can be used to download onto another TV or other SSB. Uploading is of course only possible if the software is running and if a picture is available. This method is created to be able to save the customer's TV settings and to store them into another SSB.
- **Download to USB.** To download several settings from the USB stick to the TV, same way of working needs to be followed as with uploading. To make sure that the download of the channel list from USB to the TV is executed properly, it is necessary to restart the TV and tune to a valid preset if necessary.
 

**Note:** The "History list item" can not be downloaded from USB to the TV. This is a "read-only" item. In case of specific problems, the development department can ask for this info.

### How to Navigate

- In SAM, the menu items can be selected with the "CURSOR UP/DOWN" key on the RC-transmitter. The selected item will be highlighted. When not all menu items fit on the screen, move the "CURSOR UP/DOWN" key to display the next/previous menu items.
- With the "CURSOR LEFT/RIGHT" keys, it is possible to:
  - (De) activate the selected menu item.
  - (De) activate the selected sub menu.

- With the “OK” key, it is possible to activate the selected action.

#### How to Exit SAM

Use one of the following methods:

- Switch the TV set to STAND-BY via the RC-transmitter.
- Via a standard RC-transmitter, key in “00” sequence, or select the “BACK” key.

### 5.2.3 Customer Service Mode (CSM)

#### Purpose

When a customer is having problems with his TV-set, he can call his dealer or the Customer Helpdesk. The service technician can then ask the customer to activate the CSM, in order to identify the status of the set. Now, the service technician can judge the severity of the complaint. In many cases, he can advise the customer how to solve the problem, or he can decide if it is necessary to visit the customer.

The CSM is a read only mode; therefore, modifications in this mode are not possible.

When in this chassis CSM is activated, a testpattern will be displayed during 5 seconds (1 second Blue, 1 second Green and 1 second Red, then again 1 second Blue and 1 second Green). This test pattern is generated by the PNX5100. So if this test pattern is shown, it could be determined that the back end video chain (PNX5100, LVDS, and display) of the SSB is working.

When CSM is activated and there is a USB stick connected to the TV, the software will dump the complete CSM content to the USB stick. The file (Csm.txt) will be saved in the root of the USB stick. This info can be handy if no information is displayed.

Also when CSM is activated, the LAYER 1 error is displayed via blinking LED. Only the latest error is displayed. (see also section [5.5 Error Codes](#)).

#### How to Activate CSM

Key in the code “123654” via the standard RC transmitter.

**Note:** Activation of the CSM is only possible if there is no (user) menu on the screen!

#### How to Navigate

By means of the “CURSOR-DOWN/UP” knob on the RC-transmitter, can be navigated through the menus.

#### Contents of CSM

The contents are reduced to 3 pages: General, Software versions and Quality items. The group names itself are not shown anywhere in the CSM menu.

#### General

- **Set Type.** This information is very helpful for a helpdesk/ workshop as reference for further diagnosis. In this way, it is not necessary for the customer to look at the rear of the TV-set. Note that if an NVM is replaced or is initialized after corruption, this set type has to be re-written to NVM. ComPair will foresee in a possibility to do this.
- **Production Code.** Displays the production code (the serial number) of the TV. Note that if an NVM is replaced or is initialized after corruption, this production code has to be re-written to NVM. ComPair will foresee in a possibility to do this.
- **Installed date.** Indicates the date of the first installation of the TV. This date is acquired via time extraction.
- **Options 1.** Gives the option codes of option group 1 as set in SAM (Service Alignment Mode).
- **Options 2.** Gives the option codes of option group 2 as set in SAM (Service Alignment Mode).
- **12NC SSB.** Gives an identification of the SSB as stored in NVM. Note that if an NVM is replaced or is initialized after corruption, this identification number has to be re-written to

NVM. ComPair will foresee in a possibility to do this. This identification number is the 12nc number of the SSB.

- **12NC display.** Shows the 12NC of the display.
- **12NC supply.** Shows the 12NC of the supply.
- **12NC “fan board”.** Shows the 12NC of the “fan board”-module (for sets with LED backlight)
- **12NC “LED Dimming Panel”.** Shows the 12NC of the LED dimming Panel (for sets with LED backlight).

#### Software versions

- **Current main SW.** Displays the built-in main software version. In case of field problems related to software, software can be upgraded. As this software is consumer upgradeable, it will also be published on the Internet. Example: Q5492\_1.2.3.4
- **Standby SW.** Displays the built-in stand-by processor software version. Upgrading this software will be possible via ComPair or via USB (see section [5.9 Software Upgrading](#)). Example: STDBY\_88.68.1.2.
- **MOP ambient light SW.** Displays the MOP ambient light EPLD SW.
- **LED Dimming SW.** Displays the LED Dimming EPLD SW-version (for sets with LED backlight).
- **Local contrast SW.** Displays the MOP local contrast SW-version.

#### Quality items

- **Signal quality.** Poor / average /good
- **Child lock.** Not active / active. This is a combined item for locks. If any lock (Preset lock, child lock, lock after or parental lock) is active, the item shall show “active”.
- **HDMI HDCP key.** Indicates if the HDMI keys (or HDCP keys) are valid or not. In case these keys are not valid and the customer wants to make use of the HDMI functionality, the SSB has to be replaced.
- **Ethernet MAC address.** Displays the MAC address present in the SSB.
- **Wireless MAC address.** Displays the wireless MAC address to support the Wi-Fi functionality.
- **BDS key.** Indicates if the “BDS level 1” key is valid or not.
- **CI slot present.** If the common interface module is detected the result will be “YES” or “NO”.
- **HDMI input format.** The detected input format of the HDMI.
- **HDMI audio input stream.** The HDMI audio input stream is displayed: present / not present.
- **HDMI video input stream.** The HDMI video input stream is displayed: present / not present.

#### How to Exit CSM

Press “MENU” (or HOME) / “Back” key on the RC-transmitter.


### 5.3 Stepwise Start-up

When the TV is in a protection state due to an error detected by stand-by software (error blinking is displayed) **and** SDM is activated via shortcutting the pins on the SSB, the TV starts up until it reaches the situation just before protection. So, this is a kind of automatic stepwise start-up. In combination with the start-up diagrams below, you can see which supplies are present at a certain moment. Important to know is, that if e.g. the 3V3 detection fails and thus error layer 2 = 18 is blinking while the TV is restarted via SDM, the Stand-by Processor will enable the 3V3, but the TV set will not go to protection now. The TV will stay in this situation until it is reset (Mains/AC Power supply interrupted). **Caution:** in case the start-up in this

mode with a faulty FET 7U08 is done, you can destroy all IC's supplied by the +3V3, due to overvoltage (12V on 3V3-line). It is recommended to measure first the FET 7U08 or others FET's on shortcircuit before activating SDM via the service pads.

The abbreviations "SP" and "MP" in the figures stand for:

- SP: protection or error detected by the **Stand-by Processor**.
- MP: protection or error detected by the **MIPS Main Processor**.



L\_17660\_124.eps  
140308

Figure 5-3 Transition diagram





Figure 5-4 "Off" to "Semi Stand-by" flowchart (part 1)



L\_17660\_125b.eps 140308

Figure 5-5 "Off" to "Semi Stand-by" flowchart (part 2)




**Constraints taken into account:**

- Display may only be started when valid LVDS output clock can be delivered by the AVC .
- Between 5 and 50 ms after power is supplied, display should receive valid lvds clock .
- minimum wait time to switch on the lamp after power up is 200ms.

action holder: AVC

action holder: St-by

autonomous action



L\_17660\_126.eps  
140308

Figure 5-6 “Semi Stand-by” to “Active” flowchart


**Constraints taken into account:**

- Display may only be started when valid LVDS output clock can be delivered by the AVC .
- Between 5 and 50 ms after power is supplied, display should receive valid lvds clock .
- minimum wait time to switch on the lamp after power up is 200ms.
- To have a reliable operation of the backlight, the backlight should be driven with a PWM duty cycle of 100% during the first second. Only after this first one or two seconds, the PWM may be set to the required output level (Note that the PWM output should be present before the backlight is switched on). To minimize the artefacts, the picture should only be unblanked after these first seconds.

action holder: AVC


action holder: St-by

autonomous action



L\_17660\_127.eps  
140308

Figure 5-7 “Semi Stand-by” to “Active” flowchart LCD with preheat



L\_17660\_128.eps  
140308

Figure 5-8 "Semi Stand-by" to "Active" flowchart (LED backlight)




Figure 5-9 "Active" to "Semi Stand-by" flowchart (LCD non DFI)




Figure 5-10 “Semi Stand-by” to “Stand-by” flowchart




Figure 5-11 "To Protection State" flowchart

## 5.4 Service Tools

### 5.4.1 ComPair

#### Introduction

ComPair (Computer Aided Repair) is a Service tool for Philips Consumer Electronics products. and offers the following:

1. ComPair helps to quickly get an understanding on how to repair the chassis in a short and effective way.
2. ComPair allows very detailed diagnostics and is therefore capable of accurately indicating problem areas. No knowledge on I<sup>2</sup>C or UART commands is necessary, because ComPair takes care of this.
3. ComPair speeds up the repair time since it can automatically communicate with the chassis (when the uP is working) and all repair information is directly available.
4. ComPair features TV software up possibilities.

#### Specifications

ComPair consists of a Windows based fault finding program and an interface box between PC and the (defective) product. The ComPair II interface box is connected to the PC via an USB cable. For the TV chassis, the ComPair interface box and the TV communicate via a bi-directional cable via the service connector(s).

The ComPair fault finding program is able to determine the problem of the defective television, by a combination of automatic diagnostics and an interactive question/answer procedure.

#### How to Connect

This is described in the chassis fault finding database in ComPair.




Figure 5-12 ComPair II interface connection

**Caution:** It is compulsory to connect the TV to the PC as shown in the picture above (with the ComPair interface in between), as the ComPair interface acts as a level shifter. If one connects the TV directly to the PC (via UART), ICs will be blown!

#### How to Order

ComPair II order codes:

- ComPair II interface: 3122 785 91020.
- Software is available via the Philips Service web portal.
- ComPair UART interface cable for Q54x.x. (using 3.5 mm Mini Jack connector): 3138 188 75051.

**Note:** While encountering problems, contact the local support desk.

### 5.4.2 Memory and Audio Test

With this tool you can test the memory of the PNX8543, as well if the PNX5100 is enabled and audio-testing.

#### What is needed?

- An USB-stick
- “TESTSCRIPT Q549”. Downloadable from the Philips Service website from the section “Software for Service only”
- A ComPair/service cable (3138 188 75051).

#### Procedure

Create a directory “JETTFILES” under the root of the USB-stick

- Place “MemTestTV543.bin” and “autojett.bin” (available in “TESTSCRIPT Q549”) under the directory “JETTFILES”
- Install the computer program “BOARDTESTLOGGER” (available in “TESTSCRIPT Q549”) on the PC
- Connect a “ComPair/service”-cable from the service-connector in the set, into the “multi function” jack at the front of the ComPair II box :  
Required settings in ComPair :  
- start up the ComPair application.  
- Select the correct database (open file “Q549.2E LA”, this will set the ComPair interface in the appropriate mode).  
- Close ComPair
- Start up the program “BOARDTESTLOGGER” and select “COMx”
- Put the USB stick into the TV and start up the TV while pressing the “i+”-button on a Philips DVD RC6 remote control (it’s also possible to use a TV remote in “DVD”-mode)
- On the PC the memory test is shown now. This is also visible on the TV screen.
- In “BOARDTESTLOGGER” an option “Send extra UART command” can be found where you can select “AUD1”. This command generates hear test tones of 200, 400, 1000, 2000, 3000, 5000, 8000 and 12500Hz.

## 5.5 Error Codes

### 5.5.1 Introduction

The error code buffer contains all detected errors since the last time the buffer was erased. The buffer is written from left to right, new errors are logged at the left side, and all other errors shift one position to the right.

When an error occurs, it is added to the list of errors, provided the list is not full. When an error occurs and the error buffer is full, then the new error is not added, and the error buffer stays intact (history is maintained).

To prevent that an occasional error stays in the list forever, the error is removed from the list after more than 50 hrs. of operation.

When multiple errors occur (errors occurred within a short time span), there is a high probability that there is some relation between them.

New in this chassis is the way errors can be displayed:

- There is a simple blinking LED procedure for board level repair (home repair) so called LAYER 1 errors next to the existing errors which are LAYER 2 errors (see [Table 5-2](#)).
    - LAYER 1 errors are one digit errors.
    - LAYER 2 errors are 2 digit errors.
  - In protection mode.
    - From consumer mode: **LAYER 1**.
    - From SDM mode: **LAYER 2**.
  - **Fatal errors, if I2C bus is blocked and the set reboots, CSM and SAM are not selectable.**
    - From consumer mode: **LAYER 1**.
    - From SDM mode: **LAYER 2**.
- Important remark:

For all errors detected by MIPS which are fatal => rebooting of the TV set (reboot starts after LAYER 1 error blinking), one should short the solder paths (SDM) at start-up from the power OFF state by mains interruption and not via the power button to trigger the SDM via the hardware pins.

- In CSM mode
  - When entering CSM: error **LAYER 1** will be displayed by blinking LED. Only the latest error is shown.
- In SDM mode
  - When SDM is entered via Remote Control code or the hardware pins, **LAYER 2** is displayed via blinking LED.
- In the ON state
  - In “Display error mode”, set with the RC commands “mute\_06250X\_OK” **LAYER 2** errors are displayed via blinking LED.
- Error display on screen.
  - In CSM no error codes are displayed on screen.
  - In SAM the complete error list is shown.

Basically there are three kinds of errors:

- **Errors detected by the Stand-by software which lead to protection.** These errors will always lead to protection and an automatic start of the blinking LED LAYER 1 error. (see section “[5.6 The Blinking LED Procedure](#)”).
- **Errors detected by the Stand-by software which not lead to protection.** In this case the front LED should blink the involved error. See also section “[5.5 Error Codes, 5.5.4 Error Buffer, Extra Info](#)”. Note that it can take up several minutes before the TV starts blinking the error (e.g. LAYER 1 error = 2, LAYER 2 error = 15 or 53).
- **Errors detected by main software (MIPS).** In this case the error will be logged into the error buffer and can be read out via ComPair, via blinking LED method LAYER 1-2 error, or in case picture is visible, via SAM.

### 5.5.2 How to Read the Error Buffer

Use one of the following methods:

- On screen via the SAM (only when a picture is visible).  
E.g.:
  - **00 00 00 00 00**: No errors detected
  - **23 00 00 00 00**: Error code 23 is the last and only detected error.
  - **37 23 00 00 00**: Error code 23 was first detected and error code 37 is the last detected error.
  - Note that no protection errors can be logged in the error buffer.
- Via the blinking LED procedure. See section [5.5.3 How to Clear the Error Buffer](#).
- Via ComPair.

### 5.5.3 How to Clear the Error Buffer

Use one of the following methods:

- By activation of the “RESET ERROR BUFFER” command in the SAM menu.
- With a normal RC, key in sequence “MUTE” followed by “062599” and “OK”.
- If the content of the error buffer has not changed for 50+ hours, it resets automatically.

### 5.5.4 Error Buffer

In case of non-intermittent faults, clear the error buffer before starting to repair (**before** clearing the buffer, write down the content, as this history can give significant information). This to ensure that old error codes are no longer present.

If possible, check the entire contents of the error buffer. In some situations, an error code is only the result of another error code and not the actual cause (e.g. a fault in the protection detection circuitry can also lead to a protection).

There are several mechanisms of error detection:

- Via error bits in the status registers of ICs.

- Via polling on I/O pins going to the stand-by processor.
- Via sensing of analog values on the stand-by processor or the PNX8543.
- Via a “not acknowledge” of an I<sup>2</sup>C communication.

Take notice that some errors need several minutes before they start blinking or before they will be logged. So in case of problems wait 2 minutes from start-up onwards, and then check if the front LED is blinking or if an error is logged.



Table 5-2 Error code overview

| Description  | Layer 1 | Layer 2 | Monitored by | Error/Prot | Error Buffer/ Blinking LED | Device                                      | Defective Board    |
|--|---------|---------|--------------|------------|----------------------------|---|--------------------|
| I <sup>2</sup> C3                                    | 2       | 13      | MIPS         | E          | BL / EB                    | SSB   | SSB                |
| I <sup>2</sup> C2                                    | 2       | 14      | MIPS         | E          | BL / EB                    | SSB/Display                                 | SSB/display        |
| PNX doesn't boot (HW cause)<br>PNX 5100 doesn't boot | 2       | 15      | Stby μP      | P          | BL                         | PNX8543/PNX51XX<br>I <sup>2</sup> C blocked | SSB                |
| 12V  | 3       | 16      | Stby μP      | P          | BL                         | /   | Supply             |
| Inverter or display supply                           | 3       | 17      | MIPS         | E          | EB                         | /   |                    |
| 1V2, 3V3, 5V to low                                  | 2       | 18      | Stby μP      | P          | BL                         | /   | SSB                |
| Temp protection                                      | 3       | 12      | MIPS         | E          | EB                         | /   | Display            |
| PNX 5100   | 2       | 21      | MIPS         | E          | EB                         | PNX5100                                     | SSB                |
| HDMI mux   | 2       | 23      | MIPS         | E          | EB                         | TDA9996                                     | SSB                |
| I <sup>2</sup> C switch                              | 2       | 24      | MIPS         | E          | EB                         | PCA9540                                     | SSB                |
| Boot-NVM PNX5100                                     | 2       | 25      | MIPS         | E          | EB                         | STM24C08                                    | SSB                |
| Multi Standard demodulator<br>(Micronas IF)          | 2       | 27      | MIPS         | E          | EB                         | DRX3616K<br>DRX3626K                        | SSB                |
| ARM (ambilight)                                      | 8       | 28      | MIPS         | E          | EB                         | NXP LPC2103                                 | AL module or DC/DC |
| FPGA (Local contrast)                                | 2       | 29      | MIPS         | E          | EB                         | Altera                                      | SSB                |
| Tuner  | 2       | 34      | MIPS         | E          | EB                         | UV1783S/HD1816                              | SSB                |
| Fan I2C expander                                     | 7       | 41      | MIPS         | E          | EB                         | PCA9533                                     | FAN module         |
| T° sensor  | 7       | 42      | MIPS         | E          | EB                         | LM 75                                       | T° sensor          |
| FAN 1  | 7       | 43      | MIPS         | E          | EB                         |   | FAN                |
| FAN 2  | 7       | 44      | MIPS         | E          | EB                         |   | FAN                |
| Main NVM   | 2       | /       | MIPS         | E          | X                          | STM24C128                                   | SSB                |
| PNX doesn't boot (SW cause)                          | 2       | 53      | Stby μP      | E          | BL                         | PNX8543                                     | SSB                |
| Display (only 56PFL9954H)                            | 5       | 64      | MIPS         | E          | BL / EB                    | Altera                                      | Display            |

**Extra Info**

- **Rebooting.** When a TV is constantly rebooting due to internal problems, most of the time no errors will be logged or blinked. This rebooting can be recognized via a ComPair interface and Hyperterminal (for Hyperterminal settings, see section "[5.8 Fault Finding and Repair Tips, 5.8.6 Logging](#)"). It's shown that the loggings which are generated by the main software keep continuing. In this case diagnose has to be done via ComPair.
- **Error 13 (I<sup>2</sup>C bus 3 blocked).** At the time of release of this manual, this error was not working as expected. Current situation: when this error occurs, the TV will constantly reboot due to the blocked bus. The best way for further diagnosis here, is to use ComPair.
- **Error 15 (PNX8543,PNX5100 doesn't boot).** Indicates that the main processor/PNX5100 was not able to read his bootscript. This error will point to a hardware problem around the PNX8543 (supplies not OK, PNX 8543 completely dead, I<sup>2</sup>C link between PNX and Stand-by Processor broken, etc...). When error 15 occurs it is also possible that I<sup>2</sup>C1 bus is blocked (NVM). I<sup>2</sup>C1 can be indicated in the schematics as follows: SCL-UP-MIPS, SDA-UP-MIPS, SCL-1, SDA-1, SCL-2 or SDA-2. Other root causes for this error can be due to hardware problems from the NVM PNX5100, DDR's and the bootscript reading from the PNX5100.
- **Error 16 (12V).** This voltage is made in the power supply and results in protection (LAYER 1 error = 3) in case of absence. When SDM is activated we see blinking LED LAYER 2 error = 16.
- **Error 17 (Inverter or Display Supply).** Here the status of the "Power OK" is checked by software, no protection will occur during failure of the inverter or display supply (no picture), only error logging. LED blinking of LAYER 1 error = 3 in CSM, in SDM this gives LAYER 2 error = 17.
- **Error 18 (1V2-3V3-5V too low).** All these supplies are generated by the DC/DC supply on the SSB. If one of these supplies is too low, protection occurs and blinking LED LAYER 1 error = 2 will be displayed automatically. In SDM this gives LAYER 2 error = 18.
- **Error 21 (PNX 5100).** When there is no I<sup>2</sup>C communication towards the PNX5100, the TV set will start rebooting and display LAYER 1 error = 2. Disconnect the mains cord now and start up the TV set with the solder path (SDM) short to ground during start-up to activate the LAYER 2 error blinking. Error "21" will be logged and displayed via the blinking LED procedure after a few moments from start-up. Remark : the rebooting can be recognized via a ComPair interface and Hyperterminal (for Hyperterminal settings, see section "[5.8 Fault Finding and Repair Tips, 5.8.6 Logging](#)"). It is shown that the loggings which are generated by the main software keep continuing. Check in the logging for keywords like e.g. "Device error 21".
- **Error 23 (HDMI).** When there is no I<sup>2</sup>C communication towards the HDMI mux after start-up, LAYER 2 error = 23 will be logged and displayed via the blinking LED procedure if SDM is switched on. It should be noted that in case a new spare EDID MUX device is used for repair, the initial default address must be changed from "C0" to "CE", to be done via ComPair.
- **Error 24 (I<sup>2</sup>C switch).** When there is no I<sup>2</sup>C communication towards the I<sup>2</sup>C switch, LAYER 2 error = 24 will be logged and displayed via the blinking LED procedure when SDM is switched on. Remark : this only works for TV sets with an I<sup>2</sup>C controlled screen included.
- **Error 25 (Boot-NVM PNX5100).** Same behaviour as described in "Error 21 (PNX5100)".
- **Error 27 (Micronas IF).** When there is no I<sup>2</sup>C communication towards the multi standard demodulator, LAYER 2 error = 27 will be logged and displayed via the blinking LED procedure if SDM is switched on.
- **Error 28 (ARM ambilight).** When there is no I<sup>2</sup>C communication towards the ARM processor, LAYER 2 error = 28 will be logged and displayed via the blinking LED procedure if SDM is switched on.
- **Error 29 (FPGA local contrast).** When there is no I<sup>2</sup>C communication towards this FPGA, LAYER 2 error = 29 will be logged and displayed via the blinking LED procedure if SDM is activated.
- **Error 34 (Tuner).** When there is no I<sup>2</sup>C communication towards the tuner after start-up, LAYER 2 error = 34 will be

logged and displayed via the blinking LED procedure when SDM is switched on.

- **Error 42 (Temp sensor).** Only applicable for TV sets with an I<sup>2</sup>C controlled screen.
- **Main NVM.** When there is no I<sup>2</sup>C communication towards the main NVM, LAYER 1 error = 2 will be displayed via the blinking LED procedure. In SDM, LAYER 2 error will be blinked as "15". Errors here can not be logged due to inaccessibility of the NVM device.
- **Error 53.** This error will indicate that the PNX8543 has read his bootscript (when this would have failed, error 15 would blink) but initialization was never completed because of hardware problems (NAND flash, ...) or software initialization problems. Possible cause could be that there is no valid software loaded (try to upgrade to the latest main software version). Note that it can take a few minutes before the TV starts blinking LAYER 1 error = 2 or in SDM, LAYER 2 error = 53.
- **Error 64.** Only applicable for TV sets with an I<sup>2</sup>C controlled screen .

## 5.6 The Blinking LED Procedure

### 5.6.1 Introduction

The blinking LED procedure can be split up into two situations:

- Blinking LED procedure LAYER 1 error. In this case the error is automatically blinked when the TV is put in CSM. This will be only one digit error, namely the one that is referring to the defective board (see table ["5-2 Error code overview"](#)) which causes the failure of the TV. This approach will especially be used for home repair and call centres. The aim here is to have service diagnosis from a distance.
- Blinking LED procedure LAYER 2 error. Via this procedure, the contents of the error buffer can be made visible via the front LED. In this case the error contains 2 digits (see table ["5-2 Error code overview"](#)) and will be displayed when SDM (hardware pins) is activated. This is especially useful for fault finding and gives more details regarding the failure of the defective board.

#### Important remark:

For all errors detected by MIPS which are fatal => rebooting of the TV set (reboot starts after LAYER 1 error blinking), one should short the solder paths at start-up from the power OFF state by mains interruption and not via the power button to trigger the SDM via the hardware pins.

When one of the blinking LED procedures is activated, the front LED will show (blink) the contents of the error buffer. Error codes greater than 10 are shown as follows:

1. "n" long blinks (where "n" = 1 to 9) indicating decimal digit
2. A pause of 1.5 s
3. "n" short blinks (where "n" = 1 to 9)
4. A pause of approximately 3 s,
5. When all the error codes are displayed, the sequence finishes with a LED blink of 3 s
6. The sequence starts again.

**Example:** Error 12 8 6 0 0.

After activation of the SDM, the front LED will show:

1. One long blink of 750 ms (which is an indication of the decimal digit) followed by a pause of 1.5 s
2. Two short blinks of 250 ms followed by a pause of 3 s
3. Eight short blinks followed by a pause of 3 s
4. Six short blinks followed by a pause of 3 s
5. One long blink of 3 s to finish the sequence
6. The sequence starts again.

### 5.6.2 How to Activate

Use one of the following methods:

- **Activate the CSM.** The blinking front LED will show only the latest layer 1 error, this works in "normal operation" mode or automatically when the error/protection is monitored by the standby processor. In case no picture is shown and there is no LED blinking, read the logging to detect whether "error devices" are mentioned. (see section ["5.8 Fault Finding and Repair Tips, 5.8.6 Logging"](#)).
- **Activate the SDM.** The blinking front LED will show the entire content of the LAYER 2 error buffer, this works in "normal operation" mode or when SDM (via hardware pins) is activated when the tv set is in protection.  
**Important remark:**  
For all errors detected by MIPS which are fatal => rebooting of the TV set (reboot starts after LAYER 1 error blinking), one should short the solder paths at start-up from the power OFF state by mains interruption and not via the power button to trigger the SDM via the hardware pins.
- **Transmit the commands "MUTE" - "06250x" - "OK" with a normal RC.** The complete error buffer is shown. Take notice that it takes some seconds before the blinking LED starts.
- **Transmit the commands "MUTE" - "06250x" - "OK" with a normal RC** (where "x" is a number between 1 and 5). When x = 1 the last detected error is shown, x = 2 the second last error, etc.... Take notice that it takes some seconds before the blinking LED starts.

## 5.7 Protections

### 5.7.1 Software Protections

Most of the protections and errors use either the stand-by microprocessor or the MIPS controller as detection device. Since in these cases, checking of observers, polling of ADCs, and filtering of input values are all heavily software based, these protections are referred to as software protections. There are several types of software related protections, solving a variety of fault conditions:

- **Protections related to supplies:** check of the 12V, +5V, +3V3 and 1V2.
- **Protections related to breakdown of the safety check mechanism.** E.g. since the protection detections are done by means of software, failing of the software will have to initiate a protection mode since safety cannot be guaranteed any more.

#### Remark on the Supply Errors

The detection of a supply dip or supply loss during the normal playing of the set does not lead to a protection, but to a cold reboot of the set. If the supply is still missing after the reboot, the TV will go to protection.

#### Protections during Start-up

During TV start-up, some voltages and IC observers are actively monitored to be able to optimise the start-up speed, and to assure good operation of all components. If these monitors do not respond in a defined way, this indicates a malfunction of the system and leads to a protection. As the observers are only used during start-up, they are described in the start-up flow in detail (see section ["5.3 Stepwise Start-up"](#)).

### 5.7.2 Hardware Protections

The only real hardware protection in this chassis appears in case of an audio problem e.g. DC voltage on the speakers. This protection will only affect the Class D (7D10) and puts the amplifier in a continuous burst mode (cyclus approximately 2 seconds).

#### Repair Tip

- There will be still picture available but no sound. While the Class D amplifier tries to start-up again, the cone of the

loudspeakers will move slowly in one or the other direction until the initial failure shuts the amplifier down, this cyclus starts over and over again.

### 5.7.3 Important remark regarding the blinking LED indication

As for the blinking LED indication, the blinking led of LAYER 1 error displaying can be switched off by pushing the power button on the keyboard.

This condition is not valid after the set was unpowered (via mains interruption). The blinking LED starts again and can only be switched off by unplugging the mains connection.

This can be explained by the fact that the MIPS can not load the keyboard functionality from software during the start-up and doesn't recognizes the keyboard commands at this time.

## 5.8 Fault Finding and Repair Tips

Read also section "[5.5 Error Codes](#), [5.5.4 Error Buffer](#), [Extra Info](#)".

### 5.8.1 Ambilight

Due to degeneration process of the AmbiLights, there can be a difference in the colour and/or light output of the spare ambilight module in comparison with the originals ones contained in the TV set. Via ComPair the light output can be adjusted.

### 5.8.2 Audio Amplifier

The Class D-IC 7D10 has a powerpad for cooling. When the IC is replaced it must be ensured that the powerpad is very well pushed to the PWB while the solder is still liquid. This is needed to insure that the cooling is guaranteed, otherwise the Class D-IC could break down in short time.

### 5.8.3 CSM

When CSM is activated and there is a USB stick connected to the TV, the software will dump the complete CSM content to the USB stick. The file (Csm.txt) will be saved in the root of the USB stick. If this mechanism works it can be concluded that a large part of the operating system is already working (MIPS, USB...)

### 5.8.4 DC/DC Converter

#### Description

The onboard supply consists of 5 DC/DC converters and 4 linear stabilizers. All DC/DC converters have +12V input voltage and deliver :

- +1V2-PNX85XX supply voltage (1.24V nominal), stabilized close to PNX8543 chip.
- +1V2-PNX5120 supply voltage (1.26V nominal), stabilized close to PNX5120 chip.
- +3V3 (3.34V nominal, overall 3.3 V for onboard IC's).
- +5V (5.15V nominal) for USB and Conditional Access Interface and +5V5-TUN for +5V-TUN tuner stabilizer.
- +33VTUN (34V nominal) for analog-only tuners.

The linear stabilizers are providing:

- +1V2-STANDBY (out of +3V3-STANDBY), 1.24V nominal.
- +1V8-PNX85XX and +1V8PNX5100 (connected via CFH1), 1.84V nominal.
- +2V5 (WOW FPGA diversity only), 2.5V nominal.
- +5V-TUN (out of +5V5-TUN), 5V nominal.

+3V3-STANDY and +1V2-STANDBY are permanent voltages. Supply voltages +1V2-PNX85XX and +1V2-PNX5100 are

started immediately when +12V incoming voltage is available (+12V is enabled by STANDBY signal, active low). Supply voltages +3V3, 2V5, +1V8-PNX5100, +1V8-PNX85XX, +5V and +5V-TUN are switched-on directly by signal ENABLE-3V3 (active low), provided that +12V (detected via 7U40 & 7U41) is available. +12V is considered OK (=> DETECT -12V signal becomes high and 12V/3V3 and 12V/5V DC-DC converter can be started up) if it rises above 10V5 (typical) and doesn't drop below 10V (typical).

#### Debugging

The best way to find a failure in the DC/DC converters is to check their start-up sequence at power-on via the mains cord, presuming that the standby microprocessor and the external supply are operational. Take STANDBY signal high-to-low transition as time reference.

When +12V becomes available (maximum 1 second after STANDBY signal goes low) then +1V2-PNX85XX and +1V2-PNX5100 are started immediately. Then, after ENABLE-3V3 goes low, all the other supply voltages should rise within 2ms.

#### Tips

- When an output supply voltage is short-circuited to GND the corresponding DC-DC converter is not making any audible noise, the converter switches-off immediately and will attempt a re-start only after +12V drops and rises again.
- Check the integrity (at least no short-circuit between drain and source) of power MOS-FETs, especially the high-side ones: 7U05, 7U08, 7U0D-1 and 7U0H-1 before starting the platform in SDM mode, otherwise it can be easily damaged.
- Switching frequency of DC-DC converters should be around 290KHz for 12V to 1V2 DC-DC converters and around 370KHz for 12V to 3V3 and 12V to 5V DC-DC converters.

### 5.8.5 Exit "Factory Mode"

When an "F" is displayed in the screen's right corner, this means the set is in "Factory" mode, and it normally happens after a new SSB is mounted. To exit this mode, push the "VOLUME minus" button on the TV's local keyboard for 10 seconds (this disables the continuous mode). Then push the "SOURCE" button for 10 seconds until the "F" disappears from the screen.

### 5.8.6 Logging

When something is wrong with the TV set (f.i. the set is rebooting) you can check for more information via the logging in Hyperterminal. The Hyperterminal is available in every Windows application via Programs, Accessories, Communications, Hyperterminal. Connect a "ComPair UART"-cable (3138 188 75051) from the service connector in the TV to the "multi function" jack at the front of ComPair II box. Required settings in ComPair before starting to log :

- Start up the ComPair application.
- Select the correct database (open file "Q549.2E LA", this will set the ComPair interface in the appropriate mode).
- Close ComPair

After start-up of the Hyperterminal, fill in a name (f.i. "logging") in the "Connection Description" box, then apply the following settings:

1. COMx
2. Bits per second = 115200
3. Data bits = 8
4. Parity = none
5. Stop bits = 1
6. Flow control = none

During the start-up of the TV set, the logging will be displayed. This is also the case during rebooting of the TV set (the same logging appears time after time). Also available in the logging is the "Display Option Code" (useful when there is no picture),

look for item "DisplayRawNumber" in the beginning of the logging. Tip: when there is no picture available during rebooting you are able to check for "error devices" in the logging (LAYER 2 error) which can be very helpful to determine the failure cause of the reboot. For protection state, there is no logging.

### 5.8.7 Loudspeakers

Make sure that the volume is set to minimum during disconnecting the speakers in the ON-state of the TV. The audio amplifier can be damaged by disconnecting the speakers during ON-state of the set!

### 5.8.8 IPB

In case of no picture when CSM-test pattern from PNX5100 is activated and backlight doesn't light up, it's recommended first to check the inverter on the IPB + wiring (LAYER 2 error = 17 is displayed in SDM).

### 5.8.9 Tuner

Attention: In case the tuner is replaced, always check the tuner options!

### 5.8.10 PCI bus

The splash screen image is not distributed via the regular YUV signal path from the PNX8543 to the PNX51XX, but loaded one time via the PCI bus. Once the splash screen image is loaded into the PNX51XX, it will be continuously generated by the PNX51XX until the first incoming video disables the splash screen. So when teletext and/or general UI is available, but no splash screen (option "ON") is visible during start-up, check the PCI bus as possible root cause.

### 5.8.11 Display option code


Attention: In case the SSB is replaced, always check the display option code in SAM, even when picture is available. Performance with the incorrect display option code can lead to unwanted side-effects for certain conditions.

### 5.8.12 Upgrade HDMI EDID NVM

The EDID MUX device (including all HDMI NVM except the 4th) is upgradeable via USB, see ComPair for further instructions. It should be noted that in case a new spare EDID MUX device is used for repair, the initial default address must be changed from "C0" to "CE", to be done via ComPair.

### 5.8.13 Upgrade VGA/4th HDMI EDID NVM

The EDID for VGA connector or the 4th HDMI can only be upgraded via external I<sup>2</sup>C. To upgrade the EDID for the VGA connector or 4th HDMI, pin 7 of the EDID NVM has to be short circuited to ground. Therefore a test point is foreseen (see [Figure 5-13](#)). For the VGA EDID NVM it's most suitable to connect pin 7 to ground on the NVM device itself. See ComPair for further instructions.



18310\_220\_090318.eps  
090319

Figure 5-13 4th HDMI EDID NVM pin

### 5.8.14 Wi-Fi module

To prevent damage on the coax wires, especially the female core of the coax wires (can be bend over during dis- and reconnecting), this should be carried out by use of pliers.



5.8.15 SSB Replacement

Follow the instructions in the flowchart in case a SSB has to be exchanged. See figure "SSB replacement flowchart".




Figure 5-14 SSB replacement flowchart

## 5.9 Software Upgrading

### 5.9.1 Introduction

The set software and security keys are stored in a NAND-Flash, which is connected to the PNX8543 via the PCI bus.

It is possible **for the user** to upgrade the **main** software via the USB port. This allows replacement of a software image in a stand alone set, without the need of an E-JTAG debugger. A description on how to upgrade the main software can be found in the DFU.

**Important:** When the NAND-Flash must be replaced, a new SSB must be ordered, due to the presence of the security keys! (copy protection keys, MAC address, ...).

Perform the following actions after SSB replacement:

1. Set the correct option codes (see sticker inside the TV).
2. Update the TV software => see the eUM (electronic User Manual) for instructions.
3. Perform the alignments as described in chapter 6 (section [6.5 Reset of Repaired SSB](#)).
4. Check in CSM if the HDMI key, MAC address.. are valid. For the correct order number of a new SSB, always refer to the Spare Parts list!

### 5.9.2 Main Software Upgrade

- The "UpgradeAll.upg" file is only used in the factory.
- The "FlashUtils.upg" file is only used by service centra which are allowed to do component level repair on the SSB.

#### Automatic Software Upgrade

In "normal" conditions, so when there is no major problem with the TV, the main software and the default software upgrade application can be upgraded with the "AUTORUN.UPG" (FUS part of the one-zip file: e.g. 3104 337 05661 \_FUS\_Q5492\_1.26.15.0\_commercial.zip). This can also be done by the consumers themselves, but they will have to get their software from the commercial Philips website or via the Software Update Assistant in the user menu (see eUM). The "autorun.upg" file must be placed in the root of the USB stick.

How to upgrade:

1. Copy "AUTORUN.UPG" to the root of the USB stick.
2. Insert USB stick in the set while the set is in ON MODE. The set will restart and the upgrading will start automatically. As soon as the programming is finished, a message is shown to remove the USB stick and restart the set.

#### Manual Software Upgrade

In case that the software upgrade application does not start automatically, it can also be started manually.

How to start the software upgrade application manually:

1. Disconnect the TV from the Mains/AC Power.
2. Press the "OK" button on a Philips TV remote control or a Philips DVD RC-6 remote control (it is also possible to use a TV remote in "DVD" mode). Keep the "OK" button pressed while reconnecting the TV to the Mains/AC Power.
3. The software upgrade application will start.

#### Attention!

In case the download application has been started **manually**, the "autorun.upg" will maybe not be recognized.

What to do in this case:

1. Create a directory "UPGRADES" on the USB stick.
2. Rename the "autorun.upg" to something else, e.g. to "software.upg". Do not use long or complicated names, keep it simple. Make sure that "AUTORUN.UPG" is no longer present in the root of the USB stick.
3. Copy the renamed "upg" file into this directory.
4. Insert USB stick into the TV.

5. The renamed "upg" file will be visible and selectable in the upgrade application.

#### Back-up Software Upgrade Application

If the default software upgrade application does not start (could be due to a corrupted boot 2 sector) via the above described method, try activating the "back-up software upgrade application".

How to start the "back-up software upgrade application" manually:

1. Disconnect the TV from the Mains/AC Power.
2. Press the "INFO"-button on a Philips remote control or "CURSOR DOWN" button on a Philips DVD RC-6 remote control (it is also possible to use a TV remote in "DVD" mode). Keep the "INFO"-button (or "cursor down" button) pressed while reconnecting the TV to the Mains/AC Power.
3. The software upgrade application will start.

### 5.9.3 Stand-by Software Upgrade via USB

In this chassis it is possible to upgrade the Stand-by software via a USB stick. The method is similar to upgrading the main software via USB.

Use the following steps:

1. Create a directory "UPGRADES" on the USB stick.
2. Copy the Stand-by software (part of the one-zip file, e.g. StandbySW\_CFT72\_88.0.0.0.upg) into this directory.
3. Insert the USB stick into the TV.
4. Start the download application manually (see section "[Manual Software Upgrade](#)").
5. Select the appropriate file and press the "OK" button to upgrade.

### 5.9.4 Content and Usage of the One-Zip Software File

Below the content of the One-Zip file is explained, and instructions on how and when to use it.

- **BootProm\_PNX5120\_Q5492\_x.x.x.x.zip.** A programmed device can be ordered via the regional Service organization.
- **Ceisp2padII\_P2PAD\_x.x.x.x.zip.** Not to be used by Service technicians. For ComPair development only.
- **DDC\_Q5492\_x.x.x.x.zip.** Contains the content of the VGA NVM. See ComPair for further instruction.
- **EDID\_Q5492\_x.x.x.x.zip.** Contains the EDID content of the different EDID NVM's. See ComPair for further instructions.
- **EJTAGDownload\_Q5492\_x.x.x.x.zip.** Only used by service centra which are allowed to do component level repair.
- **FUS\_Q5492\_x.x.x.x\_commercial.zip.** Contains the "autorun.upg" which is needed to upgrade the TV main software and the software download application.
- **Factory\_Q5492\_x.x.x.x\_commercial.zip.** Only for production purposes, not to be used by Service technicians.
- **FlashUtils\_Q5492\_x.x.x.x\_commercial.zip.** Not to be used by Service technicians.
- **MOP\_RAC3\_x.x.x.x.zip.** Contains the MOP local contrast software and is upgradeable via USB (UPG). This SW is not part of the FUS autorun.upg!
- **OAD\_Q5492\_x.x.x.x.zip.** Not to be used by Service Technicians.
- **OpenSourceFile\_Q5492\_x.x.x.x.zip.** Not to be used by Service technicians.
- **PQPrivate\_Q5492\_x.x.x.x.zip.** Not to be used by Service technicians.
- **StandbySW\_CFTxx\_x.x.x.x\_commercial.zip.** Contains the Stand-by software in "upg" and "hex" format.
  - The "StandbySW\_XXXXX\_prod.upg" file can be used to upgrade the Stand-by software via USB.
  - The "StandbySW\_XXXXX.hex" file can be used to upgrade the Stand-by software via ComPair.

- The files "StandbySW\_XXXXX\_exhex.hex" and "StandbySW\_XXXXX\_dev.upg" may not be used by Service technicians (only for development purposes).
- **UpgradeAll\_Q5492\_x.x.x.x\_commercial.zip.** Only for production purposes, not to be used by Service technicians.  
**Caution: Never try to use this file, because it will overwrite the HDCP keys !!!**
- **UpgradeExe\_Q5492X\_x.x.x.x.zip.** Not to be used by Service Technicians.
- **Ambilight\_Q5492\_x.x.x.x.zip.** Not to be used by Service technicians.
- **Cabinet\_Q5492\_x.x.x.x.zip.** Not to be used by Service technicians.
- **Display\_Q5492\_x.x.x.x.zip.** Not to be used by Service technicians.
- **LightGuide\_TV522\_x.x.x.x.zip.** Not to be used by Service Technicians.
- **ProcessNVM\_Q5492\_x.x.x.x.zip.** Default NVM content. Must be programmed via ComPair or can be loaded via USB, be aware that all alignments stored in NVM are overwritten here.

#### 5.9.5 Content of the MOP Ambilight ARM SW File

- MOP\_AMBILIGHT\_V1-2\_UPG\_jettsigned.zip. Contains the MOP ambientlight software (ARM processor on the DC-DC AL interface board) and is upgradeable via USB (UPG). This SW is not part of the FUS autorun.upg! and is not available in the One-Zip software file but provided separately via the commercial Philips website (software for servicers only). Instructions for upgrading are included in the zip file.

#### 5.9.6 UART logging 2K9 (see section "[5.8 Fault Finding and Repair Tips](#), [5.8.6 Logging](#))

# 6. Alignments

**Index of this chapter:**

- [6.1 General Alignment Conditions](#)
- [6.2 Hardware Alignments](#)
- [6.3 Software Alignments](#)
- [6.4 Option Settings](#)
- [6.5 Reset of Repaired SSB](#)
- [6.7 Total Overview SAM modes](#)

## 6.1 General Alignment Conditions

Perform all electrical adjustments under the following conditions:

- Power supply voltage (depends on region):
  - **AP-NTSC:** 120 V<sub>AC</sub> or 230 V<sub>AC</sub> / 50 Hz (± 10%).
  - **AP-PAL-multi:** 120 - 230 V<sub>AC</sub> / 50 Hz (± 10%).
  - **EU:** 230 V<sub>AC</sub> / 50 Hz (± 10%).
  - **LATAM-NTSC:** 120 - 230 V<sub>AC</sub> / 50 Hz (± 10%).
  - **US:** 120 V<sub>AC</sub> / 60 Hz (± 10%).
- Connect the set to the mains via an isolation transformer with low internal resistance.
- Allow the set to warm up for approximately 15 minutes.
- Measure voltages and waveforms in relation to correct ground (e.g. measure audio signals in relation to AUDIO\_GND).
- **Caution:** It is not allowed to use heat sinks as ground.
- Test probe: Ri > 10 MΩ, Ci < 20 pF.
- Use an isolated trimmer/screwdriver to perform alignments.

### 6.1.1 Alignment Sequence

- First, set the correct options:
  - In SAM, select “Options”, and then “Option numbers”.
  - Fill in the option settings for “Group 1” and “Group 2” according to the set sticker (see also paragraph [6.4 Option Settings](#)).
  - Press OK on the remote control before the cursor is moved to the left.
  - In submenu “Option numbers” select “Store” and press OK on the RC.
- OR:
  - In main menu, select “Store” again and press OK on the RC.
  - Switch the set to Stand-by.
- Warming up (>15 minutes).

## 6.2 Hardware Alignments

Not applicable.

## 6.3 Software Alignments

Put the set in SAM mode (see Chapter [5. Service Modes. Error Codes and Fault Finding](#)). The SAM menu will now appear on the screen. Select ALIGNMENTS and go to one of the sub menus. The alignments are explained below.

The following items can be aligned:

- Tuner AGC.
- White point.

To store the data:

- Press OK on the RC **before the cursor is moved to the left.**
- In main menu select “Store” and press OK on the RC.
- Press MENU on the RC to switch back to the main menu.
- Switch the set to stand-by mode.

For the next alignments, supply the following test signals via a video generator to the RF input:

- **EU/AP-PAL models:** a PAL B/G TV-signal with a signal strength of at least 1 mV and a frequency of 475.25 MHz
- **US/AP-NTSC models:** an NTSC M/N TV-signal with a signal strength of at least 1 mV and a frequency of 61.25 MHz (channel 3).
- **LATAM models:** an NTSC M TV-signal with a signal strength of at least 1 mV and a frequency of 61.25 MHz (channel 3).

### 6.3.1 Tuner AGC (RF AGC Take Over Point Adjustment)

Purpose: To keep the tuner output signal constant as the input signal amplitude varies.

No alignment is necessary, for the AGC alignment you can use the default value : “80”.

Store settings and exit SAM.

### 6.3.2 White Point

- Set “Active control” to “Off”.
- Choose “TV menu”, “TV Settings” and then “Picture” and set picture settings as follows:

| Picture Setting    |          |
|--------------------|----------|
| Dynamic backlight  | Off      |
| Dynamic Contrast   | Off      |
| Colour Enhancement | Off      |
| Picture Format     | Unscaled |
| Light Sensor       | Off      |
| Brightness         | 50       |
| Colour             | 0        |
| Contrast           | 100      |

- Go to the SAM and select “Alignments”-> “White point”.

#### White point alignment LCD screens:

- Use a 100% white screen as input signal and set the following values:
  - “Colour temperature”: “Normal”.
  - All “White point” values to: “127”.
  - “Red BL offset” values to “8”.
  - “Green BL offset” values to “8”.

#### In case you have a colour analyser:

- Measure with a calibrated contactless colour analyser in the centre of the screen. Consequently, the measurement needs to be done in a dark environment.
- Adjust the correct x,y coordinates (while holding one of the White point registers R, G or B on 127) by means of decreasing the value of one or two other white points to the correct x,y coordinates (see [Table 6-1 White D alignment values](#)). Tolerance: dx: ± 0.004, dy: ± 0.004.
- Repeat this step for the other colour temperatures that need to be aligned.
- When finished press OK on the RC and then press STORE (in the SAM root menu) to store the aligned values to the NVM.
- Restore the initial picture settings after the alignments.

**Table 6-1 White D alignment values**

| Value | Cool (11000K) | Normal (9000K) | Warm (6500K) |
|-------|---------------|----------------|--------------|
| x     | 0.270         | 0.279          | 0.309        |
| y     | 0.279         | 0.287          | 0.328        |

**If you do not have a colour analyser,** you can use the default values. This is the next best solution. The default values are average values coming from production.

- Select a COLOUR TEMPERATURE (e.g. COOL, NORMAL, or WARM).



- Set the RED, GREEN and BLUE default values according to the values in [Table 6-2](#).
- When finished press OK on the RC, then press STORE (in the SAM root menu) to store the aligned values to the NVM.
- Restore the initial picture settings after the alignments.

**Table 6-2 White tone default setting**

| White Tone | 32" |     |     | 37" |     |     | Black level offset |   |
|------------|-----|-----|-----|-----|-----|-----|--------------------|---|
|            | R   | G   | B   | R   | G   | B   | R                  | G |
| Normal     | 127 | 95  | 97  | 127 | 121 | 106 | 8                  | 8 |
| Cool       | 127 | 100 | 112 | 124 | 127 | 119 | 8                  | 8 |
| Warm       | 127 | 89  | 52  | 127 | 111 | 64  | 8                  | 8 |

| White Tone | 56" |     |     | Black level offset |   |
|------------|-----|-----|-----|--------------------|---|
|            | R   | G   | B   | R                  | G |
| Normal     | 127 | 117 | 111 | 8                  | 8 |
| Cool       | 124 | 124 | 125 | 8                  | 8 |
| Warm       | 127 | 95  | 65  | 8                  | 8 |

## 6.4 Option Settings

### 6.4.1 Introduction

The microprocessor communicates with a large number of I2C ICs in the set. To ensure good communication and to make digital diagnosis possible, the microprocessor has to know which ICs to address. The presence / absence of these PNX5100 ICs (back-end advanced video picture improvement IC which offers motion estimation and compensation features (commercially called HDNM) plus integrated Ambilight control) is made known by the option codes.

#### Notes:

- After changing the option(s), save them by pressing the OK button on the RC before the cursor is moved to the left, select STORE in the SAM root menu and press OK on the RC.
- The new option setting is only active after the TV is switched "off" / "stand-by" and "on" again with the mains switch (the NVM is then read again).

### 6.4.2 Dealer Options

For dealer options, in SAM select "Dealer options". See [Table 6-4 SAM mode overview](#).

### 6.4.3 (Service) Options

Select the sub menu's to set the initialisation codes (options) of the model number via text menus. See [Table 6-4 SAM mode overview](#).

### 6.4.4 Opt. No. (Option numbers)

Select this sub menu to set all options at once (expressed in two long strings of numbers).

An option number (or "option byte") represents a number of different options. When you change these numbers directly, you can set all options very quickly. All options are controlled via eight option numbers.

When the NVM is replaced, all options will require resetting. To be certain that the factory settings are reproduced exactly, you must set both option number lines. You can find the correct option numbers on a sticker inside the TV set and in [Table 6-3 Option and display code overview](#).

**Example:** The options sticker gives the following option numbers:

- 08192 00133 01387 45160
- 12232 04256 00164 00000

The first line (group 1) indicates hardware options 1 to 4, the second line (group 2) indicate software options 5 to 8. Every 5-digit number represents 16 bits (so the maximum value will be 65536 if all options are set). When all the correct options are set, the sum of the decimal values of each Option Byte (OB) will give the option number. See [Table 6-3 Option and display code overview](#) for the options.

#### Diversity

Not all sets with the same Commercial Type Number (CTN) necessarily have the same option code! Use of Alternative BOM => an alternative BOM number usually indicates the use of an alternative display or power supply. This results in another display code thus in another Option code. For the power supply there is no difference. Refer to [Chapter 2. Technical Specifications and Connections](#).

### 6.4.5 Option Code Overview

**Table 6-3 Option and display code overview**

| CTN           | Options Group 1         | Options Group 2         | Disp. code |
|---------------|-------------------------|-------------------------|------------|
| 32PFL9604H/12 | 08211 35971 18431 45288 | 30645 47282 00184 00000 | 181        |
| 32PFL9604H/60 | 08211 35971 18431 45288 | 30645 47282 00184 00000 | 181        |
| 37PFL9604H/12 | 08227 35972 18431 45288 | 30625 47282 00176 00000 | 161        |
| 37PFL9604H/60 | 08227 35972 18431 45288 | 30625 47282 00176 00000 | 161        |
| 56PFL9954H/12 | 08275 33925 18431 45288 | 30644 47282 00161 00000 | 180        |

**Important:** after having edited the option numbers as described above, you **must press OK** on the remote control **before the cursor is moved to the left!**

## 6.5 Reset of Repaired SSB

A very important issue towards a repaired SSB from a service repair shop implies the reset of the NVM on the SSB.

A repaired SSB in service should get the service Set type "00PF0000000000" and Production code "00000000000000". Also the virgin bit is to be set. To set all this, you can use the ComPair tool.

In case of a display replacement, reset the "Operation hours display" to "0", or to the operation hours of the replacement display.

New here in this chassis is the "Net TV" functionality. Therefore the CTN ("set type" item in CSM1) must be filled into the spare SSB to ensure access to the Net TV portals.

The loading of the CTN can be done via ComPair (Model number programming).

The reset item (Clear NET TV memory) can be selected via MENU (or HOME) => Setup => Installation => Clear NET TV memory (customer preferences stored at provider side will be reset now).

### 6.5.1 SSB identification

Whenever ordering a new SSB, it should be noted that the correct ordering number (12nc) of a SSB is located on a sticker on the SSB. The format is <12nc SSB><serial number>. The ordering number of a "Service" SSB is the same as the ordering number of an initial "factory" SSB.



18310\_221\_090318.eps  
090319

Figure 6-1 SSB identification

## 6.6 Service SSB delivered without main software loaded

Due to a changed manufacturing process, new **Service SSB's can be delivered** to the warehouse **without main TV software** loaded. Below you find the steps to follow when such an SSB is received.

### 6.6.1 When a picture is available

1. Mount the Service SSB into the TV set. After start-up, normally the download application will appear on the screen.
2. Download the latest main software (FUS) from the [www.p4c.philips.com](http://www.p4c.philips.com) website.

## 6.7 Total Overview SAM modes

Table 6-4 SAM mode overview

| Main Menu          | Sub-menu 1                   | Sub-menu 2             | Sub-menu 3 | Description   |
|--------------------|------------------------------|------------------------|------------|---|
| Hardware Info      | A. SW VERSION                | e.g. "Q5492_1.26.15.0" |            | Display TV & Standby SW version and CTN serial number.  |
|                    | B. Standby processor version | e.g. "STDBY_88.68.0.0" |            |   |
|                    | C. Production code           | e.g. "See type plate"  |            |   |
| Operation hours    |                              |                        |            | Displays the accumulated total of operation hours. TV switched "on/off" & every 0.5 hours is increase one |
| Error              |                              |                        |            | Displayed the most recent errors.   |
| Reset error buffer |                              |                        |            | Clears all content in the error buffer.   |
| Alignment          | Tuner AGC                    |                        |            | RF-AGC Take over point adjustment (AGC default value is 80)   |
|                    | Whitepoint                   | Colour temperature     | Normal     | 3 different modes of colour temperature can be selected   |
|                    |                              |                        | Warm       |   |
|                    |                              |                        | Cool       |   |
|                    |                              | White point red        |            | LCD White Point Alignment. For values, see Table 6-1 <a href="#">White D alignment values</a> .           |
|                    |                              | White point green      |            |   |
|                    |                              | White point blue       |            |   |
|                    | Red black level offset       |                        |            |   |
|                    | Green black level offset     |                        |            |   |

3. Create a folder "upgrades" in the root of a USB stick (size > 50 MB) and save the "autorun.upg" file in this "upgrades" folder. **Note:** it is possible to rename this file, e.g. "Q549\_SW\_version.upg", this in case there are more than one "autorun.upg" files on your USB stick
4. Plug the prepared USB stick into the TV set, and select the "autorun" file in the displayed browser on the screen
5. Now the main TV software will be loaded automatically, supported by a progress bar
6. Set the correct "display code" via "062598-HOME-xxx", where "xxx" is the 3-digit display panel code (see sticker on the side/bottom of the cabinet).

### 6.6.2 When no picture is available

Due to a possible wrong display option code in the received Service SSB (NVM), no picture can be available at start-up and thus no download application will be visible. Here you can proceed and finalize step by step to load the main TV software via the UART logging on the PC (for visual feedback).

1. Start-up the TV set, equipped with the Service SSB, and enable the UART logging on the PC (see for settings [5.8 Fault Finding and Repair Tips 5.8.6 Logging](#))
2. The TV set will start-up automatically in the download application if main TV software is not loaded
3. Plug the prepared USB stick into the TV set, press cursor "Right" to enter the list, and navigate to the "autorun" file in the UART logging printout via the cursor keys on the remote control. When the correct file is selected, press "OK"
4. Press cursor "Down" and "OK" to start the flashing of the main TV software. Printouts like: "L: 1-100% , V: 1-100% and P: 1-100%" should be visible now in the UART logging
5. Wait until the message "Operation successful!" is displayed and remove all inserted media. Restart the TV set
6. Set the correct "display code" via "062598-HOME-xxx", where "xxx" is the 3-digit display panel code (see sticker on the side/bottom of the cabinet).

### 6.6.3 Use of repaired SSBs instead of new

Repaired SSBs on stock will obviously already contain main TV software. This implies that only a main software upgrade is required if you use a "repaired" SSB for board swap instead of a "new" SSB.

| Main Menu            | Sub-menu 1         | Sub-menu 2                                 | Sub-menu 3                                | Description  |                                       |
|----------------------|--------------------|--|---|--|---------------------------------------|
| Dealer options       | Picture mute       | Off/On                                     |   | Select Picture mute On/Off. Picture is muted / not muted in case no input signal is detected at input connectors.  |                                       |
|                      | Virgin mode        | Off/On                                     |   | Select Virgin mode On/Off. TV starts up / does not start up (once) with a language selection menu after the mains switch is turned "on" for the first time (virgin mode) |                                       |
|                      | E-sticker          | Off/On                                     |   | Select E-sticker On/Off (USP's on-screen)  |                                       |
|                      | Auto store mode    | None<br>PDC/VPS<br>TXT page<br>PDC/VPS/TXT |   |  |                                       |
| Options              | Digital broadcast  | DVB  | Off/On                                    | Select DVB On/Off  |                                       |
|                      |                    | DVB - T installation                       | Off/On or Country dependent               | Select DVB T installation On/Off or by country   |                                       |
|                      |                    | DVB - T light                              | Off/On                                    | Select DVB T light On/Off  |                                       |
|                      |                    | DVB - C                                    | Off/On                                    | Select DVB C On/Off  |                                       |
|                      |                    | DVB - C installation                       | Off/On or Country dependent               | Select DVB C installation On/Off or by country   |                                       |
|                      |                    | Over the air download                      | Off/On or Country dependent               | Select Over the air download On/Off or by country  |                                       |
|                      |                    | 8 days EPG                                 | Off/On                                    | Select 8 day EPG On/Off  |                                       |
|                      | Digital features   | USB  | Off/On                                    | Select USB On/Off  |                                       |
|                      |                    | Ethernet                                   | Off/On                                    | Select Ethernet On/Off   |                                       |
|                      |                    | Wi-Fi                                      | Off/On                                    | Select Wi-Fi On/Off  |                                       |
|                      |                    | DLNA                                       | Off/On                                    | Select DLNA On/Off   |                                       |
|                      |                    | Online service                             | Off                                       | Online service is Off  |                                       |
|                      |                    | PTP (Picture Transfer Protocol)            | Off/On                                    | Select PTP On/Off  |                                       |
|                      |                    | Update assistant                           | Off/On                                    | Select Update assistant On/Off   |                                       |
|                      |                    | Internet software update                   | Off                                       | Internet software update is Off  |                                       |
|                      | Display            | Screen                                     | 180 / LCD Sharp Z3LA13 56"                | Displayed the panel code & type model.   |                                       |
|                      |                    | LightGuide                                 | Off/On                                    | Select LightGuide On/Off   |                                       |
|                      |                    | Display fans                               | Not present/Present                       | Select Display fans Present/Not present.   |                                       |
|                      |                    | Temperature sensor                         | Sensor present in display (only for 21:9) | N.A.   |                                       |
|                      |                    | Temperature LUT                            | 0   | N.A.   |                                       |
|                      |                    | E-box & monitor                            | Off/On                                    | Select E-box & monitor On/Off  |                                       |
|                      | Video reproduction | Picture processing                         | None/PNX5100                              | Select Picture processing None/PNX5100 (Q549.xE chassis).  |                                       |
|                      |                    | MOP local contrast                         | Off/On                                    | Select MOP local contrast On/Off   |                                       |
|                      |                    | Light sensor                               | Off/On                                    | Select Light sensor On/Off   |                                       |
|                      |                    | Light sensor type                          | 0/1/2/3                                   | Select Light sensor type form 0 to 3 (for difference styling).   |                                       |
|                      |                    | Pixel Plus type                            | Pixel Plus HD                             |  | Select type of picture improvement.   |
|                      |                    |  | Perfect Pixel HD                          |  |                                       |
|                      |                    |  | Pixel Precise HD                          |  |                                       |
|                      |                    | Ambilight                                  | None,                                     |  | Select type of Ambilight modules use. |
|                      |                    |  | 2 sided 2/2                               |  | For 8400 series only                  |
|                      |                    |  | 2 sided 4/4                               |  |                                       |
| 3 sided 2/3/2        |                    |  |   |  |                                       |
| 3 sided 4/3/4        |                    |  |   |  |                                       |
| 3 sided 4/5/4        |                    |  |   |  |                                       |
| 4 sided 4/3/4/3      |                    |  |   |  |                                       |
| Ambilight technology | LED/Future use     |  | Ambilight technology LED is in use.       |  |                                       |
| MOP ambilight        | Off/On             |  | Select MOP ambilight On/Off               |  |                                       |

| Main Menu                 | Sub-menu 1                  | Sub-menu 2                     | Sub-menu 3   | Description  |
|---------------------------|-----------------------------|--------------------------------|--|--|
|                           | Audio reproduction          | Acoustic system                |  | Cabinet design used for setting dynamic audio parameters.  |
|                           | Source selection            | EXT1/AV1 type                  | SCART CVBS RGB LR  | Select input source when connected with external equipment.  |
|                           |                             |                                | CVBS Y/C YPbPr LR  |  |
|                           |                             |                                | CVBS Y/C YPbPr HV LR   |  |
|                           |                             |                                | (CVBS) YPbPr LR  |  |
|                           |                             | EXT2/AV2 type                  | SCART CVBS RGB LR  | Select input source when connected with external equipment.  |
|                           |                             |                                | CVBS Y/C LR  |  |
|                           |                             |                                | (CVBS) YPbPr LR  |  |
|                           |                             |                                | CVBS Y/C LR  |  |
|                           |                             | EXT3/AV3 type                  | None   | Select input source when connected with external equipment.  |
|                           |                             |                                | CVBS   |  |
|                           |                             |                                | CVBS LR  |  |
|                           |                             |                                | YPbPr  |  |
|                           |                             |                                | YPbPr LR   |  |
|                           |                             |                                | YPbPr HV LR  |  |
|                           |                             | VGA                            | Off/On   | Select VGA On/Off  |
|                           |                             | SIDE I/O                       | Off/On   | Select SIDE I/O On/Off   |
|                           |                             | HDMI 1                         | Off/On   | Select HDMI 1 On/Off   |
|                           | HDMI 2                      | Off/On                         | Select HDMI 2 On/Off   |  |
|                           | HDMI 3                      | Off/On                         | Select HDMI 3 On/Off   |  |
|                           | HDMI 4                      | Off/On                         | Select HDMI 4 On/Off   |  |
|                           | HDMI side                   | Off/On                         | Select HDMI side On/Off  |  |
|                           | HDMI CEC                    | Off/On                         | Select HDMI CEC On/Off   |  |
|                           | HDMI CEC RC passthrough     | Off/On                         | Select HDMI CEC RC passthrough On/Off                          |  |
|                           | HDMI CEC Pixel Plus link    | Off/On                         | Select Pixel Plus link On/Off                                  |  |
|                           | Miscellaneous               | Region                         | Europe/AP-PAL-MULTI/Australia                                  | Select Region/country.   |
|                           |                             | Tuner type                     | HD1816-MK1/TD1716-MK4/<br>TD1716-MK3/HD1816-MK2                | Select type of Tuner used.   |
|                           |                             | System RC support              | Off/On   | Select System RC support On/Off.   |
|                           |                             | Embedded user manual           | Off/On   | Select Embedded user manual On/Off.  |
|                           |                             | Start-up screen                | Off/On   | Select Start-up screen On/Off.   |
|                           |                             | Wallpaper                      | Off/On   | Select Wallpaper On/Off.   |
|                           |                             | Hotel mode                     | Off  | Hotel mode is Off.   |
| Option number             | Group 1                     | e.g. "08192.02181.01387.45160" |  | The first line (group 1) indicates hardware options 1 to 4.  |
|                           | Group 2                     | e.g. "10185.12448.00164.00000" |  | The second line (group 2) indicates software options 5 to 8.   |
|                           | Store                       |                                |  | Store after changing.  |
| Initialise NVM            |                             |                                |  | N.A  |
| Store                     |                             |                                |  | Select Store in the SAM root menu after making <b>any</b> changes.   |
| Software maintenance      | Software events             | Display                        |  | Display information is for development purposes.   |
|                           |                             | Clear                          |  |  |
|                           |                             | Test reboot                    |  |  |
|                           | Hardware events             | Display                        |  | Display information is for development purposes.   |
|                           |                             | Clear                          |  |  |
| Operation hours display   |                             | 0003                           |  | In case the display must be swapped for repair, you can reset the "Display operation hours" to "0". So, this one does keeps up the lifetime of the display itself (mainly to compensate the degeneration behaviour). |
| Test setting              | Digital info                | QAM modulation: 64-QAM         |  | Display information is for development purposes.   |
|                           |                             | Symbol rate: 23:29             |  |  |
|                           |                             | Original network ID: 12817     |  |  |
|                           |                             | Network ID:12817               |  |  |
|                           |                             | Transportstream ID: 2          |  |  |
|                           |                             | Service ID: 3                  |  |  |
|                           |                             | Hierarchical modulation: 0     |  |  |
|                           |                             | Selected video PID: 35         |  |  |
|                           | Selected main audio PID: 99 |                                |  |  |
|                           | Selected 2nd audio PID: -1  |                                |  |  |
|                           | Install start frequency     | 000                            |  | Install start frequency from "0" MHz   |
| Install end frequency     | 999                         |                                | Install end frequency as 999 MHz                               |  |
| Default install frequency |                             |                                |  |  |
| Installation              | Digital only                |                                | Select Digital only or Digital + Analogue before installation. |  |
|                           | Digital + Analogue          |                                |  |  |

| Main Menu                 | Sub-menu 1                 | Sub-menu 2                         | Sub-menu 3 | Description  |
|---------------------------|----------------------------|------------------------------------|------------|--|
| Development file versions | Development 1 file version | Display parameters DISPT 3.26.8.7  |            | Display information is for development purposes.           |
|                           |                            | Acoustics parameters ACSTS 3.6.6.5 |            |  |
|                           |                            | PQ - PRFPP 1.26.10.4               |            |  |
|                           |                            | Ambilight parameters PRFAM 2.6.1.3 |            |  |
|                           | Development 2 file version | 12NC one zip software              |            | Display information is for development purposes.           |
|                           |                            | Initial main software              |            |  |
|                           |                            | NVM version Q5492_0.4.0.0          |            |  |
|                           |                            | Flash units SW Q5492_0.26.15.0     |            |  |
| Upload to USB             | Channel list               |                                    |            | To upload several settings from the TV to an USB stick     |
|                           | Personal settings          |                                    |            |  |
|                           | Option codes               |                                    |            |  |
|                           | Display-related alignment  |                                    |            |  |
|                           | History list               |                                    |            |  |
| Download from USB         | Channel list               |                                    |            | To download several settings from the USB stick to the TV. |
|                           | Personal settings          |                                    |            |  |
|                           | Option codes               |                                    |            |  |
|                           | Display-related alignment  |                                    |            |  |

## 7. Circuit Descriptions

### Index of this chapter:

- [7.1 Introduction](#)
- [7.2 Power Architecture](#)
- [7.3 Front-End](#)
- [7.4 HDMI](#)
- [7.5 Video and Audio Processing - PNX8543](#)
- [7.6 Common Interface CI+](#)
- [7.7 Net TV](#)
- [7.8 Ambi Light](#)

### Notes:

- Only **new** circuits (circuits that are not published recently) are described.
- Figures can deviate slightly from the actual situation, due to different set executions.
- For a good understanding of the following circuit descriptions, please use the wiring, block (see chapter 9. Block Diagrams) and circuit diagrams (see chapter 10. Circuit Diagrams and PWB Layouts). Where necessary, you will find a separate drawing for clarification.

Main difference with the previous platform is the introduction of “Net TV” and “CI+”.

### 7.1.1 Implementation

Key components of this chassis are:


- PNX8543 Digital Colour Decoder
- EP3C25F324C7N FPGA (“Local Contrast”)
- HD1816AF Hybrid Tuner
- DRX3926K Demodulator
- TDA9996 HDMI Switch
- TPA3123D2PWP Class D Power Amplifier
- DP83816AVNG PCI ethernet media access controller and physical layer (MacPhyter-II).

### 7.1.2 TV543 Architecture Overview

- For details about the chassis block diagrams refer to chapter 9. Block Diagrams. An overview of the TV543 architecture can be found in [Figure 7-1](#).

## 7.1 Introduction

The Q549.2E LA chassis (platform name TV543/92) is the successor of the Q529.1E LA chassis (platform TV522/92).




18310\_200\_090317.eps  
090317

Figure 7-1 Architecture of TV543/92 Elite Core platform



7.1.3 SSB Cell Layout




18310\_201\_090317.eps  
090317

Figure 7-2 SSB layout cells (top view)

## 7.2 Power Architecture

Refer to figure [Figure 7-3](#) for the power architecture of this platform.



18310\_202\_090317.eps  
090317

Figure 7-3 Power Architecture TV543/92 platform

### 7.2.1 Power Supply Unit

All power supplies are a black box for Service. When defective, a new board must be ordered and the defective one must be returned, unless the main fuse of the board is broken. Always replace a defective fuse with one with the correct specifications! This part is available in the regular market. Consult the Service website for the order codes of the boards.

In the TV543 Elite Core platform, for sets up to and including 47", the Integrated Power Board (IPB) - incl. inverter is used. For sets of 52" and 56", a conventional PSU (with additional inverters) is used.

In this manual, no detailed information is available because of design protection issues.

The output voltages to the chassis are:

- +3V3-STANDBY (standby-mode only)
- +12V (on-mode)
- +Vsnd (+24V) (audio power) (on-mode)
- +24V (bolt-on power) (on-mode)
- IPB: High voltage to the LCD panel (for sets up to and including 47").

### 7.2.2 Diversity

Below find an overview of the different PSUs that are used:

Table 7-1 Supply diversity


| Supplier | PSU           | Model | Input Voltage Range       |
|----------|---------------|-------|---------------------------|
| LGIT     | PLHL-T826A    | 32"   | High Mains (198- 265 Vac) |
| Delta    | DPS-298CP A   | 37"   | High Mains (198- 265 Vac) |
| Delta    | DPS-411AP-3 A | 56"   | High Mains (198- 265 Vac) |

### 7.3 Front-End

The Front-End consist of the following key compbents:

- Tuner HD1816AF
- SAW filter 36M125
- IF demodulator DRX3926K
- AGC amplifier UPC3221GV.

Below find a block diagram of the front-end application.




18440\_211\_090227.eps  
090227

**Figure 7-4 Front-End block diagram**

The DRX3926K is a multi-standard demodulator supporting DVB-C, DVB-T and analogue standards. The demodulated digital stream is fed into the parallel transport stream data ports of the PNX8543. The demodulated analogue signal in the form of CVBS is connected to the analogue video CVBS/Y input channel, while the SIF is connected via the SSIF2 positive input port.

### 7.4 HDMI


In this platform, the TDA9996 HDMI multiplexer is implemented. Only for one HDMI input, a separate EEPROM is implemented to store the EDID values. For the other HDMI inputs, the EDID contents are no longer stored in a separate EEPROM, but directly in the multiplexer. Each input has its own physical subaddress: the first 253 bytes are common, where the last 3 bytes define the specific input. The EDID contents are, at +5V power-up, downloaded to RAM. The following figures show the HDMI input configuration and EDID control.



18440\_213\_090227.eps  
090227

**Figure 7-5 HDMI input configuration**

### Platform with embedded EDID



18440\_214\_090227.eps  
090227

**Figure 7-6 EDID control (embedded EDID)**

The delta's with respect to the use of the TDA9996 as HDMI multiplexer compared with earlier chassis/platforms are:

- +5V detection mechanism
- Stable clock detection mechanism
- Integrated EDID
- RT control
- HPD control
- TMDS output control
- CEC control
- New hotplug control for PNX8543 for 5th HDMI input
- New EDID structure: EDID stored in TDA9996, therefore there are no EDID pins on the SSB. Only in the event of a 5th HDMI input, an additional EEPROM is foreseen, as was implemented in previous platforms.

After replacement of the TDA9996 HDMI mux, the default I<sup>2</sup>C address should be reprogrammed from C0 to CE, and the HDMI EDIDs should be reprogrammed as well. Both actions should be executed via ComPair.

### 7.5 Video and Audio Processing - PNX8543


The PNX8543 is the main audio and video processor (or System-on-Chip) for this platform. It is a member of the PNX85xx SoC family (described in earlier chassis) with the addition of the MPEG4 functionality; the separate STi710x MPEG4 decoder is no longer implemented in this platform.

Some more delta's compared to the previous PNX85xx are:

- 2 HDMI inputs (A & B)
- HDMI deep colour RGB/YCbCr 4:4:1 10/12 bit detection.

The PNX8543 handles the digital and analogue audio- and video decoding and processing. The processor is a MIPS32 general purpose CPU and a 8051-based TV controller for power management and user event handling.

- For a functional diagram of the PNX8543, refer to [Figure 7-7](#).




18440\_202\_090226.eps  
n9n226

Figure 7-7 PNX8543 functional diagram

7.5.1 Video Subsystem

Refer to [Figure 7-8](#) for the main video interfaces for the PNX8543 and the video signal flow between blocks and memory.



18440\_203\_090226.eps  
090226


Figure 7-8 PNX8543 video flow diagram

The Video Subsystem consist of the following blocks:

- Analogue Front-End (AFE) block
- Video and PC Capture (VPC/PC) pipe
- HDMI Receiver interface
- Memory-Based Video Processor MBVP)
- Video Composition Pipe (CPIPE)
- Memory Based Video Processor (MBVP) VO-1
- Memory Based Video Processor (MBVP) VO-2
- Video Composition Pipe (CPIPE)
- Dual Flat Panel Display-LVDS (FPD-LVDS)
- Digital Encoder (DENC)
- Digital Video VIP
- 2D graphics block.

## 7.5.2 Audio Subsystem

Refer to [Figure 7-9](#) for the main audio interfaces for the PNX8543 and the audio signal flow between blocks and memory.



18440\_204\_090226.eps  
090226

Figure 7-9 PNX8543 audio flow diagram


The Audio Subsystem consist of the following blocks:

- Analogue Audio Front End (AAFE) used to capture Baseband Audio Inputs and to sample Secondary Sound IF (SSIF) directly or via Low-IF input
- HDMI Receiver interface block
- SPDIF input block
- Audio Input (AI) block
- Audio Output (AO) block
- Demodulation & Decoding (ASDEC) DSP for decoding all analogue terrestrial TV sound standards
- Audio Post-Processing (APP) block
- Digital Audio decoder.

### 7.5.3 Connectivity and Compute Subsystem

Refer to [Figure 7-10](#) for the connectivity and compute subsystem.





**Figure 7-10 PNX8543 connectivity and compute subsystem**

The Connectivity Subsystem consists of:

- PCI/XIO interface
- USB2.0 interface
- Three 2-wire UARTs
- Four Master/Slave I<sup>2</sup>C interfaces
- Common Interface/Conditional Access Interface.

keys in the components, **unauthorised exchange of these components will always result in a defective board.**

The Computing Subsystem consists of:

- 32-bit MIPS RISC core
- Enhanced JTAG (EJTAG) block inside the MIPS
- JTAG\_MMIO blocks
- TV controller
- Audio/Video DSP (AV\_DSP)
- Memory Control Unit (MCU).

#### 7.5.4 Service Notice - FLASH RAM / PNX8543 exchange

The FLASH RAM (item 7P10) and/or PNX8543 (item 7H00) can only be exchanged by an authorised central workshop with dedicated programming tools. Due to the presence of (CI+)

## 7.6 Common Interface CI+

Together with this platform, an extension to the Common Interface (CI) Conditional Access system is added, called CI+.

CI+ or Common Interface Plus is a specification that extends the Common Interface (DVB-CI) as described in the digital broadcasting standard DVB.

The weakness of the conventional CI module as Conditional Access system was the absence of a Copy Protection mechanism, as decrypted content could be sent over the PCMCIA interface unscrambled. With the CI+ extension, a form of copy protection is established between the Conditional

Access Module (CAM) and the Integrated Digital Television (IDTV). The security mechanisms in CI+ are derived/copied from POD (with the exception of Out Of Band (OOB) used in US CA systems). For more information about conventional CA systems using a CI module, refer to the BJ3.0E L/PA or BL2.XU Service Manual.

The CI+ standard is downwards compatible with the existing CI standard.

The following figure shows the implementation of the CI+ Conditional Access system in the TV543 platform.




Figure 7-11 CI+ Conditional Access implementation

## 7.7 Net TV

In this chassis, a feature that enables access to dedicated internet pages from a limited group of information suppliers,

called "Net TV", is introduced. A separate Wi-Fi module enables wireless communication with a local network.


## 7.8 Ambi Light

The Ambi Light architecture in this platform has been entirely renewed. The characteristics are:

- Additional DC/DC board generating 12/16/24 V (optional)
- ARM processor (on DC/DC panel or AL board)
- Low-power LEDs
- SPI interface from ARM to LED drivers
- I<sup>2</sup>C upgradeable via USB
- Each AL module has a temperature sensor.

The use of the DC/DC board is optional. In case no DC/DC board is implemented, the ARM processor is located on one of the AL boards.

Refer to [Figure 7-12](#) for the Ambi Light architecture.




18310\_203\_090317.eps  
090317

Figure 7-12 Interface between Ambi Light and SSB

7.8.1 ARM controller

Refer to Figure 7-13 below for signal interfacing to and from the ARM controller. The ARM controller is located on the DC/DC board (item no. 7302) or AL panel (item no. 7102).



18310\_204\_090318.eps  
090318

Figure 7-13 ARM controller interface

Data transfer between ARM processor and LED drivers is executed by a Serial Peripheral Interface (SPI) bus interface.

The SPI bus is a synchronous serial data link standard that operates in full duplex mode.


For debugging purposes, the working principle is given below:

- At startup the controller will read-out matrix data from the EEPROM devices (via SPI DATA RETURN)
- Before operation, the driver current is set via SPI, with driver in DC mode
- During normal operation the controller receives RGB-, configuration-, operation mode- and topology data via I<sup>2</sup>C
- The controller converts the I<sup>2</sup>C RGB data via the matrixes to SPI LED data
- Via data return the controller receives error data (if applicable).

Also PWM clock and BLANK signals are generated by the controller. The controller can be reprogrammed via I<sup>2</sup>C (via USB). The controller can receive matrix values via I<sup>2</sup>C, which will be stored in the EEPROM of each AL module via the SPI bus. The temperature sensor in each AL module controls the TEMP line; in case of a too high temperature the controller will reduce the overall brightness.

7.8.2 LED driver communication (via SPI bus)

Refer to Figure 7-14 below for signal interfacing between the ARM controller and the LED drivers on the AL boards, and the LED drivers and the EEPROMs on the AL boards.



18310\_205\_090318.eps  
090318

Figure 7-14 SPI communication between ARM controller and LED drivers

The ARM controller communicates with the LED drivers (on each AL module) via an SPI bus. For debugging purposes, the working principle is given below:

- Data from the ARM controller is linked through the drivers, which are connected in cascade
- SPI CLK, SPI LATCH, PROG, BLANK and PWM CLOCK are going directly from the controller to each driver
- SPI DATA RETURN is linked from the last driver to the controller: controller decides which driver returns data.

### 7.8.3 Temperature Control

Refer to [Figure 7-15](#) for signal interfacing between the ARM controller and the temperature sensor on the AL boards.




Figure 7-15 Communication between ARM controller and temperature sensor

Each AL board is equipped with a temperature sensor. If one of the sensors detects a temperature over the threshold, the TEMP line is pulled LOW which results in brightness reduction.


# 8. IC Data Sheets

This chapter shows the internal block diagrams and pin configurations of ICs that are drawn as “black boxes” in the


electrical diagrams (with the exception of “memory” and “logic” ICs).

## 8.1 Diagram [SSB: DC/DC B01A, TPS53124PW \(IC 7U03\)](#)

### Block Diagram



### Pin Configuration




18250\_300\_090319.eps  
090319


Figure 8-1 Internal block diagram and pin configuration

8.2 Diagram [SSB: Front End](#) B02B, DRX3926K (IC 7T50)

**Block Diagram**



**Pin Configuration**




18440\_300\_090303.eps  
090303

**Figure 8-2 Pin configuration**




8.3 Diagram [SSB: PNX8543 - Stand-by Controller](#) B04A, PNX8543 (IC7H00)

Block Diagram



Pin Configuration




18440\_301\_090303.eps  
090303


Figure 8-3 Internal block diagram and pin configuration

8.4 Diagram [SSB: Ethernet B05A, PNX5120 \(IC7C00\)](#)

### Block Diagram



### Pin Configuration




18560\_300\_090403.eps  
090403

Figure 8-4 Internal block diagram and pin configuration

8.5 Diagram **SSB: Ethernet B07G, DP83816 (IC7N04)**

Block Diagram



Pin Configuration





Figure 8-5 Internal block diagram and pin configuration


F\_15710\_167.eps  
230905

8.6 Diagram [SSB: Audio B10A, TPA3123D \(IC 7D10\)](#)

**Block Diagram**



**Pin Configuration**



| TERMINAL        |              | I/O/P | DESCRIPTION  |
|-----------------|--------------|-------|--|
| NAME            | 24-PIN (PWP) |       |  |
| $\overline{SD}$ | 2            | I     | Shutdown signal for IC (low = disabled, high = operational). TTL logic levels with compliance to AVCC  |
| RIN             | 6            | I     | Audio input for right channel  |
| LIN             | 5            | I     | Audio input for left channel   |
| GAIN0           | 18           | I     | Gain select least-significant bit. TTL logic levels with compliance to AVCC  |
| GAIN1           | 17           | I     | Gain select most-significant bit. TTL logic levels with compliance to AVCC   |
| MUTE            | 4            | I     | Mute signal for quick disable/enable of outputs (high = outputs switch at 50% duty cycle, low = outputs enabled). TTL logic levels with compliance to AVCC |
| BSL             | 21           | I/O   | Bootstrap I/O for left channel   |
| PVCCCL          | 1, 3         | P     | Power supply for left-channel H-bridge, not internally connected to PVCCR or AVCC  |
| LOUT            | 22           | O     | Class-D 1/2-H-bridge positive output for left channel  |
| PGNDL           | 23, 24       | P     | Power ground for left-channel H-bridge   |
| VCLAMP          | 11           | P     | Internally generated voltage supply for bootstrap capacitors   |
| BSR             | 16           | I/O   | Bootstrap I/O for right channel  |
| ROUT            | 15           | O     | Class-D 1/2-H-bridge negative output for right channel   |
| PGNDR           | 13, 14       | P     | Power ground for right-channel H-bridge.   |
| PVCCR           | 10, 12       | P     | Power supply for right-channel H-bridge, not connected to PVCCCL or AVCC   |
| AGND            | 9            | P     | Analog ground for digital/analog cells in core   |
| AGND            | 8            | P     | Analog ground for analog cells in core   |
| BYPASS          | 7            | O     | Reference for preamplifier inputs. Nominally equal to AVCC/8. Also controls start-up time via external capacitor sizing.                                   |
| AVCC            | 19, 20       | P     | High-voltage analog power supply. Not internally connected to PVCCR or PVCCCL  |
| Thermal pad     | Die pad      | P     | Connect to ground. Thermal pad should be soldered down on all applications to properly secure device to printed wiring board.                              |


18440\_302\_090303.eps  
090303

**Figure 8-6 Internal block diagram and pin configuration**


# 9. Block Diagrams

## Wiring Diagram 32" (Elite Core)

WIRING DIAGRAM 32" (ELITE CORE)




# Wiring Diagram 37" (Elite Core)





# Wiring Diagram 56" (Elite Core)


WIRING DIAGRAM 56" (ELITE CORE)



18310\_407\_090420.eps 090508




Block Diagram Audio



18310\_403\_090305.eps 090313




# Block Diagram I<sup>2</sup>C





### Supply Lines Overview




18310\_406\_090305.aps 090306



# 10. Circuit Diagrams and PWB Layouts

## Interface Ambilight: Interface + Single DC-DC



- 1100 A6 F123 E2
- 1101 A7 F124 E2
- 1M59 C2 F125 B3
- 1M84 A2 F126 A2
- 1M85 A2 I100 A6
- 2100 A6 I102 C6
- 2101 B5 I103 C6
- 2102 C6 I104 D9
- 2103 D6 I105 D5
- 2104 D5 I106 D7
- 2105 D9 I108 D6
- 2106 D9 I109 A8
- 2107 E9 c001 E2
- 2108 D3 c002 E2
- 2109 E3
- 3100 B5
- 3101 C5
- 3102 D6
- 3103 D9
- 3104 D6
- 3105 D5
- 3106 D5
- 3107 D5
- 3108 E9
- 3109 D2
- 3110 D3
- 3111 E8
- 3112 B6
- 5100 A8
- 5101 A8
- 5102 A7
- 5103 B8
- 5104 B8
- 5105 B8
- 5106 B8
- 5107 A6
- 5108 A6
- 6100 C8
- 7100 B7
- 9101 C3
- 9102 C3
- 9103 C3
- 9104 C3
- F101 B3
- F102 B3
- F103 B3
- F104 B3
- F105 B3
- F106 B3
- F107 A7
- F108 B3
- F109 B3
- F110 B3
- F111 B3
- F112 B3
- F113 B3
- F114 B5
- F115 C2
- F116 D2
- F117 D2
- F118 D2
- F119 D2
- F120 D2
- F121 E2
- F122 E2

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

STUFFING DIVERSITIES FOR DC/DC INTERFACE AMBI 2K9

| DC/DC INTERFACE | 1101 | 1M85 | 5103/5104 | 5105/5106 | VLED1 | VLED2 |
|-----------------|------|------|-----------|-----------|-------|-------|
| 3104 328 58341  | in   | in   | in        | out       | 24V   | 16V   |
| 3104 328 58351  | out  | out  | out       | in        | 12V   | 12V   |
| 3104 328 58361  | out  | out  | out       | in        | 16V   | 16V   |
| 3104 328 58371  | out  | out  | out       | out       | 12V   | 16V   |


See the stuffing diversities table in the case of components marked with one star (\*)

| CHN                 |     | SETNAME                                       |               |                      |
|---------------------|-----|---|---------------|----------------------|
| CLASS_NO            |     | <b>DC-DC INTERFACE</b><br><br><b>AMBI 2K9</b> |               |                      |
| 08-06-19            | 1   |   |               | <b>3104 313 6325</b> |
| 08-08-06            | 2   |   |               |                      |
| 08-10-23            | 3   |   |               |                      |
|                     |     |   |               |                      |
| NAME Peter Van Hove |     | SUPERS.                                       |               |                      |
| CT                  | MGr | CHECK   | DATE 08-06-06 |                      |

Interface Ambilight: Dual DC-DC

PHILIPS

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.




7200 : TPS54383 in case of 16V or dual dc-dc converter  
 The components marked with one star (\*) belong to the 12V versions (3104 328 58351, 3104 328 58371).  
 The components marked with two stars (\*\*) belong to the 16V versions (3104 328 58331, 3104 328 58341, 3104 328 58361, 3104 328 58371).

- 2200 A4
- 2201 A4
- 2202 A5
- 2203 A5
- 2204 B3
- 2205 B6
- 2206 B1
- 2207 B2
- 2208 B7
- 2209 B7
- 2210 B8
- 2211 C3
- 2212 C4
- 2213 C6
- 2214 C3
- 2215 C6
- 2216 C2
- 2217 C7
- 2218 D1
- 2219 D2
- 2220 D7
- 2221 D3
- 2222 D5
- 2223 D8
- 2224 D8
- 3200 A3
- 3201 A6
- 3202 B3
- 3203 B6
- 3204 B3
- 3205 B6
- 3206 D3
- 3207 D2
- 3208 D7
- 3209 D5
- 3210 D3
- 3211 D3
- 3212 D6
- 3213 D6
- 5200 B2
- 5201 B7
- 6200 B2
- 6201 B7
- 7200 B4
- 9201 B5
- 9202 C4
- F200 B2
- F201 C7
- F202 D3
- F203 B5
- F204 B4
- F207 C4
- I200 A3
- I201 A6
- I204 B2
- I205 B6
- I206 B6
- I208 B3
- I209 B6
- I210 C6
- I211 C3
- I212 C3
- I213 D5
- I214 D4
- I215 D3
- I216 B5
- I217 B4

|                     |                 |                                     |            |
|---------------------|-----------------|-------------------------------------|------------|
| CHN                 |                 | SETNAME                             |            |
| CLASS_NO            | DC-DC INTERFACE |                                     | 1 08-06-19 |
| 08-06-19            | 1               | AMBI 2K9                            | 2 08-08-06 |
| 08-08-06            | 2               |                                     | 3 08-09-18 |
| 08-10-23            | 3               |                                     | 4 08-10-23 |
| NAME Peter Van Hove |                 | SUPERS.                             | 5 08-12-06 |
|                     |                 | 3                                   | A3         |
| CHECK               | DATE 08-06-09   | ROYAL PHILIPS ELECTRONICS N.V. 2008 |            |

3104 313 6325

Interface Ambient: Microcontrollerblock




- 1300 E2
- 1301 H5
- 1302 C4
- 2300 A3
- 2301 A4
- 2302 A5
- 2303 A4
- 2304 B8
- 2305 B10
- 2306 B9
- 2307 B10
- 2308 D4
- 2309 D5
- 2310 F6
- 2311 F7
- 2312 F7
- 2313 F7
- 2314 F7
- 2315 F7
- 2316 F8
- 2318 G2
- 2319 G6
- 2320 H5
- 2321 H4
- 2322 H4
- 2323 H4
- 2324 H4
- 3300-2 D5
- 3300-3 D7
- 3300-4 D7
- 3301-1 D6
- 3301-2 E5
- 3301-3 E5
- 3301-4 D7
- 3302-1 D7
- 3302-2 D6
- 3302-3 E6
- 3302-4 D6
- 3303-1 E6
- 3303-2 D6
- 3303-3 E6
- 3304-1 D6
- 3304-2 D7
- 3304-3 D7
- 3304-4 D7
- 3305-1 E7
- 3305-2 G8
- 3305-3 G9
- 3305-4 G8
- 3306-1 E8
- 3306-2 E8
- 3306-3 E8
- 3306-4 E8
- 3307-1 E8
- 3307-2 F8
- 3308-1 F8
- 3308-2 F8
- 3309-1 F8
- 3309-2 F8
- 3309-3 F8
- 3309-4 F8
- 3310 A10
- 3311 A8
- 3312 A10
- 3313 B8
- 3314 B8
- 3315 B10
- 3316 B10
- 3317 B8
- 3318 C10
- 3319 C8
- 3320 C5
- 3321 C5
- 3322 D5
- 3323 D5
- 3324 D7
- 3325 D6
- 3326 D6
- 3327 D6
- 3328 E5
- 3329 E5
- 3330 E8
- 3331 E8
- 3332 E3
- 3333 F2
- 3334 G5
- 3335 G5
- 3336 G6
- 3337 G6
- 3338 E8
- 3339 F1
- 7300-1 B9
- 7300-2 A10
- 7301 A4
- 7302 E3
- 7303 F2
- 9300 E3
- 9301 F3
- 9302 F3
- 9303 F3
- 9305 G1
- 9307 H4
- C300 B8
- F300 A5
- F301 A8
- F302 A10
- F303 B11
- F304 C4
- F305 C4
- F306 D4
- F307 F3
- F308 F3
- F309 G6
- F310 G6
- F311 G8
- F312 G8
- F313 G8
- F314 G5
- F315 H4
- F316 H4
- F317 F1
- F320 E9
- I300 E9
- I302 F9
- I303 A4
- I304 C10
- I305 E6
- I306 E7
- I307 G6
- I308 G2
- I309 G5
- I310 D5
- I311 E7
- I312 E7
- I313 E7
- I314 F7
- I315 F7
- I316 F8
- I317 F6
- I318 F7
- I319 F5
- I320 F8
- I321 F6
- I322 G5

|                      |                 |               |                                     |
|----------------------|-----------------|---------------|-------------------------------------|
| CHN                  | SETNAME         |               |                                     |
| CLASS_NO             | DC-DC INTERFACE |               |                                     |
| 08-06-19             | AMBI 2K9        |               |                                     |
| 08-08-06             |                 | 3104 313 6325 |                                     |
| 08-10-23             |                 |               |                                     |
| NAME: Peter Van Hove | SUPERS:         | 3             | 130 - 3                             |
| CHECK                | DATE: 08-06-09  |               | ROYAL PHILIPS ELECTRONICS N.V. 2008 |

All rights reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner.



6 LED Low-Pow: Microcontroller Block Liteon




PHILIPS

All rights reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner.

- 1101 E4
- 1105 B5
- 11M1A C1
- 1M2A G1
- 1M55 A1
- 1M84 E1
- 2101 A6
- 2102 A7
- 2103 A8
- 2104 B7
- 2105 B10
- 2106 B13
- 2107 B11
- 2108 B12
- 2108 D7
- 2110 D7
- 2111 G4
- 2112 H7
- 2113 H7
- 2114 F9
- 2115 F9
- 2116 F9
- 2117 F9
- 2118 H8
- 2119 H6
- 2120 H6
- 2121 H6
- 2122 F9
- 2123 F10
- 2124 F10
- 2125 B3
- 2126 F10
- 2127 B1
- 2128 B1
- 2129 B2
- 2130 F2
- 2131 F10
- 3101-2 D7
- 3101-3 D9
- 3101-4 E9
- 3102-1 D9
- 3102-2 D9
- 3102-3 E9
- 3102-4 D9
- 3103-1 E9
- 3103-2 G10
- 3103-3 C11
- 3103-4 G10
- 3104-1 D8
- 3104-2 E8
- 3104-3 E8
- 3104-4 D9
- 3105-1 E9
- 3105-2 D8
- 3105-3 E8
- 3105-4 D8
- 3106-1 E8
- 3106-2 D8
- 3106-3 E8
- 3107 C7
- 3108 C7
- 3109 D7
- 3110 D7
- 3111 B10
- 3112 D9
- 3113 D8
- 3114 E8
- 3115 E8
- 3116 E8
- 3117 E7
- 3118 E5
- 3119 F4
- 3120 F5
- 3123 C11
- 3124-1 E11
- 3124-2 E11
- 3124-3 E11
- 3124-4 E11
- 3125-1 F11
- 3125-2 F11
- 3125-4 F11
- 3126-1 F11
- 3126-2 F11
- 3126-4 F11
- 3127-1 F11
- 3127-4 F11
- 3128 E11
- 3129 E11
- 3130 G8
- 3131 G7
- 3132 H8
- 3133 H8
- 3134 A13
- 3135 A11
- 3136 A12
- 3137 B11
- 3138 B13
- 3139 B12
- 3140 C11
- 3141 C13
- 3142 F11
- 7101 A7
- 7102 E6
- 7110 F4
- 7116-1 B11
- 7116-2 A12
- 9101 E5
- 9102 F5
- 9103 F5
- 9104 F5
- 9106 H8
- 9107 A5
- 9108 A5
- 9109 A5
- 9110 B5
- 9111 A3
- 9112 B2
- 9113 B3
- 9114 B2
- 9119 H6
- 9121 G4
- C140 B10
- F101 A8
- F102 F5
- F103 H7
- F104 F5
- F105 D7
- F106 B12
- F107 C7
- F108 D7
- F109 G3
- F112 G8
- F116 A10
- F117 B13
- F118 C11
- F120 A1
- F121 A1
- F122 A1
- F123 A1
- F124 B1
- F125 B1
- F126 B1
- F127 B1
- F128 B1
- F129 B1
- F130 B1
- F131 B1
- F132 B1
- F133 E1
- F134 E1
- F135 E1
- F136 F1
- F137 F1
- F138 F1
- F139 F1
- F110 G8
- F111 G8
- F113 G10
- F114 G10
- F115 G10
- F116 G10
- F117 G10
- F118 E11
- F119 E11
- F120 E11
- F121 E11
- F122 E11
- F123 E11
- F124 E11
- F125 E11
- F126 E11
- F127 E11
- F128 E11
- F129 E11
- F130 E11
- F131 E11
- F132 E11
- F133 E11
- F134 E11
- F135 E11
- F136 E11
- F137 E11
- F138 E11
- F139 E11

|            |                    |        |                                     |
|------------|--------------------|--------|-------------------------------------|
| CHN        | SETNAME            |        |                                     |
| CLASS_NO   | DRIVER 6LED LITEON | 1      | 2008-06-10                          |
|            | 2K9                | 2      | 2008-08-08                          |
|            |                    | 3      | 2008-10-27                          |
| 2008-08-08 |                    | 2      |                                     |
| 2008-10-27 |                    | 3      |                                     |
| NAME       | Peter Van Hove     | SUPERS |                                     |
| CHECK      |                    | DATE   | 2008-06-02                          |
|            |                    |        | ROYAL PHILIPS ELECTRONICS N.V. 2008 |

6 LED Low-Pow: Microcontroller Liteon




- 2201 B8
- 2202 C8
- 2203 D8
- 2209 B2
- 2210 G6
- 2211 I6
- 2214 A6
- 2215 F7
- 2216 F7
- 2217 B12
- 2218 C12
- 2219 D12
- 2220 E9
- 3121 D9
- 3203 B5
- 3204 B7
- 3205 C5
- 3207 B9
- 3209 C9
- 3210 B3
- 3211 C9
- 3212 D11
- 3213 B3
- 3214 H6
- 3215 H6
- 3216 H6
- 3217 H6
- 3218 H6
- 3219 B11
- 3220 C11
- 3221 H11
- 3222 I8
- 3223 C11
- 3224 H11
- 6216 I6
- 7201-1 A10
- 7201-2 C10
- 7201-3 D10
- 7201-4 B10
- 7209 B2
- 7210 C2
- 7212 B3
- 7214 B6
- 7215 G7
- 9208 A10
- 9209 B9
- 9210 B10
- 9211 C9
- 9212 C10
- 9213 D8
- 9214 D10
- F202 B3
- F203 C5
- F204 H6
- F205 B10
- F206 C10
- F207 C10
- F208 D10
- F209 H11
- F210 G9
- F211 G9
- F212 G9
- F213 H9
- F214 H9
- F215 H9

|                    |         |   |
|--------------------|---------|---|
| DRIVER 6LED LITEON |         | 1 |
| 2K9                |         |   |
| 8204 000 8857      |         |   |
| 2008-08-08         | 2       |   |
| 2008-10-27         | 3       |   |
| NAME               | SUPERS. |   |
| CHECK              | DATE    |   |

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.





6 LED Low-Pow: LED Liteon



All rights reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner.




Layout 6 LED Low-Pow



3104 313 6313.3

18310\_551\_090309  
090309

### 8 LED Low-Pow: Microcontroller Block Liteon




- 1101 E4
- 1105 B5
- 1M1A C1
- 1M2A G1
- 1M85 A1
- 1M84 E1
- 2101 A6
- 2102 A7
- 2103 A8
- 2104 B7
- 2105 B10
- 2106 B13
- 2107 B11
- 2108 B12
- 2109 D7
- 2110 D7
- 2111 G4
- 2112 H7
- 2113 H7
- 2114 F9
- 2115 F9
- 2116 F9
- 2117 F9
- 2118 H8
- 2119 H6
- 2120 H6
- 2121 H6
- 2122 F9
- 2123 F10
- 2124 F10
- 2125 B3
- 2126 F10
- 2127 B1
- 2128 B1
- 2129 B2
- 2130 F2
- 2131 F10
- 3101-2 D7
- 3101-3 D9
- 3101-4 E9
- 3102-1 D9
- 3102-2 D9
- 3102-3 E9
- 3102-4 D9
- 3103-1 E9
- 3103-2 G10
- 3103-3 G11
- 3103-4 G10
- 3104-1 D8
- 3104-2 E8
- 3104-3 E8
- 3104-4 D8
- 3105-1 E8
- 3105-2 D8
- 3105-3 E8
- 3105-4 D8
- 3106-1 E8
- 3106-2 D8
- 3106-3 E8
- 3107 C7
- 3108 C7
- 3109 D7
- 3110 D7
- 3111 B10
- 3112 D9
- 3113 D8
- 3114 E8
- 3115 E8
- 3116 E8
- 3117 E7
- 3118 E5
- 3119 F4
- 3120 F5
- 3123 C11
- 3124-1 E11
- 3124-2 E11
- 3124-3 E11
- 3124-4 E11
- 3125-1 F11
- 3125-2 F11
- 3125-4 F11
- 3126-1 F11
- 3126-2 F11
- 3126-4 F11
- 3127-1 F11
- 3127-4 F11
- 3128 E11
- 3129 E11
- 3130 G8
- 3131 G7
- 3132 H8
- 3133 H8
- 3134 A13
- 3135 A11
- 3136 A12
- 3137 B11
- 3138 B13
- 3139 B12
- 3140 C11
- 3141 C13
- 3142 F11
- 7101 A7
- 7102 E6
- 7110 F4
- 7116-1 B11
- 7116-2 A12
- 9102 F5
- 9103 F5
- 9104 F5
- 9106 H8
- 9107 A5
- 9108 A5
- 9109 A5
- 9110 B5
- 9111 A3
- 9112 B2
- 9113 B3
- 9114 B2
- 9119 H6
- 9120 H6
- 9121 G4
- 9121 H7
- F101 A8
- F102 F5
- F103 H7
- F104 F5
- F105 D7
- F106 B12
- F107 C7
- F108 D7
- F109 G3
- F112 G8
- F116 A10
- F117 B13
- F118 C11
- F120 A1
- F121 A1
- F122 A1
- F123 A1
- F124 B1
- F125 B1
- F126 B1
- F127 B1
- F128 B1
- F129 B1
- F130 B1
- F131 B1
- F132 B1
- F133 E1
- F134 F1
- F135 E1
- F136 F1
- F137 F1
- F138 F1
- F139 F1
- 1110 G8
- 1111 G8
- 1113 G10
- 1114 G10
- 1115 G10
- 1124 E11
- 1125 E11
- 1126 F11

3104 313 6314.3

|                                     |                    |   |            |
|-------------------------------------|--------------------|---|------------|
| CHN                                 | SETNAME            |   |            |
| CLASS_NO                            | DRIVER 6LED LITEON | 1 | 2008-06-10 |
|                                     |                    | 2 | 2008-08-08 |
| 2008-08-08                          | 2K9                | 3 | ??         |
|                                     |                    |   |            |
| NAME Peter Van Hove                 | SUPERS.            | 3 | 130 - 1    |
| CHECK                               | DATE 2008-06-02    |   |            |
| ROYAL PHILIPS ELECTRONICS N.V. 2008 |                    |   |            |

8 LED Low-Pow: Microcontroller Block Liteon




- 2201 B8
- 2202 C8
- 2203 D8
- 2209 B2
- 2210 G6
- 2211 I6
- 2214 A6
- 2215 F7
- 2216 F7
- 2217 B12
- 2218 C12
- 2219 D12
- 2220 E9
- 3121 D9
- 3203 B5
- 3204 B7
- 3205 C5
- 3207 B9
- 3209 C9
- 3210 B3
- 3211 C9
- 3212 D11
- 3213 B3
- 3214 H6
- 3215 H6
- 3216 H6
- 3217 H6
- 3218 H6
- 3219 B11
- 3220 C11
- 3221 H11
- 3222 I8
- 3223 C11
- 3224 H11
- 6216 I8
- 7201-1 A10
- 7201-2 C10
- 7201-3 D10
- 7201-4 B10
- 7209 B2
- 7210 C2
- 7212 B3
- 7214 B6
- 7215 G7
- 9208 A10
- 9209 B9
- 9210 B10
- 9211 C9
- 9212 C10
- 9213 D9
- 9214 D10
- F202 B3
- F203 C5
- F204 H6
- F205 B10
- F206 C10
- F207 C10
- F208 D10
- F209 H11
- F210 G9
- F211 G9
- F212 G9
- F213 H9
- F214 H9
- F215 H9

3104 313 6314.3

|                                     |                    |   |            |
|-------------------------------------|--------------------|---|------------|
| CHN                                 | SETNAME            |   |            |
| CLASS_NO                            | DRIVER 6LED LITEON | 1 | 2008-06-10 |
|                                     |                    | 2 | 2008-08-08 |
| 2008-08-08                          | 2K9                | 3 | ??         |
|                                     |                    |   |            |
| NAME Peter Van Hove                 | SUPERS.            | 3 | 130 - 2    |
| CHECK                               | DATE 2008-06-02    |   |            |
| ROYAL PHILIPS ELECTRONICS N.V. 2008 |                    |   |            |

8 LED Low-Pow: LED Liteon




- 3301 F9
- 3302 F9
- 3303 F9
- 3304 G9
- 3305 G9
- 3306 H9
- 3307 H9
- 3308 H9
- 3309 I9
- 3310 D12
- 3311 D12
- 3312 E12
- 3313 E12
- 3314 E12
- 3315 E12
- 3316 E12
- 3317 F12
- 3318 F12
- 3319 F12
- 3320 F12
- 3321 G12
- 3322 G12
- 3323 G12
- 3325 G4
- 3326 H4
- 3327 H4
- 3328 G4
- 3330 I4
- 3331 F4
- 3332 F4
- 3333 H4
- 3334 F4
- 3335 D12
- 3336 D2
- 3337 D2
- 3338 D1
- 3339 D2
- 3340 D1
- 3341 D1
- 3342 E2
- 3343 D1
- 3344 D1
- 3345 D12
- 3346 E1
- 3347 D1
- 3348 E12
- 3349 E1
- 3350 E1
- 3351 E12
- 3352 E1
- 3353 E1
- 3354 D13
- 3355 E1
- 3356 E1
- 3357 D13
- 3358 E13
- 3359 E13
- 3360 E13
- 3361 E13
- 3362 E13
- 3363 F13
- 3364 F13
- 3365 F13
- 3366 F13
- 3367 G13
- 3368 G13
- 3369 F1
- 3370 F1
- 3371 F1
- 3372 F1
- 3373 F1
- 3374 G1
- 3384 E1
- 3385 F1
- 3386 F1
- 3387 F1
- 3388 F1
- 3389 F1
- 3390 G1
- 3391 G1
- 7000 C2
- 7001 C3
- 7002 C4
- 7003 C6
- 7004 C8
- 7005 C11
- 7305 G4
- 7306 H5
- 7307 F4
- 7315 G9
- 7316 H10
- 7317 F9
- 9301 C1
- 9302 C1
- 9303-1 C10
- 9303-3 C10
- 9303-4 C10
- 9304-1 E10
- 9304-2 E10
- 9304-4 E10
- 9305-1 C6
- 9305-2 C6
- 9305-4 C6
- 9306-1 D5
- 9306-3 D5
- 9306-4 D5
- 9307 A6
- 9308 A6
- 9309-1 B6
- 9309-2 B6
- 9309-4 B6
- 9310-1 B8
- 9310-2 B8
- 9310-4 B8
- 9311-1 H13
- 9311-3 H13
- 9311-4 H12
- 9312-1 B10
- 9312-3 B10
- 9312-4 B10
- 9313-1 B12
- 9313-2 B12
- 9313-4 B12
- 9314 G5
- 9315-1 C12
- 9315-2 C12
- 9315-4 C12
- 9316 H5
- 9317 F5
- 9318-1 C8
- 9318-3 C8
- 9318-4 C8
- 9319-1 D9
- 9319-3 D9
- 9319-4 D9
- 9320-1 D7
- 9320-4 D7
- 9325 F10
- 9326 G10
- 9327 H10
- F302 G5
- F303 G4
- F304 H5
- F305 H5
- F307 F5
- F308 F4
- F325 F10
- F326 F9
- F327 G10
- F328 G9
- F329 H10
- F330 H10
- F340 D1
- F341 D1
- F342 D1
- F343 D1
- F344 D12
- F345 D12
- F346 D13
- F347 G12
- F348 G13
- F349 G13

3104 313 6314.3

|                     |                    |                                     |            |
|---------------------|--------------------|-------------------------------------|------------|
| CHN                 | SETNAME            | 1                                   | 2008-06-10 |
| CLASS_NO            | DRIVER 6LED LITEON | 2                                   | 2008-06-08 |
| 2008-08-08          | 2K9                | 3                                   | ??         |
| NAME Peter Van Hove | SUPERS.            | 130 - 3                             | A2         |
| CHECK               | DATE 2008-06-02    | ROYAL PHILIPS ELECTRONICS N.V. 2008 |            |



8 LED Low-Pow: LED Drive Liteon



3104 313 6314.3

|                                     |                  |              |
|-------------------------------------|------------------|--------------|
| CHN                                 | SETNAME          |              |
| CLASS_NO                            | 2LED + CONNECTOR | 1 2008-05-23 |
|                                     | 2K9              | 2 2008-08-08 |
|                                     |                  | 3 0          |
| 2008-05-23                          | 1                |              |
| 2008-08-08                          | 2                |              |
| 2008-10-31                          | 3                |              |
| NAME Peter Van Hove                 | SUPERS.          | 130 - 1      |
| DATE 2008-04-20                     | CHECK            | A2           |
| ROYAL PHILIPS ELECTRONICS N.V. 2008 |                  |              |


Layout 8 LED Low-Pow



31043136314.3

18490\_550\_090326.eps  
090326

### 10 LED Low-Pow: Microcontroller Block Liteon



PHILIPS


All rights reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner.

|                                     |                    |            |            |
|-------------------------------------|--------------------|------------|------------|
| CHN                                 | SETNAME            |            |            |
| CLASS_NO                            | DRIVER 6LED LITEON | 1          | 2008-06-10 |
|                                     | 2K9                | 2          | 2008-08-08 |
| 2008-08-08                          |                    | 3          | ??         |
|                                     |                    |            |            |
| NAME                                | Peter Van Hove     | SUPERS.    | 3          |
| CHECK                               | DATE               | 2008-06-02 | 130 - 1    |
|                                     |                    |            | A2         |
| ROYAL PHILIPS ELECTRONICS N.V. 2008 |                    |            |            |

- 1101 E4
- 1105 B5
- 1M1A C1
- 1M2A G1
- 1M83 A1
- 1M84 E1
- 2101 A6
- 2102 A7
- 2103 A8
- 2104 B7
- 2105 B10
- 2106 B13
- 2107 B11
- 2108 B12
- 2109 D7
- 2110 D7
- 2111 G4
- 2112 H7
- 2113 H7
- 2114 F9
- 2115 F9
- 2116 F9
- 2117 F9
- 2118 H8
- 2119 H6
- 2120 H6
- 2121 H6
- 2122 F9
- 2123 F10
- 2124 F10
- 2125 B3
- 2126 F10
- 2127 B1
- 2128 B1
- 2129 B2
- 2130 F2
- 2131 F10
- 3101-2 D7
- 3101-3 D9
- 3101-4 E9
- 3102-1 D9
- 3102-2 D9
- 3102-3 E9
- 3102-4 D9
- 3103-1 E9
- 3103-2 G10
- 3103-3 G11
- 3103-4 G10
- 3104-1 D8
- 3104-2 E8
- 3104-3 E8
- 3104-4 D9
- 3105-1 E9
- 3105-2 D8
- 3105-3 E8
- 3105-4 D8
- 3106-1 E8
- 3106-2 D8
- 3106-3 E8
- 3107 C7
- 3108 C7
- 3109 D7
- 3110 D7
- 3111 B10
- 3112 D9
- 3113 D8
- 3114 E8
- 3115 E8
- 3116 E8
- 3117 E7
- 3118 E5
- 3119 F4
- 3120 F5
- 3123 C11
- 3124-1 E11
- 3124-2 E11
- 3124-3 E11
- 3125-1 F11
- 3125-2 F11
- 3125-4 F11
- 3126-1 F11
- 3126-2 F11
- 3126-4 F11
- 3127-1 F11
- 3127-4 F11
- 3128 E11
- 3129 E11
- 3130 G6
- 3131 G7
- 3132 H8
- 3133 H8
- 3134 A13
- 3135 A11
- 3136 A12
- 3137 B11
- 3138 B13
- 3139 B12
- 3140 C11
- 3141 C13
- 3142 F11
- 7101 A7
- 7102 E6
- 7110 F4
- 7116-1 B11
- 7116-2 A12
- 9101 E5
- 9102 F5
- 9103 F5
- 9104 F5
- 9106 H8
- 9107 A5
- 9108 A5
- 9109 A5
- 9110 B5
- 9111 A3
- 9112 B2
- 9113 B3
- 9114 B2
- 9119 H6
- 9121 G4
- C140 B10
- F101 A8
- F102 F5
- F103 H7
- F104 F5
- F105 D7
- F106 B12
- F107 C7
- F108 D7
- F109 G3
- F112 G8
- F116 A10
- F117 B13
- F118 C11
- F120 A1
- F121 A1
- F122 A1
- F123 A1
- F124 B1
- F125 B1
- F126 B1
- F127 B1
- F128 B1
- F129 B1
- F130 B1
- F131 B1
- F132 B1
- F133 E1
- F134 F1
- F135 E1
- F136 F1
- F137 F1
- F138 F1
- F139 F1
- F140 G8
- F141 G8
- F142 E1
- F143 G10
- F144 G10
- F145 G10
- F146 D8
- F147 E1
- F148 E1
- F149 E1
- F150 E1
- F151 E1
- F152 E1
- F153 E1
- F154 E1
- F155 E1
- F156 E1
- F157 E1
- F158 E1
- F159 E1
- F160 E1
- F161 E1
- F162 E1
- F163 E1
- F164 E1
- F165 E1
- F166 E1
- F167 E1
- F168 E1
- F169 E1
- F170 E1
- F171 E1
- F172 E1
- F173 E1
- F174 E1
- F175 E1
- F176 E1
- F177 E1
- F178 E1
- F179 E1
- F180 E1
- F181 E1
- F182 E1
- F183 E1
- F184 E1
- F185 E1
- F186 E1
- F187 E1
- F188 E1
- F189 E1
- F190 E1
- F191 E1
- F192 E1
- F193 E1
- F194 E1
- F195 E1
- F196 E1
- F197 E1
- F198 E1
- F199 E1
- F200 E1



### 10 LED Low-Pow: Microcontroller Block Liteon




- 2201 B8
- 2202 C8
- 2203 D8
- 2209 B2
- 2210 G6
- 2211 I6
- 2214 A6
- 2215 F7
- 2216 F7
- 2217 B12
- 2218 C12
- 2219 D12
- 2220 E9
- 3121 D9
- 3203 B5
- 3204 B7
- 3205 C5
- 3207 B9
- 3209 C9
- 3210 B3
- 3211 C9
- 3212 D11
- 3213 B3
- 3214 H6
- 3215 H6
- 3216 H6
- 3217 H6
- 3218 H6
- 3219 B11
- 3220 C11
- 3221 H11
- 3222 I8
- 3223 C11
- 3224 H11
- 6216 I8
- 7201-1 A10
- 7201-2 C10
- 7201-3 D10
- 7201-4 B10
- 7209 B2
- 7210 C2
- 7212 B3
- 7214 B6
- 7215 G7
- 9208 A10
- 9209 B9
- 9210 B10
- 9211 C9
- 9212 C10
- 9213 D9
- 9214 D10
- F202 B3
- F203 C5
- F204 H6
- F205 B10
- F206 C10
- F207 C10
- F208 D10
- F209 H11
- F210 G9
- F211 G9
- F212 G9
- F213 H9
- F214 H9
- F215 H9

All rights reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner.

|                     |                    |                                     |
|---------------------|--------------------|-------------------------------------|
| CHN                 | SETNAME            |                                     |
| CLASS_NO            | DRIVER 6LED LITEON | 1 2008-06-10                        |
|                     | 2K9                | 2 2008-08-08                        |
| 2008-08-08          |                    | 3 ??                                |
|                     |                    |                                     |
| NAME Peter Van Hove | SUPERS             | 130 - 2                             |
| CHECK               | DATE 2008-06-02    | ROYAL PHILIPS ELECTRONICS N.V. 2008 |

10 LED Low-Pow: LED Liteon




All rights reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner.

|                      |                    |   |                                     |
|----------------------|--------------------|---|-------------------------------------|
| CHN                  | SETNAME            |   |                                     |
| CLASS_NO             | DRIVER 6LED LITEON | 1 | 2008-06-10                          |
|                      | 2K9                | 2 | 2008-08-08                          |
| 2008-08-08           |                    | 3 | ??                                  |
|                      |                    |   |                                     |
| NAME: Peter Van Hove | SUPERS:            | 3 | 130 - 3                             |
| CHECK                | DATE: 2008-06-02   |   | ROYAL PHILIPS ELECTRONICS N.V. 2008 |

- 3301 F9
- 3302 F9
- 3303 F9
- 3304 G9
- 3305 G9
- 3306 H9
- 3307 H9
- 3308 H9
- 3309 I9
- 3310 D12
- 3311 D12
- 3312 E12
- 3313 E12
- 3314 E12
- 3315 E12
- 3316 E12
- 3317 F12
- 3318 F12
- 3319 F12
- 3320 F12
- 3321 G12
- 3322 G12
- 3323 G12
- 3325 G4
- 3326 H4
- 3327 H4
- 3328 G4
- 3330 I4
- 3331 F4
- 3332 F4
- 3333 H4
- 3334 F4
- 3335 D12
- 3336 D2
- 3337 D2
- 3338 D1
- 3339 D1
- 3340 D1
- 3341 D1
- 3342 E2
- 3343 D1
- 3344 D1
- 3345 D12
- 3346 E1
- 3347 D1
- 3348 E12
- 3349 E1
- 3350 E1
- 3351 E12
- 3352 E1
- 3353 E1
- 3354 D13
- 3355 E1
- 3356 E1
- 3357 D13
- 3358 E13
- 3359 E13
- 3360 E13
- 3361 E13
- 3362 E13
- 3363 F13
- 3364 F13
- 3365 F13
- 3366 F13
- 3367 G13
- 3368 G13
- 3369 F1
- 3370 F1
- 3371 F1
- 3372 F1
- 3373 F1
- 3374 G1
- 3384 E1
- 3385 F1
- 3386 F1
- 3387 F1
- 3388 F1
- 3389 F1
- 3390 G1
- 3391 G1
- 7000 C2
- 7001 C3
- 7002 C4
- 7003 C6
- 7004 C8
- 7005 C11
- 7305 G4
- 7306 H5
- 7307 F4
- 7315 G9
- 7316 H10
- 7317 F9
- 9301 C10
- 9302 C1
- 9303-1 C10
- 9303-3 C10
- 9303-4 C10
- 9304-1 E10
- 9304-2 E10
- 9304-4 E10
- 9305-1 C6
- 9305-2 C6
- 9305-4 C6
- 9306-1 D5
- 9306-3 D5
- 9306-4 D5
- 9307 A6
- 9308 A6
- 9309-1 B6
- 9309-2 B6
- 9309-4 B6
- 9310-1 B8
- 9310-2 B8
- 9310-4 B8
- 9311-1 H13
- 9311-3 H13
- 9311-4 H12
- 9312-1 B10
- 9312-3 B10
- 9312-4 B10
- 9313-1 B12
- 9313-2 B12
- 9313-4 B12
- 9314 G5
- 9315-1 C12
- 9315-2 C12
- 9315-4 C12
- 9316 H5
- 9317 F5
- 9318-1 C8
- 9318-3 C8
- 9318-4 C8
- 9319-1 D9
- 9319-3 D9
- 9319-4 D9
- 9320-1 D7
- 9320-2 D7
- 9320-4 D7
- 9325 F10
- 9326 G10
- 9327 H10
- F302 G5
- F303 G4
- F304 H5
- F305 H5
- F307 F5
- F308 F4
- F309 F10
- F325 F9
- F327 G10
- F328 G9
- F329 H10
- F330 H10
- F340 D1
- F341 D1
- F342 D1
- F343 D2
- F344 D12
- F345 D12
- F346 D13
- F347 G12
- F348 G13
- F349 G13



10 LED Low-Pow: LED Drive Liteon



All rights reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner.

|                     |                   |   |                                     |
|---------------------|-------------------|---|-------------------------------------|
| CHN                 | SETNAME           | 1 | 2008-08-14                          |
| CLASS_NO            | 4 LED + CONNECTOR | 2 | 2008-10-24                          |
|                     | LITEON 2K9        | 3 | 2008-10-31                          |
|                     | 8204 000 8897     |   |                                     |
| 2008-08-14          | 2                 |   |                                     |
| 2008-10-31          | 3                 |   |                                     |
| NAME Peter Van Hove | SUPERS.           | 1 |                                     |
| CHECK               | DATE 2008-07-29   |   |                                     |
|                     |                   |   | ROYAL PHILIPS ELECTRONICS N.V. 2008 |


Layout 10 LED Low-Pow



3104 313 6315.2

18310\_553\_090309  
090309

SSB: DC/DC







All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|                                     |                   |               |            |
|-------------------------------------|-------------------|---------------|------------|
| CHN                                 | SETNAME           |               |            |
| CLASS_NO                            | DC/DC             | 2             | 2008-11-21 |
|                                     | TV543 R2 LDIPNX   |               |            |
|                                     |                   | 8204 000 8932 |            |
| NAME                                | Maaßleghoe Ingrid | SUPERS        | 3          |
| CHECK                               | DATE              | 2007-11-20    | 130 - 1    |
|                                     |                   |               | A2         |
| ROYAL PHILIPS ELECTRONICS N.V. 2008 |                   |               |            |

SSB: DC/DC

PHILIPS


All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.



- 1M20 A1
- 1M95 E1
- 1M99 C1
- 1U01 E2
- 1U03 E2
- 2U21 B1
- 2U22 D2
- 2U23 D2
- 2U24 A7
- 2U25 B8
- 2U26 B9
- 2U27 F7
- 2U28 F8
- 2U29 E8
- 2U2A E8
- 2U2B E8
- 2U2C B1
- 2U30 D2
- 2U31 D3
- 2U32 E1
- 2U33 F1
- 2U34 F1
- 2U35 F1
- 2U36 F1
- 2U37 C1
- 2U40 F3
- 2U41 A2
- 2U42 A2
- 2U43 A2
- 2U44 A2
- 2U45 B2
- 2U46 B2
- 2U47 D8
- 2U48 D8
- 2U49 D7
- 2U51 D1
- 2U52 D1
- 2U53 C1
- 3U35 B6
- 3U37 A6
- 3U3V A8
- 3U3V B8
- 3U3W A8
- 3U3Y E6
- 3U3Z F6
- 3U40 E8
- 3U41 B5
- 3U42 E9
- 3U43 E8
- 3U44 E9
- 3U45 E9
- 3U46 A8
- 3U47 E8
- 3U4A B8
- 3U4B B4
- 3U55 C3
- 3U56 C3
- 3U57 C3
- 3U58 C3
- 3U59 B6
- 3U60 E5
- 3U61 E5
- 3U62 F5
- 3U63 F5
- 3U64 C2
- 3U65 C2
- 3U66 D1
- 3U67 D2
- 3U80 E3
- 3U81 E3
- 3U82 E4
- 3U83 E4
- 3U84 F2
- 3U85 F4
- 3U86 F4
- 3U88 F3
- 3U89 F3
- 3U90 A3
- 3U91 A3
- 3U92 A3
- 3U93 B2
- 3U94 B3
- 3U95 B3
- 3U96 A4
- 3U97 A4
- 3U98 C3
- 5U06 F2
- 5U07 A1
- 5U08 E7
- 5U10 A1
- 5U11 A1
- 5U12 A1
- 5U13 A1
- 5U14 A1
- 5U15 B1
- 5U16 B1
- 5U17 F2
- 5U21 F2
- 5U21 F2
- 6U0B E8
- 6U0C E8
- 6U40 E3
- 7U0M A9
- 7U0M B7
- 7U0P E7
- 7U0Q E9
- 7U10 B4
- 7U11 B3
- 7U40-1 E3
- 7U40-2 E4
- 7U41-1 F4
- 7U41-2 F5
- 7U50 C7
- 9U06 A2
- 9U07 B3
- 9U08 B5
- CU70 D1
- CU71 D1
- FU10 F1
- FU11 F1
- FU12 F1
- FU13 C1
- FU14 C1
- FU15 C2
- FU16 C1
- FU17 C2
- FU18 C2
- FU19 C1
- FU1A E1
- FU1B E1
- FU1C E1
- FU1D F1
- FU1F B9
- FU1G E9
- FU1H C4
- FU21 E1
- FU22 E1
- FU23 E1
- FU24 C1
- FU25 D1
- FU26 D1
- FU30 A1
- FU31 A1
- FU32 A1
- FU33 A1
- FU34 A1
- FU35 A1
- FU36 B1
- FU38 B1
- FU39 E5
- IU20 B4
- IU21 B4
- IU34 A8
- IU35 B8
- IU36 F7
- IU37 F8
- IU38 E7
- IU39 F9
- IU3B E8
- IU3C B8
- IU3T C8
- IU40 E3
- IU41 E3
- IU42 E4
- IU43 E3
- IU44 F3
- IU45 F4
- IU47 F3
- IU48 A4
- IU49 A4
- IU50 A5
- IU51 A3
- IU52 B3
- IU53 B4
- IU54 B3

|                                       |                 |   |               |
|---------------------------------------|-----------------|---|---------------|
| CHN                                   | SETNAME         |   |               |
| CLASS_NO                              | DC/DC           | 2 | 2008-11-21    |
|                                       | TV543 R2 LDIPNX |   |               |
|                                       |                 |   | 8204 000 8932 |
| 2008-10-10                            | 3               |   |               |
| NAME Maellegheer Ingrid               | SUPERS.         | 3 |               |
| CHECK                                 | DATE 2007-11-20 |   | 130 - 2       |
| © ROYAL PHILIPS ELECTRONICS N.V. 2008 |                 |   |               |

SSB: DC/DC




PHILIPS

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|                                     |                 |               |            |
|-------------------------------------|-----------------|---------------|------------|
| CHN                                 | SETNAME         |               |            |
| CLASS_NO                            | DC/DC           | 2             | 2008-11-21 |
|                                     | TV543 R2 LDIPNX |               |            |
|                                     |                 | 8204 000 8932 |            |
| NAME Maelgheer Ingrid               | SUPERS.         | 3             | 130 - 3    |
| CHECK                               | DATE 2007-11-20 |               |            |
| ROYAL PHILIPS ELECTRONICS N.V. 2008 |                 |               |            |




SSB: Front End



All rights reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner.

|                       |                 |   |                                     |
|-----------------------|-----------------|---|-------------------------------------|
| CHN                   | SETNAME         | 2 | 2008-11-21                          |
| CLASS_NO              | FRONT-END       |   |                                     |
|                       | TV543 R2 LDIPNX |   |                                     |
|                       | 8204 000 8929   |   |                                     |
| NAME Randal De Keyser | SUPERS          | 3 | 130 - 1                             |
| CHECK                 | DATE 2008-06-03 |   | ROYAL PHILIPS ELECTRONICS N.V. 2008 |


SSB: Demodulator



All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|                       |  |                                     |  |
|-----------------------|--|-------------------------------------|--|
| CLASS_NO              |  | SETNAME                             |  |
|                       |  | FRONT-END                           |  |
|                       |  | TV543 R2 LDIPNX                     |  |
|                       |  | 8204 000 8929                       |  |
| NAME Randal De Keyser |  | SUPERS.                             |  |
| CHECK                 |  | DATE 2008-06-03                     |  |
|                       |  | ROYAL PHILIPS ELECTRONICS N.V. 2008 |  |

SSB: PNX8543 - Stand-by Controller




All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|                       |                         |               |                                     |
|-----------------------|-------------------------|---------------|-------------------------------------|
| CHN                   | SETNAME                 |               |                                     |
| CLASS_NO              | STANDBY CONTROLLER      |               | 2 2008-11-21                        |
|                       | PNX8543 TV543 R2 LDIPNX | 8204 000 8927 |                                     |
| 2008-10-10            |                         |               |                                     |
| NAME Randal De Keyser | SUPERS.                 | 16            | 130 - 1                             |
| CHECK                 | DATE 2007-11-29         |               | ROYAL PHILIPS ELECTRONICS N.V. 2005 |



SSB: PNX8543 - Control




|                        |                         |                                       |            |
|------------------------|-------------------------|---------------------------------------|------------|
| CHN                    | SETNAME                 |                                       |            |
| CLASS_NO               | MIPS , I2C & EJTAG      | 2                                     | 2008-11-21 |
|                        | PNX8543 TV543 R2 LDIPNX | 8204 000 8927                         |            |
| 2008-10-10             | 3                       |                                       |            |
| NAME Maelegheer Ingrid | SUPERS.                 | 16                                    | 130 - 5    |
| CHECK                  | DATE 2007-11-29         | © ROYAL PHILIPS ELECTRONICS N.V. 2005 |            |

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

SSB: PNx8543 - Control

PHILIPS

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.



|                                       |                   |                         |               |
|---------------------------------------|-------------------|-------------------------|---------------|
| CHN                                   | SETNAME           |                         |               |
| CLASS_NO                              | CONTROL           |                         | 2 2008-11-21  |
| 2008-10-03                            | 2                 | PNX8543 TV543 R2 LDIPNX | 8204 000 8927 |
| NAME                                  | Maelegheer Ingrid | SUPERS.                 | 16            |
| CHECK                                 | DATE              | 2007-11-29              | 130 - 6       |
| © ROYAL PHILIPS ELECTRONICS N.V. 2005 |                   |                         |               |








SSB: PNX8543 - Digital Video In

PHILIPS

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

**BØ4H** PNX 8543 : DIGITAL VIDEO IN


**BØ4H**



- 3HK0 B2
- 7H00-4 A3
- 9HK0 D2
- IHSM B2
- TH01 C2
- TH02 C2
- TH03 C2
- TH04 C2
- TH05 C2
- TH06 C2
- TH07 D2
- TH08 D2
- TH09 B2
- TH10 B2
- TH11 B2
- TH12 B2
- TH13 B2
- TH14 C2
- TH15 C2
- TH16 C2

|                        |                         |               |                                     |
|------------------------|-------------------------|---------------|-------------------------------------|
| CHN                    | SETNAME                 |               |                                     |
| CLASS_NO               | VIDEO IN                | 2             | 2008-11-21                          |
|                        | PNX8543 TV543 R2 LDIPNX | 8204 000 8927 |                                     |
| 2008-10-10             | 3                       |               |                                     |
| NAME Maelegheer Ingrid | SUPERS.                 | 16            | 130 - 8                             |
| CHECK                  | DATE 2007-11-29         |               | ROYAL PHILIPS ELECTRONICS N.V. 2005 |

SSB: PNx8543 - Audio




- 2HM1 G5
- 2HM2 H5
- 2HM3 G4
- 2HM4 G5
- 2HM5 H5
- 2HM8 H4
- 2HM9 B3
- 2HMJ A10
- 2HMP C10
- 2HMT E10
- 2HMW G10
- 2HMY H9
- 2HMZ I10
- 2HN1 F9
- 3HMO-1 C5
- 3HMO-2 B4
- 3HMO-3 C4
- 3HMO-4 D5
- 3HM1 D4
- 3HMA G6
- 3HMB H6
- 3HMC G5
- 3HMD I5
- 3HME-1 B10
- 3HME-2 B9
- 3HME-3 E9
- 3HME-4 E10
- 3HMF B3
- 3HML G6
- 3HMM-1 I10
- 3HMM-2 I8
- 3HMM-3 G9
- 3HMM-4 G10
- 3HMU H6
- 3HMV H5
- 3HMW H5
- 3HMY F5
- 3HMZ F5
- 6HM0 B4
- 7HM1-1 B10
- 7HM1-2 D10
- 7HM1-3 F10
- 7HM1-4 H10
- 7HM2-1 F5
- 7HM2-2 H5
- 7HM3 F7
- 7HM4 H7
- 7HM5 B5
- 7HM6 C5
- 9HM0 B5
- FHM0 B11
- FHM1 D11
- FHM2 F11
- FHM3 H11
- FHR3 A10
- IH22 F4
- IH23 H4
- IHM0 B3
- IHM1 F7
- IHM2 C4
- IHM4 C4
- IHM5 D5
- IHM6 B3
- IHM7 C5
- IHM8 C5
- IHM9 H7
- IHMV D9
- IHMW B9
- IHN0 F5
- IHN3 D9
- IHN4 H5
- IHN5 D10
- IHN8 F6
- IHNA F10
- IHNB F9
- IHND H9
- IHNE H10
- IHNF H6
- IHNG F6
- IHNH H6
- IHNJ G5
- IHNK I5

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|                                     |                         |            |    |               |
|-------------------------------------|-------------------------|------------|----|---------------|
| CHN                                 | SETNAME                 |            | 2  | 2008-11-21    |
| CLASS_NO                            | AUDIO                   |            |    |               |
|                                     | PNX8543 TV543 R2 LDIPNX |            |    | 8204 000 8927 |
| 2008-10-10                          | 3                       |            |    |               |
| NAME                                | Meeleghoeer Ingrid      | SUPERS.    | 16 | 130 - 9       |
| CHECK                               | DATE                    | 2007-11-29 |    | A2            |
| ROYAL PHILIPS ELECTRONICS N.V. 2005 |                         |            |    |               |


SSB: PNX8543 - Analogue AV



All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|          |                         |                                     |              |
|----------|-------------------------|-------------------------------------|--------------|
| CHN      | SETNAME                 |                                     |              |
| CLASS_NO | ANALOG AV               |                                     | 2 2008-11-21 |
|          | PNX8543 TV543 R2 LDIPNX | 8204 000 8927                       |              |
| NAME     | Maaßleighter Ingrid     | SUPERS                              | 16 130 - 11  |
| CHECK    | DATE 2007-11-29         |                                     | A2           |
|          |                         | ROYAL PHILIPS ELECTRONICS N.V. 2005 |              |

SSB: PNX8543 - Audio



PHILIPS


All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

- 2HP4 D10
- 2HP5 D9
- 2HP6 D9
- 2HP7 D9
- 2HP8 D9
- 2HPA C11
- 2HPB D10
- 2HR0 C4
- 2HR1 D5
- 2HR2 C4
- 2HR3 C5
- 2HR4 D4
- 2HR5 D4
- 2HR6 D4
- 2HR7 D4
- 2HR8 E4
- 2HR9 E4
- 2HRA D4
- 2HRB D4
- 2HRC E4
- 2HRD E4
- 2HRE E4
- 2HRF E4
- 2HRG E3
- 2HRH F4
- 2HRJ F3
- 2HRK F4
- 2HRM D6
- 2HRN D6
- 2HRP C6
- 2HRS E11
- 2HRT E11
- 2HRU C6
- 2HRV C6
- 2HRW G6
- 2HRY G6
- 3H6Z F6
- 3H63 F6
- 3HAG D11
- 3HAH D11
- 3HP0 F9
- 3HP1 F10
- 3HP5-1 E10
- 3HP5-2 E9
- 3HP5-3 F10
- 3HP5-4 F9
- 3HPN G9
- 3HR0-1 C3
- 3HR0-2 C4
- 3HR0-3 C3
- 3HR0-4 D3
- 3HR3-1 D3
- 3HR3-2 D4
- 3HR3-3 D3
- 3HR3-4 D3
- 3HR8-1 E3
- 3HR8-2 E3
- 3HR8-3 D3
- 3HR8-4 D3
- 3HRC-1 E3
- 3HRC-2 E3
- 3HRC-3 E3
- 3HRC-4 E2
- 3HRJ-1 F2
- 3HRJ-2 E3
- 3HRJ-3 F3
- 3HRJ-4 F2
- 3HRK H6
- 3HRM G5
- 3HRN G5
- 3HT8-1 F9
- 3HT8-2 F9
- 3HT8-3 D10
- 3HT8-4 E9
- 5HP2 C10
- 5HRW D6
- 5HRZ D6
- 7H00-7 D7
- 7HPD C10
- 9H11 C4
- 9H12 C4
- FHPE C10
- IH11 C10
- IHPD F9
- IHRN C4
- IHRJ D4
- IHRK G5
- IHRL G6
- IHRM G6
- IHRT F3
- IHRU F3
- IHRV E3
- IHRW E3
- IHRY D3
- IHRZ E3
- IHS0 D3
- IHS1 D3
- IHSU C6
- IHSV D6
- IHSW C9
- IHSY D11
- IHSZ D6

|                                     |                         |               |            |
|-------------------------------------|-------------------------|---------------|------------|
| CHN                                 | SETNAME                 |               |            |
| CLASS_NO                            | AUDIO                   | 2             | 2008-11-21 |
|                                     | PNX8543 TV543 R2 LDIPNX | 8204 000 8927 |            |
| NAME                                | Mawleghaar Ingrid       | SUPERS        | 16         |
| CHECK                               | DATE                    | 2007-11-29    | 130 - 12   |
|                                     |                         |               | A3         |
| ROYAL PHILIPS ELECTRONICS N.V. 2006 |                         |               |            |




**SSB: PNx8543 - Video Streams**



All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|                                     |                                |                      |            |
|-------------------------------------|--------------------------------|----------------------|------------|
| CHN                                 | SETNAME                        | 2                    | 2008-11-21 |
| CLASS_NO                            | <b>CONDITIONAL ACCESS</b>      |                      |            |
|                                     | <b>PNX8543 TV543 R2 LDIPNX</b> |                      |            |
|                                     |                                | <b>8204 000 8927</b> |            |
| 2008-10-10                          | 3                              |                      |            |
| NAME                                | Maaßigheer Ingrid              | SUPERS               | 16         |
| CHECK                               | DATE                           | 2008-06-05           | 130 - 14   |
|                                     |                                |                      | A2         |
| ROYAL PHILIPS ELECTRONICS N.V. 2008 |                                |                      |            |

**SSB: PNX8543 - Digital Video Out/LVDS**




All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|                        |                         |    |                                       |
|------------------------|-------------------------|----|---------------------------------------|
| CHN                    | SETNAME                 |    |                                       |
| CLASS_NO               | LVDS                    | 2  | 2008-11-21                            |
|                        | PNX8543 TV543 R2 LDIPNX |    | 8204 000 8927                         |
| 2008-10-10             | 3                       |    |                                       |
| NAME Maelegheer Ingrid | SUPERS.                 | 16 | 130 - 15                              |
| CHECK                  | DATE 2007-11-29         |    | © ROYAL PHILIPS ELECTRONICS N.V. 2005 |




SSB: PNX8543 - Power




All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|            |                         |            |                                     |
|------------|-------------------------|------------|-------------------------------------|
| CHN        | SETNAME                 |            |                                     |
| CLASS_NO   | POWER                   |            | 2 2008-11-21                        |
|            | PNX8543 TV543 R2 LDIPNX |            | 8204 000 8927                       |
| 2008-10-10 | 3                       |            |                                     |
| NAME       | Maeleghoeur Ingrid      | SUPERS.    | 16                                  |
| CHECK      | DATE                    | 2007-11-29 | 130 - 16                            |
|            |                         |            | ROYAL PHILIPS ELECTRONICS N.V. 2005 |

**SSB: PNX5100 - SDRAM**




SSB: PNX5100 - Video-In



All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|                       |                 |                                       |         |            |
|-----------------------|-----------------|---------------------------------------|---------|------------|
| CHN                   | SETNAME         |                                       | 2       | 2008-11-21 |
| CLASS_NO              | VIDEO PNX5100   |                                       |         |            |
|                       | TV543 R2 LDIPNX |                                       |         |            |
| 2008-10-10            | 3               | 8204 000 8928                         |         |            |
| NAME Maelgheer Ingrid | SUPERS.         | 9                                     | 130 - 2 | A3         |
| CHECK                 | DATE            | © ROYAL PHILIPS ELECTRONICS N.V. 2008 |         |            |

SSB: PNX5100 - Power



All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.


|                                       |                   |                 |   |   |            |
|---------------------------------------|-------------------|-----------------|---|---|------------|
| CHN                                   | SETNAME           |                 |   |   |            |
| CLASS_NO                              |                   | SUPPLY PNX5100  |   | 2 | 2008-11-21 |
|                                       |                   | TV543 R2 LDIPNX |   |   |            |
|                                       |                   |                 |   |   |            |
|                                       |                   |                 |   |   |            |
| 2008-10-10                            |                   |                 |   |   |            |
| NAME                                  | Maelegheer Ingrid | SUPERS.         | 9 |   | A3         |
| CHECK                                 |                   | DATE            |   |   |            |
| © ROYAL PHILIPS ELECTRONICS N.V. 2008 |                   |                 |   |   |            |

- 2C45 D1
- 2C55 D1
- 2C56 D1
- 2C57 D9
- 2C58 F9
- 2C59 A1
- 2C60-1 B1
- 2C60-2 B1
- 2C60-3 B1
- 2C60-4 B1
- 2C61-1 B2
- 2C61-2 B2
- 2C61-3 B2
- 2C61-4 B2
- 2C62-1 B2
- 2C62-2 D6
- 2C62-3 B2
- 2C62-4 E6
- 2C63-1 B3
- 2C63-2 B3
- 2C63-3 E6
- 2C63-4 B3
- 2C64 B3
- 2C65 B3
- 2C66-1 C1
- 2C66-2 C2
- 2C66-3 C2
- 2C66-4 C2
- 2C67-1 C2
- 2C67-2 C2
- 2C67-3 C2
- 2C67-4 C2
- 2C68-1 D1
- 2C68-2 D2
- 2C68-3 D2
- 2C68-4 D2
- 2C69-1 D2
- 2C69-2 D2
- 2C69-3 D2
- 2C69-4 D2
- 2C70-1 D3
- 2C70-2 D3
- 2C70-3 D3
- 2C70-4 D3
- 2C71 E2
- 2C72 E2
- 2C73 E2
- 2C74 E2
- 2C75 E2
- 2C76 E3
- 2C77 C9
- 2C78-1 B1
- 2C78-2 B1
- 2C78-3 B1
- 2C78-4 D3
- 2C79 D6
- 2C80 D6
- 2C81 B3
- 2C82 F6
- 2C83 F6
- 2C84 D8
- 2C85 D9
- 2C86 D9
- 2C87 D9
- 2C88 E9
- 2C89 E9
- 2C90 F9
- 2C91 F8
- 2C92 F9
- 2C94 F7
- 2C95 A1
- 2C96 A2
- 2C97 A2
- 5C60 D6
- 5C61 D6
- 5C62 E6
- 5C63 E6
- 5C64 F6
- 5C65 F6
- 5C66 D8
- 5C67 E8
- 5C68 E8
- 5C69 E8
- 5C70 F8
- 7C00-10 A4
- 7C00-11 A7
- CC60 A3
- FC07 A2
- IC80 D7
- IC81 D7
- IC82 E7
- IC83 E7
- IC84 E7
- IC85 F7
- IC86 D9
- IC87 E9
- IC88 E9
- IC89 E9
- IC90 F9

**SSB: PNX5100 - Audio**

**PHILIPS**


All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.



- 3C41 D4
- 3C95-1 B5
- 3C95-2 B5
- 3C95-3 B4
- 3C95-4 B4
- 7C00-6 B3
- 7C00-7 C3

|                                       |                   |         |   |            |
|---------------------------------------|-------------------|---------|---|------------|
| CHN                                   | SETNAME           |         | 2 | 2008-11-21 |
| CLASS_NO                              | AUDIO PNX5100     |         |   |            |
|                                       | TV543 R2 LDIPNX   |         |   |            |
|                                       | 8204 000 8928     |         |   |            |
| 2008-10-10                            | 3                 |         |   |            |
| NAME                                  | Maelegheer Ingrid | SUPERS. | 9 | 130 - 4    |
| CHECK                                 |                   | DATE    |   | A3         |
| © ROYAL PHILIPS ELECTRONICS N.V. 2008 |                   |         |   |            |

SSB: PNX5100 - LVDS



All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.


|          |                      |         |                                     |
|----------|----------------------|---------|-------------------------------------|
| CHN      | SETNAME              |         |                                     |
| CLASS_NO | LVDS PNX5100         | 2       | 2008-11-21                          |
|          | TV543 R2 LDIPNX      |         |                                     |
|          |                      |         | 8204 000 8928                       |
| NAME     | Maaßleghoefer Ingrid | SUPERS. | 9                                   |
| CHECK    | DATE                 |         | 130 - 5                             |
|          |                      |         | ROYAL PHILIPS ELECTRONICS N.V. 2008 |



**SSB: PNX5100 - Control**

**PHILIPS**

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.




- 1CD0 A2
- 2CD0 A2
- 2CD1 A2
- 3C40 C1
- 3CD0 B2
- 3CD1-1 C2
- 3CD1-2 C2
- 3CD1-3 C2
- 3CD1-4 C1
- 3CD2 C2
- 3CD3 B2
- 3CD7 B5
- 3CD8 B5
- 3CD9 B5
- 3CDA B5
- 3CDB D7
- 3CDC D6
- 3CDD D6
- 7C00-1 A3
- 7C00 C4
- 9CD0 D7
- FCD0 B3
- FCD1 B3
- FCD2 B3
- FCD3 B3
- FCD4 B3
- FCD6 D5
- FCD8 B3
- FCD9 D5
- ICD8 B3

|                                       |                 |   |               |
|---------------------------------------|-----------------|---|---------------|
| CHN                                   | SETNAME         |   |               |
| CLASS_NO                              | CONTROL PNX5100 | 2 | 2008-11-21    |
|                                       | TV543 R2 LDIPNX |   |               |
|                                       |                 |   | 8204 000 8928 |
| 2008-10-10                            | 3               |   |               |
| NAME Maelegheer Ingrid                | SUPERS.         | 9 |               |
| CHECK                                 | DATE            |   |               |
| © ROYAL PHILIPS ELECTRONICS N.V. 2008 |                 |   |               |




**SSB: PNX5100 - PCI**



All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|                       |                 |   |                                     |
|-----------------------|-----------------|---|-------------------------------------|
| CHN                   | SETNAME         |   |                                     |
| CLASS_NO              | PCI PNX5100     | 2 | 2008-11-21                          |
|                       | TV543 R2 LDIPNX |   |                                     |
|                       |                 |   | 8204 000 8928                       |
| 2008-10-10            |                 | 3 |                                     |
| NAME Maelgheer Ingrid | SUPERS.         | 9 | 130 - 7                             |
| CHECK                 | DATE            |   |                                     |
|                       |                 |   | ROYAL PHILIPS ELECTRONICS N.V. 2008 |
|                       |                 |   | A3                                  |

**SSB: PNX5100 - Display-Interfacing**




All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|          |                        |               |            |
|----------|------------------------|---------------|------------|
| CHN      | SETNAME                |               |            |
| CLASS_NO | DISPLAY INTERF PNX5100 | 2             | 2008-11-21 |
|          | TV543 R2 LDIPNX        |               |            |
|          |                        | 8204 000 8928 |            |
| NAME     | Maaßigheer Ingrid      | SUPERS.       | 9          |
| CHECK    | DATE                   |               | 130 - 8    |
|          |                        |               | A2         |

- 1C01 A5
- 1C02 B5
- 2C03 H5
- 2C04 G4
- 2C09 A5
- 2C01 B5
- 2C02 C4
- 2C03 C2
- 2C04 D5
- 2C05 F5
- 2C06 F5
- 2C07 F5
- 2C08 F5
- 2C0B H2
- 2C0C H2
- 2C0D G11
- 2C0E E2
- 2C0F E2
- 2C10 G11
- 2C11 E2
- 3C37 G3
- 3C38 G3
- 3C39 G3
- 3C42 G9
- 3C43 A7
- 3C44 B8
- 3C00-2 D5
- 3C00-3 D5
- 3C00-4 C3
- 3C01 C2
- 3C05 D4
- 3C06 E5
- 3C07 E5
- 3C08 E5
- 3C09 E5
- 3C0A E3
- 3C0F E3
- 3C0G E3
- 3C0H E3
- 3C0J E3
- 3C0N H11
- 3C0P H12
- 3C0R H13
- 3C0S G12
- 3C0T G11
- 3C0V G13
- 3C0Z B12
- 3C0B B12
- 3C0C C4
- 3C0D G11
- 3C0E H11
- 3C0F G11
- 3C0G E13
- 5C00 A4
- 5C01 A4
- 5C02 B4
- 5C03 B4
- 6C00 C3
- 6C02 C5
- 7C00-3 A9
- 7C03 G4
- 7C08 B2
- 7C01 C3
- 7C02 C4
- 7C04 H12
- 7C05 G12
- 7C06-1 G13
- 7C06-2 G13
- 7C08 B12
- 7C08 D12
- 7C11-1 D13
- 7C11-2 D13
- 9C00 B3
- 9C01 B3
- 9C04 H13
- 9C07 G10
- 9C08 G10
- 9C09 H10
- 9C0E E13
- BC01 E6
- BC02 E6
- BC03 E6
- BC05 A5
- BC06 B5
- FC00 A5
- FC01 B5
- FC02 E6
- FC03 E6
- FC04 E6
- FC05 E6
- FC06 H13
- FC07 E13
- FC08 B4
- IC01 E3
- IC02 G3
- IC03 G3
- IC04 C4
- IC02 C2
- IC03 C2
- IC04 D4
- IC05 D4
- IC06 D5
- IC07 E2
- IC08 E2
- IC09 E2
- IC0A E2
- IC0B H12
- IC0C G13
- IC0D G12
- IC0E G11
- IC0F G11
- IC0G H10
- IC0H B8
- IC0I B8
- IC0J B8
- IC0K B8
- IC0L B8
- IC0M B8
- IC0N B8
- IC0O B8
- IC0P B8
- IC0Q B8
- IC0R B8
- IC0S B8
- IC0T B8
- IC0U B8
- IC0V B8
- IC0W B8
- IC0X B8
- IC0Y B8
- IC0Z B8
- IC0A B8
- IC0B B8
- IC0C B8
- IC0D B8
- IC0E B8
- IC0F B8
- IC0G B8
- IC0H B8
- IC0I B8
- IC0J B8
- IC0K B8
- IC0L B8
- IC0M B8
- IC0N B8
- IC0O B8
- IC0P B8
- IC0Q B8
- IC0R B8
- IC0S B8
- IC0T B8
- IC0U B8
- IC0V B8
- IC0W B8
- IC0X B8
- IC0Y B8
- IC0Z B8



# SSB: FPGA Backlight-LVDS I<sup>2</sup>C-Mux




All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.



SSB: Temperature & Fan control

PHILIPS


All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.



- 1F01 A1
- 1F02 B1
- 2F50 B2
- 2F51 B2
- 2F52 B2
- 2F53 C2
- 2F54 C2
- 2F55 C2
- 2F56 E4
- 2F57 E4
- 2F58 B8
- 2F59 C8
- 2F60 E8
- 2F61 F8
- 3F50 E3
- 3F51 E2
- 3F52 E5
- 3F53 E3
- 3F54 E4
- 3F55 E5
- 3F56 E2
- 3F57 F2
- 3F58 F3
- 3F59 D2
- 3F60 A7
- 3F61 B7
- 3F62 B7
- 3F63 C8
- 3F64 C9
- 3F65 B9
- 3F66 D7
- 3F67 D7
- 3F68 E8
- 3F69 E8
- 3F70 E6
- 3F71 F8
- 3F72 F8
- 3F73 F8
- 6F50 B7
- 6F51 D2
- 7F50 B7
- 7F51 C8
- 7F52 D3
- 7F53 E4
- 7F54 D9
- 7F55 E3
- 7F56 F9
- 7F57 F6
- 9F07 F6
- 9F50 B8
- 9F51 B9
- 9F52 C9
- FF49 A2
- FF50 A3
- FF51 B3
- FF52 C3
- FF53 C3
- IF50 D2
- IF51 E3
- IF52 E3
- IF53 E4
- IF54 E5
- IF55 F2
- IF56 F3
- IF57 E8
- IF58 E8
- IF59 E6
- IF60 F8
- IF61 F8
- IF62 B8
- IF63 B7
- IF64 B9
- IF65 B7
- IF66 B9
- IF67 E4
- IF68 D7
- IF69 D7

|                        |                            |   |                                     |
|------------------------|----------------------------|---|-------------------------------------|
| CHN                    | SETNAME                    |   |                                     |
| CLASS_NO               | TEMPERATURE- & FAN-CONTROL |   | 2 2008-11-21                        |
|                        | TV543 R2 LDIPNX            |   | 8204 000 8933                       |
| 2008-10-10             | 3                          |   |                                     |
| NAME Maelegheer Ingrid | SUPERS.                    | 8 | 130 - 3                             |
| CHECK                  | DATE 2007-12-04            |   | ROYAL PHILIPS ELECTRONICS N.V. 2007 |

SSB: FPGA WOW - LVDS In/Out




All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|                                       |                        |               |            |
|---------------------------------------|------------------------|---------------|------------|
| CHN                                   | SETNAME                |               |            |
| CLASS_NO                              | FPGA WOW - LVDS IN/OUT |               | 2          |
|                                       | TV543 R2 LDIPNX        |               | 2008-11-21 |
| 2008-10-10                            | 3                      | 8204 000 8933 |            |
| NAME Maelgheer Ingrid                 | SUPERS.                | 8             | 130 - 4    |
| CHECK                                 | DATE 2007-12-04        |               | A3         |
| © ROYAL PHILIPS ELECTRONICS N.V. 2007 |                        |               |            |



SSB: FPGA WOW - Power & Control




All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|                         |                            |   |                                     |
|-------------------------|----------------------------|---|-------------------------------------|
| CHN                     | SETNAME                    |   |                                     |
| CLASS_NO                | FPGA WOW - POWER & CONTROL |   | 2 2008-11-21                        |
|                         | TV543 R2 LDIPNX            |   | 8204 000 8933                       |
| 2008-10-10              | 3                          |   |                                     |
| NAME Meeleghoeer Ingrid | SUPERS.                    | 8 | 130 - 5                             |
| CHECK                   | DATE 2007-12-04            |   | ROYAL PHILIPS ELECTRONICS N.V. 2007 |

SSB: FPGA WOW - DDR

PHILIPS


All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.



- 2FL0 A1
- 2FL1 A1
- 2FL2 B3
- 2FL3 B4
- 2FL4 B4
- 2FL5 B5
- 2FL6 C1
- 2FL7 B6
- 2FL9 B6
- 2FLA B8
- 2FLB B8
- 2FLC B8
- 2FLD C6
- 2FLE C6
- 2FLF D7
- 2FLH C7
- 2FLJ C8
- 2FLK C8
- 2FLM C8
- 2FLN C9
- 2FLP A1
- 2FLR B4
- 2FLS B4
- 3FL0 B4
- 3FL1 B4
- 3FL2 C4
- 3FL3 C4
- 3FL4 C4
- 3FL5 C4
- 3FL6 C4
- 3FL7 C4
- 3FL8 C4
- 3FL9 C4
- 3FLA C4
- 3FLB C4
- 3FLC C4
- 3FLD C4
- 3FLE C4
- 3FLF C4
- 3FLG D4
- 3FLH D4
- 3FLJ D1
- 3FLK B6
- 3FLM B6
- 3FLN B9
- 5FL0 C7
- 5FL1 C7
- 7FL0 B2
- FFL0 B8
- FFL1 B7
- IFL1 C7

|                                       |                 |               |              |
|---------------------------------------|-----------------|---------------|--------------|
| CHN                                   |                 | SETNAME       |              |
| CLASS_NO                              | FPGA WOW - DDR  |               | 2 2008-11-21 |
|                                       | TV543 R2 LDIPNX |               |              |
| 2008-10-10                            | 3               | 8204 000 8933 |              |
| NAME Maelgheer Ingrid                 |                 | SUPERS.       | 8            |
| CHECK                                 | DATE 2007-12-04 | 130 - 6       |              |
| © ROYAL PHILIPS ELECTRONICS N.V. 2007 |                 |               |              |


SSB: FPGA WOW - I/O Banks



All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|                        |                     |                                     |            |
|------------------------|---------------------|-------------------------------------|------------|
| CHN                    | SETNAME             |                                     |            |
| CLASS_NO               | FPGA WOW - IO-BANKS | 2                                   | 2008-11-21 |
|                        | TV543 R2 LDIPNX     | 8204 000 8933                       |            |
| 2008-10-10             |                     | 3                                   |            |
| NAME Maaelgheer Ingrid | SUPERS              | 8                                   | 130 - 7    |
| CHECK                  | DATE 2007-12-06     | ROYAL PHILIPS ELECTRONICS N.V. 2007 |            |

**SSB: CI: PCMCIA Connector**




All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|            |                          |                                       |            |
|------------|--------------------------|---------------------------------------|------------|
| CHN        | SETNAME                  |                                       |            |
| CLASS_NO   | UFD2K8                   |                                       | 2          |
|            | DIGI i/O TV543 R2 LDIPNX |                                       | 2008-11-21 |
|            | 8204 000 8934            |                                       |            |
| 2008-10-10 | 3                        |                                       |            |
| NAME       | Maelgheer Ingrid         | SUPERS.                               | 8          |
| CHECK      |                          | DATE                                  | 2007-10-18 |
|            |                          | © ROYAL PHILIPS ELECTRONICS N.V. 2007 |            |

**SSB: Audio In HDMI**

**PHILIPS**

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.




- 1P0A B2
- 1P0B D2
- 1P9A B3
- 1P9B D3
- 2P06 B2
- 2P07 B3
- 2P08 B4
- 2P09 D2
- 2P10 D3
- 2P11 D4
- 3P05 B3
- 3P06 B4
- 3P07 D3
- 3P08 D4
- 6P01 B3
- 6P02 D3
- FP01 D2
- FP02 B2
- FP24 D2
- IP06 B4
- IP07 D4

|                        |                          |   |                                     |
|------------------------|--------------------------|---|-------------------------------------|
| CHN                    | SETNAME                  |   |                                     |
| CLASS_NO               | UFD2K8                   |   | 2 2008-11-21                        |
|                        | DIGI I/O TV543 R2 LDIPNX |   | 8204 000 8934                       |
| 2008-10-10             | 3                        |   |                                     |
| NAME Maelegheer Ingrid | SUPERS.                  | 8 | 130 - 2                             |
| CHECK                  | DATE 2007-10-18          |   | ROYAL PHILIPS ELECTRONICS N.V. 2005 |



SSB: HDMI



All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.


|          |                         |                                     |
|----------|-------------------------|-------------------------------------|
| CHN      | SETNAME                 |                                     |
| CLASS_NO | UFD2K8                  | 2   2008-11-21                      |
|          | DIGI IO TV543 R2 LDIPNX | 8204 000 8934                       |
| NAME     | Maahtegheer Ingrid      | 130 - 4                             |
| CHECK    | DATE 2007-10-18         | ROYAL PHILIPS ELECTRONICS N.V. 2005 |



SSB: HDMI Switch


PHILIPS

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.



|                                       |                          |            |               |
|---------------------------------------|--------------------------|------------|---------------|
| CHN                                   | SETNAME                  |            |               |
| CLASS_NO                              | UFD2K8                   | 2          | 2008-11-21    |
|                                       | DIGI I/O TV543 R2 LDIPNX |            |               |
|                                       |                          |            | 8204 000 8934 |
| 2008-10-10                            | 3                        |            |               |
| NAME                                  | Maelegheer Ingrid        | SUPERS.    | 8             |
| CHECK                                 | DATE                     | 2007-10-18 |               |
|                                       |                          |            | 130 - 5       |
|                                       |                          |            | A3            |
| © ROYAL PHILIPS ELECTRONICS N.V. 2006 |                          |            |               |


SSB: PNX8543: Flash



All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.


|                        |                          |   |                                     |
|------------------------|--------------------------|---|-------------------------------------|
| CHN                    | SETNAME                  |   |                                     |
| CLASS_NO               | UFD 2K8                  | 2 | 2008-11-21                          |
|                        | DIGI I/O TV543 R2 LDIPNX |   |                                     |
|                        | 8204 000 8934            |   |                                     |
| 2008-10-10             |                          | 3 |                                     |
| NAME Maaßgeheer Ingrid | SUPERS.                  | 8 | 130 - 6                             |
| CHECK                  | DATE 2007-10-18          |   |                                     |
|                        |                          |   | ROYAL PHILIPS ELECTRONICS N.V. 2007 |

SSB: Ethernet



All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

SSB: Buffering




- 2N30 D3
- 2N31 B5
- 2N32 D5
- 2N33 B3
- 2P18 E9
- 2P19 E9
- 2P20 D7
- 2P21 C8
- 2P22 C8
- 2P25 D8
- 2P26 E9
- 2P61 C7
- 2P62 C8
- 3N30 D1
- 3N31 B4
- 3N32 D4
- 3N33 E4
- 3N34 D2
- 3P46 C7
- 3P49 D6
- 3P50 D8
- 3P51 D8
- 3P52 E8
- 3P54 E8
- 5P10 C9
- 7N10 D2
- 7N11 B5
- 7N12 D5
- 7N13 B2
- 7P11 D9
- 7P13 D7
- FP18 D7
- FP19 D8
- IN20 B4
- IN21 D4
- IN22 D2
- IN30 D2
- IN32 E4
- IN34 B2
- IN35 B2
- IP31 D8
- IP32 D8

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.


|            |                          |                                       |               |
|------------|--------------------------|---------------------------------------|---------------|
| CHN        | SETNAME                  |                                       |               |
| CLASS_NO   | UFD 2K8                  | 2                                     | 2008-11-21    |
|            | DIGI I/O TV543 R2 LDIPNX |                                       |               |
|            |                          |                                       | 8204 000 8934 |
| 2008-10-10 | 3                        |                                       |               |
| NAME       | Maelegheer Ingrid        | SUPERS.                               | 8             |
| CHECK      |                          | DATE                                  | 2007-10-18    |
|            |                          | © ROYAL PHILIPS ELECTRONICS N.V. 2007 |               |
|            |                          | 130 - 8                               | A3            |

SSB: Analogue Externals A



All rights reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner.


SSB: Analogue Externals B



- 1011 G12
- 1012 C4
- 1013 F3
- 1014 F11
- 1016 A4
- 1026 E11
- 1235 G3
- 1240 A5
- 1241 A6
- 1242 C5
- 1246 H3
- 1250 I3
- 1255 I3
- 1E03-1 I3
- 1E03-2 G3
- 1E03-3 H3
- 1E04-1 F11
- 1E04-2 E11
- 1E04-3 E3
- 1E05 A2
- 1E07 F14
- 1E10 I3
- 2E05 G8
- 2E07 G8
- 2E08 H11
- 2E11 A5
- 2E21 D8
- 2E22 G12
- 2E26 C10
- 2E27 F4
- 2E28 F9
- 2E34 F8
- 2E46 C5
- 2E48 E9
- 2E52 G8
- 2E64 C6
- 2E65 A6
- 2E67 H5
- 2E68 G5
- 2E71 I5
- 2E72 I5
- 2E76 H11
- 2E78 H14
- 2E79 I14
- 2E81 H12
- 2E92 I3
- 2E93 I3
- 2E95 F10
- 2E96 E10
- 2E99 C9
- 2EB1 H12
- 2EB3 H14
- 2E84 A4
- 2E2C F3
- 3E01 B6
- 3E03 B7
- 3E04-1 G8
- 3E04-2 G8
- 3E04-3 H8
- 3E05 A4
- 3E10 F4
- 3E13 H9
- 3E20 H10
- 3E25 D9
- 3E29 E5
- 3E33 D10
- 3E35 C6
- 3E36 G4
- 3E42 B7
- 3E46 C5
- 3E47 C11
- 3E48 F10
- 3E50 F9
- 3E53 F10
- 3E56 F8
- 3E58 E8
- 3E60 E10
- 3E65 C12
- 3E70 B13
- 3E71 B13
- 3E72 C13
- 3E82 B7
- 3E89 C7
- 3E90 B8
- 3E92 H4
- 3E95 I5
- 3E96 I4
- 3E97 I4
- 3E98 I5
- 3EA1 H14
- 3EA2 H13
- 3EA3 H13
- 3EA5 I14
- 3EA6 I13
- 3EB1 H13
- 3EB2 H13
- 3EB4 I11
- 3EB5 I12
- 3ED3 H14
- 5E02 H12
- 5E05 B10
- 5E06 F12
- 6E04 C4
- 6E05 A7
- 6E06 I4
- 6E11 C6
- 6E13 C10
- 6E15 C11
- 6E16 C13
- 6E17 B14
- 6E18 A4
- 6E38 I4
- 6E40 F4
- 6E46 G13
- 6E47 E10
- 6E48 F10
- 6E51 H4
- 6E52 G4
- 6E53 A5
- 6E54 A3
- 7E03 H9
- 7E06-1 I13
- 7E06-2 I13
- 7E10-1 E9
- 7E10-2 F9
- 7E16 I11
- 7E18 B12
- 9E00 G5
- 9E01 H5
- 9E02 H5
- 9E04 F5
- 9E06 H9
- 9E07 I8
- 9E11 G5
- 9E21 I12
- 9E28 I8
- 9E29 C14
- 9E37 C14
- FE13 B4
- FE19 B9
- FE26 C10
- FE38 C4
- FE39 C12
- FE40 E11
- FE41 G14
- FE42 G3
- FE43 I3
- FE48 G4
- FE49 I3
- FE50 I3
- FE51 G4
- FE52 A6
- FE53 F10
- FE54 E3
- FE55 A5
- FE58 A4
- FE59 F13
- FE69 D10
- FE82 C13
- FE83 D13
- IE01 H10
- IE02 H9
- IE03 G5
- IE07 H2
- IE08 F5
- IE10 B12
- IE13 I9
- IE15 F11
- IE19 A2
- IE24 G8
- IE25 G8
- IE26 G5
- IE27 E5
- IE29 I5
- IE31 I5
- IE32 C13
- IE33 F9
- IE34 F8
- IE35 F9
- IE38 I12
- IE57 D8
- IE60 I14
- IE61 I14
- IE62 E9
- IE68 D9
- IE70 H13
- IE89 H13
- IE90 H13

|                       |                 |                                     |
|-----------------------|-----------------|-------------------------------------|
| CHN                   | SETNAME         |                                     |
| CLASS_NO              | ANA + SIDE I/O  | 2 2008-11-21                        |
|                       | TV543 R2 LDIPNX |                                     |
|                       | 8204 000 8930   |                                     |
| 2008-10-10            |                 |                                     |
| NAME Maelgheer Ingrid | SUPERS.         | 4                                   |
| CHECK                 | DATE 2008-01-18 | 130 - 2                             |
|                       |                 | ROYAL PHILIPS ELECTRONICS N.V. 2005 |

SSB: Analogue Externals C




- 1000 F3
- 1002 E2
- 1003 D3
- 1004 C2
- 1005 B2
- 1006 B3
- 1007 A3
- 1010 F4
- 1E11-1 C1
- 1E11-2 C2
- 1E11-3 D2
- 1E14 B1
- 1E15 E2
- 1M36 B8
- 2E35 A3
- 2E36 B3
- 2E37 D3
- 2E39 F4
- 2E40 F5
- 2E42 C3
- 2E45 D5
- 2E53 A7
- 2E54 A7
- 2E55 B7
- 2E56 B8
- 2E57 D8
- 2E58 D8
- 2E80 D5
- 2E97 C4
- 2E98 D4
- 3E26-1 E5
- 3E26-2 F5
- 3E26-3 F5
- 3E26-4 F5
- 3E74 A4
- 3E75 B4
- 3E76 C4
- 3E77 D4
- 3E78 D4
- 3E79 F3
- 3E80 F4
- 3E81 C4
- 3E81 B8
- 3E81 A8
- 3E81 D8
- 3E81 F3
- 3E81 F2
- 3E81 F1
- BE20 A3
- BE21 B2
- BE22 B2
- BE23 C3
- BE24 D2
- BE25 D2
- BE26 F3
- BE27 F4
- BE28 F2
- FE17 D2
- FE18 F2
- FE20 B2
- FE21 B2
- FE22 C3
- FE23 D3
- FE24 F3
- FE25 F5
- FE56 A2
- FE86 B7
- FE87 B7
- FE88 B7
- FE89 B8
- FE90 C8
- FE91 D7
- FE98 B8
- IE58 C4
- IE66 E5
- IE67 F5
- IE72 D5

|                       |                 |   |                                     |
|-----------------------|-----------------|---|-------------------------------------|
| CHN                   | SETNAME         |   |                                     |
| CLASS_NO              | ANA + SIDE I/O  | 2 | 2008-11-21                          |
|                       | TV543 R2 LDIPNX |   |                                     |
|                       |                 |   | 8204 000 8930                       |
| 2008-10-10            | 3               |   |                                     |
| NAME Maelegher Ingrid | SUPERS.         | 4 | A3                                  |
| CHECK                 | DATE 2008-01-18 |   |                                     |
|                       |                 |   | ROYAL PHILIPS ELECTRONICS N.V. 2007 |

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.




SSB: Analogue Externals D



All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.

|                       |                                     |              |
|-----------------------|-------------------------------------|--------------|
| CHN                   | SETNAME                             |              |
| CLASS_NO              | ANA + SIDE I/O                      | 2 2008-11-21 |
|                       | TV543 R2 LDIPNX                     |              |
|                       | 8204 000 8930                       |              |
| NAME Maaigheer Ingrid | SUPERS.                             | 130 - 4      |
| CHECK                 | DATE 2008-01-18                     | AZ           |
|                       | ROYAL PHILIPS ELECTRONICS N.V. 2007 |              |

**SSB: Mini PCI Connector**




- 1A01-A A1
- 1A01-B A6
- 2A00 A3
- 2A01 A3
- 2A02 A3
- 2A03 A3
- 2A04 A4
- 2A05 A4
- 2A06 A4
- 2A07 A4
- 2A08 A5
- 2A09 A5
- 2A50 A7
- 2A51 A7
- 2A52 A8
- 3A00 E9
- 3A01 C4
- 3A02 B9
- 3A03 D9
- 3A04 D9
- 3A05 D9
- 3A06 E9
- 5A00 A2
- 5A01 A7
- 9A00 B3
- 9A01 B7
- 9A02 B9
- FA30 E1
- FA31 E2
- FA32 E1
- FA33 E1
- FA34 E6
- FA35 E6
- FA36 E6
- FA37 A8
- IA20 B9
- IA21 D9
- IA22 D9
- IA23 D9
- IA24 E9
- IA25 E9
- IA26 B7
- IA27 B7
- IA28 A3
- IA29 B2
- IA30 C4

|                       |                 |                                       |            |
|-----------------------|-----------------|---------------------------------------|------------|
| CHN                   | SETNAME         |                                       |            |
| CLASS_NO              | MINI PCI        | 2                                     | 2008-11-21 |
|                       | TV543 R2 LDIPNX | 8204 000 8935                         |            |
| 2008-10-10            | 3               |                                       |            |
| NAME Maelgheer Ingrid | SUPERS.         | 2                                     |            |
| CHECK                 | DATE 2007-10-16 | © ROYAL PHILIPS ELECTRONICS N.V. 2008 |            |
|                       |                 | 130 - 1                               | A3         |

SSB: DDR Supply

PHILIPS

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.




- 1M01 E3
- 2A10 E3
- 2A11 E5
- 2A12 E5
- 2A13 B6
- 2A14 B6
- 2A15 C4
- 2A16 C4
- 2A19 A5
- 2A20 A4
- 2A21 B5
- 2A22 C1
- 2A23 E6
- 2A24 E6
- 2A25 A7
- 2A26 A7
- 2A27 B7
- 2A28 D7
- 2A29 D7
- 2A30 E7
- 2AC0 E1
- 3A07 C1
- 3A08 A3
- 3A09 A3
- 3A10 B3
- 3A11 A3
- 3A12 A4
- 3A13 A6
- 3A14 B5
- 3A15 B5
- 3A16 E5
- 3A17 B5
- 3A18 E6
- 3A19 D6
- 3A20 C3
- 3A21 C3
- 3A22 C4
- 3A23 C5
- 3A24 D4
- 3A25 D4
- 3A26 A1
- 3A27 A1
- 3AC0 E1
- 5AC1 E2
- 5AC2 E2
- 5AC4 E3
- 6A01 E7
- 7A00-1 A5
- 7A00-2 D5
- 7A01 A6
- 7A02 D7
- 7A03 D3
- 7A07 A1
- FA01 A6
- FA02 E6
- FA03 E6
- FA04 A1
- FA06 C4
- FAC0 E3
- IA01 B3
- IA02 A4
- IA03 A5
- IA04 B5
- IA05 A6
- IA06 B5
- IA07 D4
- IA08 D3
- IA09 E5
- IA10 C1
- IA11 E5
- IA12 E7
- IA13 E6
- IAC2 E3
- IAC3 E3
- IAC4 E1

|                                       |                 |   |            |
|---------------------------------------|-----------------|---|------------|
| CHN                                   | SETNAME         |   |            |
| CLASS_NO                              | MINI PCI        | 2 | 2008-11-21 |
|                                       | TV543 R2 LDIPNX |   |            |
|                                       | 8204 000 8935   |   |            |
| 2008-10-10                            | 3               |   |            |
| NAME Maelegher Ingrid                 | SUPERS.         | 2 | A3         |
| CHECK                                 | DATE 2008-01-18 |   |            |
| © ROYAL PHILIPS ELECTRONICS N.V. 2008 |                 |   |            |

**SSB: Audio**

**PHILIPS**

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.



- 1735 E9
- 1D38 E6
- 1D50 E8
- 1D51 F8
- 1D52 F9
- 1D53 F5
- 1D54 F6
- 2D01 E2
- 2D02 D2
- 2D05 A4
- 2D06 A5
- 2D07 A5
- 2D08 A7
- 2D09 C7
- 2D10 C7
- 2D11 C8
- 2D12 C8
- 2D13 F9
- 2D14 E9
- 2D15 C8
- 2D16 C4
- 2D17 C4
- 2D18 B8
- 2D19 A7
- 2D20 A5
- 2D21 D8
- 2D22 B8
- 2D23 C4
- 2D24 B4
- 2D25 F8
- 2D26 B8
- 2D27 D8
- 2D30 A5
- 2D31 A6
- 3D03 E2
- 3D06-1 D2
- 3D06-2 D2
- 3D06-3 D2
- 3D06-4 D2
- 3D09 A3
- 3D10-1 D8
- 3D10-2 D8
- 3D10-3 D7
- 3D10-4 D7
- 3D11-1 F7
- 3D11-2 F8
- 3D11-3 E8
- 3D11-4 E7
- 3D14-1 B8
- 3D14-2 B8
- 3D14-3 B8
- 3D14-4 B7
- 3D16 A4
- 3D17 C4
- 5D01 C7
- 5D02 C7
- 5D04 C9
- 5D05 C9
- 5D07 A6
- 5D08 A6
- 5D09 F8
- 7D03-1 A4
- 7D03-2 C2
- 7D10-1 B6
- 7D10-2 D3
- CD10 D5
- FD02 F9
- FD05 E9
- FD06 F9
- FD07 D2
- FD14 A5
- ID05 C8
- ID06 C8
- ID07 C8
- ID08 C8
- ID09 C7
- ID10 C7
- ID11 A4
- ID12 A4
- ID16 C4
- ID18 C5
- ID19 B5
- ID27 A6
- ID28 B6
- ID29 C5
- ID30 C5
- ID31 C6
- ID32 C6
- ID33 D2
- ID36 B4
- ID37 C4
- ID38 D4

|                                       |                 |   |            |
|---------------------------------------|-----------------|---|------------|
| CHN                                   | SETNAME         |   |            |
| CLASS_NO                              |                 | 2 | 2008-11-21 |
| <b>CLASS D</b>                        |                 |   |            |
| <b>TV543 R2 LDIPNX</b>                |                 |   |            |
| 2008-10-10                            | 3               |   |            |
| NAME Randal De Keyzer                 | SUPERS.         | 1 |            |
| CHECK                                 | DATE 2007-10-12 |   |            |
|                                       |                 |   | 130 - 1    |
| © ROYAL PHILIPS ELECTRONICS N.V. 2007 |                 |   |            |







SSB: SRP List Part 2


| Netname   | Schematic  | B05G (2x) | PCI-AD25 | B09A (1x) | PCI-IRDY     | B05A (2x) | PNX5100-DDR2-D30       | B05F (1x) | SCL-AMBI-3V3   | B05E (3x) | TX1C-     | B05E (1x) | TXDAT+      |
|-----------|------------|-----------|----------|-----------|--------------|-----------|------------------------|-----------|----------------|-----------|-----------|-----------|-------------|
| B06F (1x) | MM1-WE     | B07F (1x) | PCI-AD25 | B04F (1x) | PCI-ARD      | B05A (2x) | PNX5100-DDR2-D31       | B06A (1x) | SCL-AMBI-3V3   | B05E (3x) | TX1C+     | B06A (1x) | TXDAT+      |
| B06G (1x) | MM1-WE     | B07G (1x) | PCI-AD25 | B05G (1x) | PCI-PAR      | B05A (2x) | PNX5100-DDR2-D4        | B06B (1x) | SCL-AMBI-3V3   | B05E (3x) | TX1CLK-   | B06B (2x) | TXD-MIPS    |
| B07A (4x) | MOCCLK_VS2 | B07H (1x) | PCI-AD25 | B09A (1x) | PCI-PAR      | B05A (2x) | PNX5100-DDR2-D5        | B04N (1x) | SCL-BOLT-ON    | B05E (3x) | TX1CLK+   | B08D (3x) | TXD-MIPS2   |
| B06A (3x) | MOSI       | B04F (1x) | PCI-AD26 | B09A (1x) | PCI-PAR      | B05A (2x) | PNX5100-DDR2-D6        | B06A (3x) | SCL-BOLT-ON    | B05E (3x) | TX1D-     | B04E (2x) | TXD-MIPS2   |
| B07A (4x) | MOSTRT     | B05G (1x) | PCI-AD26 | B04F (1x) | PCI-PERR     | B05A (2x) | PNX5100-DDR2-D7        | B08D (1x) | SCL-BOLT-ON    | B05E (3x) | TX1D+     | B06B (1x) | TXD-MIPS2   |
| B07A (4x) | MOVAL      | B07F (1x) | PCI-AD26 | B05G (1x) | PCI-PERR     | B05A (2x) | PNX5100-DDR2-D8        | B05E (2x) | SCL-DISP       | B05E (3x) | TX1E-     | B04A (2x) | TXD-UP      |
| B06A (2x) | MPCIACT0   | B07G (1x) | PCI-AD26 | B07F (1x) | PCI-PERR     | B05A (2x) | PNX5100-DDR2-D9        | B06A (3x) | SCL-DISP       | B05E (3x) | TX1E+     | B08D (4x) | TXD-UP      |
| B06G (1x) | MSEL0      | B07H (1x) | PCI-AD26 | B09A (1x) | PCI-PERR     | B05A (2x) | PNX5100-DDR2-DQM0      | B06D (1x) | SCL-DISP       | B05E (3x) | TX2A-     | B06D (1x) | TXF1A-      |
| B06G (1x) | MSEL1      | B07H (1x) | PCI-AD26 | B04F (2x) | PCI-REQ      | B05A (2x) | PNX5100-DDR2-DQM1      | B01B (1x) | SCL-SET        | B05E (3x) | TX2A+     | B06G (1x) | TXF1A-      |
| B06G (1x) | MSEL2      | B09A (1x) | PCI-AD26 | B04F (2x) | PCI-REQ-B    | B05A (2x) | PNX5100-DDR2-DQM2      | B04E (2x) | SCL-SET        | B05E (3x) | TX2B-     | B06D (1x) | TXF1A+      |
| B06G (1x) | MSEL3      | B04F (1x) | PCI-AD27 | B04F (1x) | PCI-REQ-ETH  | B05A (2x) | PNX5100-DDR2-DQM3      | B06A (5x) | SCL-SET        | B05E (3x) | TX2B+     | B06G (1x) | TXF1A+      |
| B07F (2x) | NAND-AD(0) | B05G (1x) | PCI-AD27 | B07G (1x) | PCI-REQ-ETH  | B05A (2x) | PNX5100-DDR2-DQS0_N    | B06C (2x) | SCL-SET        | B05E (3x) | TX2C-     | B06D (1x) | TXF1B-      |
| B07F (2x) | NAND-AD(1) | B07F (1x) | PCI-AD27 | B04F (1x) | PCI-REQ-MINI | B05A (2x) | PNX5100-DDR2-DQS0_P    | B06A (2x) | SCL-SET0       | B05E (3x) | TX2C+     | B06G (1x) | TXF1B-      |
| B07F (2x) | NAND-AD(2) | B07G (1x) | PCI-AD27 | B09A (2x) | PCI-REQ-MINI | B05A (2x) | PNX5100-DDR2-DQS1_N    | B06A (2x) | SCL-SET1       | B05E (3x) | TX2D-     | B06D (1x) | TXF1B+      |
| B07F (2x) | NAND-AD(3) | B07H (1x) | PCI-AD27 | B04F (2x) | PCI-SERR     | B05A (2x) | PNX5100-DDR2-DQS1_P    | B02B (2x) | SCL-SSB        | B05E (3x) | TX2D+     | B06G (1x) | TXF1B+      |
| B07F (2x) | NAND-AD(4) | B09A (1x) | PCI-AD27 | B05G (1x) | PCI-SERR     | B05A (2x) | PNX5100-DDR2-DQS2_N    | B04E (2x) | SCL-SSB        | B05E (3x) | TX2E-     | B06D (1x) | TXF1C-      |
| B07F (2x) | NAND-AD(5) | B04F (1x) | PCI-AD28 | B07G (1x) | PCI-SERR     | B05A (2x) | PNX5100-DDR2-DQS2_P    | B05F (2x) | SCL-SSB        | B05E (3x) | TX2E+     | B06G (1x) | TXF1C-      |
| B07F (2x) | NAND-AD(6) | B05G (1x) | PCI-AD28 | B09A (1x) | PCI-SERR     | B05A (2x) | PNX5100-DDR2-DQS3_N    | B06A (1x) | SCL-SSB        | B05E (3x) | TX3A-     | B06D (1x) | TXF1C+      |
| B07F (2x) | NAND-AD(7) | B07F (1x) | PCI-AD28 | B04F (2x) | PCI-STOP     | B05A (2x) | PNX5100-DDR2-DQS3_P    | B06G (1x) | SCL-SSB        | B05E (3x) | TX3A+     | B06G (1x) | TXF1C+      |
| B07F (2x) | NAND-ALE   | B07G (1x) | PCI-AD28 | B05G (1x) | PCI-STOP     | B05A (3x) | PNX5100-DDR2-ODT       | B07D (1x) | SCL-SSB        | B05E (3x) | TX3B-     | B06D (1x) | TXF1CLK-    |
| B07F (2x) | NAND-CLE   | B07H (1x) | PCI-AD28 | B07G (1x) | PCI-STOP     | B05A (2x) | PNX5100-DDR2-ODT       | B07D (1x) | SCL-SSB        | B05E (3x) | TX3B+     | B06G (1x) | TXF1CLK+    |
| B07F (2x) | NAND-REN   | B09A (1x) | PCI-AD28 | B09A (1x) | PCI-STOP     | B05A (2x) | PNX5100-DDR2-VREF-CTRL | B04A (3x) | SCL-UP-MIPS    | B05E (3x) | TX3B+     | B06G (1x) | TXF1D-      |
| B07F (2x) | NAND-WEN   | B04F (1x) | PCI-AD29 | B04F (2x) | PCI-TRDY     | B05A (3x) | PNX5100-DDR2-VREF-DDR  | B04E (3x) | SCL-UP-MIPS    | B05E (3x) | TX3C-     | B06D (1x) | TXF1D+      |
| B06G (2x) | nCE        | B05G (1x) | PCI-AD29 | B07G (1x) | PCI-TRDY     | B05F (1x) | PNX5100-RST-OUT        | B04E (2x) | SDA1           | B05E (3x) | TX3C+     | B06G (1x) | TXF1D+      |
| B06G (2x) | nCONF      | B07G (1x) | PCI-AD29 | B09A (1x) | PCI-TRDY     | B09A (1x) | PNX5100-RST-OUT        | B04E (2x) | SDA2           | B05E (3x) | TX3C+     | B06G (1x) | TXF1D+      |
| B06E (1x) | nCSO       | B07H (1x) | PCI-AD29 | B07A (1x) | PCMCIA-A0    | B07A (1x) | PCMCIA-A0              | B05F (1x) | SDA-AMBI-3V3   | B05E (3x) | TX3CLK-   | B06G (1x) | TXF1D+      |
| B06G (1x) | nCSO       | B09A (1x) | PCI-AD29 | B07H (1x) | PCMCIA-A0    | B07H (1x) | PCMCIA-A0              | B06A (1x) | SDA-AMBI-3V3   | B05E (3x) | TX3D-     | B06G (1x) | TXF1E-      |
| B06G (2x) | nSTATUS    | B04F (1x) | PCI-AD3  | B07A (1x) | PCMCIA-A1    | B07A (1x) | PCMCIA-A1              | B06G (1x) | SDA-AMBI-3V3   | B05E (3x) | TX3D+     | B06G (1x) | TXF1E+      |
| B07D (6x) | PCEC-HDMI  | B05G (1x) | PCI-AD3  | B07H (1x) | PCMCIA-A1    | B07H (1x) | PCMCIA-A1              | B04N (1x) | SDA-BOLT-ON    | B05E (3x) | TX3E-     | B06D (1x) | TXF1E+      |
| B07E (2x) | PCEC-HDMI  | B07G (1x) | PCI-AD3  | B07A (1x) | PCMCIA-A10   | B07A (1x) | PCMCIA-A10             | B06A (3x) | SDA-BOLT-ON    | B05E (3x) | TX3E+     | B06G (1x) | TXF1E+      |
| B04F (1x) | PCI-AD0    | B07H (1x) | PCI-AD3  | B07H (1x) | PCMCIA-A10   | B07H (1x) | PCMCIA-A10             | B08D (1x) | SDA-BOLT-ON    | B05E (3x) | TX4A-     | B06D (1x) | TXF2A-      |
| B05G (1x) | PCI-AD0    | B09A (1x) | PCI-AD3  | B07A (1x) | PCMCIA-A11   | B07A (1x) | PCMCIA-A11             | B05E (2x) | SDA-DISP       | B05E (3x) | TX4A+     | B06G (1x) | TXF2A+      |
| B07F (1x) | PCI-AD0    | B04F (1x) | PCI-AD30 | B07H (1x) | PCMCIA-A11   | B07H (1x) | PCMCIA-A11             | B06F (1x) | SDA-DISP       | B05E (3x) | TX4B+     | B06G (1x) | TXF2A+      |
| B07G (1x) | PCI-AD0    | B05G (1x) | PCI-AD30 | B07A (1x) | PCMCIA-A12   | B07A (1x) | PCMCIA-A12             | B06D (1x) | SDA-DISP       | B05E (3x) | TX4B+     | B06G (1x) | TXF2A+      |
| B07H (1x) | PCI-AD0    | B07G (1x) | PCI-AD30 | B07H (1x) | PCMCIA-A12   | B07H (1x) | PCMCIA-A12             | B01B (1x) | SDA-SET        | B05E (3x) | TX4C-     | B06G (1x) | TXF2B-      |
| B09A (1x) | PCI-AD0    | B07H (1x) | PCI-AD30 | B07A (1x) | PCMCIA-A13   | B07A (1x) | PCMCIA-A13             | B04E (2x) | SDA-SET        | B05E (3x) | TX4C+     | B06G (1x) | TXF2B-      |
| B04F (1x) | PCI-AD1    | B07H (1x) | PCI-AD30 | B08D (1x) | PCMCIA-A13   | B08D (1x) | PCMCIA-A13             | B06A (5x) | SDA-SET        | B05E (3x) | TX4CLK-   | B06D (1x) | TXF2B+      |
| B05G (1x) | PCI-AD1    | B09A (1x) | PCI-AD30 | B07A (1x) | PCMCIA-A14   | B07A (1x) | PCMCIA-A14             | B06C (2x) | SDA-SET        | B05E (3x) | TX4CLK+   | B06G (1x) | TXF2B+      |
| B07F (1x) | PCI-AD1    | B04F (1x) | PCI-AD31 | B07H (1x) | PCMCIA-A14   | B07H (1x) | PCMCIA-A14             | B06A (2x) | SDA-SET0       | B05E (3x) | TX4D-     | B06G (1x) | TXF2C+      |
| B07G (1x) | PCI-AD1    | B05G (1x) | PCI-AD31 | B07A (1x) | PCMCIA-A14   | B07A (1x) | PCMCIA-A14             | B06B (1x) | SDA-SET1       | B05E (3x) | TX4E-     | B06D (1x) | TXF2C+      |
| B07H (2x) | PCI-AD1    | B09A (1x) | PCI-AD31 | B07H (1x) | PCMCIA-A2    | B07H (1x) | PCMCIA-A2              | B02B (2x) | SDA-SSB        | B05E (3x) | TX4E+     | B06G (1x) | TXF2C+      |
| B09A (1x) | PCI-AD1    | B07G (1x) | PCI-AD31 | B07A (1x) | PCMCIA-A3    | B07A (1x) | PCMCIA-A3              | B04E (2x) | SDA-SSB        | B05E (3x) | TX4E+     | B06G (1x) | TXF2C+      |
| B04F (1x) | PCI-AD10   | B07H (1x) | PCI-AD31 | B07H (1x) | PCMCIA-A3    | B07H (1x) | PCMCIA-A3              | B04F (2x) | SDA-SSB        | B04D (1x) | TX851A-   | B06D (1x) | TXF2C+      |
| B05G (1x) | PCI-AD10   | B09A (1x) | PCI-AD31 | B07A (1x) | PCMCIA-A4    | B07A (1x) | PCMCIA-A4              | B05F (2x) | SDA-SSB        | B04D (1x) | TX851A-   | B06D (1x) | TXF2C+      |
| B07G (1x) | PCI-AD10   | B04F (1x) | PCI-AD4  | B07H (1x) | PCMCIA-A4    | B07H (1x) | PCMCIA-A4              | B06A (1x) | SDA-SSB        | B06G (1x) | TX851A-   | B06D (1x) | TXF2C+      |
| B07H (1x) | PCI-AD10   | B07G (1x) | PCI-AD4  | B07H (1x) | PCMCIA-A4    | B07H (1x) | PCMCIA-A4              | B06G (1x) | SDA-SSB        | B06G (1x) | TX851A-   | B06D (1x) | TXF2C+      |
| B09A (1x) | PCI-AD10   | B09A (1x) | PCI-AD4  | B07H (1x) | PCMCIA-A5    | B07H (1x) | PCMCIA-A5              | B07G (2x) | RESET-ETHERNET | B06D (1x) | TX851A+   | B06D (1x) | TXF2D-      |
| B04F (1x) | PCI-AD11   | B07H (1x) | PCI-AD4  | B07A (1x) | PCMCIA-A6    | B07A (1x) | PCMCIA-A6              | B08D (1x) | RESET-ETHERNET | B06D (1x) | TX851A+   | B06D (1x) | TXF2D-      |
| B05G (1x) | PCI-AD11   | B09A (1x) | PCI-AD4  | B07H (1x) | PCMCIA-A6    | B07H (1x) | PCMCIA-A6              | B04A (3x) | RESET-mPCI     | B06G (1x) | TX851A+   | B06D (1x) | TXF2D+      |
| B07G (1x) | PCI-AD11   | B04F (1x) | PCI-AD5  | B07A (1x) | PCMCIA-A7    | B07A (1x) | PCMCIA-A7              | B04E (3x) | RESET-NVM      | B04E (1x) | TX851B-   | B06D (1x) | TXF2D+      |
| B07H (1x) | PCI-AD11   | B05G (1x) | PCI-AD5  | B07A (1x) | PCMCIA-A7    | B07A (1x) | PCMCIA-A7              | B04A (2x) | RESET-NVM      | B04E (2x) | TX851B-   | B06G (1x) | TXF2D+      |
| B09A (2x) | PCI-AD11   | B07G (1x) | PCI-AD5  | B07H (1x) | PCMCIA-A7    | B07H (1x) | PCMCIA-A7              | B04A (2x) | RESET-PNX5100  | B04B (1x) | TX851B-   | B06D (1x) | TXF2E-      |
| B04F (1x) | PCI-AD12   | B09A (1x) | PCI-AD5  | B07H (1x) | PCMCIA-A8    | B07H (1x) | PCMCIA-A8              | B04A (2x) | RESET-PNX5100  | B04B (1x) | TX851B+   | B06G (1x) | TXF2E-      |
| B05G (1x) | PCI-AD12   | B04F (1x) | PCI-AD5  | B07A (1x) | PCMCIA-A8    | B07A (1x) | PCMCIA-A8              | B02B (1x) | RESET-STBY     | B04F (2x) | TX851B+   | B06D (1x) | TXF2E+      |
| B07G (1x) | PCI-AD12   | B05G (1x) | PCI-AD5  | B07H (1x) | PCMCIA-A9    | B07H (1x) | PCMCIA-A9              | B02B (1x) | RESET-SYSTEM   | B08D (1x) | TX851B+   | B06G (1x) | TXF2E+      |
| B07H (1x) | PCI-AD12   | B09A (1x) | PCI-AD5  | B07H (1x) | PCMCIA-A9    | B07H (1x) | PCMCIA-A9              | B04B (1x) | RESET-SYSTEM   | B04L (1x) | TX851C-   | B04A (2x) | UART-SWITCH |
| B09A (2x) | PCI-AD12   | B04F (1x) | PCI-AD6  | B07A (1x) | PCMCIA-D0    | B07A (1x) | PCMCIA-D0              | B04E (1x) | RESET-SYSTEM   | B08B (1x) | TX851C-   | B08D (2x) | UART-SWITCH |
| B04F (1x) | PCI-AD13   | B07G (1x) | PCI-AD6  | B07H (1x) | PCMCIA-D0    | B07H (1x) | PCMCIA-D0              | B02A (1x) | RF-AGC         | B04A (2x) | TX851C-   | B08D (2x) | UART-SWITCH |
| B05G (1x) | PCI-AD13   | B09A (1x) | PCI-AD6  | B07A (1x) | PCMCIA-D1    | B07A (1x) | PCMCIA-D1              | B02B (1x) | RF-AGC         | B04A (2x) | TX851C+   | B04E (2x) | USB20-DM    |
| B07G (1x) | PCI-AD13   | B04F (1x) | PCI-AD7  | B07H (1x) | PCMCIA-D1    | B07H (1x) | PCMCIA-D1              | B10 (3x)  | RIBT-SPEAKER   | B04A (2x) | TX851C+   | B04E (4x) | USB20-DM    |
| B07H (1x) | PCI-AD13   | B05G (1x) | PCI-AD7  | B07A (1x) | PCMCIA-D2    | B07A (1x) | PCMCIA-D2              | B04H (1x) | RREF-PNX85XX   | B04B (1x) | TX851C-   | B04E (2x) | USB20-DP    |
| B09A (2x) | PCI-AD13   | B07G (1x) | PCI-AD7  | B07H (1x) | PCMCIA-D2    | B07H (1x) | PCMCIA-D2              | B04P (2x) | RREF-PNX85XX   | B04A (3x) | TX851CLK- | B07C (1x) | USB20-DP    |
| B04F (1x) | PCI-AD14   | B09A (1x) | PCI-AD7  | B07A (1x) | PCMCIA-D3    | B07A (1x) | PCMCIA-D3              | B04K (1x) | R-VGA          | B04A (2x) | TX851CLK+ | B04E (1x) | USB-OC      |
| B05G (1x) | PCI-AD14   | B07H (1x) | PCI-AD7  | B07H (1x) | PCMCIA-D3    | B07H (1x) | PCMCIA-D3              | B08B (1x) | R-VGA          | B04A (3x) | TX851CLK+ | B07C (1x) | USB-OC      |
| B07G (1x) | PCI-AD14   | B09A (1x) | PCI-AD7  | B07A (1x) | PCMCIA-D4    | B07A (1x) | PCMCIA-D4              | B01B (1x) | STANDBY        | B01B (1x) | TX851CLK+ | B04P (2x) | VDDA-ADC    |
| B07H (1x) | PCI-AD14   | B04F (1x) | PCI-AD8  | B07H (1x) | PCMCIA-D4    | B07H (1x) | PCMCIA-D4              | B04A (2x) | STANDBY        | B04A (2x) | TX851CLK+ | B04E (2x) | VDDA-AUDIO  |
| B09A (1x) | PCI-AD14   | B05G (1x) | PCI-AD8  | B07A (1x) | PCMCIA-D5    | B07A (1x) | PCMCIA-D5              | B08D (1x) | STANDBY        | B08D (1x) | TX851CLK+ | B04P (2x) | VDDA-AUDIO  |
| B04F (1x) | PCI-AD15   | B07G (1x) | PCI-AD8  | B07H (1x) | PCMCIA-D5    | B07H (1x) | PCMCIA-D5              | B04A (2x) | SUPPLY-FAULT   | B04A (2x) | TX851D-   | B04L (1x) | VDDA-DAC    |
| B05G (1x) | PCI-AD15   | B09A (1x) | PCI-AD8  | B07A (1x) | PCMCIA-D6    | B07A (1x) | PCMCIA-D6              | B06C (2x) | TACH01         | B06C (2x) | TX851D-   | B04P (2x) | VDDA-DAC    |
| B07G (1x) | PCI-AD15   | B04F (1x) | PCI-AD8  | B07H (1x) | PCMCIA-D6    | B07H (1x) | PCMCIA-D6              | B06C (2x) | TACH01-INV     | B06C (2x) | TX851D+   | B04O (1x) | VDDA-LVDS   |
| B09A (1x) | PCI-AD15   | B07H (1x) | PCI-AD8  | B07A (1x) | PCMCIA-D7    | B07A (1x) | PCMCIA-D7              | B06C (2x) | TACH02         | B06C (2x) | TX851D+   | B04P (1x) | VDDA-LVDS   |
| B04F (1x) | PCI-AD16   | B09A (1x) | PCI-AD9  | B07H (1x) | PCMCIA-D7    | B07H (1x) | PCMCIA-D7              | B06C (2x) | TACH02-INV     | B06C (2x) | TX851D+   | B04O (1x) | VDDA-LVDS   |
| B05G (1x) | PCI-AD16   | B04F (1x) | PCI-AD9  | B07A (1x) | PCMCIA-D7    | B07A (1x) | PC                     |           |                |           |           |           |             |








Layout Small Signal Board (Bottom Side)



3104 313 6343.2

18310\_555\_090309.eps  
090309


Light guide



- 1P09 C1
- 2001 B4
- 2002 B3
- 3000 B4
- 3001 B4
- 3002 B4
- 3003 B5
- 3004 B5
- 3005 B5
- 3007 B6
- 3008 B6
- 3009 B6
- 3015 C3
- 3016 C3
- 6001 B4
- 6002 B4
- 6003 B4
- 6004 B5
- 6005 B5
- 6006 B5
- 6007 B6
- 6008 B6
- 6009 B6
- 7001 C4
- I000 C3
- I001 C4
- I002 B4
- I003 B4
- I004 B4
- I005 B5
- I006 B5
- I007 B5
- I008 B6
- I009 B6
- I010 B6

|                                       |                   |     |
|---------------------------------------|-------------------|-----|
| CHN                                   | SETNAME           | 2K9 |
| CLASS_NO                              | LIGHT STRIP PANEL |     |
|                                       |                   |     |
|                                       | 9 LEDS 2K9        |     |
|                                       | 3104 313 6344     |     |
| 2008-10-17                            | 3                 |     |
| NAME                                  | Luc Buffel        |     |
| SUPERS.                               |                   | 1   |
| CHECK                                 | DATE              |     |
| © ROYAL PHILIPS ELECTRONICS N.V. 2007 |                   |     |

Layout guide panel




31043136344.1

18310\_559\_090420.eps  
090508



Wi-Fi Antenna

PHILIPS

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.



Layout Wi-Fi Antenna



|                                       |                   |              |               |
|---------------------------------------|-------------------|--------------|---------------|
| CHN                                   | *****             | SETNAME      | *****         |
| CLASS_NO                              | *****             | WIFI antenna | 3104 303 5212 |
| **..**                                | *                 |              |               |
| 08-07-07                              | 2                 |              |               |
| 08-10-20                              | 3                 |              |               |
| NAME                                  | Maelegheer Ingrid | SUPERS.      | 1             |
|                                       |                   |              | 130 - 1       |
|                                       |                   |              | A4            |
| CHECK                                 |                   | DATE         | ****-**-**    |
| © ROYAL PHILIPS ELECTRONICS N.V. 2008 |                   |              |               |

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>