

Specifications are subject to change without notice.




Register your product and get support at www.philips.com/welcome



Docking Entertainment System DC320

What's in the box




Quick start guide

- 1 Connect
- 2 Setup
- 3 Enjoy



1 Connect

- A Connect power
- 1 Prepare the AC power adaptor.
- 2 Connect one end of the AC adaptor to the **DC IN** socket on the main
- 3 Connect the other end of the AC adaptor to the wall outlet.



2 Setup

A Set time and date

- 1 In standby mode, press and hold **SET TIME/PROG** for 2 seconds.
- \rightarrow [12 HR] begins to blink.
- 2 Press |◀◀/▶▶| to select 12/24 hour format.
- 3 Press SET TIME/PROG to confirm.

 → The hour digits begin to blink.
- Daniel and the later
- 4 Press |◀◀/▶▶| to set the hour.
- 5 Press SET TIME/PROG to confirm.

 → The minute digits begin to blink.
- 6 Repeat steps 4-5 to set the minute, year, month, and day.

B Set the alarm timer

You can set two alarms which go off at different time.

Ensure that you have set the clock correctly.

- 2 Press and hold ALM 1 or ALM 2 for 2 seconds.
 - → [AL 1] or [AL 2] begin to blink.
- 3 Press SOURCE to select an alarm sound source: iPod/iPhone, iPod/ iPhone playlist, FM tuner, or buzzer.
- 4 Press ALM 1 or ALM 2.
- → Hour digits begin to blink.
- 5 Press I◀◀/▶▶ repeatedly to set the hour.
- 6 Press ALM 1 or ALM 2 to confirm.
- → Minute digits begin to blink.
- 7 Repeat steps 5-6 to set the minute.
- 8 Repeat steps 5-6 to select whether to ring alarm the whole week, on weekdays, or at weekend.
- **9** Repeat steps 5-6 to set the alarm volume.

2 Setup

Repeat alarm

(3) Tip

Stop alarm ring

1 Press ALM 1 or ALM 2 repeatedly

or [AL2] is displayed.

→ If the timer is deactivated.

1 When the alarm rings, press

minutes later.

interval to repeat alarm.

settings remain.

BRIGHTNESS/REP ALM.

→ The alarm repeats ringing

You can press |◄◄/▶▶| to adjust the

1 When the alarm rings, press the

corresponding ALM 1 or ALM 2.

→ The alarm stops but the alarm

to activate or deactivate the timer.

→ If the timer is activated, [♣ AL 1]

[AL1] or [AL2] disappears.

3 Enjoy

Activate and deactivate the alarm timer

A Play from iPod/iPhone

1 Place the iPod/iPhone in the dock.



- 2 Press **SOURCE** repeatedly to select iPod/iPhone source.
- → The connected iPod/iPhone plays automatically.
- To pause/resume play, press
- To skip to a track, press I◄
 /▶►I.

3 Enjoy

- To search during play, press and hold I◄◄/▶►I, then release to resume normal play.
- To go back to previous iPod/ iPhone menu, press MENU.
 To scroll through the menu, press PRESET +/-. To confirm a selection, press OK/>II.
 - If no key is pressed for more than 10 seconds,
 OK/▶II acts back as the play/pause key.

B Program and listen to radio stations

- 1 In the tuner mode, press and hold **SET TIME/PROG** for more than 2 seconds to activate automatic program mode.
- All available stations are programmed in the order of waveband reception strength.
- → The first programmed radio station is broadcast automatically.
- 2 Press PRESET +/- to select a preset number.



 Detailed functions and features are described in the user manual.

Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com