

EQUIPMENT APPROVAL INFORMATION

Your telephone equipment is approved for connection to the Public Switched Telephone Vertwork and is in compliance with parts 15 and 68, FCC Rules and Regulations and the fechnical Requirements for Telephone Terminal Equipment published by ACTA.

Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the US number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not xceed 5. To be certain of the number of devices you may connect to your line as etermined by the REN, you should contact your local telephone company.

A plug and lack used to connect this equipment to the premises wiring and telephone A plug altrigate was do collined, in the equipment to the primases willing and telepin network must comply with the applicable FCC Part 68 rules and requirements adop by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

· This equipment may not be used on coin service provided by the telephone company.

- Party lines are subject to state tariffs, and therefore, you may not be able to use
- your own telephone equipment if you are on a party line. Check with your local
- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.
- If your home has specially wired alarm equipment connected to the telephone lin ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer

Rights of the Telephone Company

should your equipment cause trouble on your line which may harm the telephone network he telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the felephone company must: (1) promptly notify you of such temporary discontinuance: (2) afford you the opportunity to correct the situation: and (3) inform you of your right to bring a complaint to the Commissic pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations. The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service


HEARING AID COMPATIBILITY (HAC)

This telephone system meets ECC standards for Hearing Aid Compatibili US NUMBER IS LOCATED ON THE CABINET BOTTOM REN NUMBER IS LOCATED ON THE CABINET BOTTOM

Model 26971A 15969130 (Rev. 1 DOM E) 02-50 Printed in China

ATLINKS USA, Inc. 101 West 103rd Stree Indianapolis, IN 46290 © 2002 ATLÍNKS USA Inc Marca(s) ® Registrada(s)

INTRODUCTION



Your Caller ID phone stores and displays specific information provided by your local telephone company, to subscribers of Caller D or similar caller identification services

Your Caller ID phone enables you to

- · Identify callers before you answer the phone.
- View the time and date of each incoming call.
- Record up to 40 Caller ID messages sequentially

· Know who called while you were away or on the phone. To get the most from your new phone, we suggest that you take a few minutes right now to read through this user's guide.

IMPORTANT: In order to use all of the features of this phone, you must subscribe to either the standard Name/Number Caller ID Service or Call Waiting Caller ID Service.

IMPORTANT: Because cordless phones operate on electricity you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT **FXPOSETHIS** PRODUCT TO PAIN

BEFORE YOU BEGIN

Parts Checklist

Make sure your package includes the items shown here.















TELEPHONE JACK REQUIREMENTS

To use this phone, you need an RJ11C type modular telephone jack, which might look like the one pictured here, installed in your home. If you don't have a modular jack, call your local phone company to find out how to get one installed.



INSTALLATION NOTE: Some cordless telephones operate at frequencies that may cause interference to nearby TVs. microwave ovens, and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV, microwave ovens, or VCR. If such interference continues, move the cordless telephone


DIGITAL SECURITY SYSTEM


farther away from these appliances.

Your cordless phone uses a digital security system to provide protection against false ringing, unauthorized access, and charges

When you place the handset in the base, the unit verifies its security code. After a power outage or battery replacement, you should place the handset in the base for about 20 seconds to reset

HANDSET AND BASE LAYOUT





IMPORTANT INSTALLATION INFORMATION

- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations
- Never touch uninsulated telephone wires or terminals, unless the telephone line has been disconnected at the network
- · Use caution when installing or modifying telephone lines.
- · Temporarily disconnect any equipment connected to the phone such as faxes, other phones, or modems.


IMPORTANT INSTALLATION GUIDELINES:

- Install telephone near both a telephone (modular) jack and an electrical power outlet.
- Avoid sources of noise, such as a window by a busy street, and electrical noise, such motors, microwave ovens, and fluorescent
- · Avoid heat sources, such as heating air ducts, heating appliances, radiators, and direct sunligh
- · Avoid areas of excessive moisture or extremely low temperature
- Avoid dusty locations
- · Avoid other cordless telephones or personal computers.

INSTALLING THE PHONE

Choose the best location to install your base and handset charge cradle. Your base and handset charge cradle should be placed on a level surface such as a desk or table top, or you may mount the base on a wall.

NOTE: The handset can be charged facing up or down.



CONNECTING THE AC (ELECTRICAL) POWER

· Plug the power supply into the power jack on the bottom of the base and the other end into an electrical outlet. The CHARGE/IN USE indicator comes on, verifying the battery is charging.

CAUTION: Use only the ATLINKS USA, Inc. 5-2576 power supply that came with this unit. Using other

power supplies may damage the unit. Allow the phone to charge for 12 hours prior to first use. If you don't properly charge the phone, battery performance will be compromised.


NOTE: DO NOT connect the telephone line to the modular jack until the phone has charged for 12 hours.

CONNECTING THE TELEPHONE LINE

- Plug the telephone line cord to the jack marked PHONE LINE jack on the bottom of the base and into the a modular phone jack
- Place the handset in the cradle on the base

NOTE: The phone automatically defaults to touch-tone dialing. To change to pulse (rotary) dialing, see TONE/ PULSE DIALING. If you don't know which type of service you have, check with your local telephone compan

WALL MOUNTING



NOTE: For best results, leave the base on a flat surface during initial charging before you hang it on the wall.

- Slip the mounting holes on the back of the base over the wall plate posts and firmly slide the unit down into place (wall plate
- · Place the handset in the cradle

PEN AND NOTEPAD

For your convenience, a writing pen and standard 3" x 3" notepad is included with your phone.

- Insert the pen into the hole on the top right side of the base.
- Remove the plastic wrap from around the notepad, remove the on the front of the base

TELEPHONE SET UP

There are three programmable menus available: Language, Tone/ Pulse Dialing and Area Code

LANGUAGE SETTING

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Press the PROGRAM/FLASH button until 1ENG 2FRA 3ESP shows in the display. 1ENG is the default setting.
- 3. Use the touch tone pad on the handset or press the left or right arrow button to scroll to enter the desired setting. For example to choose English, press the number 1 key.
- 4. Press PROGRAM/FLASH to store selection. You will hear a

TONE/PULSE DIALING

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Press the PROGRAM/FLASH button until 1 Tone 2 Pulse shows in the display. *Tone* is the default setting.
- 3. Use the touch tone pad on the handset or press the left or right arrow button to scroll the desired setting. For example, to choose Tone dialing, press the number 1 key.
- 4. Press PROGRAM/FLASH to store selection. You will hear a

AREA CODE SETTING

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Press the PROGRAM/FLASH button until - SET AREA CODE shows in the display. - - - is the default setting.
- 3. Use the handset number pad to enter your three digit area code 4. Press PROGRAM/FLASH to store selection. You will hear a

TELEPHONE OPERATION

RECEIVING A CALL

- 1. Check the display to see who is calling.
- 2. Press the TALK/callback button.

Making a Call

To make a call, press the TALK/callback button before you dial and

While the phone is on, press the redial button to redial the last number you dialed (up to 32 digits). If you get a busy signal, and want to keep dialing the number, just press redial again (you don't have to turn the phone off and back on).

FLASH

Use the PROGRAM/FLASH button to activate custom calling services such as call waiting or call transfer, which are available through your local phone company.

TIP: Don't use the TALK/callback button to activate custom calling services such as call waiting, or you'll hang up the

CHARGE/IN USE INDICATOR LIGHT

The in use/charge indicator is lit when the handset is in the cradle on the base, or when the phone is ON. It flashes when an incoming call is received. It blinks when a message is waiting or when paging the handset

CHANNEL

While talking, you might need to manually change the channel to get rid of static. Press and release the DELETE/CHANNEL button to move to the next channel.

TEMPORARY TONE

This feature enables pulse (rotary) service phone users to access touchtone services offered by banks, credit card companies, etc., by pressing the TONE*/CANCEL button to temporarily make the phone touch-tone compatible. To get information about your bank account, for example,

- 1. Call the bank's information line.
- 2. Press the TONE*/CANCEL button after your call is answered.
- 3. Follow the voice instructions to complete your transaction.
- 4. Hang up when finished. The phone returns to pulse (rotary)

CANCEL

When the phone is OFF (not in TALK mode), press the TONE*/ CANCEL button to cancel any command you initiated.

VOLUME

While talking, press the CID/VOL buttons (left and right arrows) to control the volume of the handset's earpiece. There are four volume levels. Press the right arrow (>) button to increase the volume level, and press the left arrow (4) button to decrease. VOL 1 is the lowest level and VOL 4 is the loudest.

HANDSET RINGER

Three options are available: RINGER OFF, LOW, and HIGH. The default setting is RINGER LOW.

- When the phone is OFF (not in TALK mode), press RINGER once to listen to the current ringer tone
- Press RINGER again to change the setting. The desired setting

NOTE: If you turn the ringer off, the display shows RINGER OFF when the phone is in standby mode

BASE RINGER

Three options are available: RINGER LOW, MEDIUM, and HIGH. • When the phone is OFF (not in TALK mode), press the left or right

- arrow button on the base to listen to the current ringer tone. To change the ringer tone, press and release the right arrow button to increase the tone or the left arrow to decrease the tone.
- **NOTE:** You cannot turn off the base ringer.

SPEAKERPHONE OPERATION

SPEAKERPHONE LOCATION

For best speakerphone performance, avoid the following:

- · Areas with high background noise. (The microphone might pick up these sounds and prevent the speakerphone from going into the receiving mode when you finish talking.)
- · Surfaces affected by vibration.
- Recessed areas such as in a corner, under a cupboard, or next to a cabinet, which can generate an echo effect

SPEAKERPHONE USE

Note the following guidelines when using the speakerphone:

- The speakerphone works similar to a two-way radio in that you can only listen or talk at one time.
- Stay reasonably close to the phone so that you can be clearly heard by the person to whom you are talking.

RECEIVING A CALL

When the phone rings, press the SPEAKER button to answer a call.

NOTE: You cannot not dial out while in speakerphone mode You can only receive and answer calls

3-Way Conference

While the handset is engaged in an external call, a third party may press the SPEAKER button to join in a three-way conference between the base, handset, and external party.

INDICATOR LIGHT

The speakerphone is ON when the indicator light is turned on.

SPEAKERPHONE VOLUME

You may choose from eight volume levels.

Press the left or right arrow button on the base to adjust the speakerphone listening level. You will hear a tone when you reach the minimum or maximum volume level.


· Press the SPEAKER button to turn on the speakerphone.

FINDING THE HANDSET

The PAGE feature helps you locate a misplaced handset. Press the PAGE button on the base, and the handset beeps continuously for about two minutes or until you press any button on the handset. ou may also press PAGE again to cance

NOTE: The handset ringer does not need to be turned ON for this feature to work

Caller ID (CID) Features



This unit receives and displays information transmitted by your local phone company. This information can include the phone number, date, and time; or the name, phone number, date, and time. The unit can store up to 40 calls for later review

CALLER ID WITH CALL WAITING

Provided you subscribe to Caller ID with Call Waiting service from your phone company, you are able to see who is calling when you hear the call waiting beep. The caller identification information appears in the display after you hear the tone

Press the PROGRAM/FLASH button to put the current person on hold so that you can answer the incoming call

IMPORTANT: In order to use the Caller ID functions with this unit, you must subscribe to either the standard Name Number Caller ID Service or Caller ID with Call Waiting Service. To know who is calling while you are on the phone, you must subscribe to Caller ID with Call Waiting Service.

RECEIVING AND STORING CALLS

When you receive a call, the information is transmitted by the phone company to your Caller ID telephone between the first and second ring.

When the memory is full, a new call automatically replaces the oldest call in memory. NEW appears in the display for calls received that have not been reviewed. REPT indicates that a new call from the same number was received more than once.

NOTE: Check with your local phone company regarding name service availability.

REVIEWING CID RECORDS

know how many calls have been received

records from the oldest to the newest

As calls are received and stored, the display is updated to let you

- Press the CID/VOL left arrow button to scroll through the call records from the most recent to the oldest
- Press the CID/VOL right arrow button to scroll through the call

Transferring CID Records to MEMORY

You may transfer a Caller ID record to your phone's memory.

NOTE: It is important that you format CID records correctly before storing in memory. It is not possible to re-format CID records stored in memory.

- 1. Use the CID/VOL (left or right arrow) button to scroll to the
- 2. Press the MEMORY button.
- 3. Press the desired memory location. Example, press the number 1 key to store the record in memory location 1

To replace a CID record stored in a memory location with a new

- 1. Repeat steps 1 through 3.
- 2. Press the MEMORY button and REPLACE MEMO? shows in the
- 3. Press TONE*/CANCEL to exit, or press memory again and the new CID record replaces the old CID record in that memory location. You will hear a confirmation tone

DELETING THE CID RECORD SHOWING IN THE DISPLAY

- 1. Make sure the phone is **OFF** (not in TALK mode)
- 2. Use the CID/VOL (left or right arrow) button to display the
- 3. Press DELETE/CHANNEL. The display shows DELETE?
- 4. Press DELETE/CHANNEL again to erase the record. You will hear a confirmation tone. The display shows *DELETED*. Then the next Caller ID record shows in the display.

DELETING ALL CID RECORDS

1. Make sure the phone is **OFF** (not in TALK mode)

2. Use the CID/VOL (left or right arrow) button to display any Caller

confirmation tone, and the display shows NO CALLS

3. Press and hold DELETE/CHANNEL button until the unit beeps and DELETE ALL? shows in the display. 4. Press DELETE/CHANNEL again to erase all records. You will hear a

DIALING A CID NUMBER

- 1. Make sure the phone is **OFF** (not inTALK mode).
- 2. Use the CID/VOL (left or right arrow) button to display the desired Caller ID record.
- 3. PressTALK/callback button. The number dials automatically.

CHANGING THE CID NUMBER FORMAT The FORMAT button lets you change the format of the displayed CID

long distance code "1" + 3-digit area code +

number. The available formats are as follows. 7-digit 7-digit telephone number 10-digit 3-digit area code + 7-digit telephone number.

11-diait

7-digit telephone number 1. Use the CID/VOL (left or right arrow) button to scroll to the number you want to call back.

2. If the number does not dial as shown, press the FORMAT button. Repeat if necessary, until the correct number of digits

3. Press TALK/callback button. The number dials automatically.

Download from Www.Somanuals.com. All Manuals Search And Download

MEMORY

Store up to ten 24-digit numbers in memory for quick dialing. This memory feature is in addition to the 40 Caller ID records that can be stored in the Caller ID memory log.

STORING A NAME AND NUMBER IN

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Press the MEMORY button.
- 3. Press the desired memory location (0 through 9)
- 4. Press the MEMORY button again. The display shows ENTER

NOTE: If you don't want to enter the name, skip step 5.

For example, to enter the name Bill Smith, press the two key twice for the letter B, press the four key three times for the letter I, and press the five key three times for the letter L. After one second, press the five key three times again for the second letter L and press the one key to insert a space between the letter L and S. Press the seven key four times for the letter S, press the six key once for the letter M, press the four key three times for the letter I, press the eight key once for the letter T, and press the four key twice for the letter H

NOTE: If you enter a wrong letter, press DELETE/CHANNEL

- 5. Press the MEMORY button to save the name. The display shows **ENTER TEL NUMBR**
- 6. Use the number keypad to enter the telephone number you want to store (up to 24 digits)
- 7. Press MEMORY again to store the number. You will hear a confirmation tone

CHANGING A STORED NUMBER

- 1. Repeat steps 1 through 7 in Storing a Name and Number in
- 2. Press the MEMORY button and REPLACE MEMO? shows in the
- 3. PressTONE*/CANCEL to exit, or press the MEMORY button to store the number. You will hear a confirmation ton

STORING A REDIAL NUMBER

- 1. Repeat steps 1 through 6 in Storing a Name and Number in
- Press the REDIAL button
- 3. Press the MEMORY button to store the number. You will hear a confirmation tone

To replace an old redial number stored in a memory locations with

- 1. Repeat steps 1 through 6 in Storing a Name and Number in Memory
- 2. Press the MEMORY button and REPLACE MEMO? shows in the
- 3. PressTONE*/CANCEL to exit, or press the MEMORY button again and the new redial number replaces the old redial number in that memory location. You will hear a confirmation tone.

DIALING A STORED NUMBER

- 1. Make sure the phone is ON by pressing the TALK/callback
- 2 Press MFMORY button
- 3. Press the number (0-9) for the desired memory location. The number dials automatically.

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Press MEMORY button.
- 3. Use the CID/VOL (left or right arrow) button to scroll through the numbers stored in memory until the desired number is shown.
- 4. Press TALK/callback. The numbers dial automatically

INSERTING A PAUSE IN THE DIALING **SEQUENCE**

When storing information in memory, press the PAUSE # button twice within one second to insert a delay in the dialing sequence of a stored telephone number when a pause is needed to wait for a dial tone (for example after you dial 9 for an outside line, or to wait for a computer access tone). PAUSE shows on the display as a "P." Each pause counts as 1 digit in the dialing sequence.

REVIEWING AND DELETING STORED Numbers

- 1. Press MEMORY, then use the CID/VOL (left or right arrow) button to view the entry.
- 2. While the entry is displayed, press DELETE/CHANNEL button to delete the entry. The display shows DELETE?
- 3. Press DELETE/CHANNEL again to delete the entry. DELETED shows in the display.

CHAIN DIALING FROM MEMORY

Use this feature to make calls which require a sequence of numbers such as using a calling card for a frequently called long distance number. Basically, you dial each part of the sequence from memory. The following example shows how you can use chain dialing to make a call through a long distance service:

The Number For	Memory Location		
Long distance access number			
Authorization code			
Frequently called long distance number			

- 1. Make sure the phone is **ON**
- 2. Press MEMORY and then press 7.
- 3. When you hear the access tone, press MEMORY again and then
- 4. At the next access tone, press MEMORY and then 9.

TIP: Wait for the access tones between pressing the memory button, or your call might not go through.

PROGRAMMABLE TIMER

Keep track of baking or cooking times with the built-in, easy-to-read digital display timer. A loud two-minute alarm sounds when

SETTING THE TIMER

- 1. Make sure the phone is OFF (not in TALK mode)
- 2. Press the TIMER button.
- 3. The unit displays SETTIMER 00 MIN 00 SEC, and the first digit (minutes) blinks in the display
- 4. Press the desired number 0-9.
- 5. After the first digit is entered, the second digit blinks.
- 6. Continue entering digits for the number of seconds you want

NOTE: Maximum timing period is 99 minutes 99 seconds, while one minute equals 60 seconds.

STARTING THE TIMER

When the countdown time is set

- 1. Press the TIMER button to start counting down. You will hear a confirmation tone
- 2. When the countdown time expires, TIMER ON 00 MIN 00 SEC shows in the display, and an alarm sounds for two minutes

STOPPING THE TIMER

When the phone is OFF (not in TALK mode), press the TONE*/ CANCEL or TIMER button to stop the countdown and return to standby mode.

NOTE: The timer stops automatically if the battery charge is

Pausing the Timer

Press the TIMER button to pause the countdown. The remaining time is held. Press TIMER again to resume the countdow

Using the Timer with Other Modes

Once the countdown starts, the timer keeps counting down until time runs out and the alarm sounds even if the phone is in other modes. To cancel the timer while in other modes, press TONE*/ CANCEL or TIMER. The timer does not show in the display in other modes. To view the remaining time, press the TIMER button.

TALK Mode


- Press the TIMER button to view the remaining time, and press TIMER again to display the channel number, call counter, and
 - · When the countdown is complete, TIMER STOP shows in the display, and an alarm sounds for two minutes
- 2. Press the TIMER button to stop the alarm and display the channel number, call counter, and volume leve

NOTE: To maximize the countdown timer's functionality,

HEADSET AND BELT CLIP **OPERATION**

CONNECTING AN OPTIONAL HEADSET TO THE HANDSET

For hands free conversation connect the headset (optional) to the HEADSET jack as shown The handset receiver and microphone are disabled when the headset is connected.



approximately 2 to 3 inches

• Press the TALK/callback button to answer or place a call before using the headset

TIP: To order a HEADSET, please refer to the accessory order form at the end of this user's guide.

CONNECTING THE BELT CLIP

There are two slots, one on each side of the handset

Attach the belt clip by inserting the sides of the belt clip into the slots. Snap the ends of the belt



CHANGING THE BATTERY Make sure the telephone is **OFF** before you replace

1. Remove the battery compartment door.

- 2. Disconnect the battery plug from the jack in the handset battery compartment and remove the
- battery pack. 3. Insert the new battery pack and connect the cord into the jack inside the handset
- 4. Put the battery compartment door back on.
- 5. Place handset in the base to charge

Allow the handset battery to properly charge (for 12 hours) prior to first use or when you install a new battery pack If you do not properly charge the phone, battery performance will



CAUTION: To reduce the risk of fire or personal injury.

use only the battery 5-2461.

BATTERY SAFETY PRECAUTIONS

- Do not burn, disassemble, mutilate, or puncture. Like other batteries of this type, toxic materials could be released which
- To reduce the risk of fire or personal injury, use only the battery listed in the User's Guide
- Keep batteries out of the reach of children
- Remove batteries if storing over 30 days



NOTE: The RBRC seal on the battery used in your ATLINKS USA, Inc. product indicates that we are articipating in a program to collect and recycle Nickel Cadmium batteries throughout the United States. Please call 1-800-8-BATTERY for information or contact your local recycling center.

GENERAL PRODUCT CARE

To keep your telephone working and looking good, follow these quidelines

- Avoid putting the phone near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture
- · Avoid dropping and other rough treatment to the phone
- · Clean with a soft cloth.
- Never use a strong cleaning agent or abrasive powder because this will damage the finish.
- Retain the original packaging in case you need to ship the

Causes of Poor Reception

- · Foil backing on insulation
- · Heating ducts and other metal construction can shield radio
- You're too close to appliances such as microwaves, stoves,
- · Atmospheric conditions, such as strong storms. Base is installed in the basement or lower floor of
- · Base is plugged into an AC outlet with other electronic devices
- · Baby monitor is using the same frequency.
- · Handset battery is low.

DELETE ALL?

NEW

REDT

NO DATA

· You're out of range of the base.

DISPLAY MESSAGES

The following indicators show the status of a message or of the unit. INCOMPLETE DATA Caller information has been interrupted

during transmission or the phone line is excessively noisy. ENTER NAME Prompt telling you to enter the name for one of the 10 memory locations.

ENTERTEL NUMBR Prompt telling you to enter the telephone number for one of the 10

memory locations. DELETE? Prompt asking if you want to erase Caller ID records or one of the 10 numbers stored in the phone's outgoing memory.

Prompt asking if you want to erase all

Caller ID records DELETED Prompt confirming the Caller ID / Memory record is erased.

END OF LIST Indicates that there is no additional information in Caller ID memory. Indicates call or calls have not been

UNKNOWN NAME/ The incoming call is from CALLER/NUMBER an area not serviced by Caller ID or the information was not sent.

PAGING Someone has pressed the page button on the base. BLOCKED CALL The person is calling from a number that has been blocked from

transmission **BLOCKED NAME** The person's name is blocked from transmission

> Repeat call message. Indicates that a new call from the same number was received more than once. No Caller ID information was received Indicates a memory location is vacant.

NO CALLS Indicates no CID records have been MESSAGE WAITING Indicates a message is available. BLOCK NUMBER The caller's number is blocked from

MSG WAITING OFF Indicates a message is received. REPLACE MEMO? Prompt asking if you want to replace

HANDSET SOUND SIGNALS

Meaning A long warbling tone Signals an incoming call (with rinaer on) Confirmation Tone Two long beeps One short and one long beep Page signal

Low battery warning

Three short beeps Frror tone TROUBLESHOOTING TIPS

TELEPHONE

No dial tone

One short beep

every seven seconds

· Check and/or repeat installation steps:

Make sure the base power cord is connected to a working electrical outlet Make sure the telephone line cord is connected to the base and

the modular wall jack. Disconnect the base from the wall jack and connect another phone to the same jack. If there is no dial tone on the second phone, the problem might be your wiring or local service.

· The handset may be out of range of the base. Move closer to

- Make sure the battery is properly charged (12 hours).
- · Make sure the battery pack installed correctly.
- Did the handset beep when you pressed the TALK/callback button? Did the display turn on? The battery may need to be

Dial tone is OK, but can't dial out

 Make sure the tone/pulse dialing mode is set according to the type of service you are subscribed to.

Handset does not ring

- · Make sure the ringer switch on the handset is turned ON.
- You may have too many extension phones on your line. Try unplugging some phones
- See solutions for No dial tone.

You experience static, noise, or fading in and out

- · Change channels · The handset may be out of range of the base. Move closer to the base
- Relocate the base Charge the battery
- Make sure base is not plugged into an electrical outlet with another household appliance.

- · Place handset in base for 20 seconds to reset the security code. If that doesn't work, charge battery for 12 hours.
- Clean charging contacts on handset and base with a soft cloth, or an erase
- · See solutions for No dial tone. Replace the battery.
- Memory Dialing
- · Make sure the memory location keys are programmed correctly.
- · Follow proper dialing sequence.
- · Make sure the tone/pulse dialing mode is set according to the type of service you are subscribed to.
- · Did you reprogram numbers into memory after power outage or battery replacement?

CALLER ID

No Display

company?

Caller ID Error Message

- Is battery fully charged? Try replacing the battery. Make sure the battery is properly installed and connected.
- · If you are using AC power, make sure that the unit is connected to a non-switched electrical outlet. Disconnect the unit from the plug and plug it in again. Did you order Caller ID service from your local telephone
- The unit displays this message if it detects anything other than valid Caller ID information during the silent period after the first
- ring. This message indicates the presence of noise on the line. In use/charge indicator on the base flashes Provided your phone company offers voice messaging service and you subscribe to it, the in use/charge indicator on the base flashes when the phone is not in use to indicate there is a message

waiting. It stops flashing after the message has been reviewed SERVICE

Name of store

If trouble is experienced with this equipment, for repair or warranty information, please contact customer service at 1-800-448-0329. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

This product may be serviced only by the manufacturer or its authorized service agents. Changes or modifications not expressly approved by ATLINKS USA, Inc. could void the user's authority to operate this product. For instructions on how to obtain service efer to the warranty included in this guide or call customer service at 1-800-448-0329

Or refer inquiries to: ATLINKS USA, Inc. Manager, Consumer Relations P O Box 1976 Indianapolis, IN 46206

down the date this product was purchased or received as a giff This information will be valuable if service should be required during the warranty period. Purchase date

Attach your sales receipt to the booklet for future reference or jot

INTERFERENCE INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation

This equipment generates, uses, and can radiate radio frequency

energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna (that is, the antenna

- for radio or television that is "receiving" the interference) Reorient or relocate and increase the separation between the
- telecommunications equipment and receiving antenna Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is
- Consult the dealer or an experienced radio/TV technician for help

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies

LIMITED WARRANTY

What your warranty covers:

What we will do:

connected.

Defects in materials or workmanship For how long after your purchase:

> One year, from date of purchase (The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.)

Provide you with a new or, at our option, a refurbished unit. The exchange unit is under warranty for the remainder of the original product's warranty period.

How you get service: Properly pack your unit. Include any cables, etc., which were originally provided with the product. We recommend using the original carton and packing materials. "Proof of purchase in the form of a bill of sale or receipted invoice which is

evidence that the product is within the warranty period, must be presented to obtain warranty service." For rental firms, proof of first rental is also required. Also print your name and address and a description of the defect. Send via standard UPS or its equivalent to: ATLINKS USA Inc

- c/o Thomson 11721 B Alameda Ave Socorro, Texas 79927 Pay any charges billed to you by the Exchange Center for service not covered by
- the warranty Insure your shipment for loss or damage. ATLINKS accepts no liability in case of

Customer instruction. (Your Owner's Manual provides information regarding

- A new or refurbished unit will be shipped to you freight prepaid What your warranty does not cove
- operating instructions and user controls. Any additional information, should be obtained from your dealer.) Installation and setup service adjustments
- Rattorios

damage or loss

Damage from misuse or neglect. Products which have been modified or incorporated into other products.

Acts of nature, such as but not limited to lightning damage

- Products purchased or serviced outside the USA.
- **Product Registration:** Please complete and mail the Product Registration Card packed with your unit

the card is not required for warranty coverage. Limitation of Warranty:

THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDI ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED, NO VERBAL OR WRITTEN INFORMATION GIVEN BY ATLINKS USA, INC., ITS AGENTS, OR EMPLO SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS

It will make it easier to contact you should it ever be necessary. The return of

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. ATLINKS USA, INC. SHALL NOT B LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCI AIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF INDIANA. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

How state law relates to this warranty:

- Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations or exclusions may not apply to you
- This warranty gives you specific legal rights, and you also may have other rights
- If you purchased your product outside the USA:
- This warranty does not apply. Contact your dealer for warranty information

Accessory Order Form DESCRIPTION MODEL NO PRICE* OTV TOTAL 5-2576 Belt clip \$4.95 5-2425 Headset \$19 95 Replacement battery 5-2461 \$16.25 \$20.85 Power supply 5-2556 To order, call 1-800-338-0376 (for accessories only) or complete this order form. For credit card purchases

Your complete charge card number, its expiration date and your

signature are necessary to process all charge card orders. Copy your complete account number from your VISA card.

:					╵╙			┚┖			┚┖			
	My c	ard 6	vnir	DC.										
i	iviy C	ai a c	, Apii	C3.										
ı														
	 	My ca	My card 6	My card expir	My card expires:									

Master Card or Discover.

Copy your complete account number from your

name on the Master Card.

Total Mer

Sales Tax.

My card expires:

Copy the number above your

Authorized Signature	
bject to change without notice.	
chandise\$	

We are required by law to collect the appropriate sales tax for each individual state county, and locality to which the merchandise is being sent. Duties will apply fo shipments to Canada.

Use VISA or Master Card or Discover preferably. Money order or check must be in U.S.

urrency only. No COD or Cash. All accessories are subject to availability. Whe

Mail order form and money order or check (in U.S. currency)

\$5.00 Shipping/Handling... Total Amount Enclosed

Mail Order Department P.O. Box 8419 Ronks, PA 17573-8419

applicable, we will ship a superseding model.

Address State City Daytime Phone Number (Email Address

Please make sure that this form has been filled out completely

Download from Www.Somanuals.com. All Manuals Search And Download

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com