

VKC140 Digital Photo Key Chain

Dear Customer,
CONGRATULATIONS. The VKC140 Digital Photo Key chain, when used as described, will give you years of dependable service in your car, truck, RV or minivan. We have taken numerous measures in quality control to ensure that your product arrives in top condition, and will perform to your satisfaction. In the rare event that your VKC140 Digital Photo Key chain contains a damaged or missing item, does not perform as specified, requires warranty service or you have an installation problem, **DO NOT RETURN THIS PRODUCT TO THE STORE. PLEASE CALL OUR TOLL FREE NUMBER FROM THE U.S.A. AND CANADA (800-445-1797)** and ask to speak with a member of our technical service team, or submit your questions by e-mail our web site vr-3.com, and a member of our technical service team will respond by e-mail to your questions. Our in-house technical service team will expedite delivery of your part, advise you on installation, or help troubleshoot a problem with you. If your product needs warranty service, our technical service team representative will help you obtain the fastest remedy possible under the warranty.

Specifications



Photo Key chain



USB Cable



Photo Viewer Ver 2.4 CD

• Storage Volume	72 photos
• Image Format	JPG / JPEG / BMP / GIF / TIF
• Computer Compatibility	PC format only-Windows®
• Interface	USB 1.1
• Functions	Power Off/Delete Image/Display Mode/Clock Set/Clock Disp/ Language

Unit Parts

Front Of Unit



Key chain

LCD Screen

Unit With Stand Open



Unit With Stand Open

Right Side



Down

Up

Power/Select

Left Side



Mini USB Port

Operation

WARNING!

DO NOT CONNECT THE VKC140 TO A COMPUTER UNTIL AFTER THE SOFTWARE IS INSTALLED!

Software Installation

NOTE: The Computer User must have Admin Rights on the computer that the Photo Viewer software is being installed on.

1. Insert the supplied PhotoViewer CD-ROM into your computer's CD drive.
2. The PhotoViewer install screen will be displayed on the monitor.
3. Choose the language you want to install, then follow the on-screen instructions.



Computer Connection

DO NOT START THE SOFTWARE UNTIL THE VKC140 IS CONNECTED!

1. After you have installed the Photo Viewer software, insert the supplied USB cable into your computer's USB port, then insert the other end into the port on the side of the VKC140.
2. Once connected you will see a menu with two choices, USB Charge & USB Connect.
3. Choose USB Connect, then press the Power/Select button to confirm your selection. The screen will say "Connected".
4. Double click the Photo Viewer shortcut that was installed on your Windows desktop to start the Photo Viewer software.




Fig. 6

PhotoViewer Browser

The PhotoViewer browser is divided in half. The computer's window is on the left side, and the VKC140's window is on the right side. Each Window has its own icons for performing functions related to it.

If the VKC140 is disconnected from the computer, then re-connected, the software must be re-started.



Computer VKC140

Charging The Battery

The battery will have a nominal charge from the factory. We recommend fully charging the unit before use.

1. To charge the unit's battery, insert the supplied USB cable into your computer's USB port, then insert the other end into the port on the side of the VKC140. The VKC140 will display the photos that are stored on it while charging. The battery takes about 3.5 hours to charge. The battery will last up to 5 hours on a single charge.
2. After the battery is charged disconnect the unit.
3. Press the power button once to access the menu.
3. Use the Up & Down button to navigate the menu to Power Off, then press the Power/Select button once to shut the unit off.

Operation

Main Menu

1. Press and hold the Power/Select button for 3 seconds to turn the unit on.
2. The unit will start to display any photos that are on it.
3. Press the Power/Select button once and the Main Menu will be displayed. (Fig. 1)




Fig. 1

Delete Image

1. Display the image you wish to delete.
2. Press the Power/Select image once.
3. Then press the Up & Down arrow to navigate to Delete Image.
4. Press the Power/Select image once and you will be asked if you want to delete the image.
5. Press the Power/Select button again to delete the image.

Display Mode

1. On the Main Menu choose Display Mode, you will have two choices, Auto Slide & Manual Slide. (Fig. 2)
2. Press the Up & Down arrow to navigate to your choice.
3. Press the Power/Select to confirm your selection.




Fig. 2

a. Auto Slide

1. Use the Up & Down buttons to change the time. (Fig.3)
2. Press the Power/Select to confirm your selection. In Auto Slide mode the photos will be displayed for the time chosen before changing to the next photo.




Fig. 3

b. Manual Slide

1. If you have chosen Manual slide, press the Up or Down button to change the photo displayed.

Clock Set

1. On the Main Menu choose Clock Set, then the Clock Set menu will be displayed. (Fig.4)
2. The Year will begin to blink. Use the Up & Down arrows to change the year, then press the Power/Select button to confirm.
3. After confirming the Year, the Month will begin to blink. Use the Up & Down arrows to change the month, then press the Power/Select button to confirm.
4. After confirming the Month, the Day will begin to blink. Use the Up & Down arrows to change the Day, then press the Power/Select button to confirm.
5. After confirming the Day, the Hour will begin to blink. Use the Up & Down arrows to change the Hour, then press the Power/Select button to confirm.
6. After confirming the Hour, the Minutes will begin to blink. Use the Up & Down arrows to change the Minutes, then press the Power/Select button to confirm.
7. After confirming the Minutes, the Seconds will begin to blink. Use the Up & Down arrows to change the Seconds, then press the Power/Select button and you will return to the Main Menu.



Fig. 4



GIVE US A CALL, WE'LL HELP YOU INSTALL.

PLEASE DO NOT RETURN PRODUCT TO STORE.
 Visit us on the WEB

www.vr-3.com

For Information and Technical Assistance,
 Call Toll-Free in U.S.A. and Canada.

1-800-445-1797

Operation

Clock Display

1. On the Main Menu choose Clock Display, then the Clock will be displayed. (Fig.4)
2. The Clock will remain on the screen until Power/Select is pressed.

Language

1. On the Main Menu Choose Language.
2. Use the Up & Down Arrows to choose a language on the Language Select Menu, then press the Power/Select button to confirm your choice. (Fig.5)




Fig. 5

PHOTO VIEWER SOFTWARE

Choosing and Editing Photos to Transfer to the VKC140

1. On the top left of the Photo Viewer screen choose a Drive from the Drop Down menu.
2. Choose a folder on the Folder List, the photo files in the folder will be displayed in the file list.
3. Next highlight a file on the File List, it will be displayed in the Preview Pane.
4. Before creating a Selection Area you can rotate the image by pressing either of the Rotate icons. One icon will rotate the Preview 90° clockwise, the other rotates the Preview 90° counter clockwise
5. Click the top icon next to the Preview Pane to create a standard Selection Area to edit. You can move the position of the selection area with your mouse
To create a custom selection area in the Preview Pane, press the pencil eraser icon to delete the current Selection Area. With your mouse click and drag a box around the area you wish to edit.
6. When you are satisfied with your selection, press the Blue Arrow icon at the bottom of the icon list. The image will appear on the VKC140's Preview Pane.




Photo Viewer Software

The VKC140 Preview Pane

Synchronizing Photos on the VKC140

1. Once you have transferred photos from the Computer's Preview Pane to the VKC140's Preview Pane, press the Synchronize button. The browser will show the progress at the bottom of the screen as the images are synchronized.

Editing Photos on the VKC140

Rotate an Image


1. With your mouse click on an image to rotate
2. Press either of the Rotate icons at the top of the Preview Pane.
3. Press the Synchronize button and the image on the VKC140 will be updated with the rotated image.

Delete an Image

1. With your mouse click on an image to delete.
2. Press the icon with the Red X.
3. Press the Synchronize button and the image on the VKC140 will be updated and the image will be deleted.

Save an Image

1. With your mouse click on an image to save to your computer.
2. Click on the top left icon of the Preview Pane.
3. The computer's Save Menu will be displayed.
4. Choose a folder on the computer to save the image.
5. You may change the name if you wish, or leave it the same.
6. Click Save, then a confirmation menu will be displayed, click OK.



GIVE US A CALL, WE'LL HELP YOU INSTALL.

PLEASE DO NOT RETURN PRODUCT TO STORE.
Visit us on the WEB

www.vr-3.com

**For Information and Technical Assistance,
Call Toll-Free in U.S.A. and Canada.**

1-800-445-1797

Frequently Asked Questions

Q. Why don't photos transferred to the VKC140 Preview Pane display on the VKC140 Key Chain?

A. The VKC140 Key Chain was not Synchronized before it was disconnected from the computer.

Q. I pressed the Synchronize button and received a "Synchronization Failed" message?

A. The VKC140 was removed from the computer, then re-connected without re-starting the Photo Viewer Browser.

Q. I saved a file from the VKC140 Key Chain to my computer, but when I look in the folder where I saved it?

A. The VKC140 Key Chain was not Synchronized before it was disconnected from the computer.

Q. How long does it take to fully charge the battery?

A. It takes about 3.5 hours to fully charge the battery.

Q. How long does a fully charged battery last?

A. A full charge will last about 5 hours.

Q. Is the VKC140 compatible with a Apple Macintosh® computer?

A. No. The VKC140 is only compatible with PCs running the Windows® Operating System.

Limited Warranty

VIRTUAL REALITY VIDEO LABS® products are designed and manufactured to provide a high level of trouble-free performance. VIRTUAL REALITY VIDEO LABS® warrants, to the original purchaser, that its products are free from defects in material and workmanship for 30 days from the date of original purchase, as part of our commitment to product excellence. VIRTUAL REALITY VIDEO LABS® and/or its affiliates routinely improves the designs, materials or production methods of its existing products. Because it is impractical to publicize all changes in every product, we reserve the right to make such changes without notice.

CONDITIONS OF WARRANTY:

If during the 30 day warranty period your new product is found to be defective, VIRTUAL REALITY VIDEO LABS® will repair such defect, or replace the product, without charge for parts or labor subject to the following conditions:

1. All repairs must be performed by VIRTUAL REALITY VIDEO LABS® and/or its affiliates in Eatontown, New Jersey.
2. The equipment must not have been altered or been damaged through negligence, accident, or improper operation.
3. The replacement of parts are exempted from this warranty when replacement is necessary due to normal wear and tear.
4. All warranty claims must be accompanied by a copy of the sales receipt or bill of sale.
5. Repair or replacement parts supplied by VIRTUAL REALITY VIDEO LABS® under this warranty are protected only for the unexpired portion of the original warranty.
6. In the case of car stereos, this warranty does not extend to the elimination of car static or motor noise; correction of antenna problems; costs incurred for the removal or reinstallation of the product; damage to tapes, speakers, accessories or car electrical systems.
7. VIRTUAL REALITY VIDEO LABS® will not be responsible for any charge incurred for installation.

OWNER'S RESPONSIBILITIES:

VIRTUAL REALITY VIDEO LABS® will make every effort to provide warranty service within a reasonable period of time. SHOULD YOU HAVE ANY QUESTIONS ABOUT SERVICE RECEIVED, OR IF YOU WOULD LIKE ASSISTANCE IN OBTAINING SERVICE, PLEASE CALL TOLL FREE 1-800-445-1797, 8:30am - 4:30pm EST.

In order to provide you with the proper warranty service, we request that you adhere to the following procedure:

1. Include a copy of your sales receipt or bill of sale with your unit when it is returned for warranty service.
2. If it is necessary to return your product for service, please return it securely packed, preferably in the original shipping carton, and freight and insurance prepaid to the following address: VIRTUAL REALITY VIDEO LABS, Service Department, 41 James Way, Eatontown, New Jersey 07724.
3. Please include a detailed explanation of the problem you are having.
4. If your product is found by VIRTUAL REALITY VIDEO LABS® to have a defect in material or workmanship, within the warranty period, it will be repaired or replaced at no charge and returned to you prepaid. Where permitted by law VIRTUAL REALITY VIDEO LABS® liability shall be limited to that set forth in this warranty. This warranty shall be the exclusive remedy of the purchaser.

VIRTUAL REALITY VIDEO LABS® makes no other warranty of any kind, expressed or implied; and all implied warranties, are hereby disclaimed by VIRTUAL REALITY VIDEO LABS® and excluded from this warranty, VIRTUAL REALITY VIDEO LABS® and/or its affiliates, the manufacturer, distributor and seller shall not be liable for any injury, loss or damage, incidental or consequential, arising out of the use or intended use of the product.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>