

PN. 33-2931

INTRODUCTION

Thank you for purchasing the Sonance Ellipse SUR in-ceiling speaker. When properly installed, this product will provide you with years of entertainment pleasure.

To obtain the full potential of your new speakers, please read all instructions before starting the installation. If you do not have the necessary skills to install the speakers yourself, contact your authorized Sonance dealer for installation options.

PARTS LIST

Each Ellipse speaker package includes the following items:

- (2) Sonance Ellipse SUR speakers
- (2) Paintable grille
- (2) Plastic paint plug to protect speaker during painting
- (1) Mounting cutout template (in packaging)

OPTIONAL ACCESSORIES

FlexBracket - part number 91922

Plastic template to reserve a hole in new construction.

Designed to be used with the Flexbar™ mounting system.

Acoustical Enclosure - part number 91921

A 1/2" medium density fiberboard enclosure designed specifically for the Ellipse speakers.


Sonafill in-ceiling - part number 91928

Sonafill is a retrofitable acoustical treatment for that virtually eliminates the noise produced by resonating drywall and dramatically improves mid-bass sound quality

5 - CHANNEL HOME THEATER PLACEMENT

The ideal location for the Ellipse SUR is two to four feet behind the listening position with the speakers separated approximately eight to twelve feet.

The speakers should be oriented so the coaxial drivers face the front and rear walls of the room.



Placement with two surround speakers

INSTALLATION INSTRUCTIONS


SONANCE ELLIPSE SUR IN-CEILING SPEAKER

7 - CHANNEL HOME THEATER PLACEMENT

Try to apply as many of the following suggestions when using four Ellipse SUR speakers as your surround speakers.

Front surround speakers can be located directly to the sides of the seating or approximately two to three feet in front of the seating for better integration with the left, center and right speakers. The speakers should be oriented so the coaxial drivers face the front and rear walls of the room.

Rear surround speakers should be located approximately four to eight feet behind the seating and the speakers should be separated six to ten feet apart. The speakers should be oriented so the coaxial drivers face the left and right side walls of the room.




Placement with four surround speakers

ALTERNATIVE PLACEMENT OPTIONS

In many installations the main seating will be against the rear wall of the room. In this type of room we suggest locating the speakers approximately two feet from the rear wall and spaced from ten to fifteen feet apart.

Locating the speakers in this way will provide a more diffuse surround presentation.



Alternative placement with two surround speakers

WIRE GAUGE AND QUALITY

The total wire resistance should be less than 10% of the speaker impedance. If using an 8 ohm speaker, your total wire resistance should be no more than 0.8 ohms.

In simple terms, the extra resistance from the wire will have a very negative affect on the sound quality of the speaker. The sound can be less dynamic, definition of bass frequencies can be reduced, and in extreme cases, the high frequencies can be attenuated. Amplifier power is also wasted in the wire, reducing the maximum output level of the system.

Please refer to the following chart when deciding on the appropriate wire gauge for your installation.

Wire resistance in Ohms vs. length of cable run						
Distance in Feet	50'	100'	150'	200'	250'	300'
20 gauge	.86	1.73	2.59	3.45	4.32	5.18
18 gauge	.65	1.30	1.94	2.59	3.24	3.89
16 gauge	.43	.85	1.28	1.71	2.14	2.56
14 gauge	.27	.54	.81	1.08	1.35	1.62
12 gauge	.17	.34	.51	.68	.85	1.02
10 gauge	.11	.22	.33	.44	.56	.67

PREPARING THE INSTALLATION LOCATION

All Sonance speakers are designed to be relatively insensitive to changes in enclosure volume. To achieve the ultimate performance from the Ellipse SUR speaker, a section of the ceiling bay can be sectioned off to form a back box. Building this enclosure will create a dramatic improvement in the quality of bass response and power handling.

Ideal Back box volume:

Ellipse SUR 1.00 cubic feet (28.3 liters)

Insulating the ceiling cavity

Speaker performance can be enhanced by insulating the cavity with fiberglass insulation.


When installing speakers in a ceiling, it is best to lay a sheet of unfaced fiberglass insulation over the back of the speaker.

To further improve the sound quality, install insulation in the bays adjacent to the speaker location. This will reduce noise produced by the unsupported drywall.

Sonafill ®

Sonafill is a retrofitable acoustical treatment for loudspeakers that virtually eliminates the noise produced by resonating drywall and dramatically improves mid-bass sound quality. Sonafill also reduces room-to-room noise especially in multi-channel installations where many speakers are installed.


The Sonafill system consists of two pillows and four tiles. Installation is accomplished by first adhering the tiles to the inside of the cavity, then stuffing the two pillows in place behind the tiles.



New Construction

The Ellipse LCR speaker features an integral FlexBar mouthing system for quick mounting into ceilings. The Ellipse FlexBracket is only necessary in new construction installations when reserving a location for the speaker is desired.

The FlexBracket will serve as a guide for the drywall installer when cutting holes for in-ceiling speakers. The FlexBracket can be nailed, screwed or stapled to the joists so that the hole is in the desired location once the drywall is installed.



Ellipse FlexBracket


Retrofit

With the FlexBar system, the speaker can be installed directly into existing ceilings. Once the hole is cut and the cable is run, the speakers can be installed in a matter of seconds.

Once you have determined the area you would like to locate your speakers, you will need to do an obstruction survey. Before you cut the hole for the speaker, be certain no joist, conduit, pipe, heating duct or air return will interfere with the speaker.


A cut out template is provided in the packaging of the speaker. Position the template where the speaker is to be located and pencil an outline on the ceiling. If you are unsure about obstructions drill a small hole in the center of the circle and insert a coat hanger into the hole to feel for possible obstructions. If no obstructions are found, proceed with cutting the hole using a drywall saw and run the speaker wires.

INSTALLING THE SPEAKERS




Step 1

Remove the paint plug from the speaker. Attach the wire from your amplifier to the terminals on the back of the speaker. Double check the polarity of the speaker wires, amplifier + to speaker + and amplifier - to speaker -. Proper polarity is critical in home theater installations.




Step 2

To install the Ellipse LCR, insert one side of the Flexbar clamps through the hole in the drywall. Once the feet are through the hole, insert the other side of the Flexbars into the cutout.



Note: The maximum clamp thickness is 1-1/4" (32mm)



PAINTING THE SPEAKERS AND GRILLES

Speakers and grilles can be painted before installation, which will eliminate the "paint scar" if the speaker needs to be removed for service. Speakers may also be painted after installation, but before the grilles are attached. All speakers come from the factory fitted with a plastic "paint plug." Use the paint plug to protect the drivers while the flange is being painted with the ceiling.

Sonance suggests always painting the grilles separate from the speaker. The grilles may be lightly sprayed with thin paint (5 parts thinning agent to 1 part paint), but be careful not to plug the holes. Too much paint will adversely affect the sound of the speaker.

Once the grilles and flange are painted and dry, remove the paint plug from the flange and install the grilles.




Tighten the four screws on the front of the baffle. The Flexbars will automatically begin clamping the speaker. When you notice resistance on the four screws, the speaker has been clamped successfully.

The flange is designed to flex and conform to any small imperfections in the wall surface. The screws should not be tightened so far that the flange bows out.



Step 3



After the four Flexbar screws are tightened the grille can be installed. Insert about half of the grille into the groove at the edge of the speaker. Gently fit the remaining half of the grill into the speaker by working your hands around the speaker fitting the grille into the groove as you go along.

Note: The torque applied to the mounting screws can be adjusted for proper grille fit.

Ellipse SUR -

Speaker Design In-ceiling surround infinite baffle

Two - 1/2" (13mm) Cloth domes Tweeter

Midrange Two - 3" (76 mm) Black glass composite cone 6 1/2" (165 mm) Black glass composite cone with a Woofer

rubber surround

Frequency Response 50Hz to 20 kHz +/- 3dB

Impedance 8 ohms nominal, 6 ohms minimum


5 to 125 watts Power SPL 89 dB 1W / 1m


Grille Aluminum

Speaker Dimensions 10 1/2" (267mm) x 15 1/2" (394mm) x 5 7/8" (149mm)

Cutout Dimensions 9" (229mm) x 14" (356mm) elliptical

16.0 lbs (7.26 kg) per pair Weight





TECHNICAL ASSISTANCE AND SERVICE

The Technical Assistance Department at Sonance is available at (800) 582-0772 or (949) 492-7777 to answer any questions concerning the operation and installation of your speakers between the hours of 7:00 AM and 5:00 PM Pacific time, Monday through Friday, except holidays.

In the event your unit should need repair or service, you may return the unit to your authorized dealer or use the following guidelines:

- Be prepared to state the model number and / or serial number, date of purchase and dealer's name and address when calling.
- Contact Sonance directly at (800) 582-0772 or (949) 492-7777 or at www.sonance.com
- 3. If you are returning the product directly to Sonance, call us to obtain a return authorization number before shipping. YOU MUST HAVE PRIOR AUTHORIZATION TO RETURN YOUR UNIT.
- The original packaging must be used. If the original packaging is unavailable, replacements can be obtained from Sonance for a small fee.
- Ship the product via United Parcel Service, Federal Express, or RPS. Please do not use the U.S. Mail service.
- Write the return authorization number on the outside of the box.
- Ship to:

Attn: Quality Assurance Department Sonance 212 Avenida Fabricante San Clemente, CA 92672-7531

8. FREIGHT COLLECT SHIPMENTS WILL BE REFUSED!

Limited Lifetime Warranty

Sonance warrants to the original retail purchaser only that this Sonance product will be free from defects in materials and workmanship, provided the speaker was purchased from a Sonance Authorized Dealer after September 1, 2003. Purchases made before that date carry a limited 5 year warranty.

Defective products must be shipped, together with proof of purchase, prepaid insured to the Sonance Authorized Dealer from whom they were purchased, or to the Sonance factory at the address listed on this installation instruction manual. Freight collect shipments will be refused. It is preferable to ship this product in the original shipping container to lessen the chance of transit damage. In any case, the risk or loss or damage in transit is to be borne by the purchaser. If, upon examination at the Factory or Sonance Authorized Dealer, it is determined that the unit was defective in materials or workmanship at any time during this warranty period, Sonance or the Sonance Authorized Dealer will, at its option, repair or replace this product at no additional charge, except as set forth below. If this model is no longer available and can not be repaired effectively, Sonance, at its sole option may replace the unit with a current model of equal or greater value. In some cases where a new model is substituted, a modification to the mounting surface may be required. If mounting surface modification is required, Sonance assumes no responsibility or liability for such modification. All replaced parts and product become the property of Sonance. Products replaced or repaired under this warranty will be returned to the original retail purchaser, within a reasonable time, freight

This Warranty does not include service or parts to repair damage caused by accident, disaster, misuse, abuse, negligence, inadequate packing or shipping procedures, commercial use, voltage inputs in excess of the rated maximum of the unit, or service, repair or modification of the product which has not been authorized or approved by Sonance. This Warranty also excludes normal cosmetic deterioration caused by environmental conditions. This Warranty will be void if the Serial Number on the product has been removed, tampered with or defaced. This Warranty is in lieu of all other expressed warranties. If the product is defective in materials or workmanship as warranted above, the purchaser's sole remedy shall be repair or replacement as provided above. In no event will Sonance be liable for any incidental or consequential damages arising out of the use or inability to use the product, even if Sonance or a Sonance. Authorized Dealer has been advised of the possibility of such damages, or for any claim by any other party.

Some states do not allow the exclusion or limitation of consequential damages, so the above limitation and exclusion may not apply. All implied warranties on the product are limited to the duration of this expressed Warranty. Some states do not allow limitation on the length of an implied warranty. If the original retail purchaser resides in such a state, this limitation does not

w.sonance.com

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com