Uniden

Model CEZ260 Speakerphone with 13 **Number Memory User's** Guide



Important Safety Instructions!

WARNING:TO PREVENT FIRE OR **ELECTRICAL SHOO** HAZARD, DO NOT EXPOSETHIS PRODUCT TO RAIN OR MOISTURE.

	A	CAUTION: RISK OF ELECTRIC SHOCK DO NOT OPEN	lack	
CK N	THE LIGHTNING FLASH AND ARROW HEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF "DANGEROUS VOLTAGE" INSIDE THE PRODUCT.	CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK), NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.	THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU COMPORTANT INSTRUCTIONS ACCOMPANYING THE PRODUCT.	
	SEE MARKING ON BOTTOM / BACK OF PRODUCT			

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- This unit is NOT waterproof. DO NOT expose it to rain or moisture. • Do not use this unit near water, for example, near a bath tub, wash bowl, kitchen sink
- or laundry tub, in a wet basement or near a swimming pool. • Avoid using a telephone (other than a cordless type) during an electrical storm. There
- may be a remote risk of electric shock from lightning.
- Do not use the telephone to report a gas leak in the vicinity of the leak.
- Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special
- disposal instructions • Do not place the handset in any charging cradle without the battery installed and the
- battery cover securely in place
- Never install telephone wiring during a lightning storm. • Never touch uninsulated telephone wires or terminals unless the telephone line has
- been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.
- Never install telephone jacks in wet locations unless the jack is specifically designed for

SAVE THESE INSTRUCTIONS!

Before You Begin

Parts Checklist

Make sure your package includes the following items:













A RJ11C type modular telephone jack similar to image at right is required. If necessary, call your local phone company to get one installed.

Installation

Placing the Unit

Place your phone on a level surface such as a desk or table top, or mount it on a wall. For best speakerphone performance, avoid the following:

- Areas with high background noise; the microphone may pick up the sounds and prevent the phone from going into receiving mode when you finish talking.
- · Surfaces affected by vibration.
- Recessed areas such as corners, under cupboards, or next to a cabinet, which can generate an echo effect.

Installing (or Replacing) the Batteries



CAUTION: Disconnect the phone cord from the wall outlet before installing or replacing the batteries.

Your Caller ID phone uses 4 AA-size alkaline batteries for receiving and storing Caller ID records and for storing saved numbers (memory dial, pulse dial, and redial.)

IMPORTANT: You will have approximately 90 seconds to replace the batteries before the stored records and numbers are lost. Please read the instructions before replacing the batteries and have the batteries ready to be inserted beforehand.

If the low battery icon appears in the display, replace the batteries as soon as possible to maintain Caller ID operation.

If you are not going to use the telephone for more than 30 days, remove the batteries because they may leak and damage the unit.

1. If necessary, disconnect the phone line cord and remove the desk stand (turn the base over, press in on the tabs, and slip them out of the slot.)

2. Unlatch and open the battery compartment cover.

3. Insert 4 AA-size alkaline batteries as shown on the diagram. 4. Snap the battery compartment cover into

place and replace the desk stand.

5. Connect the line cord and check your memory locations.

6. Reattach the desk stand if necessary.

Connecting the Handset 1. Connect one end of the coiled handset cord to the handset jack.

2. Plug the other end of the coiled handset cord to the base jack

3. Place the handset in the cradle.

Setting Up the Phone

Note: You should not plug the

telephone into the modular jack while configuring the phone; unplug the phone if necessary. REMINDER: The time and date are programmed automatically when the first Caller ID record is successfully

received after set up. 1. Press **MENU** to access the menu configuration mode.

- Display Language (ENG FRA ESP) CONTRAST
- LOCAL AREA CODE
- TONE/PULSE
- 2. Press **MENU** to scroll through the 4 menu screens.
- 3. Use **LEFT** or **RIGHT** to select the desired setting. 4. Press **MENU** to save.
- NOTE: The phone returns to the Summary Screen 20 seconds after an entry.

This adjustment lets you display Caller ID prompts in English, French, or Spanish. 1. Press **MENU** until ENG FRA ESP appears in the display.

- 2. Use **LEFT** or **RIGHT** to select ENG, FRA, or ESP.
- Press MENU to save.

This adjustment lets you adjust the display's contrast [1 (lightest) to 5 (darkest)].

- 1. Press **MENU** until CONTRAST shows in the display.
- 2. Use **LEFT** or **RIGHT** to select a level.
- 3. Press **MENU** to save.

The telephone uses programmed area codes to determine the number format to display when a valid Caller ID signal is received. If you enter your area code, incoming local calls will display as a 7-digit number.

If	The phone displays a
Incoming area code matches the programmed area code	7-digit number
programmed area code	(555-5555)
	10-digit number (3-digit area code + 7-digit phone number)
Incoming area code does not	(444-555-5555)
match the programmed area code	11-digit number (1 + 3-digit area code + 7-digit phone number)
	(1-444-555-5555)

1. Press **MENU** until LOCAL AREA CODE shows in the display.

2. Enter the area code on the number pad.

NOTE: If you need to edit your entry, use LEFT or RIGHT to select an entered number; re-enter it. You can also press DELETE to erase all the digits and start over.

3. Press MENU to save.

Dialing Mode

Wall plate

Modular 🚤

telephone

line jack

This adjustment allows you to select tone (touch-tone) or pulse (rotary) dialing.

1. Press **MENU** until 4 TONE PULSE shows in the display 2. Press either **LEFT** or **RIGHT** to select a dialing mode (default = Tone).

3. Press **MENU** to save.

Connecting the Telephone Line

1. Connect one end of the straight telephone line cord to the jack on the back of the

- 2. Connect the other end to a wall phone jack.
- 3. Set the RINGER volume switch located on the right side of the base to the desired
- OFF Telephone will not ring.
- LO Lowest volume.
- HI Highest volume.
- 4. Lift the handset and check for dialtone.
- If dialtone is present, make a test call. If the test call is successful, set the display language as in the following section.
- If dialtone is not present, check the connections.
- If dialtone does not break, change the dialing mode (refer to the Setting Up the Phone section).

Wall Mounting (Optional)

Your speakerphone can also be mounted on the wall using a standard telephone wall

REMINDER: To prevent the handset from falling out of the cradle while the phone is hanging on the wall, adjust both the handset hook and the desk

stand to their wall-mount positions. 1.On the base front, pull the handset hook out of the slot. Rotate the hook 180 degrees and flip it

from front to back. Slide it back into the slot. 2. Turn the base over and remove the desk stand.


3. Rotate the stand 180 degrees, and insert WALL hooks into WALL notches. Press in on tabs and snap the stand into place.

4. Connect the telephone line cord to the wall jack and phone. Wrap excess cord around the cord hooks as shown. 5.Place the mounting slots over the pins on the wall plate and slide

Telephone Basics

the base down to lock it

into place.



Making Phone Calls

1. Lift the handset or press **SPEAKER**. Wait for a dial tone.

2. Dial the telephone number.

Answering Phone Calls

2. Replace the handset in the cradle or press **SPEAKER** to hang up.

3. Replace the handset or press **SPEAKER** to hang up after your conversation.

1. Lift the handset or press **SPEAKER** to answer the call.

Adjusting the Handset Receiver Volume Press + or - to adjust the handset receiver volume. REC (Handset Receiver) volume

Boosting the Volume for a Call Press **Boost** to temporarily boost the handset receiver volume during a call. Press it again to cancel. Volume levels also return to normal when the handset is replaced on the base after a call.

- 1. Set the volume to minimum. Pick up the handset and press **Boost** to turn on the incoming voice amplifier. The indicator around the button illuminates
- 2. Adjust the volume by pressing + or When **BOOST** is pressed, volume increases by up to 20dB of gain and level control. **Boost** resets after you hang up. NOTE: The Boost feature applies only to the handset.

Redialing a Number

Press **REDIAL/PAUSE** after you hear a dial tone to redial the last number.

NOTE: The redial feature holds the last number (up to 32 digits) that you dialed in memory. If you pressed any other numbers after dialing the phone number (for example, when accessing a voice-menu system) then those numbers are also dialed.

If you get a busy signal, press **Redial/Pause** again without hanging up.

Using the Speakerphone

- When using the handset, press the **SPEAKER** button to activate the speakerphone. Hang up the handset.
- To return to handset operation, pick up the handset and then press the **SPEAKER** button to disconnect the speakerphone
- Speakerphone operation is similar to a two-way radio; you can only listen or talk at one time.
- Stay reasonably close to the phone so that you can be clearly heard by the person to whom you are talking
- Adjust the speaker volume by pressing + or −.
- The speakerphone indicator light comes on when the speakerphone is in use.

Muting the Microphone

Use **MUTE** to turn the microphone in the handset or the speakerphone on and off.

1. Press **MUTE**. The mute indicator lights up, indicating the microphone is turned off. 2. Press MUTE again. The microphone turns back on and the mute indicator light

Using the Flash Button Press **FLASH/EXIT** to activate special features of your telephone network, such as call

transfer, or special services from your local telephone company, such as call waiting.

Temporary Tone Dialing

If you have pulse (rotary) service and want to access customer calling services (such as telebanking and long distance services) that require tone dialing, use this feature to temporarily change from pulse to tone service.

After dialing the telephone number and connecting to the customer calling service,

- Press and release *TONI
- 2. Proceed with conversation.
- 3. When you hang up, the telephone automatically returns to pulse dialing mode.
- TIP: Temporary Tone can also be used while storing numbers in memory by pressing *TONE at the necessary point in the storage sequence.

Caller ID (CID) Features

IMPORTANT: To use all the features of this telephone, you must subscribe to two separate services from your local telephone company: the standard Name/Number Caller ID Service to know who is calling when the phone rings, and Call Waiting Caller ID Service to know who is calling while you are on the phone.

This unit receives and displays information transmitted by your local phone company This information can include the phone number, date, and time, or the name, phone number, date, and time. The unit can store up to 75 calls for later review. When the memory is full, a new call automatically replaces the oldest call in memory. NEW appears in the display for calls received that have not been reviewed.

CID Screen

The CID main screen shows the current time, date, and number of new calls (i.e., the number of new calls since the last time the call list was reviewed). It displays until any button is pressed.

NOTE: The number of new calls displays until all new calls are reviewed.

Caller ID Display Messages

The following messages display for incoming calls. They provide phone status or Caller ID information:

BLOCKED CALL	The caller of the incoming call is registered as "Private	
DEOCKED CHEE	Number" and their Caller ID information is withheld.	
CALL WAITING	Indicates a call is waiting on the line.	
INCOMPLETE DATA	Caller information has been interrupted during	
INCOMPLLIE DATA	transmission or the phone line is excessively noisy.	
NO CALLS	The caller memory is empty.	
NO DATA	No Caller ID information was received.	
START/END	You are at the beginning or the end of the Caller ID	
סואתו/בוזט	memory log.	
	The incoming call does not have Caller ID service or	
UNKNOWN CALLER	their service area is not linked to yours. If UNKNOWN	
UNKNOWN CALLER	CALLER appears along with a calling number, the name	
	information for that number was not available.	

Reviewing CID Records

Press **LEFT** or **RIGHT** to view the call records.

• Press **LEFT** to scroll through the call records from the oldest to the newest. • Press **RIGHT** to scroll through the call records from the most recent to the oldest. When all of the records have been viewed, START/END appears in the display.

Dialing Back

When reviewing Caller ID records, you can dial back a displayed number.

NOTE: If PICKUP PHONE shows in the display, no other changes to the number can be made. The information sent from the telephone company is known to be a valid number for dialing back (used only in very limited areas). Once you pick up the phone, the number is automatically dialed.

If You Did Not Program Your Local Area Code

1. Use LEFT or RIGHT until the number you want to dial displays. You will only see 10-digit numbers (i.e. 234-555-1234).

NOTE: A timer (10 seconds on-hook and 3 seconds off-hook) located in the upper right side of the display will start, indicating how much time is left until the unit returns to the Summary Screen.

2. Press DIAL

If You Programmed Your Local Area Code 1. Press either **LEFT** or **RIGHT** until the number you want to dial displays. Number with seven digits (i.e. 555-1234) are within your area code; however, this does not guarantee the call is a local call. A number with 10 or 11 digits (i.e. 1-234-555-

1234) is not a local call. NOTE: A timer (10 seconds on-hook and 3 seconds off-hook) located in the upper right side of the display will start, indicating how much time is left

- until the unit returns to the Summary Screen.
- 2. Press DIAL. 3. If the phone is on-hook and PICKUP OR ADJ displays (or ADJUST if you are offhook), adjust the phone number format by pressing **DIAL** repeatedly to scroll
- through the 7, 10, and 11-digit numbers 4. To dial the displayed number with the phone on-hook, pick up the handset or press **SPEAKER** before the timer reaches 0. Press **DIAL**. If the phone is off-hook, wait until the time reaches 0. NOW DIALING displays and the number is dialed.

- **Deleting CID Records**
- 1. To delete the record shown in the display, press **DELETE** once. 2. To delete all records while reviewing, press and hold **Delete** for about three
- seconds. DELETE ALL? appears in the display. 3. Press **DELETE** again to complete.

Storing a Name and Number in Memory

- 1. Press **STORE**. LOCATION? shows in the display.
- 2. Press the desired memory location (0 to 9 or quick call buttons A, B, or C.) NOTE: Press LEFT or RIGHT to scroll through 0 - 9 or quick call buttons A, B, or C to select a location.
- 3. Press **STORE** again to confirm the memory location.

NOTE: Use Delete to erase existing memories or to correct errors. 4. Use the number keys to enter the telephone number (up to 32 digits) and then

press **STORE** to save. (The unit will not dial a phone number in this mode.) The cursor automatically moves to the text line for name entry. 5. Use the number keys to enter the name of the person associated with the

telephone number you just entered. More than one letter is stored in each of the

number keys. Press the keys multiple times to scroll through the letters for that

key. For example, to enter "B," press "2" twice. Press **LEFT** two times to create a

NOTE: The flashing cursor automatically moves to the next position or you may press LEFT or RIGHT to move the cursor to the next position.

Download from Www.Somanuals.com. All Manuals Search And Download.

6. Press **STORE** to save the name

7. To enter another name and number in a different memory location, return to step 1 and repeat this process.

Storing a Pause in Memory

The **REDIAL/PAUSE** button has dual functionality and becomes a pause button when pressed in sequence after the **STORE** button. It is valid only when storing a number into memory locations. Use the **REDIAL/PAUSE** button to insert a pause when a delay is needed in an automatic dialing sequence (for example, when you must dial a 9 to get an outside line or when you enter codes to access your long distance company).

NOTE: A pause is 3 seconds in length and you can store more than one if a longer pause is needed.

Changing a Stored Number

Repeat the storage sequence under Storing A Name and Number in Memory, and press **DELETE** to delete the old number before entering the new number.

Erasing a Stored Name & Number

- 2. Press the memory location (**0** to **9** or quick call buttons **A**, **B**, or **C**) to be erased. 3. Press DELETE.

Copying Caller ID Memories to User Memory

- 1. Press **LEFT** or **RIGHT** to view the caller number and name you want to copy.
- 3. Press the memory location (**0** to **9** or quick call buttons **A**, **B**, or **C**). The number
- flashes if there is a number already stored in that memory location. 4. Press **STORE** to enter Edit mode, and then press **STORE** again to edit the name.

NOTE: Select a different memory location by using LEFT and RIGHT to scroll

through 0 - 9 or quick call buttons A, B, or C.

5. Press **STORE** to confirm and save. Wait three seconds to exit. NOTE: If the name you want to enter is longer than 12 characters, only the first 12 characters will be copied into memory.

2. Press any key (**0** to **9** or quick call buttons **A**, **B**, or **C**) for the memory location. If a

number is already stored in the memory location, it will appear on the display. Use

Storing a Redial Number to Memory

- **LEFT** and **RIGHT** to select a different location. 3. Press **STORE** again to confirm.
- 4. Press **REDIAL/PAUSE**, and then press **STORE** again.

5. Enter the name, if necessary, and then press **STORE** to confirm. Copying a Redial Number to Memory

PICKUP PHONE. 2. Press STORE

3. Press any key (**0** to **9** or quick call buttons **A**, **B**, or **C**) for the memory location. If

1. Press **REDIAL/PAUSE** while on-hook. Redial number will display along with

there is a number already stored in the memory location, it will appear on the display. Use the **RIGHT** or **LEFT** buttons to select a different location.

4. Press **STORE** twice.

5. Enter name, if necessary, and then press **STORE** again to confirm and save.

- Dialing Numbers Stored in Memory 1. Press DIAL. 2. Press a memory location button or use **LEFT** or **RIGHT** to scroll through stored
- memory locations to find the desired number. The number in that memory location displays.

3. Press **SPEAKER** or pick up the handset to dial the displayed number.

- 1. Lift the handset or press **SPEAKER**. 2. Press a memory location button or use **LEFT** or **RIGHT** to scroll through stored memory locations to find the desired number. The number in that memory
- location displays

3. Press **DIAL** again to dial the stored number.

Long distance phone number

1. Pick up the handset or press **SPEAKER**.

2. Press **DIAL**, then press **6** for the memory location.

3. Press **DIAL**, then press **7** for the memory location.

4. Press **DIAL**, then press for the memory location.

Using Chain Dialing This process allows you to dial a succession of stored numbers from separate memory locations. This is useful when you must dial several sequences of numbers, such as

ith frequent calls via a telephone company long distance provider.			
For example	Memory location		
Local access number of long distance company	6		
Authorization code (ID)	7		

5. The number dials automatically.

Problem

Pre-Dialing 1. With the handset on the cradle, enter the telephone number you wish to call. The telephone number shows in the display.

2. Lift the handset or press **SPEAKER** and the number automatically dials.

NOTE: Use **DELETE** to delete an incorrectly entered number.

Resolution

<u>Troubleshooting Tips</u>

No Dial Tone. 1. Check all cabling to make sure that all connections are secure and undamaged 2. Check hook switch: Does it fully extend when handset is lifted from cradle? 3. Try switching between tone and pulse. No Information is . Are you subscribed to Caller ID service from your local Shown After the telephone company? Phone Rings 2. Be sure to wait until the second ring before answering.

Problem Resolution Make sure T/P MODE is set to TONE DIAL. Phone Dials in Pulse with Tone Service Phone Won't Dial Out Make sure T/P MODE is set to PULSE DIAL with Pulse Service Phone Does Not Ring . Make sure ringer switch is ON. . You may have too many extension phones on your line. Try unplugging some extension phones. . Check for dial tone. See Troubleshooting Tips for No Dial Tone. Incoming Voice . Are other phones off hook at same time? If so, this is Volume Low normal condition as volume drops when additional phones are used at once 2. Check the handset receiver or speaker volume. Incorrect memory Make sure you correctly entered the numbers into

General Product Care

Follow these guidelines to care for your phone:

memory.

- 1. Do not put it near heating appliances or devices that generate electrical noise (for example, motors or fluorescent lamps).
- 2. DO NOT expose it to direct sunlight or moisture.

Compatibility.

dialing

- 3. Handle it carefully. 4. Clean it with a soft cloth.
- 5. Never use a strong cleaning agent or abrasive powder because this will damage

This telephone system meets FCC/Industry Canada standards for Hearing Aid

6. Retain the original packaging in case you need to ship it at a later date.

Compliance Information Hearing Aid Compatibility (HAC)

number must be provided to the phone company.

FCC Part 68 information This equipment complies with Part 68 of the FCC rules & the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US: AAAEQ##TXXXX. If requested, this

An applicable Universal Service Order Codes (USOC) certification for the jacks used in this equipment is provided (i.e., RJ11C) in the packaging with each piece of approved terminal equipment. A plug & jack used to connect this equipment to the premises wiring & telephone network must comply with the applicable FCC Part 68 rules & requirements adopted by the ACTA. A compliant telephone cord & modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

The REN is used to determine the number of devices that may be connected to a

phone line. Excessive RENs on a phone line may result in devices not ringing in

response to an incoming call. In most but not all areas, the sum of RENs should not

exceed five (5.0). To be certain of the number of devices that may be connected to

a line, as determined by the total RENs, contact the telephone provider. The REN for

this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary. The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service. Please follow instructions for repairing, if any (e.g. battery replacement section); otherwise do not substitute or repair any parts of the device except as specified in this

public utility commission, public service commission or corporation commission for information. This equipment is hearing aid compatible. If you experience trouble with this equipment, contact the manufacturer (see the cover of this manual for contact information) or an authorized agent. If the equipment is causing harm to the telephone network, the telephone company may

If your home has wired alarm equipment connected to a phone line, be sure that

installing the system does not disable your alarm equipment. If you have questions

request that you disconnect the equipment until the problem is resolved.

manual. Connection to party line service is subject to state tariffs. Contact the state

about what will disable alarm equipment, contact your telephone company or a qualified installer. Any changes or modifications to this product not expressly approved by the

manufacturer or other party responsible for compliance could void your authority to

operate this product. NOTICE: According to telephone company reports, AC electrical surges, typically resulting from lightning strikes, are very destructive to telephone equipment connected to AC power sources. To minimize damage from these types of surges, a

This device complies with part 15 of the FCC rules. Operation is subject to the

following two conditions: (1) This device may not cause harmful interference, & (2)

This device must accept any interference received, including interference that may cause undesired operation. Privacy of communications may not be ensured when

FCC PART 15.105(b)

using this phone.

surge arrestor is recommended.

FCC Part 15 information

Note: This equipment has been tested & found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses & can radiate radio frequency energy and, if not installed & used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off & on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Increase the separation between the equipment and receiver.

• Reorient or relocate the receiving antenna.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

- limitation of incidental or consequential damages so the above limitation or exclusion may not apply to you. LEGAL REMEDIES: This warranty gives you specific legal rights, & you may also have other
 - America & Canada. PROCEDURE FOR OBTAINING PERFORMANCE OF WARRANTY: If, after following the instructions in the owner's manual you are certain that the Product is defective, pack the Product carefully (preferably in its original packaging). Disconnect the battery from the Product & separately secure the battery in its own separate packaging within the shipping carton. The Product should include all parts & accessories originally packaged

with the Product. Include evidence of original purchase & a note describing the defect that

has caused you to return it. The Product should be shipped freight prepaid, by traceable

4700 Amon Carter Blvd Fort Worth, TX 76155

means, to warrantor at:

Uniden America Service

The pictures in this manual are used for examples only. Your actual phone may not look exactly like the pictures.

Printed in China

- This product complies with FCC radiation exposure limits under the following
- The base must be placed to allow a minimum of 20 cm (8 inches) between the antenna and all persons during normal operation

• The base must not be collocated or operated in conjunction with any other antenna or

Industry Canada (I.C.) Notice

RF exposure information

Terminal equipment

THE CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003. NOTICE: This equipment meets the applicable Industry Canada Terminal Equipment Technical Specifications. This is confirmed by the registration number. The abbreviation *IC* before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved

NOTICE: The Ringer Equivalence Number (REN) for this terminal equipment is marked on the equipment itself. The REN assigned to each terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5.

Canada technical specifications were met. Operation is subject to the following two

conditions: (1) this device may not cause interference, & (2) this device must accept

any interference, including interference that may cause undesired operation of the

Radio equipment The term *IC* before the radio certification number only signifies that Industry

device. "Privacy of communications may not be ensured when using this telephone"

warranty service

Licensing

Licensed under US Patent 6,427,009.

WARRANTOR: UNIDEN AMERICA CORPORATION ("Uniden")

One-year Limited Warranty Important: Evidence of original purchase is required for

ELEMENTS OF WARRANTY: Uniden warrants, for one year, to the original retail owner,

this Uniden Product to be free from defects in materials & craftsmanship with only the limitations or exclusions set out below. WARRANTY DURATION: This warranty to the original user shall terminate & be of no further effect 12 months after the date of original retail sale. The warranty is invalid if the Product is (A) damaged or not maintained as reasonable or necessary, (B) modified, altered, or used as part of any conversion kits, subassemblies, or any configurations not sold by Uniden, (C) improperly installed, (D) serviced or repaired by someone other than an authorized Uniden service center for a defect or malfunction covered by this warranty, (E) used in any conjunction with equipment or parts or as part of any system not

manufactured by Uniden, or (F) installed or programmed by anyone other than as detailed

by the owner's manual for this product. STATEMENT OF REMEDY: In the event that the product does not conform to this warranty at any time while this warranty is in effect, warrantor will either, at its option, repair or replace the defective unit & return it to you without charge for parts, service, or any other cost (except shipping & handling) incurred by warrantor or its representatives in connection with the performance of this warranty. Warrantor, at its option, may replace the unit with a new or refurbished unit. THE LIMITED WARRANTY SET FORTH ABOVE IS THE SOLE & ENTIRE WARRANTY PERTAINING TO THE PRODUCT & IS IN LIEU OF & EXCLUDES ALL OTHER WARRANTIES OF ANY NATURE WHATSOEVER, WHETHER EXPRESS, IMPLIED OR ARISING BY OPERATION OF LAW, INCLUDING, BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THIS NARRANTY DOES NOT COVER OR PROVIDE FOR THE REIMBURSEMENT OR PAYMENT OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow this exclusion or

rights which vary from state to state. This warranty is void outside the United States of

Uniden® is a registered trademark of Uniden America Corporation.

© 2009 Uniden America Corporation, Fort Worth, Texas

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com