

THEATER 3D LED LCD HDTV

XVT3D650SV - QUICK START GUIDE

Download from Www.Somar

IMPORTANT SAFETY INFORMATION FOR VIEWING 3D CONTENT



You may experience discomfort while watching 3D content. You may feel symptoms of eye strain, vision fatigue, color or depth distortion, motion sickness, nausea, dizziness, disorientation, or other discomforts. If you experience any of these symptoms, stop watching and take a break for at least thirty minutes before resuming. If the symptoms are severe or continue even after you have stopped watching 3D content, consult a doctor.



Take care to monitor children's watching of 3D content. Children (including teenagers) may be more at risk of experiencing discomfort while watching 3D content and less likely to report symptoms. Monitor children's 3D content viewing and watch for signs of discomfort.



Some viewers may be susceptible to epileptic seizures or strokes when viewing 3D images, even if those conditions have not been previously diagnosed. If you or anyone in your family has a history of seizures or strokes, or if you have any other reason to think you or someone under your supervision may be susceptible to epileptic seizures or strokes, consult a doctor before watching 3D content.



Even if you do not experience any of the above symptoms, take regular breaks from watching 3D content.

PACKAGE CONTENTS







Premium Theater 3D Glasses (2)



Basic Theater 3D Glasses (2)





Power Cord










Safety Cable

Bluetooth[®] Remote Control with Batteries

User Guide and Quick Start Guide

USING THE BLUETOOTH® REMOTE CONTROL

Device Power/Standby:	Turn external device on or off.	Power/Standby:	Turn the TV on or off.
Input:	Change input device.	Info:	Display program information and time.
A/V Controls:	Control external device.	Menu:	Display on-screen menu.
List:	Display list of available channels.	Arrow:	Navigate on-screen menu or episode guide.
Exit:	Close on-screen menu.	Guide:	Display episode guide.
OK:	Select highlighted menu option.	VIA Shortcuts:	Control VIZIO Internet Apps (see diagram).
Back:	Go to previous menu screen.	Channel Up/Down:	Change channel up or down.
VIA:	Start VIZIO Internet Apps.	Last:	Return to previous channel.
Volume Up/Down:	Increase or decrease volume.	Number Pad:	Enter a channel.
Mute:	Turn sound off or on.	QUERTY Keypad:	Enter letters and numbers.
/ 3D:	Activate 3D content.		





BEFORE THE FIRST-TIME SETUP




To get the best high-resolution picture and sound on your new 3D HDTV, connect your devices with an HDMI cable.

To make the best HDMI connection, use **VIZIO XCH408D1 Premium High-Speed Flat HDMI Cables**. VIZIO HDMI cables are manufactured to produce the best picture on VIZIO 3D HDTVs and feature:


- 3D ready Bring true 3D gaming and titles to your 3D HDTV
- 1080p and for full HD video and future Ultra-HD video
- Great flexibility for thin wall mounts
- Stays securely connected at sharp angles
- Limited lifetime warranty

Visit www.VIZIO.com to purchase online.





Connect the power cord to the back of the 3D HDTV. Plug the power cord into an electrical outlet. 2



3



Connect your HDMI devices. These include Blu-ray[™] players, game consoles, and cable TV boxes.

For each device, connect one end of an HDMI cable to the device, and connect the other end of the HDMI cable to an available HDMI port on your HDTV.

Ensure the cables are securely connected.

Remove the battery cover by pressing gently on the arrow and sliding away from the remote.

Correctly insert the batteries. The + and - symbols on the batteries must correspond to the + and - symbols inside the battery compartment.

Replace the battery cover by gently sliding it back into place.

COMPLETING THE FIRST-TIME SETUP



Add home theater surround sound without the excess clutter of front and center speakers and excess wires.

The VIZIO VHT510 5.1 Surround Sound Home Theater with Wireless Subwoofer delivers big home theater sound in a sleek design that's perfect for your 3D HDTV:

- Universal 5.1 soundbar with rear satellite speakers and wireless subwoofer turns any HDTV into a full surround sound home theater
- Wireless subwoofer uses Wireless HD Audio[™] 2.4 GHz, so you can place it anywhere in the room
- Premium sound with Dolby Digital[®], DTS, SRS CircleCinema HD[™] and SRS TruVolume[™].

Visit www.VIZIO.com to purchase online.




Press the **Power/Standby** button on the remote to turn the TV on. The Setup App starts automatically. Use the **Up/Down Arrow** buttons to highlight **Home Mode Setup** and press **OK**.

Activate the remote by pressing both **Record** and the **Green VIA Shortcut** button for 5 seconds, then highlight **Begin Activation** and press **OK**. Wait for the remote to be found.







When the remote is found, use the **Arrow Up/Down** buttons on the remote to highlight **Connect to the Internet** and press **OK**.

Use the **OK** and **Arrow Up/Down** buttons on the remote to read and accept the Terms of Service and Privacy Policy for Yahoo! TV Widgets.

When you are finished, highlight Next and press OK.

Turn Page to Step 4

COMPLETING THE FIRST-TIME SETUP (CONTINUED)

4





Select the name of your wireless network from the list of available networks and press **OK**.


Enter the network key using the **QUERTY Keypad** on the remote, then highlight **Connect** and press **OK**.

If the 3D HDTV is connected to your network with an ethernet cable, you will not see this screen.

Enter your First Name, Last Name, Phone Number, ZIP Code, and E-mail Address using the **QUERTY Keypad** on the remote.

Highlight **Next** and press **OK**.

6





Choose the input to which your TV signal is connected.

Answer the on-screen questions about your TV connection using the **Arrows** and **OK** button on the remote.

Choose the device you would like to connect.

Answer the on-screen questions about your TV connection using the **Arrows** and **OK** button on the remote.

When you have finished adding devices, highlight **Exit to Live TV** and press **OK**.

USING VIZIO INTERNET APPS



For the best online experience, VIZIO recommends the next-generation **XWR100 Dual-Band HD Video and Wireless Internet Router**. This state-of-the-art router prioritizes the sending of media files over regular data files, delivering a superior streaming experience with fewer delays.

Visit www.VIZIO.com to purchase online.

Press the **VIA** button on the remote.



To start an App, use the **Left/Right Arrow** buttons to highlight an App from the App Bar and press **OK**. Once you have started an App, use the **Arrow**, **OK**, and **VIA Shortcut** buttons on the remote to control the App.

The highlighted App is in the lower left corner of the screen.



To use VIZIO Internet Apps, the 3D HDTV must be set up with a high-speed internet connection. If you did not set up your network during First-Time Setup, see **Setting Up Your Network Connection** in the User Guide.

Download from Www Somanuals com, All Manuals Search And Downloa

VIEWING 3D CONTENT



To view high-definition 3D content on your 3D HDTV, you will need:

- A 3D Blu-ray[™] player
- A Blu-ray 3D[™] disc
- VIZIO Theater 3D Glasses
- A 3D-ready HDMI cable connecting the 3D Blu-ray player to the 3D HDTV

For a superior 3D experience, pair your 3D HDTV with the **VIZIO 3D Blu-Ray Player**.

Go to **www.VIZIO.com** to purchase online.




Ensure your 3D Blu-ray player and TV are off.

Press the **Power/Standby** button on the remote to turn the TV on.

Press the **INPUT** button and select the input to which the Blu-ray player is connected (HDMI-1, HDMI-2, etc).







*Blu-ray Player/Disc Not Included

Turn your 3D Blu-ray player* on.

Insert your Blu-ray 3D disc* into your 3D Blu-ray player.

Select the **Play Movie** option in the Blu-ray 3D disc's main menu.



The 3D HDTV asks if you would like to watch the movie in 3D.

Select Yes and press OK.

Put on your VIZIO Theater 3D glasses and enjoy Theater 3D!

HELP TOPICS

There is no power.	 Ensure the power cord is securely connected to the AC socket on the TV and a working electrical outlet. Press the Power/Standby button on the remote or press the Jag Wheel on the left side of the TV. Try plugging the power cord into a different electrical outlet.
There is a picture, but there is no sound.	 Press the Volume Up button on the remote, or turn the Jag Wheel on the left side of the TV. Press the MUTE button on the remote to ensure Mute is off. Press MENU, then select TV Settings > Audio. Ensure TV Speakers is set to On.
The picture quality seems low.	 View high-definition (HD) programs when possible. Ensure all cables are securely connected.
I cannot view 3D content.	 Ensure you have a 3D Blu-ray[™] player, VIZIO Theater 3D glasses, and a Blu-ray 3D[™] disc. Turn your 3D HDTV and 3D Blu-ray player off. Turn the 3D Blu-ray Player on first, then turn the 3D HDTV on. Try to play your Blu-ray 3D[™] movie again. Ensure your 3D Blu-ray player's 3D setting is Enabled/Auto. (Devices differ, see your player's user guide.)
I cannot return to the Setup App.	 The on-screen menu has guided setup. Press MENU, then select Help > Guided Setup. Remember, any of the TV settings can be adjusted using the on-screen menu. See Using the On-Screen Menu in the User Guide.

There are black/gray bars on the top/bottom/ sides of the picture.	 Set the TV to Wide or Zoom Mode. Press MENU, then select Wide. Adjust the video settings of your external device (Blu-ray[™] or DVD player). If using the RGB (computer) input, ensure you are using a supported desktop resolution. Some television channels add black bars to the picture.
I cannot access VIZIO Internet Apps, or my Apps are not working correctly.	 Press the VIA button on the remote. Ensure the TV is connected to your network. See Connecting to Your Network in the User Guide. Press the Green VIA Shortcut button to display the help screen for an App.
My 3D content is displayed as two separate images.	• Enable SBS (side-by-side) 3D Mode. Press MENU > 3D > SBS .
The TV does not respond when I press buttons on the remote control.	 Insert new batteries into the remote. Ensure no objects are blocking the TV's sensor. (The sensor is on the front of the TV, in the lower left corner.) Activate your remote. See Activating the Bluetooth Remote Control in the User's Guide.
The TV displays "No Signal"	 Ensure your connected devices are turned on. Press the INPUT button on the remote and select the input to which your device is connected (HDMI, Composite, etc).

TRADEMARKS SHOWN ARE THE PROPERTY OF THEIR RESPECTIVE OWNERS. IMAGES USED ARE FOR ILLUSTRATION PURPOSES ONLY. VIZIO, THE V LOGO, WHERE VISION MEETS VALUE, AND OTHER VIZIO TRADEMARKS ARE THE INTELLECTUAL PROPERTY OF VIZIO INC. PRODUCT FEATURES AND SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE. © 2010 VIZIO INC. ALL RIGHTS RESERVED. Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com