






















## Reading Messages

When you receive a new message, use the 9501's One-Button feature to read the entire message by repeatedly pressing .

## Setting the Pager Alarm














1. From the main menu, press  or  to move to  (settings).
2. Press  and use  or  to move to  (set alarm).
3. Press  to enter "Settings" mode.
4. Press  or  to choose either "Enabled Daily", "Enabled One-time", or "Disabled".
5. Press  or  to move to the hour digit and press  or  to set the hour you want for the alarm.
6. Press  or  to move to each entry selection (minute, AM/PM, day, month, year) and press  or  to set each field.
7. Press  to save your settings.

 Motorola are registered trademarks of Motorola, Inc.





© 1998 by Motorola, Inc. All Rights Reserved

## Satellite Series 9501 Pager Quick Reference Card



























### Main Menu Icons

-  Message Envelope
-  Message Envelope (5 unread)
-  Information Folder
-  Information Folder (unread)
-  Personal Folder
-  PhoneBook
-  Time Alert Settings
-  Power On/Off
-  Quiet Time Enabled
-  Audible Alert Enabled
-  Alarm Enabled
-  Home Time
-  Travel Time

### Control Buttons

-  Move Left/Right
-  Select
-  Move Up/Down
-  Escape

## Pager Icons

	Alarm Enabled
	Alarm Disabled
	Quiet Time
	Quiet Time Disabled
	View Message
	Return to Previous Screen
	Add to Folder
	Add to PhoneBook
	Receive PhoneBook
	Battery Full Indicator
	Battery 2/3 Full Indicator
	Battery 1/3 Full Indicator
	Battery Low Indicator
	Signal Strength Strong
	Signal Strength Moderate
	Signal Strength Low
	No Signal, Out of Range
	Set to Vibrate
	Set Audible Alerts
	Set Alarm
	Set Alert to Silent
	View Next Message
	Delete Message
	Message Read
	Scroll Up and Down
	Truncated Message

## Wearing Your Pager

Your 9501 pager comes with a multi-functional holster that orients the pager for the best possible performance. It is recommended that you place the pager in the holster (display side facing in) and wear it on your belt. The holster can also be used effectively off the body as a stand for your pager. To ensure optimum reception, extend the belt clip, stand it up on a desk or table, and point it toward the nearest window.


**Note:** Improper positioning of the 9501 pager will impair message reception.

## Checking Satellite Strength

**Note:** Availability of the satellite feature described herein may vary, depending on the region of the world that you are in and the type of service provided.

It is possible that you may have difficulty receiving messages in the interior of large urban buildings. When you arrive in an unfamiliar office, hotel room, or meeting room,

you may want to check the pager's ability to receive messages in that location. To determine the likelihood of receiving messages in a given environment, perform the following steps:

1. Position the pager correctly.
2. Press and hold  for 2 seconds. The LED blinks yellow while the pager is looking for the nearest satellite.
3. It can take up to 26 seconds to locate the nearest satellite. Upon completion your pager alerts with a single chirp. The LED will be either green (in range), or red (out of range). *If you press any button during the test, the test will be cancelled.*
4. When complete, remove the pager from the holster to view the display.
5. If your signal strength indicator shows you are out-of-range (antenna with no strength bars), or weak (antenna with 1 or 2 strength bars), move to an outer part of the building or room with a window, where you may obtain better reception results.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>