

Start Guide

GALAXY S™ 4G

exclusively from T-Mobile

OVERVIEW

This guide provides you with everything you need to get started. For more information and support, please visit www.t-mobile.com/support where you can:

- Register for **my.t-mobile.com** to check your minutes, pay your bill, upgrade your phone, and change your rate plan.
- Review the User Manual and troubleshooting FAQs.
- View the latest troubleshooting solutions in the Support Forums or ask a question of your own.

You can also access Help information on your phone:

1. From any Home screen, tap **Applications**.
2. On the **Application** screen, tap **My Account** or **My Device**.

TABLE OF CONTENTS

Service Activation	1	Wi-Fi Calling	18
Introducing Your Phone.....	2	Tethering & Wi-Fi Sharing.....	21
Cool Apps	3	Text Messaging	24
SIM Card	4	E-mail	24
Memory Card	5	Social Networking	29
Battery	6	Camera & Video	30
Battery Life	7	Music Player	32
Power.....	7	Web Browsing	34
Home Screens	8	Location.....	35
Application Screens	10	Bluetooth®	38
Notification Screen.....	10	Accessories for Your Phone	39
Calls.....	11	Emergency Dialing.....	40
Voicemail.....	12	Caring for Your Phone	41
Contacts.....	13	Tips for Safety	42
Volume & Ringtones	14	Additional Information	43
T-Mobile Video Chat	17		

SERVICE ACTIVATION

If you are a new T-Mobile® customer and your service has not been activated, simply call Customer Care at **1-800-937-8997** from your landline phone and a T-Mobile Activations representative will assist you. You will need the following information when activating service:

- Service Agreement and agent code on your Agreement
- Your name, home address, home phone, and billing address

NOTE: For business and government accounts, please provide the name of your company or government agency, address, and tax ID.

- Your Social Security number, current driver's license number, and date of birth for credit check purposes
- Your choice of T-Mobile rate plan and services (see www.t-mobile.com for latest plan information)
- SIM serial number and IMEI number (located on the box bar code label)

By activating service, you acknowledge that you have read, understand, and agree to be bound by each of T-Mobile's Terms and Conditions and your Service Agreement.

INTRODUCING YOUR PHONE

GALAXY S™ 4G



COOL APPS

Please visit <http://galaxy-s.t-mobile.com/4G> for more information on the following content, applications, and services for your phone.


- INCEPTION – full length movie
- T-Mobile TV – live and on demand mobile HDTV
- Media Hub – Rent or Buy next day TV shows and top movies
- T-Mobile Video Chat powered by Qik™
- doubleTwist® AirSync – Sync music, photos and videos with your computer over Wi-Fi, no cable needed
- Facebook®
- Slacker Radio – Personalized Radio
- Kindle for Android – Read the largest selection of the most popular books

SIM CARD

Your Subscriber Identity Module (SIM) card identifies you to the wireless network. Your phone will not work without the SIM card.

To insert the SIM card and battery:

1. Detach your SIM card from its packaging.



2. Place your fingernail in the notch on the bottom of the phone and pull the back cover off.



3. Insert the SIM card into the SIM card slot, as shown, with the gold contacts on the SIM card facing downward.





4. Align the gold contacts on the battery with the contacts in the battery compartment. Push the battery into place and replace the battery cover.

MEMORY CARD

Your phone comes with a microSD memory card where multimedia files, such as video clips, music tracks, sound files, and images are stored by default.

WARNING: Applications, personal settings, and other data may be lost or not function properly if the memory card is removed.

Install the memory card

1. Remove the battery cover.
2. Insert the memory card with the gold contacts facing downward.
3. Push in until it clicks into place.
4. Replace the battery cover.



BATTERY

Charge using a wall outlet

On your phone, slide open the charger/USB port cover and insert the small end of the charger into the charging port. Plug the other end of the charger into a wall outlet.

Charge using a computer

You can also charge using the USB cable. Insert the small end of the USB cable into the charging port of your phone and the other end into the USB port of your computer.



BATTERY LIFE

Your Galaxy S 4G has two convenient widgets to help you monitor and maximize your phone's battery life. To add the **Power Control** or **Program Monitor** widgets to your Home screen:

1. Touch and hold an empty spot on your Home screen.
2. Tap **Widgets**.
3. Tap **Power Control** or **Program Monitor**.

POWER


To turn on the phone, press and hold the **Power** key on the right side of the phone.

To turn it off, press and hold the **Power** key and tap **Power Off**.



HOME SCREENS

Your phone has seven Home screens. Swipe left and right to view all the screens.



You can customize each screen with widgets and shortcuts to your favorite applications.

Add widgets, shortcuts, and folders to your Home screen

1. Navigate to the Home screen where you want to add the item.
2. Touch and hold an empty spot on your Home screen.
3. Tap **Widgets**, **Shortcuts**, or **Folders**.
4. Tap the item to add.



Change your wallpaper

1. Touch and hold an empty spot on your Home screen.
2. Tap **Wallpapers**.
3. Tap **Home screen wallpaper**, **Live wallpapers**, or **Wallpaper gallery**.
4. Tap the wallpaper.
5. Tap **Set wallpaper**.

Remove items from your Home screen

1. From the Home screen, touch and hold the item you want to delete.
2. Drag it to the **Trash** icon and release your finger.


APPLICATION SCREENS

There are three Application screens available by default. As you download new applications, they will appear on the Application screens in alphabetical order. Additional Application screens will appear as needed to accommodate future downloads.

To access the Application screens, from any Home screen, tap **Applications** and swipe left and right to view all the screens.

NOTIFICATION SCREEN

To view your notifications, touch and drag the **Status** bar down to open the **Notification** screen.



Wireless coverage indicators

	Indicates that your phone is connected to HSPA+ technology
	Indicates high-speed data connection
	Indicates that your phone is connected to 3G technology
	Indicates that your phone is connected to EDGE technology
	Indicates that your phone is connected to GPRS technology
	Indicates that your phone is connected to Wi-Fi technology
	Indicates your signal strength (the more bars, the stronger the signal strength)

Device speeds depend on factors such as wireless traffic, topography, weather, and network conditions.

CALLS

Make a call

1. From any Home screen, tap **Phone**.
2. Enter the phone number and tap **Call**.

Answer and end calls

To answer a call, touch and slide the green **Answer** icon to the right.

To end the call, tap **End Call**.

VOICEMAIL

Use voicemail

To call and set up voicemail:

1. From any Home screen, tap **Phone**.
2. Touch and hold **1** to call voicemail.
3. Follow the tutorial to set up your voicemail account.

To reset the voicemail password to the last four digits of your phone number:

1. From any Home screen, tap **Phone**.
2. Enter **#793#**.
3. Tap **Call**.
4. Tap **OK**.

Use Visual Voicemail

Visual Voicemail allows you to play and replay messages in any order, save voice messages to your phone, choose how you want to respond to messages, share special audio messages via e-mail, and create personalized greetings.

To set up Visual Voicemail:

1. From any Home screen, tap **Applications**.
2. On the **Application** screen, tap **Visual Voicemail**.
3. Tap **Next** to activate Visual Voicemail and view your Inbox.
4. Tap **Done**.

To check Visual Voicemail:

1. From any Home screen, tap **Applications**.
2. On the **Application** screen, tap **Visual Voicemail**.
3. Tap the voicemail message.
4. Tap the **Play** icon on the left side of the screen to play.

To reply to a Visual Voicemail:

While in the voicemail message, tap the **Phone** icon.

CONTACTS


Add new contact

1. From any Home screen, tap **Contacts**.
2. If necessary, tap **Done** at the Tips screen.
3. While on the **Contacts** tab, tap the **Menu** key.

4. Tap **Create contact**.
5. Tap **Phone, SIM, or T-Mobile** to save the contact to the phone memory, to the SIM card, or to my.t-mobile.com.
6. Tap the **First name** field and enter the contact's first name.
7. Tap the **Last name** field and enter the contact's last name.
8. Tap the **Phone number** field and enter the contact's phone number.
9. Continue on to enter more contact information if desired.
10. Tap **Save** when done.

Call contact from the contact list

1. From any Home screen, tap **Contacts**.
2. Tap the **Contacts** tab, if necessary.
3. Tap the contact.
4. Tap the desired number to initiate the call.



VOLUME & RINGTONES

Adjust call volume

While on an active call, press the **Volume** key up or down to adjust the call volume.

Adjust ring volume

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Tap **Volume**.
5. Touch and drag the **Incoming call volume** slider to the desired level.
6. Tap **OK**.

TIP: You can also touch and drag the **Notification volume** bar to adjust the notification volume as well at this screen.

Adjust media volume

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Tap **Volume**.
5. Touch and drag the **Media volume** slider to the desired level.
6. Tap **OK**.

Adjust touch tone volume

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Sound**.

4. Scroll to and tap the **Audible touch tones** and **Audible selection** check boxes to turn on/off touch tone volume.

Silence ring / notification volume

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Tap the **Silent mode** check box to silence all sounds except media and alarms.

Set incoming call ringtone

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Tap **Phone ringtone**.
5. Tap the desired tone.
6. Tap **OK**.

Set notification ringtone

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Tap **Notification ringtone**.
5. Tap the desired tone.
6. Tap **OK**.

T-MOBILE VIDEO CHAT POWERED BY QIK

Video Chat allows you to connect face-to-face with your friends and family whether at home or on the go.

Sign up for a Qik™ account

1. From any Home screen, tap **Applications**.
2. Tap **Video Chat**.
3. Tap **Sign up**.
4. Tap the **Email address** field and enter the e-mail address you want to use for your Qik account.
5. Tap the **Username** field and enter the username you want to use.
6. Tap the **Password** field and enter a password.
7. Tap **Sign up**.

Initiate Video Chat

1. From any Home screen, tap **Applications**.
2. Tap **Video Chat**.
3. Tap **Video Chat** again.
4. Tap a contact displaying the green **Video** icon to initiate a video call.

WI-FI CALLING

Wi-Fi Calling can improve your coverage and allows you to make phone calls and send messages over a Wi-Fi network (when one is available). Unless your rate plan provides otherwise, Wi-Fi Calling minutes count the same as your T-Mobile wireless calling minutes on your phone bill.

- To use Wi-Fi Calling, you must first turn on Wi-Fi on your phone, connect to a Wi-Fi network, and then turn on Wi-Fi Calling.
- When the Wi-Fi Calling feature is on, your phone displays the **Wi-Fi Calling** icon on the **Status** bar on the top of your screen. 
- To stay on a Wi-Fi call, you must remain in range of the Wi-Fi network. Your call will drop as you leave the Wi-Fi range. Your phone makes an audible beep and shows a message when a call will drop.


Wi-Fi Calling offers three connection options:

- **Wi-Fi Preferred:** All calls go through Wi-Fi when connected to a Wi-Fi network. Calls drop as you leave the Wi-Fi range.

- **Cellular Preferred:** Calls go over the cellular network, and Wi-Fi Calling is a backup if the cellular network is not available.
- **Wi-Fi Only:** Calls can be made when connected to a Wi-Fi network. If there is no Wi-Fi network, then your calls cannot connect.

Turn on Wi-Fi and Wi-Fi Calling

1. Touch and slide the **Status** bar down to view the **Notification** screen.
2. Tap **Wi-Fi**. When Wi-Fi is blue, the Wi-Fi radio is turned on.
3. Tap the desired network.
4. Enter the password, if necessary, and tap **Connect**.
5. Go back to the Home screen.
6. Tap **Applications**.
7. Tap **Wi-Fi Calling**.
8. Tap **View Tutorial**, if desired.
9. At the bottom of the screen, tap the **On/Off** icon to turn on/off Wi-Fi Calling.



When Wi-Fi Calling is on, your phone displays the **Wi-Fi Calling**  icon on the **Status** bar on the top of your screen. You

can now make phone calls and send messages over the Wi-Fi network.

Turn Off Wi-Fi Calling

You can choose to turn off Wi-Fi Calling. You can stay connected to Wi-Fi for data usage but not use the Wi-Fi Calling feature. To turn off Wi-Fi Calling, follow these steps:

1. From any Home screen, tap **Applications**.
2. On the **Application** screen, tap **Wi-Fi Calling**.
3. At the bottom of the screen, tap the **On/Off** icon to turn on/off Wi-Fi Calling.

Set Connection Preference to Wi-Fi or Cellular

NOTE: Wi-Fi Calling must be turned on to change connection preferences.

1. From any Home screen, tap **Applications**.
2. Tap **Wi-Fi Calling**.
3. Tap the **Menu** key.
4. Tap **Settings**.
5. Tap **Connection preferences**.
6. Tap one of the following options:
 - **Wi-Fi Preferred:** All calls go through Wi-Fi when connected to a Wi-Fi network. Calls drop as you leave the Wi-Fi range.

- **Cellular Preferred:** Calls go over the cellular network, and Wi-Fi Calling is a backup if the cellular network is not available.
- **Wi-Fi Only:** Calls can be made when connected to a Wi-Fi network. If there is no Wi-Fi network, then your calls cannot connect.

7. Tap **OK**.

TETHERING & WI-FI SHARING

To use tethering or Wi-Fi sharing, you must have a Tethering and Wi-Fi Sharing service plan.

Tethering

Your phone has the capability to share its mobile data connection with a single computer via a USB cable.

- Tethering works with Windows® 7, Windows XP, Windows Vista®, and Linux. For more information on tethering with operating systems, go to www.android.com/tether#usb.
- For Windows XP, first install the driver on your computer before you can tether. To install the driver, go to www.android.com/tether.

- When you connect your phone to your computer with the USB cable, you can either tether or access files on the memory card but you cannot do both. If you want to use your computer to access the memory card, then you must not turn on tethering.

Wi-Fi Sharing

You can share the mobile data connection from your phone with other devices by turning your phone into a portable Wi-Fi hotspot.

- When your phone is serving as a Wi-Fi hotspot, you cannot access the Internet via its Wi-Fi connection.
- For more information, go to www.android.com/tether#wifi.

Tether Your Phone

1. Connect your phone to your computer using a USB cable.
2. On your phone, tap the **Back** key.
3. Tap the **Menu** key.
4. Tap **Settings**.
5. Tap **Wireless and network**.
6. Tap **Tethering**.
7. Tap to select the **USB tethering** check box.

Your phone starts sharing its wireless network data connection with your computer via the USB connection.

Turn on Wi-Fi Sharing

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Wireless and network**.
4. Tap **Mobile AP**.
5. Tap to select the **Mobile AP** check box.
6. Tap **OK**.

Your phone starts broadcasting its Wi-Fi network name (SSID) so you can connect to it with up to five computers or other devices. Your phone's default SSID is AndroidAP.

7. Tap **Mobile AP settings**.
8. Enter a new name for the SSID.
9. Tap the **Security** drop-down menu.
10. Tap **WPA2 PSK**.
11. Tap the **Password** field.
12. Enter your password.
13. Tap **Save**.
14. On your computer, connect to your phone (SSID) via Wi-Fi Sharing.

TEXT MESSAGING

Access messaging

From any Home screen, tap **Messaging**.

Delete a message or message thread

1. While viewing your message or while in your message inbox, touch and hold the message.
2. Tap **Delete message** or **Delete thread**.
3. Tap **OK**.

E-MAIL

Set up Internet e-mail

1. From any Home screen, tap **Applications**.
2. On the **Application** screen, tap **E-mail**.
3. At the **Email address** field, enter your e-mail address.
4. Tap the **Password** field and enter your password for the e-mail account.
5. Tap **Next**.
6. Tap **OK**.
7. Enter a name for your account (optional).
8. Enter a name that will be displayed on outgoing messages.
9. Tap **Done**.

Set up Corporate/work e-mail

Contact your company's IT department if you need more help. This feature works with **Microsoft® Exchange e-mail servers only.**

1. From any Home screen, tap **Applications.**
2. On the **Application** screen, tap **E-mail.**

NOTE: If you have already set up an e-mail account, tap the **Menu** key, tap **Accounts**, tap the **Menu** key again, and then tap **Add account.**

3. At the **Email address** field, enter your e-mail address.
4. Tap the **Password** field and enter your password.
5. Tap **Manual setup.**
6. Tap **Microsoft Exchange ActiveSync.**
7. At the **Domain\Username** field, enter your domain and username.
8. Tap the **Exchange Server** field and enter the Exchange server address.
9. Scroll down and tap **Next.**
10. Read the Activation message and tap **OK.**
11. Adjust the e-mail checking frequency, synchronization schedule, e-mail size, and so on if desired.
12. Scroll down and tap **Next.**
13. Enter a name for your account (optional) and tap **Done.**

Create a Gmail™ e-mail account

1. From any Home screen, tap **Applications.**
2. On the **Application** screen, tap **Gmail.**
3. Tap **Next.**
4. Tap **Create.**


NOTE: If you already have a Google account, tap **Sign in** and enter your login information.

5. Enter your first name, last name, and the username you want on your account.
6. Tap **Next.**

TIP: Tap the **Back** key to close the on-screen keyboard.
7. Enter a password.
8. Tap the **Confirm password** field and re-enter the password.
9. Tap **Next.**
10. Tap the **Security question** drop-down menu and tap the desired question.
11. Tap the **Answer field** and enter your answer.
12. Tap the **Secondary Email** field and enter a backup e-mail address (optional).
13. Tap **Create.**

Add additional e-mail accounts

1. From any Home screen, tap **Applications**.
2. On the Application screen, tap **E-mail**.
3. Tap the **Menu** key.
4. Tap **Accounts**.
5. Tap the **Menu** key again.
6. Tap **Add account**.
7. Enter your e-mail address.
8. Tap the **Password** field and enter the password.
9. Tap **Next**.
10. Enter a name for your account (optional).
11. Enter a name that will be displayed on outgoing messages and tap **Done**.



Delete e-mail accounts

1. While in your mailbox, tap the **Menu** key.
2. Tap **Accounts**.
3. Touch and hold the account that you want to delete.
4. Tap **Remove account**.
5. Tap **OK**.

Access your mailbox

1. From any Home screen, tap **Applications**.
2. On the **Application** screen, tap **Email** to view the inbox for the last e-mail account you viewed.
3. To change to a different account, tap the account name at the top of the screen.
4. Tap the desired account.
5. Tap the message to view.

Send e-mail

1. While in your mailbox, tap the **Menu** key.
2. Tap **Compose**.
3. At the **To** field, enter the e-mail address or tap **Recent**, **Contacts**, or **Group** to select a saved contact.
4. Tap the **Subject** field and enter the subject of your message.
5. Scroll to and tap the next field and enter your message and tap **Send**.

SOCIAL NETWORKING

NOTE: The Facebook application comes pre-installed on your phone. To log in, on the **Application** screen, tap **Facebook** and follow the on-screen instructions.

Add account and sign in

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Accounts and sync**.
4. Tap **Add account**.
5. Tap the account that you want to add.
6. Continue on to sign in to your account.

Adjust sync settings

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Accounts and sync**.
4. Tap to select or clear the **Background data** and/or **Auto-sync** check boxes.

CAMERA & VIDEO

Take a picture

Pictures are saved to the memory card and can be viewed on your phone at **Applications > Gallery**.

1. From the center Home screen, tap the **Camera** shortcut to open the capture screen in landscape mode.
2. Frame the subject.
3. Tap the **Camera** icon to capture.

Send a picture

1. Take a picture.
2. Tap **Share**.
3. Tap the following and continue on to send your picture:
 - **AllShare**
 - **Audio Postcard**
 - **Bluetooth**
 - **Email**
 - **Facebook**
 - **Gmail**
 - **Messaging**
 - **Picasa**
 - **Kodak Gallery**
 - **Snapfish**

Record a video

Videos are saved to the memory card and can be viewed on your phone at

Applications > Gallery.

1. From the center Home screen, tap the **Camera** shortcut to open the capture screen in landscape mode.
2. Tap the **Arrow** icon on the left side of the screen to open more menu options.
3. Tap **Camcorder**.
4. Frame the subject.
5. Tap the red **Circle** icon to start recording.
6. Tap the **Square** icon to stop.

Send a video

1. Record the video.
2. Tap **Share**. If you don't see the **Share** option, tap the picture to display that option.
3. Tap the following and continue on to send your video:
 - **AllShare**
 - **Bluetooth**
 - **Email**
 - **Gmail**
 - **Messaging**
 - **YouTube**

Adjust settings

1. From any Home screen, tap the **Camera** shortcut to open the capture screen in landscape mode.
2. Tap the **Arrow** icon on the left side of the screen to open more menu options.
3. Tap **Settings**.
4. Tap the desired settings to adjust.

MUSIC PLAYER

Access the music player

1. From any Home screen, tap **Applications**.
2. On the **Application** screen, tap **Music Player**.

Transfer music from computer

1. Connect your phone to your computer using the USB cable.
2. Tap **Connect USB storage**.
3. Tap **OK**. The Removable Disk window opens on your computer.
4. Click **Open folder to view files using Windows Explorer**.
5. Click **OK**.
6. Locate the file on your computer that you want to copy.

7. Copy and paste the file into the memory card drive.
8. When finished, on your phone tap **Turn off** and disconnect your phone.

doubleTwist AirSync

Your phone comes preloaded with doubleTwist AirSync. This application allows you to use your home Wi-Fi network to wirelessly transfer:

- Photos
- Videos
- Music from your iTunes® playlist

For more information, visit <http://galaxy-s.t-mobile.com/4G>.

Play music

1. From any Home screen, tap **Applications**.
2. On the **Application** screen, tap **Music Player**.
3. Locate and tap the song.

WEB BROWSING

Experience the mobile Web like never before with T-Mobile's web2go® experience. Features include a phone browser optimized for the Web, a customizable start page for easy, one-click access to information, a powerful built-in Web search engine, and the ability to manage your account right from your phone.

For more information about these services visit www.t-mobile.com/shop/addons.

Visit a Web site

1. From the center Home screen, tap **Web**.
2. Touch and slide the screen down to display the Web address (URL) field.
3. Tap the Web address field at the top of the screen.
4. Enter the Web address.
5. Tap the **Enter** key or the **Arrow** icon.

Save a favorite

1. On the Web browser, go to the Web address that you want to bookmark.
2. Tap the **Menu** key.
3. Tap **More**.
4. Tap **Add bookmark**.
5. Enter a new name for the bookmark, if desired, and tap **OK**.

Full access to Web requires the purchase of a qualifying data plan. Separate additional charges may apply for downloads; actual content available for download may vary.

LOCATION

Use GPS satellites

For the best performance using your location features, turn on GPS satellites.

Turn on using Settings:

1. From any Home screen, tap the Menu key.
2. Tap **Settings**.
3. Tap **Location and security**.
4. Tap to select the **Use GPS satellites** check box.

NOTE: For best performance, make sure the **Use wireless networks** check box is also selected.

Turn on using Notification screen:

1. Touch and slide the **Status** bar down to view the **Notification** screen.
2. Tap **GPS**. When GPS is blue, using GPS satellites is turned on.

Google Maps™

To find a location:

1. From any Home screen, tap **Applications**.
2. On the **Application** screen, tap **Maps**.
3. Tap **OK** at **What's new in Maps** screen.
4. Tap **Search Maps**.
5. Enter your search.
6. Tap the **Enter** key or the **Magnifying Glass** icon to search.

To get directions:

1. From any Home screen, tap **Applications**.
2. On the **Application** screen, tap **Maps**.
3. Tap **OK** at **What's new in Maps** screen.
4. Tap the **Menu** key.
5. Tap **Directions**.
6. Tap **End point**.
7. Enter your destination. A list of locations displays.
8. Tap a location or business on the list.
9. Tap **Go**.

TeleNav GPS Navigator™

To sign up:

1. From any Home screen, tap **Applications**.
2. On the **Application** screen, tap **TeleNav GPS**.
3. Continue on to sign up to TeleNav.

To find a location:

1. While in TeleNav, tap **Search**.
2. Tap the **Business Name or Category** field.
3. Enter your search.
4. Tap **Search**.
5. Tap the desired business to view more details.

Additional charges may apply to subscribe to TeleNav GPS Navigator; see www.telenav.com for details. TeleNav is a registered trademark and TeleNav GPS Navigator is a trademark of TeleNav, Inc.

BLUETOOTH®

Your phone comes with Bluetooth technology, a wireless technology that enables a data connection between your phone and a Bluetooth wireless headset and other Bluetooth devices (sold separately).

Prepare Bluetooth headset

To pair your phone with a Bluetooth headset, make sure that your headset is fully charged and that you set the headset into pairing mode. See your Bluetooth headset's manual for more information.

Turn on Bluetooth and pair with headset

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Wireless and network**.
4. Tap **Bluetooth settings**.
5. Tap the **Bluetooth** check box to turn it on. A list of available Bluetooth devices displays.
6. Tap your headset on the list.
7. Enter the PIN or passcode, if requested.
8. Tap **OK**.

ACCESSORIES FOR YOUR PHONE

Whether you are looking for a charger, a fashionable carrying case, a Bluetooth® headset or just want to browse for fun extras for your phone, T-Mobile is the place to shop for accessories. Here are a few examples...



microSD Card
with adaptor



Car Charger

To purchase accessories for your phone, visit T-Mobile.com, call 1.800.204.2449 or visit your nearest T-Mobile store.

Accessory selection subject to change and may vary by location.

EMERGENCY DIALING

While all phones are equipped with 911 emergency calling, this phone may or may not permit its location to be approximated during a 911 call.*

* Availability of this feature depends on upgrades to the (a) wireless network and (b) 911 calling system that are required to be installed by the local 911 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within our wireless coverage area or your roaming area. This approximation of the phone's location and the transmittal of location information are subject to emergency situations, transmission limits, network problems/limitations, interconnecting carrier problems, your phone, buildings/tunnels, signal strength and atmospheric/topographical conditions, and may be curtailed, interrupted, dropped or refused. The phone's approximate location is transmitted to the local 911 response agency or PSAP while the call is in progress; this approximation is intended solely to aid the PSAP in dispatching emergency assistance or to limit the search area for emergency services personnel. You should not rely solely on a phone for essential communications (such as a medical or other emergency). Please see T-Mobile's Terms and Conditions and Privacy Policy for additional service restrictions and details.

CARING FOR YOUR PHONE

MAKING IT LAST

Your phone is a complex electronic device; think of it as a mini-computer. Here are some hints that should help you extend the life of your new phone.

Store your phone in a protective case.

The touch screen of your phone is delicate and should be protected from scratches.

Phones aren't cheap, so keep yours in a safe place—away from children who may find it fun to see if the phone sinks or floats, and away from dogs that find plastic-coated products to be irresistible chew toys.

Water will damage your phone and accessories—even a small amount such as water droplets from a soda in your car cup-holder, melting snowflakes, tears of joy, squirt-gun crossfire or steam from hot water in the kitchen or bathroom.

Use only batteries and accessories from the original manufacturer of your phone. Non-approved accessories can cause damage to you or your phone and shorten the phone's life. Hint: If it's being sold out of someone's car trunk, walk away.

If your charger or any other accessory is damaged, replace it or take it to a qualified service dealer. Do not attempt to operate your phone charger if it has received a sharp blow, been dropped,

thrown from a speeding motorcycle or is otherwise damaged; doing so may damage your phone.

TIPS FOR SAFETY

Check with your doctor if you have a pacemaker or hearing aid in order to ensure that cell phone usage is safe with your phone. If you have questions about the interaction of cellular radio frequency and any other electronic equipment, ask the manufacturer of the equipment if cell phone radio frequencies will disrupt the equipment's performance.

When you are driving, T-Mobile encourages you to use your phone in a safe and sensible manner. Here are a few tips:

- Assess road conditions before answering. Your safety is more important than any call.
- Prepare your hands-free headset, if you have one, or turn on your speakerphone option before you start moving.
- Keep your phone close. If it rings and you discover it's in the back seat, do NOT crawl over the seat to answer it while driving.

- Program frequently used numbers into your speed dial for easy one-touch dialing.
- Remember that laws prohibiting or restricting the use of a mobile phone while driving may apply in your area.

ADDITIONAL INFORMATION

4G used in connection with the Galaxy S™ 4G product name refers to the fact that the Galaxy S™ 4G is designed with HSPA+ technology.

Use of some features or services may incur separate, additional charges and/or require a qualifying data plan.

Messaging/Data: You will be charged for all data sent by or to you through the network, regardless of whether received. Character length/file size of messages/attachments may be limited. T-Mobile is not liable for content of messages/attachments or for any failures, delays or errors in any T-Mobile generated alerts or notifications. T-Mobile is not responsible for any third party content or Web site you may be able to access using your phone.

Downloads/Applications: Additional charges may apply; not all downloads available on all phones. You obtain no rights in downloads; duration of use may be limited and downloads may be stored

solely for use with your phone. T-Mobile is not responsible for any download lost due to your error. T-Mobile is not responsible for Apps, including download, installation, use, transmission failure, interruption or delay, third party advertisements you may encounter while using an App, alterations any App may make to the functionality of your device, **including any changes that may affect your T-Mobile plan, service, or billing**, or any content or website you may be able to access through an App.

See brochures and the **Terms and Conditions (including arbitration provision)** at T-Mobile.com, for rate plan information, charges for features and services, and restrictions and details, **including important limitations on availability and reliability of 9-1-1 emergency service when using Wi-Fi calling.**

Wi-Fi Calling: This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility.

If you have questions about return or exchange policies, consult your service provider or phone retailer.

The Bluetooth® word mark and logo are owned by the Bluetooth SIG, Inc. and are used by T-Mobile under license. T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG. web2go is a registered trademark, and Audio Postcard is a trademark, of T-Mobile USA, Inc. © 2010 All Rights Reserved. Slacker and the Slacker Logo are registered trademarks of Slacker, Inc. KINDLE and the AMAZONKINDLE logo are trademarks of Amazon.com, Inc. or its affiliates. INCEPTION © 2010 Warner Bros. Entertainment Inc. and Legendary Pictures. All rights reserved. All other trademarks are the property of their respective owners. ©2011 T-Mobile USA, Inc.

T-Mobile®

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>