

MULTIFUNCTIONAL DIGITAL SYSTEMS

# Copying Guide

---

**e-STUDIO555/655/755/855**



# Preface

## ■ How to read this manual

Thank you for purchasing TOSHIBA Multifunctional Digital Systems. This manual describes how to use the copying functions. Read this manual before using this equipment. Keep this manual within easy reach, and use it to configure an environment that makes the best use of the e-STUDIO's functions.

This equipment provides the scanning function as an option. However, this optional scanning function is already installed in some models.

## □ Symbols in this manual

In this manual, some important items are described with the symbols shown below. Be sure to read these items before using this equipment.


**⚠ WARNING** Indicates a potentially hazardous situation which, if not avoided, could result in death, serious injury, or serious damage, or fire in the equipment or surrounding objects.

**⚠ CAUTION** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, partial damage to the equipment or surrounding objects, or loss of data.

**Note** Indicates information to which you should pay attention when operating the equipment.

Other than the above, this manual also describes information that may be useful for the operation of this equipment with the following signage:


**Tip** Describes handy information that is useful to know when operating the equipment.

 Pages describing items related to what you are currently doing. See these pages as required.


## □ Description of original/paper direction

Paper or originals of A4, B5 or LT size can be placed either in a portrait direction or in a landscape direction. In this manual, “-R” is added to this paper size when this size of paper or original is placed in a landscape direction.

Example: A4 size original on the original glass



Placed in a portrait direction: A4



Placed in a landscape direction: A4-R

Paper or originals of A3, B4, LD or LG can only be placed in a landscape direction, therefore “-R” is not added to these sizes.

## □ Screens

- Screens on this manual may differ from the actual ones depending on how the equipment is used, such as the status of the installed options.
- The illustration screens used in this manual are for paper in the A/B format. If you use paper in the LT format, the display or the order of buttons in the illustrations may differ from that of your equipment.

---

## □ Trademarks

The company names and product names in this manual are the trademarks of their respective companies.

# CONTENTS

---

Preface.....	1
--------------	---

## Chapter 1 BEFORE USING EQUIPMENT

---

<b>BASIC Menu for the Copier Function .....</b>	<b>8</b>
<b>Placing Paper.....</b>	<b>11</b>
Acceptable copy paper.....	11
Placing paper in drawers.....	13
Placing paper in the tandem large capacity feeder .....	16
Registering paper size.....	17
Setting paper type .....	18
Placing paper in the External Large Capacity Feeder (optional).....	20

## Chapter 2 HOW TO MAKE COPIES

---

<b>Placing Originals .....</b>	<b>22</b>
Acceptable originals .....	22
Placing originals on the original glass .....	23
Book-type originals .....	24
Using the RADF (Reversing Automatic Document Feeder) .....	25
<b>Making Copies .....</b>	<b>28</b>
Basic copying procedure .....	28
Scanning the next original during copying.....	31
Interrupting copying and making other copies.....	32
Proof copy .....	33
Selecting exit tray .....	35
<b>Bypass Copying .....</b>	<b>36</b>
Bypass copying on standard size paper.....	37
Bypass copying on non-standard size paper.....	42

## Chapter 3 BASIC COPY MODES

---

<b>Before Using Copying Functions.....</b>	<b>46</b>
Default settings.....	46
Confirming the set functions.....	46
Clearing the set functions .....	47
Restrictions on function combinations .....	47
<b>Paper Selection.....</b>	<b>48</b>
Automatic Paper Selection (APS).....	48
Selecting desired paper manually .....	49
Copying mixed-size originals in one operation .....	50
<b>Setting Original Modes .....</b>	<b>52</b>
<b>Density Adjustment.....</b>	<b>53</b>
<b>Enlargement and Reduction Copying .....</b>	<b>54</b>
Automatic Magnification Selection (AMS) .....	54
Specifying both the original size and the copy paper size separately .....	56
Specifying reproduction ratio manually.....	58
<b>Selecting Finishing Mode .....</b>	<b>60</b>
Finishing modes and optional finishing devices .....	60
Sort/Group mode.....	62

Rotate sort mode .....	64
Staple sort mode .....	65
Magazine sort / Saddle stitch .....	67
Hole punch mode .....	69
Insert mode .....	70
<b>Duplex Copying .....</b>	<b>72</b>
Making a 1-sided copy.....	73
Making a 2-sided copy.....	74
Making a 2-sided copy from a book-type original .....	75
<b>Performing Copy &amp; File.....</b>	<b>78</b>
Setting share folder .....	80

---

## Chapter 4 EDITING FUNCTIONS

---

<b>Displaying EDIT Menu.....</b>	<b>84</b>
<b>Image Shift .....</b>	<b>85</b>
Creating top/bottom margin or left/right margin .....	85
Creating bookbinding margin.....	87
<b>Edge Erase .....</b>	<b>89</b>
<b>Book Center Erase .....</b>	<b>90</b>
<b>Dual Page .....</b>	<b>92</b>
<b>2IN1 / 4IN1 .....</b>	<b>94</b>
<b>Magazine Sort Mode.....</b>	<b>97</b>
<b>Image Editing .....</b>	<b>99</b>
Trimming / Masking .....	99
Mirror image / Negative/Positive reversal.....	102
<b>XY Zoom .....</b>	<b>103</b>
<b>Cover Sheet.....</b>	<b>104</b>
<b>Sheet Insertion.....</b>	<b>107</b>
<b>Time Stamp .....</b>	<b>110</b>
<b>Page Number .....</b>	<b>111</b>
<b>Job Build .....</b>	<b>113</b>
<b>Image Direction.....</b>	<b>116</b>
<b>Book - Tablet.....</b>	<b>118</b>
<b>ADF -&gt; SADF .....</b>	<b>119</b>
<b>Tab Paper .....</b>	<b>121</b>
Preparing an original to copy on the tab paper.....	121
Setting tab paper .....	121
TAB EXTENSION.....	123
COPY ON TAB.....	124
BLANK TAB INSERT.....	126
COPIED TAB INSERT.....	128
<b>Insert mode .....</b>	<b>130</b>

---

## Chapter 5 IMAGE ADJUSTMENT

---

<b>Displaying IMAGE Menu</b> .....	<b>134</b>
<b>Using Image Adjustment Functions</b> .....	<b>135</b>
Background adjustment.....	135
Sharpness .....	136

## Chapter 6 TEMPLATES

---

<b>Templates</b> .....	<b>138</b>
Displaying template menu .....	138
Using “Useful templates” .....	139
<b>Registering Templates</b> .....	<b>141</b>
Registering templates into the public template group.....	141
Creating a new private group .....	144
Registering templates into a private group .....	145
<b>Recalling Templates</b> .....	<b>147</b>
<b>Changing Data</b> .....	<b>150</b>
Changing private group data .....	150
Changing template data .....	151
<b>Deleting Groups or Templates</b> .....	<b>153</b>
Deleting private groups.....	153
Deleting templates.....	155

## Chapter 7 CONFIRMING JOB STATUS

---

<b>Confirming Copy Job Status</b> .....	<b>158</b>
Confirming jobs in progress or ones in waiting .....	158
Confirming copy job history .....	162
Confirming drawers .....	163

## Chapter 8 OTHER INFORMATION

---

<b>Continuous Copying Speed</b> .....	<b>166</b>
<b>Copying Function Combination Matrix</b> .....	<b>168</b>
Combination matrix 1/2.....	168
Combination matrix 2/2.....	169
<b>INDEX</b> .....	<b>171</b>






# BEFORE USING EQUIPMENT

This chapter describes what you need to know before using this equipment, such as the composition of the BASIC menu for the copying functions and how to place copy paper.

<b>BASIC Menu for the Copier Function .....</b>	<b>8</b>
<b>Placing Paper.....</b>	<b>11</b>
Acceptable copy paper .....	11
Placing paper in drawers .....	13
Placing paper in the tandem large capacity feeder .....	16
Registering paper size .....	17
Setting paper type .....	18
Placing paper in the External Large Capacity Feeder (optional) .....	20

## BASIC Menu for the Copier Function

When a few seconds have passed after you have turned the power ON, the BASIC menu for the copier function appears on the touch panel. The BASIC menu shows the following information:



### 1. Message indication area

This shows a brief description of the functions or the current status of this equipment in message form.

### 2. Equipment status indication area ( P.10)

This shows the size, paper type or amount of paper remaining in each drawer.

### 3. Index tabs (BASIC, EDIT, IMAGE) ( P.83, P.133)

These are for switching between the menus of "BASIC", "EDIT" and "IMAGE".

### 4. Alert message indication area

This shows alert messages such as the replacement timing of the toner cartridges.

#### When this equipment is managed with the user management function and department management function

When this equipment is managed with the user management function and the department management function, the number of copies available for each user ( ) or department ( ) appears here for approx. 5 seconds after user authentication.

#### Tips

- The display may differ depending on the management status of this equipment.
- For details of the user management function or the department management function, ask your administrator.

### 5. [APS] (automatic paper selection) button ( P.48)

This is for changing the mode to automatic paper selection.

### 6. [ZOOM] button ( P.54)

This is for changing the reproduction ratio of images.

### 7. [2-SIDED] button ( P.72)

This is for selecting simplex/duplex copying (e.g. 1 -> 2-sided, 2 -> 2 sided).

### 8. [FINISHING] button ( P.60)

This is for selecting a sorting mode.

### 9. [ORIGINAL MODE] button ( P.52)

This is for selecting an original mode.

### 10. Date and time

### 11. [JOB STATUS] button ( P.158)

This is for confirming the processing status of copy, fax, scan or print jobs, and also for viewing their performing history.

---

**12. [PROOF COPY] button (P.33)**

This is for making a proof copy to check an image before making a large amount of copies.

**13. Density adjustment buttons (P.53)**

These are for adjusting the density level of images.

**14. Number of copy sets****15. Number of remaining copy sets****16. Help button**

This is for viewing the explanation of each function or the buttons on the touch panel.

**17. [TEMPLATE] button (P.137)**

This is for the template function.

**18. [SETTINGS] button (P.46)**


This is for checking currently set functions.

**19. [STORAGE] button (P.78)**

This is for the storage function.

## Equipment status indication area

The equipment status indication area shows the following information:



1. **Receiving tray indication (📄 P.35)**  
This shows the tray to which copied paper exits.
2. **[EXIT TRAY] button (📄 P.35)**  
This is for switching receiving (exit) trays.
3. **Drawer buttons (📄 P.49)**  
These show the size of paper, amount of paper remaining in each drawer and the paper type set for the drawer. When you want to use a particular drawer, press the corresponding button.
4. **[BYPASS FEED] button (📄 P.36)**  
When this button is pressed with paper set in the bypass tray, it will be selected as the paper source.
5. **Paper type on the bypass tray (📄 P.36)**  
This shows the type of paper placed on the bypass tray with an icon.

## Placing Paper

### ■ Acceptable copy paper

The following paper can be placed and used for copying.

The values are valid only when Toshiba-recommended paper is used. For the recommended paper, refer to the **Quick Start Guide**.

#### Notes

- Do not place paper with mixed sizes or paper types in the same drawer.
- Be sure that the height of the stacked paper does not exceed the line indicated on the guides.

Feeder	Paper type	Maximum sheet capacity	Size
Drawers	Plain paper (64 - 80 g/m <sup>2</sup> ) (17 - 20 lb. Bond)	550 sheets (64 g/m <sup>2</sup> ) (17 lb. Bond) 500 sheets (80 g/m <sup>2</sup> ) (20 lb. Bond)	<b>A/B format:</b> A3, A4, A4-R, A5-R, B4, B5, B5-R, FOLIO  <b>LT format:</b> LD, LG, LT, LT-R, ST-R, COMP, 13"LG, 8.5"SQ  <b>K format:</b> 8K, 16K, 16K-R
	THICK 1 (81 - 105 g/m <sup>2</sup> ) (21 - 28 lb. Bond)	400 sheets	
	THICK 2 (106 - 163 g/m <sup>2</sup> ) (29 lb. Bond - 90 lb. Index)	200 sheets	
	THICK 3 (164 - 209 g/m <sup>2</sup> ) (91 - 110 lb. Index)	150 sheets	
	Tab paper *1, *2, *3	—	A4, LT
Tandem large capacity feeder	Plain paper (64 - 80 g/m <sup>2</sup> ) (17 - 20 lb. Bond)	3000 sheets (64 g/m <sup>2</sup> ) (17 lb. Bond) 2500 sheets (80 g/m <sup>2</sup> ) (20 lb. Bond)	A4, LT
	THICK 1 (81 - 105 g/m <sup>2</sup> ) (21 - 28 lb. Bond)	2000 sheets	
	THICK 2 (106 - 163 g/m <sup>2</sup> ) (29 lb. Bond - 90 lb. Index)	1000 sheets	
	THICK 3 (164 - 209 g/m <sup>2</sup> ) (91 - 110 lb. Index)	750 sheets	
External Large Capacity Feeder (optional)	Plain paper (64 - 80 g/m <sup>2</sup> ) (17 - 20 lb. Bond)	4500 sheets (64 g/m <sup>2</sup> ) (17 lb. Bond) 4000 sheets (80 g/m <sup>2</sup> ) (20 lb. Bond)	A4, LT
	THICK 1 (81 - 105 g/m <sup>2</sup> ) (21 - 28 lb. Bond)	3500 sheets	
	THICK 2 (106 - 163 g/m <sup>2</sup> ) (29 lb. Bond - 90 lb. Index)	2000 sheets	
	THICK 3 (164 - 209 g/m <sup>2</sup> ) (91 - 110 lb. Index)	1500 sheets	

Feeder	Paper type	Maximum sheet capacity	Size
Bypass tray	Plain paper (64 - 80 g/m <sup>2</sup> ) (17 - 20 lb. Bond)	100 sheets	<b>A/B format:</b> A3, A4, A4-R, A5-R, A6-R <sup>*6</sup> , B4, B5, B5-R, FOLIO
	THICK 1 (81 - 105 g/m <sup>2</sup> ) (21 - 28 lb. Bond)	80 sheets	<b>LT format:</b> LD, LG, LT, LT-R, ST-R, COMP, 13"LG, 8.5"SQ
	THICK 2 (106 - 163 g/m <sup>2</sup> ) (29 lb. Bond - 90 lb. Index)	40 sheets	<b>K format:</b> 8K, 16K, 16K-R
	THICK 3 (164 - 209 g/m <sup>2</sup> ) (91 - 110 lb. Index)	30 sheets	<b>Non-standard size:</b> Length: 100 - 297 mm (3.9" - 11.7"), Width: 148 - 432 mm (5.8" - 17") <sup>*6</sup>
	Tracing paper <sup>*1, *4</sup> (75 g/m <sup>2</sup> ) (20 lb. Bond)	—	
	Sticker labels <sup>*1, *5</sup>	—	
	Tab paper <sup>*1, *2, *3</sup>	—	A4, LT
	OHP film <sup>*1</sup>	30 sheets	A4, LT

<sup>\*1</sup> Duplex copying is not available.

<sup>\*2</sup> Tab paper can be set in any drawer other than the External Large Capacity Feeder (optional) or the bypass tray (the 2nd drawer recommended).

<sup>\*3</sup> When a finisher (optional) is installed in the equipment, use 5 or 8-tab paper.

<sup>\*4</sup> For making copies on the tracing paper, select "PLAIN" for the paper type.

<sup>\*5</sup> For making copies on the sticker labels, select "THICK 3" for the paper type.

<sup>\*6</sup> If a copy is made on either A6-R or non-standard size paper with a width of less than 182 mm (7.2"), or on paper of an unregistered size, the paper exits with its copied side up.

#### Tips

- "LT format" is the standard size only for use in North America.
- "K format" is a Chinese standard size.
- Abbreviations for paper sizes: LT: Letter, LD: Ledger, LG: Legal, ST: Statement, COMP: Computer, SQ: Square

## ❑ Unacceptable copy paper

Do not use the types of paper shown below. This could cause a paper jam.

- Damp paper
- Folded paper
- Curled or creased paper
- Paper whose surface is extremely smooth or rough

Do not use the types of paper shown below. This could cause an equipment malfunction.

- Paper whose surface has had a special treatment
- Paper once printed with other copiers or printers

## ❑ Precautions for storing copy paper

Make sure of the following when storing copy paper:

- Wrap the paper in its wrapping to keep it free from dust.
- Avoid direct sunlight.
- Store in a damp-free space.
- To prevent paper from being folded or bent, store it in a flat place.

## ■ Placing paper in drawers


Follow the procedure below to place paper in a drawer. For acceptable copy paper, see the following page:

📖 P.11 “Acceptable copy paper”

- 1 Turn the power of this equipment ON.
- 2 Pull out a drawer carefully until it comes to a stop.

### ⚠ CAUTION


Be careful not to touch the slide rails (A in the figure).  
This could injure you.




- 3 Push the lower part of the end guide in the direction of the arrows to remove it, then reinstall it at the position of the desired paper size.

#### Tip

The paper size is indicated on the bottom inner surface of the drawer.




- 4 Push the part shown with an arrow (right side) of the side guide to unlock it.



- 5 While holding the green lever of the side guide in the direction of the arrow, set the side guide to the desired paper size.


#### Tips


- The paper size is indicated on the bottom inner surface of the drawer.
- Adjust the side guides with both hands.



## 6 Place paper in the drawer.

### Notes


- Up to 550 sheets (64 g/m<sup>2</sup>) (17 lb. Bond) can be placed in one drawer. Be sure that the height of the stacked paper does not exceed the line indicated inside of the side guides.  
 P.11 "Acceptable copy paper"
- Fan and jog the stack of paper well before you place it in a drawer, or the sheets may not be separated before being fed. Be careful not to cut your fingers when fanning.
- Place paper with its copy side down. The copy side may be noted on its wrapping paper.




## 7 Adjust the side guides.

Make sure that a gap ("A" in the figure on the right) of 0.5 mm (0.02") (1.0 mm (0.04") or less in total)<sup>\*1</sup> is left between the paper and the side guide for plain paper. If the gap is inappropriate, it could cause paper misfeeding.


<sup>\*1</sup> For thick paper, the gap must be 0.5 mm (0.02") to 1.0 mm (0.04") (1.0 mm (0.04") to 2.0 mm (0.08") in total).



## 8 Push the part shown with an arrow (left side) to lock the side guide.



## 9 Change the paper size indicator if required.




## 10 Push the drawer straight into this equipment carefully until it comes to a stop.

### ⚠ CAUTION

Be careful not to let your fingers be caught when pushing the drawer into this equipment. This could injure you.



- 11** The menu below appears. When the size or type of paper is different from the one that was in the drawer, press [YES] on the touch panel. When they are the same, press [NO].




#### Tips

- The menu above may not appear depending on the setting of this equipment. In this case, see the following pages to change the settings of the paper size and paper type:
  - 📖 P.17 "Registering paper size"
  - 📖 P.18 "Setting paper type"
- If you want to change the setting for displaying this menu, ask your administrator.

If you press [NO], the procedure is completed.

- 12** Select the size and type of the paper placed in the drawer on the touch panel.

- 1) Select the paper size.
- 2) Select the paper type if required (📖 P.18).
- 3) Press [OK].




## ■ Placing paper in the tandem large capacity feeder

### 1 Pull out the drawer of the tandem large capacity feeder carefully until it comes to a stop.


#### ⚠ CAUTION

Be careful not to touch the slide rails (A in the figure). This could injure you.



### 2 Place 2 stacks of paper in the right and left trays correspondingly.

Fan and jog the paper well before placing it. Place it with its copy side down. Place one stack of paper in the right-hand tray (shown as "A" in the figure) with its side touching the right corner of the tray, and place the other stack of paper in the left-hand tray (shown as "B" in the figure) with its side touching the left corner of the tray. Paper can be placed neatly if you divide stacks into small bundles and pile them up on the two trays alternately.



#### Notes

- Paper in the right-hand tray is used first. When it runs out, paper in the left-hand tray will be moved automatically to the right-hand tray and fed.
- A maximum of 2500 sheets (80 g/m<sup>2</sup>) (20 lb. Bond) can be placed in the 2 trays. However the stack height of the paper must not exceed the line indicated inside the side guides.  
 📖 P.11 "Acceptable copy paper"
- The copy side may be noted on its wrapping paper.
- Be careful not to cut your fingers when fanning the paper.
- When placing paper, be sure that the center lever is not open. (See the label attached in the tandem large capacity feeder.)

### 3 Push the drawer of the tandem large capacity feeder straight into this equipment carefully.

When the drawer is completely inserted, the right-hand tray will move up to the paper feeding position.


#### ⚠ CAUTION

Be careful not to let your fingers be caught when pushing the drawer into this equipment. This could injure you.


## ■ Registering paper size

When you place paper for the first time or you replace the paper with that of a different size, you need to register the size to this equipment.

- 1 Press the [USER FUNCTIONS] button on the control panel.




- 2 Press the [USER] tab on the touch panel to display the user setting menu, and then press [DRAWER].



- 3 Select the paper size on the touch panel.

- 1) Select the drawer in which you placed paper.
- 2) Select the paper size.




- 4 Press the [USER FUNCTIONS] or [COPY] button on the control panel.  
The menu returns to the BASIC menu.

## ■ Setting paper type


When you place any special paper other than plain paper or that not used for normal copying, you need to set the thickness and attribute into this equipment.

### Tips








- The thickness and the attribute can be set together; however, one of “THICK 1” to “THICK 3” and the attribute “TAB PAPER” cannot be set together. If one of them is set, the other setting will be cleared.
- When the thickness “THICK 1, 2 or 3”, or an attribute other than “NONE” is set for a drawer, the paper placed in this drawer will not be used for the automatic paper selection mode.
- When an attribute other than “NONE” is set for a drawer, the Automatic Change of Paper Source function (Feeding the same size of paper from a different drawer even if the specified drawer from which paper is being fed is empty) is disabled for the paper in this drawer.  
For how to set Automatic Change of Paper Source, refer to the **MFP Management Guide**.
- The set paper type appears on the equipment status indication area with an icon.  
 P.10 “Equipment status indication area”

Acceptable paper types are as follows:

### Thickness

Button	Description	Icon
PLAIN	Plain paper: 64 - 80 g/m <sup>2</sup> (17 - 20 lb. Bond)	—
THICK 1 - 3	Thick paper <b>THICK 1:</b> 81 - 105 g/m <sup>2</sup> (21 - 28 lb. Bond) <b>THICK 2:</b> 106 - 163 g/m <sup>2</sup> (29 lb. Bond - 90 lb. Index) <b>THICK 3:</b> 164 - 209 g/m <sup>2</sup> (91 lb. Index - 110 lb. Index)	


### Attribute

Button	Description	Icon
NONE	No attribute specified	—
INSERT	Sheets used in the sheet insertion mode  P.107 “Sheet Insertion” Up to 2 types of sheets (Insertion sheets 1 and 2) can be set. To set Insertion sheet 1 and 2, select the drawer for Insertion sheet 1 and press [INSERT], and then select a drawer for Insertion sheet 2 and press [INSERT].	
COVER	Sheets used in the cover sheet mode  P.104 “Cover Sheet”	
SPECIAL	Colored paper or paper with watermarks, etc.	
FAX *1, *2	FAX paper	
TAB	Tab paper	


\*1 Fax transmission and reception is available only when the Fax Unit (optional) is installed.

\*2 When lists are printed, paper set as “FAX” is used. For printing lists, refer to the **MFP Management Guide**.


## 1 Press the [USER FUNCTIONS] button on the control panel.



- 2** Press the [USER] tab on the touch panel to display the user setting menu, and then press [DRAWER].




- 3** Press [PAPER TYPE].



- 4** Select the paper type.

- 1) Select the drawer in which you placed paper.
- 2) Select the paper type.



- 5** Press the [USER FUNCTIONS] or [COPY] button on the control panel. The menu returns to the BASIC menu.

#### Clearing the set paper type

Press the drawer button on the menu in step 4, and then press the paper type whose setting you want to clear.

#### Tip


If both INSERT 1 and INSERT 2 are set and you clear the setting of only INSERT 1, the setting for INSERT 2 automatically becomes the setting for INSERT 1.

## ■ Placing paper in the External Large Capacity Feeder (optional)

### 1 Pull out the drawer of the External Large Capacity Feeder carefully until it comes to a stop.


#### ⚠ CAUTION

Be careful not to touch the slide rails (A in the figure).  
This could injure you.



### 2 Place paper on the tray.

Fan and jog the paper well before placing it on the tray. Place it with its copy side up. Do not allow any gap between the paper and the rear side guide.



#### Notes

- A maximum of 4500 sheets (64 g/m<sup>2</sup>) (17 lb. Bond) can be placed. However the stack height of the paper must not exceed the line indicated on the rear side guide.  
 ☞ P.11 "Acceptable copy paper"
- The copy side may be noted on its wrapping paper.
- Be careful not to cut your fingers when fanning the paper.
- Do not allow any gap between the paper and the rear side guide. If there is any gap, the copied image may be skewed.

### 3 Push the drawer of the External Large Capacity Feeder straight into this equipment carefully.

When the drawer is completely inserted, the tray will move up to the paper feeding position.

#### ⚠ CAUTION

Be careful not to let your fingers be caught when pushing the drawer into this equipment.  
This could injure you.

# HOW TO MAKE COPIES

This chapter explains the basic copying procedures.

<b>Placing Originals .....</b>	<b>22</b>
Acceptable originals .....	22
Placing originals on the original glass .....	23
Book-type originals .....	24
Using the RADF (Reversing Automatic Document Feeder) .....	25
<b>Making Copies .....</b>	<b>28</b>
Basic copying procedure .....	28
Scanning the next original during copying .....	31
Interrupting copying and making other copies .....	32
Proof copy .....	33
Selecting exit tray .....	35
<b>Bypass Copying .....</b>	<b>36</b>
Bypass copying on standard size paper .....	37
Bypass copying on non-standard size paper .....	42

## Placing Originals

### ■ Acceptable originals

When the RADF (Reversing Automatic Document Feeder) is used, 2-sided originals can be automatically scanned one sheet after another. When the original glass is used, originals such as OHP films, tracing paper, booklet or 3-dimensional objects, that cannot be placed on the RADF can be scanned, as well as plain paper.

Location	Maximum size	Paper weight	Acceptable sizes for automatic size detection
Original glass	Length: 297 mm (11.69") Width: 432 mm (17.01")	—	Other than North America: A3, A4, A4-R, A5-R, B4, B5, B5-R North America: LD, LG, LT, LT-R, ST-R
RADF		1-sided originals: 35 - 209 g/m <sup>2</sup> (9.3 - 110 lb.) *1 2-sided originals: 50 - 157 g/m <sup>2</sup> (13.3 - 41.8 lb.)	Other than North America: A3, A4, A4-R, A5-R, B4, B5, B5-R, FOLIO North America: LD, LG, LT, LT-R, ST-R, COMP


\*1 You may not obtain enough image quality when an original with a paper weight of more than 157 g/m<sup>2</sup> (41.8 lb.) is used.

#### Notes

- Automatic size detection does not work properly when A/B format originals are used in equipment for North America. It does not work properly when LT format originals are used in equipment other than that for North America.
- Automatic size detection does not work properly when K format paper is used for printing. (K format is a standard paper size in China.)
- Do not place any heavy objects (4 kg (9 lb.) or over) on the original glass and do not press on it with force.
- Be sure to place ST-size or A5-size originals in a landscape direction when using the RADF.

### Maximum number of sheets for one scanning

A maximum of 2000 sheets can be scanned per 1 copy job or up until the embedded memory becomes full. When the number of scanned sheets has exceeded the above limit, this equipment stops scanning and the message below appears.



If you want to print out the data scanned up until then, press [YES]. If you want to delete them, press [NO].



## ■ Placing originals on the original glass

The original glass can be used for originals such as OHP films or tracing paper, as well as plain paper, that cannot be placed on the RADF.

### ⚠ CAUTION


**Do not place any heavy objects (4 kg (9 lb.) or over) on the original glass and do not press on it with force.** Breaking the glass could injure you.

## 1 Raise the RADF.

### Note


Raise it 60 degrees or more so that the size of the original can be detected correctly.

## 2 Place the original with its face down on the original glass and align it against the left rear corner of the glass.



### When you copy highly transparent originals

When you copy highly transparent originals such as OHP films or tracing paper, place a blank sheet, which is the same size as the original or larger, over the original.



## 3 Lower the RADF carefully.

## ■ Book-type originals


You can place book-type originals on the original glass.

### ⚠ CAUTION

**Do not place any heavy objects (4 kg (9 lb.) or over) on the original glass and do not press on it with force.** Breaking the glass could injure you.

### 1 Raise the RADF.


### 2 Open the desired page of the original and place it with its face down. Align it against the left rear corner of the original glass.



When you make 2-sided copies from book-type originals in modes such as book-type original to 2-sided copying or dual page copying, align the center of the original on the yellow indicator line of the original glass.

📖 P.75 "Making a 2-sided copy from a book-type original"

📖 P.92 "Dual Page"



### 3 Lower the RADF carefully.

#### Notes

- Do not lower the RADF forcibly when the original is very thick. There will be no problem in copying even if it is not fully lowered.
- Do not look directly at the original glass because intensive light may escape during copying.

## ■ Using the RADF (Reversing Automatic Document Feeder)


### □ Precautions

Do not use the types of originals 1 to 8 shown below because such originals may cause misfeeding or damage to the equipment.

1. Badly wrinkled, folded or curled originals
2. Originals with carbon paper
3. Taped, pasted or cut-out originals
4. Clipped or stapled originals
5. Originals with holes or tears
6. Damp originals
7. OHP films or tracing paper
8. Coated paper (with wax, etc.)

Use the types of originals 9 and 10 shown below with extra care.

9. Originals which resist sliding with the fingers, or surface-treated originals (The sheets of such originals may not be separated.)
10. Folded or curled originals (They should be fully smoothed out before being used.)



### When black streaks appear

If the scanning area or the guide area is dirty, image trouble such as black streaks may occur on printouts. Weekly cleaning of these areas is recommended. For cleaning, refer to the **Quick Start Guide**.

## □ Continuous feed mode


The feeding mode is set at “continuous feed mode” by default. Once you set the originals and then press the [START] button, they are scanned page by page continuously. It is useful when you want to copy more than one original at one time.


### 1 Align all the originals.

Collate the originals in the order that you want them to be copied. The top sheet of the originals will be copied first.

### 2 Place the originals with their face up and align the side guides to the original length.

#### Notes

- Regardless of their sizes, originals are acceptable up to 100 sheets (35 to 80 g/m<sup>2</sup> (9.3 to 20 lb.)) or 16 mm (0.62") in height.
- For mixed-size originals, see the following page:  
 P.50 “Copying mixed-size originals in one operation”




#### For long originals

Pull out the original stopper so that the scanned original will not fall off.


#### Note

After the original stopper was used, lift it slightly and push it in.



#### Tip

When there are too many originals to be scanned at one time, divide the originals into several sets before copying. Place the first set of the originals and then press [CONTINUE] on the touch panel while the data of this set are being scanned. When this scanning is finished, place the next set of the originals and press the [START] button on the control panel.




## □ Single feed mode

When the feeding mode is set at “single feed mode”, an original is fed automatically as it is placed on the RADF. It is useful when you want to copy only 1 original sheet.

📖 P.119 “ADF -> SADF”

2

### 1 Align the side guides to the original length.




### 2 Insert the original with its face up and straight along the side guides.


The original is automatically pulled in and then the menu of step 3 will be displayed on the touch panel.

#### Note

Be sure to let go of the original when it starts being pulled.



### 3 If there is another original, insert it in the same way.



The original is pulled in whether or not you press [YES].

### 4 After all the originals are pulled in, press [FINISHED].

#### Tip


Even if you do not press [FINISHED], copying will start when the current operation is cleared by means of the automatic function clear.

📖 P.47 “Clearing all settings changed”

## Making Copies

### ■ Basic copying procedure

Make copies following the procedure below.



#### 1 Make sure that paper is placed in the drawer(s).

For the types and sizes of acceptable paper and how to place it, see the following pages:

- 📖 P.11 “Acceptable copy paper”
- 📖 P.13 “Placing paper in drawers”
- 📖 P.16 “Placing paper in the tandem large capacity feeder”
- 📖 P.20 “Placing paper in the External Large Capacity Feeder (optional)”

#### 2 Place the original(s).

For the types and sizes of originals and how to place them, see the following pages:

- 📖 P.22 “Acceptable originals”
- 📖 P.25 “Using the RADF (Reversing Automatic Document Feeder)”
- 📖 P.23 “Placing originals on the original glass”
- 📖 P.24 “Book-type originals”

#### 3 Key in the desired number of copies if you want more than one copy.

Press the [CLEAR] button on the control panel to delete the number keyed in.

#### 4 Select the copy modes as required.

- 📖 P.45 “BASIC COPY MODES”
- 📖 P.83 “EDITING FUNCTIONS”
- 📖 P.133 “IMAGE ADJUSTMENT”

## 5 Press the [START] button on the control panel.


Copying starts. The paper exits with its copied side down.

### Note

Be careful because the paper exiting area and the paper itself are hot.

2

The menu shown below may appear when you are using particular modes.



This menu appears when “SADF (single feed mode)” is set to the document feeder or in modes where the original is placed on the original glass and the scanned data are temporarily stored in the memory, such as sort copying or 1-sided to 2-sided copying. When this menu appears, follow the procedure below.

## 6 Place the next original on the original glass, and then press the [START] button on the control panel.

Scanning starts.

## 7 Press [FINISHED] on the touch panel after all the originals have been scanned.


Copying starts.

### Tip


When the drawer runs out of paper during copying, another drawer can feed paper instead if it holds paper of the same size and orientation, and copying will not stop. If there is no such drawer, copying stops and “Add paper” appears on the touch panel. In this case, add paper in the drawer.

## □ Stopping and restarting copying

- 1 Press the **[STOP]** button on the control panel.  
Copying or scanning stops.



- 2 Press **[MEMORY CLEAR]** on the touch panel to stop copying. Press the **[START]** button on the control panel to restart.



When you press **[MEMORY CLEAR]**, the scanned data will be deleted and any waiting jobs will be performed.

### Tip

Even if you do not press **[MEMORY CLEAR]**, the scanned data will be deleted by means of the automatic function clear.



## ■ Scanning the next original during copying

Even if copying is in progress or “READY (WARMING UP)” is displayed on the touch panel, you can scan the next original (auto job start). Up to 10 jobs can be stored in the memory.

### 1 Place the original(s).

### 2 Set the number of copy sets and the copy modes as required.


#### Note

The new job starts in the copy modes that you previously selected unless you select other modes.

### 3 Press the [START] button on the control panel.

#### Tips

- Up to 10 jobs can be stored in the memory. When the originals for the 11th job are placed and the [START] button is pressed, “Auto Start” appears on the touch panel. Scanning of the 11th job starts when a waiting space for this job becomes available as the preceding jobs are processed.
- A maximum of 2000 sheets (A4-size and LT-size originals) can be scanned per 1 copy job or up until the embedded memory becomes full.



### Confirming auto jobs

You can confirm which jobs are in waiting on the touch panel or cancel them as required. For details, see the following page:


P.158 “Confirming Copy Job Status”

### Canceling jobs being scanned

Press the [STOP] button on the control panel to stop a job while originals are being scanned.

When you press [MEMORY CLEAR] on the touch panel or the [FUNCTION CLEAR] button on the control panel while the scanning is being paused, the scanning will end. (In this case, the data which were scanned before the job is paused will be copied.) To restart the scanning, press the [START] button.

To cancel the 11th auto job, press the [STOP] button.



## ■ Interrupting copying and making other copies

You can interrupt the copy job in progress to make other copies (interrupt copying). When restarting the interrupted job, you do not have to reselect copy modes that have been set because they are memorized in this equipment.

### Notes


- The following functions cannot be used together with interrupt copying:  
Cover sheet copying, Sheet insertion copying, Job build, Store to e-Filing, Copy & File
- During interrupt copying, the mode cannot be changed by pressing the [e-FILING], [SCAN], [PRINT] or [FAX] button on the control panel.

### 1 Press the [INTERRUPT] button on the control panel.

“Job interrupted job 1 saved” appears and then the [INTERRUPT] button lights.

#### Tip

If the original is being scanned, the message above appears after the scanning has finished.



### 2 Replace the original with a new one.

### 3 Select other copy modes as required and then press the [START] button on the control panel.

### 4 Press the [INTERRUPT] button again after the interrupt copying has finished.

“READY to resume job 1” appears and the interrupted job restarts.

#### Tip

Even if you do not press the [INTERRUPT] button, an interrupted copy job will restart when the current status is cleared by means of the automatic function clear after a specified period of time.


## ■ Proof copy

When you make a large amount of copies, you can check if they will be made exactly as you desire by copying only one page before copying them all (proof copy). Then you can change the modes or settings (e.g. the number of copy sets, receiving tray, page number, time stamp, sort/stapling, hole punching) after checking the proof copy.

### Note

If you want to change settings such as the reproduction ratio, density, original mode or 1/2-sided copying, you must finish the proof copy first. Then change these settings and scan the original again.

- 1 Place paper in the drawer(s).
- 2 Place the original(s).
- 3 Select the number of copy sets and copy modes.
- 4 Press [PROOF COPY] on the touch panel.  
"PROOF COPY is set Press START button to copy" appears for approx. 2 seconds.



### Note

If [NON-SORT NON-STAPLE] or [GROUP] is selected as a finishing mode, the mode will be changed to [SORT] automatically.

- 5 Press the [START] button on the control panel.  
Scanning starts. 1 set of copies will be printed out.

## 6 Change the number of copy sets and copy modes as required after checking the proof copy.

Modes or settings such as the number of copy sets, the receiving tray, page number, time stamp, sort/stapling and hole punching can be changed.



### Note

If you want to change settings such as the reproduction ratio, density, original mode or 1/2-sided copying, you must finish the proof copy first. Then change these settings and scan the original again. Press [MEMORY CLEAR] on the touch panel or the [FUNCTION CLEAR] button on the control panel to end the proof copy.

## 7 Press the [START] button on the control panel.

If you did not change the number of copies in step 6 above, the number of copies printed out will be one fewer than that previously set because you have already copied one as a proof copy. (However, if the number of copies you previously set was 1, another set of copies will be printed out besides the proof copy.)

## ■ Selecting exit tray


You can select the exit tray if an optional finisher is installed.

### Notes

- The available exit tray may be restricted depending on copy modes and paper sizes.
- Exit tray selection is set at automatic selection by default.

### Changing the exit tray

The exit tray currently selected is displayed on the equipment status indication area. To change the exit tray, press [EXIT TRAY]. Every time you press this, the display changes from each tray of the finisher and automatic selection.



## Bypass Copying


When you make copies on OHP film, sticker labels or non-standard size paper, place the copy paper on the bypass tray. Bypass copying is also recommended for copying on standard size paper which is not set in any of the drawers.

### Tip


If you select the paper size, you can utilize various functions such as the automatic paper selection (APS) or the automatic magnification selection (AMS). For details, see the following page:

📖 P.168 "Copying Function Combination Matrix"

Open the bypass tray for bypass copying.



If the paper is large, pull out the paper holder.



The operating procedure for bypass copying differs depending on the paper size to be used. See the table below for the operating procedure of each size.

Paper size		Procedure
Standard size	Other than North America: A3, A4, B4, B5 North America: LD, LT, LG, ST-R	📖 P.37 "Copying on A3, A4, B4 and B5 size paper (in equipment other than for North America) / LD, LT, LG and ST-R size paper (in equipment for North America)"
	Other than the above	📖 P.40 "Copying on other than the above standard sizes of paper"
Others (Non-standard sizes)		📖 P.42 "Bypass copying on non-standard size paper"

### Tips

- Bypass copying stops when the paper placed on the bypass tray runs out during copying, even if the paper of the same size is in any of the drawers. Copying restarts when paper is supplied to the bypass tray.
- When bypass copying has been completed, the [FUNCTION CLEAR] button on the control panel blinks. Press this button to switch bypass copying to normal copying using the drawers. (Even if you do not press the [FUNCTION CLEAR] button, bypass copying will be switched to normal copying using the drawers when the current status is cleared by means of the automatic function clear after a specified period of time.)


## ■ Bypass copying on standard size paper

### □ Copying on A3, A4, B4 and B5 size paper (in equipment other than for North America) / LD, LT, LG and ST-R size paper (in equipment for North America)

1 Place the original(s).

2 Place paper with its copy side up on the bypass tray. Then align the side guides to the paper length while holding the tab.


When paper is placed, the menu for bypass copying appears.



#### Notes

- The height of the paper must not exceed the indicator on the side guides.
- When you use more than one sheet of paper, fan the sheets well before placing them on the bypass tray. Be careful not to cut your fingers when fanning them.
- Do not push paper into the entrance of the bypass feeder. This could cause a paper jam.

3 Press the button of the same size as that of the paper you placed on the bypass tray.




The paper size is now set.


#### Note

If the paper size is not selected in this step, copying may be slowed down.

- 4** Press [PAPER TYPE] on the touch panel if the paper type of the paper you placed on the bypass tray is other than plain paper.




- 5** Select the paper type and then press [OK].










## Notes

- If you select a wrong paper type, this could cause a paper jam or significant image trouble.
- When you select a paper type, you can confirm it with the icons displayed on the equipment status indication area as shown below.



Paper type	Icon	Paper type	Icon
PLAIN	—	THICK 3	
THICK 1		TRANSPARENCY	
THICK 2		TAB PAPER	

## Notes

- Automatic 2-sided copying can be applied to plain paper, THICK 1, THICK 2 and THICK 3.
- For OHP films (TRANSPARENCY), only 1-sided copying can be performed.
- For tab paper, only 1-sided copying can be performed on its front side.

## 6 Select other copy modes as required, and then press the [START] button on the control panel.


## Note

When you copy on sheets of OHP film, remove the copied OHP film one sheet at a time as they exit onto the receiving tray. If the sheets of OHP film pile up, they may get curled and may not be projected properly.


## □ Copying on other than the above standard sizes of paper

**1** Place the original(s) and paper in the same procedure noted in steps 1 and 2 in “Copying on A3, A4, B4 and B5 size paper (in equipment other than for North America) / LD, LT, LG and ST-R size paper (in equipment for North America)” (📖 P.37)


**2** Press [SIZE SETTING] on the touch panel.



**3** Press the button of the same size as the paper you placed on the bypass tray.



**4** Press [OTHER] under “COPY”.




The paper size is now set.

### Note


If the paper size is not selected in this step, copying may be slowed down.

- 5** Press [PAPER TYPE] if the paper you placed on the bypass tray is other than plain paper.



2

- 6** Press the button of the same paper type as the paper you placed on the bypass tray. Then press [OK].




#### Notes

- If you select a wrong paper type, this could cause a paper jam or significant image trouble.
- When you select a paper type, you can confirm it with the icons displayed on the equipment status indication area. For details, see the following page:  
Table in step 5 in "Copying on A3, A4, B4 and B5 size paper (in equipment other than for North America) / LD, LT, LG and ST-R size paper (in equipment for North America)" (P.37)

- 7** Select other copy modes as required, and then press the [START] button on the control panel.

## ■ Bypass copying on non-standard size paper

You can use non-standard size paper within the sizes shown on the right.



**1** Place the original on the original glass.

**2** Place paper with its copy side up on the bypass tray. Then align the side guides to the paper length while holding the tab.


When paper is placed, the menu for bypass copying appears.



### Notes


- The height of the paper must not exceed the indicator on the side guides.
- When you use more than one sheet of paper, fan the sheets well before placing them on the bypass tray. Be careful not to cut your fingers when fanning them.
- Do not push paper into the entrance of the bypass feeder. This could cause a paper jam.

**3** Press [CUSTOM PAPER] on the touch panel.




## 4 Key in the dimension.


- 1) Press [LENGTH] and key in the value. (100 mm to 297 mm (3.94" to 11.69"))
- 2) Press [WIDTH] and key in the value. (148 mm to 432 mm (5.83" to 17.01"))
- 3) Press [OK].



Length and width are indicated as shown on the right:



To call up the dimension data registered previously, press the desired button from [MEMORY 1] to [MEMORY 4], and then press [OK].



### Tip

To register dimension data into the memory, see the following page:  
 P.44 "Registering non-standard size in the memory"


## 5 Select other copy modes as required, and then press the [START] button on the control panel.

## □ Registering non-standard size in the memory

**1** Follow the same procedure noted in steps 1 to 3 in “Bypass copying on non-standard size paper” (P.42).

### **2** Register dimensions.

- 1) Select a desired memory number.
- 2) Press [LENGTH] and key in the value. (100 mm to 297 mm (3.94" to 11.69"))
- 3) Press [WIDTH] and key in the value. (148 mm to 432 mm (5.83" to 17.01"))
- 4) Press [MEMORY].



# BASIC COPY MODES

This chapter describes the basic copying functions including how to change the reproduction ratio, how to set sorting modes or how to perform duplex copying.

<b>Before Using Copying Functions .....</b>	<b>46</b>
Default settings.....	46
Confirming the set functions.....	46
Clearing the set functions.....	47
Restrictions on function combinations.....	47
<b>Paper Selection .....</b>	<b>48</b>
Automatic Paper Selection (APS) .....	48
Selecting desired paper manually .....	49
Copying mixed-size originals in one operation.....	50
<b>Setting Original Modes .....</b>	<b>52</b>
<b>Density Adjustment.....</b>	<b>53</b>
<b>Enlargement and Reduction Copying .....</b>	<b>54</b>
Automatic Magnification Selection (AMS) .....	54
Specifying both the original size and the copy paper size separately .....	56
Specifying reproduction ratio manually.....	58
<b>Selecting Finishing Mode .....</b>	<b>60</b>
Finishing modes and optional finishing devices .....	60
Sort/Group mode.....	62
Rotate sort mode.....	64
Staple sort mode .....	65
Magazine sort / Saddle stitch .....	67
Hole punch mode .....	69
Inserter mode .....	70
<b>Duplex Copying.....</b>	<b>72</b>
Making a 1-sided copy .....	73
Making a 2-sided copy .....	74
Making a 2-sided copy from a book-type original.....	75
<b>Performing Copy &amp; File .....</b>	<b>78</b>
Setting share folder .....	80

## Before Using Copying Functions

### ■ Default settings



This equipment is under its “default settings” when the power is turned ON, namely, if no setting change has been applied yet, the equipment’s settings return to the default ones when the energy saving mode is cleared or the [FUNCTION CLEAR] button on the control panel is pressed. The default settings for basic copy modes at installation are shown below.

Item	Default setting
Reproduction ratio	100%
Copy quantity	1
Paper selection	Automatic Paper Selection (APS)
Simplex/Duplex	1-sided original -> 1-sided copy
Density adjustment	Automatic adjustment
Original mode	TEXT/PHOTO
Finishing mode	When using the original glass: NON-SORT NON-STAPLE When using the RADF (Reversing Automatic Document Feeder): SORT
Feeding mode when using the RADF	Continuous feed mode

The default settings are changeable. For details, refer to the **MFP Management Guide**.

### ■ Confirming the set functions

If you press [SETTINGS] on the touch panel, the menu shown below is displayed. On this menu, you can view the functions that are currently set.






## ■ Clearing the set functions

If you want to clear any settings of the EDIT menu, press the button of the desired functions.

📖 P.83 “EDITING FUNCTIONS”



If you want to clear any setting of the IMAGE menu, reset the adjustment value in the setting menu of the desired functions.

📖 P.133 “IMAGE ADJUSTMENT”

### Clearing all settings changed

When you press the [FUNCTION CLEAR] button on the control panel, all the function changes will be cleared.

Even if you do not press the [FUNCTION CLEAR] button, the changes will be cleared if the equipment is left idle for 45 sec. (default setting). For how to change this period, refer to the *MFP Management Guide*.

## ■ Restrictions on function combinations

Several copy functions can be used together. However some functions may not be used with other ones. For details, see the following page:



📖 P.168 “Copying Function Combination Matrix”

## Paper Selection


### Automatic Paper Selection (APS)

This equipment detects the size of an original and selects paper of the same size automatically. This function is called Automatic Paper Selection (APS).

#### Tips

- For the original sizes detectable, see the following page:  
 P.22 “Acceptable originals”
- Some original sizes may not be detected with this function. In this case, select the desired size manually.  
 P.49 “Selecting desired paper manually”

- 1 Place paper in the drawer(s).
- 2 Place the original(s).
- 3 Press [APS] on the touch panel.



The paper selection mode is now set at Automatic Paper Selection.

#### Tips

- The paper selection mode is set at Automatic Paper Selection by default.
- Even if the direction of the paper placed in the selected drawer differs from that of the original, this equipment rotates the data of the original by 90 degrees to make copies as long as their sizes are the same. (This works on A4, B5 or LT paper only.) For example, when an A4 original is placed in a portrait direction and A4-R paper is placed in the drawer, the data of the A4 original will be rotated and copied correctly on A4-R paper.

#### Note

If “Change direction of original” or “CHANGE DRAWER TO CORRECT PAPER SIZE” appears, follow the directions.

- 4 Select other copy modes as required, and then press the [START] button on the control panel.

## ■ Selecting desired paper manually

You need to select paper by yourself when copying the following originals whose sizes cannot be detected correctly:

- Highly transparent originals (e.g. OHP film, tracing paper)
- Totally dark originals or originals with dark borders
- Non-standard size originals (e.g. newspaper, magazines)

### Tip

When paper of the size you want to use is not in any drawer, place it in a drawer or on the bypass tray.

📖 P.13 "Placing paper in drawers"


📖 P.36 "Bypass Copying"

### 1 Place paper in the drawer(s).

When using bypass copying, be sure to set the paper size.

### 2 Place the original(s).

### 3 Press the drawer button corresponding to the desired paper size.



### 4 Select other copy modes as required, and then press the [START] button on the control panel.

## ■ Copying mixed-size originals in one operation

You can copy a set of originals whose sizes are individually different, using the RADF (Reversing Automatic Document Feeder).

The original sizes that can be mixed are as follows:

North America: LD, LG, LT, LT-R, COMP


Other than North America: A3, A4, A4-R, B4, B5, FOLIO

### 1 Place paper in the drawer(s).


The bypass tray cannot be used. Use drawers.

### 2 Adjust the side guides to the widest original, and then align the originals against the side guide on the front side.

When original widths are the same




When original widths are not the same




#### Note

When copying originals of different widths, the copied image of the smaller one may be skewed because it does not touch the side guide on the rear side.

### 3 Press [ZOOM] on the touch panel.




#### 4 Press [MIXED SIZE].



3

#### 5 Press [AMS] to make copies on paper in one size. To make copies on paper of the same size as the originals, press [CLOSE] so that the menu returns to the BASIC menu, and then press [APS].

When [AMS] is selected:



#### Notes

- In the Automatic Magnification Selection, copy images cannot be enlarged from A4 (portrait), B5 (portrait) or LT (portrait) to A3 (landscape), B4 (landscape), LD (landscape) or LG (landscape). In this case, place A4, B5 or LT originals in a landscape direction.
- Before you use Automatic Paper Selection, be sure that all paper sizes corresponding to the original sizes have been placed in the drawers.

#### 6 Select other copy modes as required, and then press the [START] button on the control panel.

#### Note

If "Change direction of original" appears while scanning is in progress, remove the original from the RADF and change its direction accordingly.

## Setting Original Modes

You can make copies with the optimal image quality by selecting the following modes for your original.

**TEXT/PHOTO:** Originals with text and photographs mixed


**TEXT:** Originals with text (or text and line art) only

**PHOTO:** Originals with photographs


Tip

TEXT/PHOTO is set by default.

### 1 Press [ORIGINAL MODE] on the touch panel.



### 2 Select the original mode.




## Density Adjustment

This equipment detects the density level of originals and automatically adjusts the density level of the copied image to the optimal one. Alternatively, you can manually adjust it to the desired level.

### Adjusting automatically (automatic density adjustment)



Press [AUTO] on the touch panel.




#### Tip

The automatic density adjustment is set by default at installation.

### Adjusting manually

Press either  or  to select the desired density level.



## Enlargement and Reduction Copying

You can change the reproduction ratio of copied images in the following procedures:

### Automatic Magnification Selection (AMS):

You need to specify the copy paper size in advance. Then this equipment will detect the original size and automatically select the optimal reproduction ratio for the copy paper size.

### Specifying both original size and copy paper size separately:

You need to specify both the original size and the copy paper size separately in advance. According to the sizes you specified, the optimal reproduction ratio is selected automatically. It is used when the Automatic Magnification Selection is not available, such as when copying OHP film originals.

### Specifying reproduction ratio manually:

You can select the desired reproduction ratio by pressing [ZOOM] or one-touch zoom buttons on the touch panel.

#### Tip

The available range of reproduction ratio differs depending on whether the original is placed on the original glass or on the RADF (Reversing Automatic Document Feeder).

Original glass: 25 to 400%

RADF: 25 to 200%

## ■ Automatic Magnification Selection (AMS)

Specify the copy paper size in advance so that this equipment will detect the original size and automatically select the optimal reproduction ratio to the copy paper size.

This function is available when the size of the originals is as follows:

North America: LD, LG, LT, LT-R, ST-R and COMP (COMP is available only when the RADF is used.)

Other than North America: A3, A4, A4-R, A5-R, B4, B5, B5-R, FOLIO (FOLIO is available only when the RADF is used.)


#### Note

This function does not work properly for the originals noted below. Select other methods when copying them.

- Highly transparent originals (e.g. OHP film, tracing paper)
- Totally dark originals or ones with dark borders
- Non-standard size originals (e.g. newspapers, magazines)


### 1 Place paper in the drawer(s).

### 2 Press [ZOOM] on the touch panel.





### 3 Select the desired paper size and then press [AMS].



3

#### Tips

- If you want to select a paper size other than the following, you need to register the size as "OTHER". Once you register this size, it will be specified every time you press [OTHER] on the touch panel.  
North America: LD, LG, LT, ST  
Other than North America: A3, A4, B4, B5  
For how to register, see the following page:  
 P.57 "Registering paper sizes to "OTHER" size"
- Paper sizes can also be registered by pressing the desired drawer button of the equipment status indication area on the BASIC menu.

### 4 Place the original(s).

If the original is placed on the original glass, the reproduction ratio is set when the original is placed. If the original is placed on the RADF, the reproduction ratio is set when the original is scanned.


#### Note

If "Change direction of original" appears, change it accordingly.


### 5 Select other copy modes as required, and then press the [START] button on the control panel.

## ■ Specifying both the original size and the copy paper size separately

- 1 Place paper in the drawer(s).
- 2 Place the original(s).
- 3 Press [ZOOM] on the touch panel.



- 4 Select the desired sizes for the original and copy paper.



### Tips

- If you want to select a size other than the following for the original size and copy paper size, you need to register the size as "OTHER". Once you register this size, it will be specified every time you press [OTHER] on the touch panel.  
North America: LD, LG, LT, ST  
Other than North America: A3, A4, B4, B5  
For how to register, see the following page:  
📖 P.57 "Registering paper sizes to "OTHER" size"
- Paper sizes can also be registered by pressing the desired drawer button of the equipment status indication area on the BASIC menu.

- 5 Select other copy modes as required, and then press the [START] button on the control panel.

## □ Registering paper sizes to “OTHER” size

If you want to select a size other than the following for the original size and copy paper size, you need to register the size as “OTHER” following the procedures below. Once you register this size, it will be specified every time you press [OTHER] on the touch panel.


North America: LD, LG, LT, ST

Other than North America: A3, A4, B4, B5


### Note

You can register only standard sizes as [OTHER] and cannot register any non-standard sizes.

## 1 Press [SIZE SETTING] on the touch panel.




## 2 Select the desired size.



The selected size will be registered as an “OTHER” size.

## ■ Specifying reproduction ratio manually

- 1 Place paper in the drawer(s).
- 2 Place the original(s).
- 3 Press [ZOOM] on the touch panel.



- 4 Press the buttons below to select the desired reproduction ratio.

### [▲ UP] and [▼ DOWN] buttons


The reproduction ratio changes by 1% every time either of them is pressed. When you hold either down, the ratio goes up or down automatically.

### One-touch zoom buttons


Select the desired ratio from [400%], [200%], [100%], [50%] and [25%].

### Note

When the RADF is used, the maximum ratio available is 200%.



## 5 Select the desired size.



3

### Tips

- If you want to select a paper size other than the following, you need to register the size as "OTHER". Once you register this size, it will be specified every time you press [OTHER] on the touch panel.  
North America: LD, LG, LT, ST  
Other than North America: A3, A4, B4, B5  
For how to register, see the following page:  
 P.57 "Registering paper sizes to "OTHER" size"
- Paper sizes can also be registered by pressing the desired drawer button of the equipment status indication area on the BASIC menu.

## 6 Select other copy modes as required, and then press the [START] button on the control panel.

## Selecting Finishing Mode

### ■ Finishing modes and optional finishing devices

See the table below for each finishing mode.

Finishing mode	Description
Non-sort Non-staple	Copies exit without being sorted or stapled.
Sort (☞ P.62)	Copies exit in the same page order as the originals one set after another.
Group (☞ P.62)	Copies grouped by page exit.
Rotate sort (☞ P.64)	Copies exit set by set alternately in a different direction.
Staple sort (☞ P.65)	Copies exit with their corner stapled.
Magazine sort (☞ P.67)	Copies exit in a book-type page order.
Saddle stitch (☞ P.67)	Copies exit in a book-type page order with their center folded and stapled.
Magazine sort & saddle stitch (☞ P.67)	Magazine sort and saddle stitch are used together.
Hole punch (☞ P.69)	Copies exit with their side punched.
Insert mode (☞ P.70)	Stapling and hole punching the sheets without making copies

The available finishing modes differ depending on the type of optional finishing devices (Finisher, Hole Punch Unit and Inserter) installed. Finishing devices available for this equipment are as follows:

#### Finisher

- Finisher MJ-1027
- Saddle Stitch Finisher MJ-1028/MJ-1029

#### Hole Punch Unit

Hole Punch Unit MJ-6003

#### Inserter


Inserter MJ-7001

Check the finishing modes enabled with each finishing device.

Devices	Finishing mode							
	Sort/ Group	Rotate sort	Staple sort	Magazine sort	Magazine sort & saddle stitch	Saddle stitch	Hole punch	Inserter mode
MJ-1027 & MJ-6003 & MJ-7001	Yes	—	Yes	Yes	—	—	Yes	Yes
MJ-1027 & MJ-6003	Yes	—	Yes	Yes	—	—	Yes	—
MJ-1027 & MJ-7001	Yes	—	Yes	Yes	—	—	—	Yes
MJ-1027	Yes	—	Yes	Yes	—	—	—	—
MJ-1028/1029 & MJ-6003 & MJ-7001	Yes	—	Yes	Yes	Yes	Yes	Yes	Yes
MJ-1028/1029 & MJ-6003	Yes	—	Yes	Yes	Yes	Yes	Yes	—
MJ-1028/1029 & MJ-7001	Yes	—	Yes	Yes	Yes	Yes	—	Yes
MJ-1028/1029	Yes	—	Yes	Yes	Yes	Yes	—	—
No device	Yes	Yes	—	Yes	—	—	—	—


## □ Name of each part of the finishers (optional)

### MJ-1027



1. Tray 1
2. Sub-tray
3. Tray 2
4. Front cover
5. Hole Punch Unit MJ-6003
6. Inserter MJ-7001
7. Upper cover

### MJ-1028/1029




1. Tray 1
2. Sub-tray
3. Tray 2
4. Saddle stitch tray
5. Lower cover
6. Front cover
7. Hole Punch Unit MJ-6003
8. Inserter MJ-7001
9. Upper cover


## Sort/Group mode

When you make more than one set of copies, they can be made to exit in the same page order as that of the originals. This mode is called the sort mode. Copies can also be made to exit grouped by page. This mode is called the group mode.

### Sort mode



### Group mode



#### Tip

When you use large-size paper, such as A3, B4, LD and LG, pull out the sub-tray in advance so that the copied paper will not fall off and will be sorted neatly.


### 1 Place paper in the drawer(s).

### 2 Place the original(s).

#### Tip


When you place originals on the RADF (Reversing Automatic Document Feeder), the display of the sorting mode button will change to "SORT".

### 3 Press [FINISHING] on the touch panel.





#### 4 Press [SORT] or [GROUP].




3

#### 5 Select other copy modes as required, and then press the [START] button on the control panel.

## ■ Rotate sort mode


When you make more than one set of copies, one set can be made to exit on top of another set, alternating in portrait and landscape directions. This mode is called the rotate sort mode. Use 2 drawers and 2 stacks of paper of the same size. Place one stack of paper in one drawer in a portrait direction and place the other in another drawer in a landscape direction before you start copying.




### Notes

- A4, B5 and LT sized paper placed on the drawer or bypass tray can be used.
- The rotate sort mode is not available when Automatic Paper Selection is selected.
- When an optional finisher is installed, this mode cannot be used.

- 1 Place paper in the drawer(s).
- 2 Place the original(s).
- 3 Press [FINISHING] on the touch panel.



- 4 Press [ROTATE SORT].



- 5 Select other copy modes as required, and then press the [START] button on the control panel.

## ■ Staple sort mode

When you make more than one set of copies, the copied paper can be automatically stapled set by set. This mode is called the staple sort mode. You can choose from 3 different stapling positions.


Example: When [FRONT STAPLE] is selected




### Notes

- Special paper such as OHP film or sticker labels is not applicable.
- Copies in different sizes cannot be stapled. (If the lengths of the copies are the same, they can be stapled.)

- 1 Place paper in the drawer(s).**  
When using bypass copying, be sure to set the paper size.
- 2 Place the original(s).**
- 3 Press [FINISHING] on the touch panel.**



- 4 Select the desired stapling position from [FRONT STAPLE], [DOUBLE STAPLE] or [REAR STAPLE].**



## 5 Select other copy modes as required, and then press the [START] button on the control panel.

### Tip

When the number of sheets exceeds the maximum number of sheets available for stapling, this equipment automatically enters into the sort mode.

## □ Maximum number of sheets available for stapling

The maximum number of sheets available for stapling differs depending on the type of the finishing device installed, paper size or paper weight.

### Finisher MJ-1027 / Saddle Stitch Finisher MJ-1028

Paper size	Paper weight		
	64 - 80 g/m <sup>2</sup> (17 - 20 lb. Bond)	81 - 90 g/m <sup>2</sup> (21 - 24 lb. Bond)	91 - 105 g/m <sup>2</sup> (25 - 28 lb. Bond)
A4, B5, LT	50 sheets	30 sheets	30 sheets
A3, A4-R, B4, FOLIO, LD, LG, LT-R, COMP	30 sheets	15 sheets	15 sheets

### Saddle Stitch Finisher MJ-1029 (When staples for 100-sheet stapling are used)

Paper size	Paper weight		
	64 - 80 g/m <sup>2</sup> (17 - 20 lb. Bond)	81 - 90 g/m <sup>2</sup> (21 - 24 lb. Bond)	91 - 105 g/m <sup>2</sup> (25 - 28 lb. Bond)
A4, B5, LT	100 sheets	—	—
A3, A4-R, B4, FOLIO, LD, LG, LT-R, COMP	50 sheets	—	—

### Saddle Stitch Finisher MJ-1029 (When staples for 50-sheet stapling are used)

Paper size	Paper weight		
	64 - 80 g/m <sup>2</sup> (17 - 20 lb. Bond)	81 - 90 g/m <sup>2</sup> (21 - 24 lb. Bond)	91 - 105 g/m <sup>2</sup> (25 - 28 lb. Bond)
A4, B5, LT	50 sheets	30 sheets	30 sheets
A3, A4-R, B4, FOLIO, LD, LG, LT-R, COMP	30 sheets	15 sheets	15 sheets


### Notes

- 2 cover sheets can be added to paper whose weight is 64 to 256 g/m<sup>2</sup> (17 lb. Bond to 140 lb. Index). In this case, the number of sheets available shall include the 2 cover sheets.
- For the maximum number of sheets loadable on the tray, refer to the **Quick Start Guide**.


## Magazine sort / Saddle stitch

You can copy more than one original and bind them in a booklet format. This mode is called the magazine sort mode. Also you can have the copied booklet folded and stapled at its center. This mode is called the saddle stitch mode.


### Magazine sort mode



### Magazine sort & saddle stitch mode



### Saddle stitch mode



### Requirements for saddle stitching

Paper size	Paper weight *1	Maximum number of sheets available for saddle stitching *2	Maximum number of sets loadable on the saddle stitch tray *3
A3, A4-R, B4, LD, LT-R, LG	64 - 80 g/m <sup>2</sup> (17 - 20 lb. Bond)	15 sheets	11 - 15 sheets / 10 sets 6 - 10 sheets / 20 sets Less than 5 sheets / 25 sets
	81 - 105 g/m <sup>2</sup> (21 - 28 lb. Bond)	10 sheets	6 - 10 sheets / 15 sets Less than 5 sheets / 25 sets

\*1 When the paper weights are mixed, take the value of the heavier one.

\*2 1 cover sheet (64 to 256 g/m<sup>2</sup> (17 lb. Bond to 140 lb. Index)) can be added. In this case the number of sheets per set shall include the cover sheet.


\*3 When 1 cover sheet of 200 to 256 g/m<sup>2</sup> (110 to 140 lb. Index) is added to paper of 81 to 105 g/m<sup>2</sup> (21 to 28 lb. Bond), a maximum of 5 sets can be loaded on the saddle stitch tray.

#### Tip

When placing portrait originals in a landscape direction as shown on the right in the magazine sort mode or the magazine sort & saddle stitch mode, set the image direction function to ON on the EDIT menu.

Otherwise the originals will not be copied in the proper page order.

📖 P.116 "Image Direction"



The magazine sort mode can also be selected on the EDIT menu. If you select it on the EDIT menu, you can adjust the binding margin. For details, see the following page:

📖 P.97 "Magazine Sort Mode"

## 1 Place paper in the drawer(s).

### Note

Special paper such as OHP film or sticker labels is not applicable.

## 2 Select the desired paper size.

Sizes are available as follows:

**Magazine sort:** A3, A4-R, A5-R, B4, B5-R, LD, LT-R, LG, ST-R

**Magazine sort & saddle stitch, Saddle stitch:** A3, A4-R, B4, LD, LT-R, LG

## 3 Place the original(s).


When placing the originals on the RADF, place them according to the illustration on the previous page.

When placing the originals on the original glass, place them in the following order:


**Magazine sort, Magazine sort & saddle stitch:** Place the first page of the original first.

**Saddle stitch:** For example, if the total number of pages is 12, place pages 1 and 12 together, and then pages 2 and 11, then pages 10 and 3, then pages 4 and 9, then pages 8 and 5, then pages 6 and 7.

## 4 Press [FINISHING] on the touch panel.



## 5 Select the desired mode from [MAGAZINE SORT], [MAGAZINE SORT & SADDLE STITCH] and [SADDLE STITCH].



### Note

[MAGAZINE SORT & SADDLE STITCH] and [SADDLE STITCH] are selectable only when the Saddle Stitch Finisher (optional) is installed.

## 6 Select other copy modes as required, and then press the [START] button on the control panel.

## ■ Hole punch mode

You can punch copied paper when the Hole Punch Unit (optional) is installed on a finisher.

### Notes


- Paper whose size is any of A3, A4, A4-R, B4, B5, B5-R, FOLIO, LD, LG, LT, LT-R, ST-R and COMP, and whose weight is 64 to 256 g/m<sup>2</sup> (17 lb. Bond to 140 lb. Index) is available.
- Special paper such as OHP film or sticker labels is not applicable.

### 1 Place paper in the drawer(s).


When using bypass copying, be sure to set the paper size.

### 2 Place the original(s).

### 3 Press [FINISHING] on the touch panel.



### 4 Press [HOLE PUNCH].



### 5 Select other copy modes as required, and then press the [START] button on the control panel.

## ■ Inserter mode

You can add a cover sheet previously created or insert a color page at a specified position using the Inserter (optional). Also, you can set paper on the Inserter to only have sheets stapled, hole-punched and stitched without making copies. This section explains how to set paper on the Inserter, how to only staple, hole-punch and stitch sheets without performing copying. See the following page for how to insert a cover sheet and a color page at a specified position.

📖 P.130 "Inserter"

## □ Placing paper on the Inserter

The following paper can be set on the Inserter.

Paper size	A3, A4, A4-R, B4, B5, FOLIO, LD, LG, LT, LT-R, COMP
Media type *1	Plain paper: 64 - 80 g/m <sup>2</sup> (17 - 20 lb. Bond) Thick paper: 81 - 256 g/m <sup>2</sup> (21 lb. Bond - 140 lb. Index) Recycled paper Special paper (e.g. OHP film, color paper) *2
Maximum number of sheets can be set	64 - 80 g/m <sup>2</sup> (17 - 20 lb. Bond): 100 sheets 81 - 256 g/m <sup>2</sup> (21 lb. Bond - 140 lb. Index): Less than 12 mm (0.47") in paper height (less than 7 mm (0.28") in case of special paper)

\*1 Note that some types of paper may not be applicable for the Inserter due to their paper qualities, even if you are using the paper listed above.

\*2 Contact a Toshiba-product distributor for details of the special paper available.

### Note

There are some restrictions for stapling or saddle stitching the paper set on the Inserter. See the following pages for details.

- Stapling: 📖 P.66 "Maximum number of sheets available for stapling"
- Saddle Stitching: 📖 P.67 "Magazine sort / Saddle stitch"



## 1 Place paper on the Inserter tray with its face up. Align the side guides with the paper width.

The start lamp of the Inserter lights.

### Notes

- Be sure that the height of the paper placed on the Inserter does not exceed the line indicated on the side guide.
- Sheets of different sizes cannot be set together.
- Match the size and direction of the paper to be set on the Inserter with those of the original or paper in the paper source.

If the paper size is large, extend the tray.






## □ Stapling and hole punching the sheets without making copies

You can place paper on the Inserter and only staple, hole punch or stitch the sheets without making copies. This is useful when you forget to perform the finishing process after making copies.

### 1 Place paper on the Inserter.

📖 P.70 “Placing paper on the Inserter”

When performing saddle stitching, place paper so that the cover or back cover sheet will be at the bottom.




3

### 2 Perform settings of stapling and hole punching.

For stapling or saddle stitching, press the stapling button. The lamp corresponding to the selected staple mode lights. Press the stapling button to switch the staple mode.

For hole punching, press the hole punch button. The hole punch lamp lights.




#### Tips

- Saddle stitching is available only when the Saddle Stitch Finisher (optional) is installed.
- The hole punch mode can be used together with the staple mode, not with the saddle stitch mode.

### 3 Press the start button on the Inserter.


The operation starts. The start lamp blinks during operation and all the lamps go off when it has finished.




## Duplex Copying

You can copy a 1-sided original to a 2-sided copy or vice versa, or copy a 2-sided original to a 2-sided copy. This is useful when you want to save the paper, or when you want to copy a book-type original maintaining the same page order.


### 1-sided original -> 1-sided copy (📖 P.73)




### 2-sided original -> 1-sided copy (📖 P.73)




### 1-sided original -> 2-sided copy (📖 P.74)



### 2-sided original -> 2-sided copy (📖 P.74)



### Book-type original -> 2-sided copy (📖 P.75)



#### Note


Use plain paper, THICK 1, THICK 2 or THICK 3 for duplex copying.

## ■ Making a 1-sided copy


### Tip

When you copy 2-sided portrait originals which open to the left/right on only 1 side of the paper, use the image direction function on the EDIT menu so that all the copied paper will exit in the proper direction.


📖 P.116 "Image Direction"



- 1 Place paper in the drawer(s).**  
When using bypass copying, be sure to set the paper size.
- 2 Place the original(s).**
- 3 Press [2-SIDED] on the touch panel.**



- 4 Select the desired mode.**  
[1→1 SIMPLEX]: 1-sided original to 1-sided copy  
[2→1 SPLIT]: 2-sided original to 1-sided copy




- 5 Select other copy modes as required, and then press the [START] button on the control panel.**

## ■ Making a 2-sided copy


### Tip

If 1-sided portrait originals have been placed in a landscape direction and you copy them on both sides of the paper, copied sheets are usually in the open to top/bottom direction. You can make copies in the open to left/right direction with the image direction function.


📖 P.116 “Image Direction”



- 1 Place paper in the drawer(s).**  
When using bypass copying, be sure to set the paper size.
- 2 Place the original(s).**
- 3 Press [2-SIDED] on the touch panel.**



- 4 Select the desired mode.**  
[1 → 2 DUPLEX]: 1-sided original to 2-sided copy  
[2 → 2 DUPLEX]: 2-sided original to 2-sided copy



- 5 Select other copy modes as required, and then press the [START] button on the control panel.**  
When placing the original on the original glass, follow steps 6 and 7 on 📖 P.28 “Basic copying procedure”.


## ■ Making a 2-sided copy from a book-type original

You can make 2-sided copies from book-type originals such as books or catalog as in the same page order.


Tip

A4, B5 and LT sizes are applicable.


- 1 Place paper in the drawer(s).**  
When using bypass copying, be sure to set the paper size.
- 2 Press [2-SIDED] on the touch panel.**




- 3 Press [BOOK → 2] on the touch panel.**



#### 4 Select the book copying type.




Example: If pages 2 to 6 of a book which opens to the left are to be copied, select [LEFT -> LEFT].



#### 5 Press the drawer button corresponding to the desired paper size.

Only A4, B5 and LT sizes are applicable.




#### 6 Select other copy modes as required.

If the copy needs a binding space, select the book margin mode on the EDIT menu.

P.87 "Creating bookbinding margin"

#### 7 Place the original on the original glass.

Place the original with its bottom toward you, matching its center to the yellow indicator under the original glass.




**⚠ CAUTION**

Do not place any heavy objects (4 kg (9 lb.) or over) on the original glass and do not press on it with force.

Breaking the glass could injure you.

**8 Press the [START] button on the control panel. Once the pages are scanned, set the next ones on the original glass.**

Repeat this step until all the desired pages have been scanned. If the last page is a single page, press [COPY FINAL PAGE] on the touch panel, and then press the [START] button on the control panel to start scanning. The scanned pages will be copied.

**9 When all the pages have been scanned, press [FINISHED].**

The scanned pages will be copied.

**Tip**

Even if you do not press [FINISHED], copying will start by means of the automatic function clear.

## Performing Copy & File

With the Copy & File function, you can store the copied data in the share folder of the hard disk of this equipment or a specified PC on a network. The data can be stored in any of PDF, TIFF and XPS formats.

### Notes


- The “COPY & FILE” function is available only when the Scanner Kit or Printer/Scanner Kit (both optional) is installed.
- Scanned data are stored at the resolution of 600 dpi only. The data stored with this function are suited for printing but not for being imported as an image into your PC. To obtain the optimal image quality for importing, it is recommended to store the data with the Scan to File function of this equipment.
- The network administrator must make settings for Copy & File in advance. For details, refer to the **TopAccess Guide**.
- It is recommended to back up the data stored in the share folder.

### Tip


You can store data in an e-Filing box with the Store to e-Filing function. For details, refer to the **e-Filing Guide**.

**1** Place the original(s).

**2** Press [STORAGE] on the touch panel.




**3** Press [COPY & FILE] on the touch panel.





#### 4 Press the necessary buttons for entering information about the data to be stored. Then press [OK].



**FILE NAME:** Press this to display the on-screen keyboard. Then enter the file name within 45 letters.

**MFP LOCAL:** Press this to store the data into the share folder of this equipment.

**REMOTE 1, REMOTE 2:** Press either of them to store the data into the share folder of a PC that is connected with this equipment via a network.

#### Notes

- You can select up to 2 of [MFP LOCAL], [REMOTE 1] and [REMOTE 2]. You can cancel the selected item by pressing the same button again.
- When a user who has the privilege of changing the setting of [REMOTE 1] and [REMOTE 2] has pressed either of them, the menu for specifying a directory appears. In this case, see the following page to specify the directory:  
[P.80 "Setting share folder"](#)

**PDF / TIFF / XPS:** These are file formats in which the data are stored. Select one of them.

**MULTI / SINGLE:** These are for selecting whether the data are stored as a multiple page file or a single page file. If you select "MULTI", all the scanned data will be stored as one file. If you select "SINGLE", a folder is created and each page of the scanned data will be stored individually as one file in the folder.

#### 5 Press the [START] button on the control panel.


When the original is placed on the RADF (Reversing Automatic Document Feeder), copying and storing start simultaneously.

When the original is placed on the original glass, follow the procedure below.

#### 6 Place the next original on the original glass, and then press the [START] button on the control panel.

Repeat this step until the scanning of all the originals is finished.

#### 7 When all have been scanned, press [FINISHED] on the touch panel.




Copying and storing start.

## ■ Setting share folder

When a user who has the privilege of setting a share folder has pressed [REMOTE 1] or [REMOTE 2], the menu for specifying a directory appears.

The setting items differ depending on the file transfer protocol to be used. FTP, SMB, NetWare IPX/SPX and NetWare TCP/IP are selectable for a file transfer protocol.

### FTP



When you press any of the buttons below, the on-screen keyboard appears. Enter with the buttons on the touch panel or the digital keys on the control panel. When you finish the entry, press [OK].

**SERVER NAME:** Press this to enter the IP address of FTP server. For example, if the data should be transferred to an FTP folder ftp://10.10.70.101/user01/scan/, key in "10.10.70.101".


**NETWORK PATH:** Press this to enter a network path to an FTP folder where the data are to be stored. For example, if the data should be transferred to an FTP folder ftp://10.10.70.101/user01/scan/, enter "user01\scan".

**LOGIN USER NAME:** Press this to enter a user name to login to the FTP server. Enter this as required.

**PASSWORD:** Press this to enter a password to login to the FTP server. Enter this as required.

**COMMAND PORT:** Press this to key in a command port number for executing commands. Normally "-" is entered in this field and it means a port number set by the administrator will be used. Change this only when you want to use any other port number.

### SMB



When you press any of the buttons below, the on-screen keyboard appears. Enter with the buttons on the touch panel or the digital keys on the control panel. When you finish the entry, press [OK].

**NETWORK PATH:** Press this to enter a network path to the folder where the data are to be stored.


**LOGIN USER NAME:** Press this to enter a user name to access the network folder. Enter this as required.

**PASSWORD:** Press this to enter a password to access the network folder. Enter this as required.

#### Tip

If you selected [SMB], the settings for [SERVER NAME] and [COMMAND PORT] are not required.

## NetWare IPX/SPX / NetWare TCP/IP



3

When you press any of the buttons below, the on-screen keyboard appears. Enter with the buttons on the touch panel or the digital keys on the control panel. When you finish the entry, press [OK].

**SERVER NAME:** When you selected [NetWare IPX], enter either the server name of NetWare server or Tree/Context (if NDS is useable). When you selected [NetWare IP], enter the IP address of NetWare server.

**NETWORK PATH:** Press this to enter a network path to a NetWare server folder where the data are to be stored. For example, if the data should be transferred to a folder "sys\scan" of NetWare server, enter "\sys\scan".

**LOGIN USER NAME:** Press this to enter a user name to login NetWare server. Enter this as required.

**PASSWORD:** Press this to enter a password to login NetWare server. Enter this as required.



# 4



## EDITING FUNCTIONS



This chapter describes how to use various copying functions on the EDIT menu.


<b>Displaying EDIT Menu</b> .....	<b>84</b>
<b>Image Shift</b> .....	<b>85</b>
Creating top/bottom margin or left/right margin .....	85
Creating bookbinding margin .....	87
<b>Edge Erase</b> .....	<b>89</b>
<b>Book Center Erase</b> .....	<b>90</b>
<b>Dual Page</b> .....	<b>92</b>
<b>2IN1 / 4IN1</b> .....	<b>94</b>
<b>Magazine Sort Mode</b> .....	<b>97</b>
<b>Image Editing</b> .....	<b>99</b>
Trimming / Masking .....	99
Mirror image / Negative/Positive reversal.....	102
<b>XY Zoom</b> .....	<b>103</b>
<b>Cover Sheet</b> .....	<b>104</b>
<b>Sheet Insertion</b> .....	<b>107</b>
<b>Time Stamp</b> .....	<b>110</b>
<b>Page Number</b> .....	<b>111</b>
<b>Job Build</b> .....	<b>113</b>
<b>Image Direction</b> .....	<b>116</b>
<b>Book - Tablet</b> .....	<b>118</b>
<b>ADF -&gt; SADF</b> .....	<b>119</b>
<b>Tab Paper</b> .....	<b>121</b>
Preparing an original to copy on the tab paper.....	121
Setting tab paper .....	121
TAB EXTENSION .....	123
COPY ON TAB .....	124
BLANK TAB INSERT .....	126
COPIED TAB INSERT .....	128
<b>Inserter</b> .....	<b>130</b>

## Displaying EDIT Menu

You can display the EDIT menu by pressing the [EDIT] tab on the touch panel when you want to use various editing functions.




The EDIT menu has 2 pages. To switch the pages, press  or .



## Image Shift

You can create a binding margin by shifting an image to the left, right, top or bottom of the copy paper. This function is called "image shift". It is useful when you wish to punch or staple a stack of paper after copying it. With this function you can easily make a binding margin when you copy a book-type original on both sides of the paper.




### Tip

You can make a binding margin in the combinations as follows:


- Top/bottom margin and left/right margin
- Top/bottom margin and bookbinding margin

### ■ Creating top/bottom margin or left/right margin

- 1 Place paper in the drawer(s).**  
When using bypass copying, be sure to set the paper size.
- 2 Place the original(s).**
- 3 Press [IMAGE SHIFT] on the EDIT menu.**




- 4 Select the type of binding margin.**



## 5 Adjust the width of the binding margin.


- 1) Press [FRONT MARGIN] and adjust the binding margin width on the front side using [▼ 2 mm] and [▲ 100 mm].
- 2) Press [BACK MARGIN] and adjust the binding margin width on the back side using [▼ 2 mm] and [▲ 100 mm].
- 3) Press [OK].



### Tip

Note that a left/right binding margin will be created on the opposite side on the back side of paper in duplex copying. (For example, when a binding margin is created on the right of the front side of the paper, it will be created on the left of the back side.)

## 6 Press [OK].



## 7 Select other copy modes as required, and then press the [START] button on the control panel.




## ■ Creating bookbinding margin


You can easily make a binding margin when you copy a book-type original on both sides of the paper.

📖 P.75 “Making a 2-sided copy from a book-type original”

### 1 Press [IMAGE SHIFT] on the EDIT menu.




### 2 Press [BOOK].




### 3 Adjust the width of the binding margin.

- 1) Press either [▼ 2 mm] (0.08") or [▲ 30 mm] (1.18").
- 2) Press [OK].




## 4 Press [OK].



Select the “Book-type original -> 2-sided copy” mode as well.  
📖 P.75 “Making a 2-sided copy from a book-type original”

## Edge Erase


You can whiten the edge of the copied image when a shadow-like dark part appears on it. This function is called "edge erase". It is useful when you want to make the copied image neat and clear if the edge of the original is dirty or torn.




### Tip

Only standard size originals are applicable.

- 1 Place paper in the drawer(s).**  
When using bypass copying, be sure to set the paper size.
- 2 Place the original(s).**
- 3 Press [EDGE ERASE] on the EDIT menu.**




- 4 Adjust the width of the part to be erased.**
  - 1) Press either [▼ 2 mm] (0.08") or [▲ 50 mm] (1.97").
  - 2) Press [OK].




- 5 Select other copy modes as required, and then press the [START] button on the control panel.**

## Book Center Erase


You can whiten the center of the copied image when a shadow-like part appears on it. This function is called “book center erase”. It is useful when you copy book-type originals.



- 1 Place paper in the drawer(s).**  
When using bypass copying, be sure to set the paper size.
- 2 Select the drawer for the desired paper size.**




- 3 Press [BOOK CENTER ERASE] on the EDIT menu.**



#### 4 Adjust the width of the part to be erased.


- 1) Press either [▼ 2 mm] (0.08") or [▲ 50 mm] (1.97").
- 2) Press [OK].



4

#### 5 Place the original on the original glass.

Place the original with its bottom toward you, matching its center to the yellow indicator under the original glass.



#### ⚠ CAUTION


Do not place any heavy objects (4 kg (9 lb.) or over) on the original glass and do not press on it with force.

Breaking the glass could injure you.

#### 6 Select other copy modes as required, and then press the [START] button on the control panel.

## Dual Page


You can copy the 2 facing pages of a book-type original or 2 original sheets placed side by side onto 2 separate sheets of paper or on both sides of 1 sheet of paper. This function is called “dual page”. You do not have to shift the original on the original glass.



### Tip

Only A4, B5 and LT sizes are applicable.


- 1** Place paper in the drawer(s).
- 2** Press [DUAL PAGE] on the EDIT menu.



- 3** Press [1 SIDE] or [2 SIDE].

**1 SIDE:** Copying the 2 facing pages of the original to only 1 side of 2 separate sheets of paper

**2 SIDE:** Copying the 2 facing pages of the original to 2 sides of 1 sheet of paper



- 4** Select other copy modes as required.

You can select “image shift” as well.


P.85 “Creating top/bottom margin or left/right margin”

## 5 Press the [BASIC] tab to display the BASIC menu, and then select A4, B5 or LT as the copy paper size.

When using bypass copying, be sure to set the paper size.

## 6 Open the desired page of the original and place it on the original glass.

Place the original with its bottom toward you, matching its center to the yellow indicator under the original glass.



4


### ⚠ CAUTION

**Do not place any heavy objects (4 kg (9 lb.) or over) on the original glass and do not press on it with force.**

Breaking the glass could injure you.

## 7 Press the [START] button on the control panel. When the scanning of the opened pages is finished, open the next pages and place them.

Repeat this procedure until all the desired pages have been scanned. If the last page is a single page, press [COPY FINAL PAGE] on the touch panel, and then press the [START] button on the control panel to start scanning. The scanned pages will be copied.



## 8 When all the pages have been scanned, press [FINISHED].


The scanned pages will be copied.

## 2IN1 / 4IN1


You can copy 2 or 4 originals to 1 sheet of paper by shrinking them. This function is called “2IN1” or “4IN1”. If you use this function together with duplex copying, you can make a total of 8 images on 1 sheet of paper.

The illustrations below show how you can arrange the images.


### 2IN1




### 4IN1



### 2IN1 & duplex copying (a: side 1, b: side 2)



### 4IN1 & duplex copying (a: side 1, b: side 2)






## 1 Place paper in the drawer(s).

When using bypass copying, be sure to set the paper size.

### Tip


If you select paper of a different size to that of the original, press [ZOOM] on the BASIC menu. Then select the desired paper size and press [AMS] in the menu shown below.



4

## 2 Place the original(s).


## 3 Press [2IN1 / 4IN1] on the EDIT menu.



## 4 Perform 2IN1 / 4IN1 setting.

**NUMBER OF PAGES PER SHEET:** If you want to copy 2 originals on 1 page, select [2IN1]. If you want 4 on 1 page, select [4IN1].

**2-SIDED:** Select from [1->1 SIMPLEX], [1->2 DUPLEX], [2->2 DUPLEX] or [2->1 SPLIT].



Press [OK] after you have selected all the necessary items.

---

**5 Select other copy modes as required, and then press the [START] button on the control panel.**

When the originals are placed on the RADF, scanning and copying start. When they are placed on the original glass, follow steps 6 and 7.

**6 Place the next original, and then press the [START] button on the control panel.**

Scanning of the next original starts. The scanning also starts when you press [YES] on the touch panel and then the [START] button on the control panel. If you have more than one original, repeat this step until the scanning of all the originals is finished.


**7 When the scanning of all the originals is finished, press [FINISHED] on the touch panel.**

Copying starts.


## Magazine Sort Mode

You can copy more than one original in the book-type page order. This mode is called the magazine sort mode. Also you can do this as well as fold and staple the copied sheets at their center. This mode is called the magazine sort & saddle stitch mode.

### Magazine sort mode



### Magazine sort & saddle stitch mode



The magazine sort mode can also be selected on the BASIC menu. For details, see the following page:

P.67 “Magazine sort / Saddle stitch”

### 1 Place paper in the drawer(s).

Sizes are available as follows:

**Magazine sort:** A3, A4-R, A5-R, B4, B5-R, LD, LG, LT-R, ST-R

**Magazine sort & saddle stitch:** A3, A4-R, B4, LD, LG, LT-R

### 2 Select the paper size.

Drawer: P.48 “Automatic Paper Selection (APS)”


Bypass tray: P.36 “Bypass Copying”

### 3 Place the original(s).


#### Tip

When placing portrait originals in a landscape direction as shown on the right in the magazine sort mode or the magazine sort & saddle stitch mode, set the image direction function to ON on the EDIT menu. Otherwise the originals will not be copied in the proper page order.

P.116 “Image Direction”




#### 4 Press [MAGAZINE SORT] on the EDIT menu.



#### 5 Set the saddle stitch mode and the binding margin width as required.

- 1) When setting the saddle stitch mode, press [STAPLE ON]. If not required, press [STAPLE OFF].
- 2) Press either [▼ 2 mm] (0.08") or [▲ 30 mm] (1.18") to adjust the binding margin width.
- 3) Press [OK].



#### Tip

For the maximum number of sheets available for saddle stitching, see the following page:  
 P.67 "Magazine sort / Saddle stitch"

#### 6 Select other copy modes as required, and then press the [START] button on the control panel.

## Image Editing

You can select the various editing functions shown below for scanned images.

**Trimming:** You can select a certain area of an original and copy only the selected area.


**Masking:** You can mask a certain area of an original and copy only the unmasked area.

**Mirror image:** You can reverse a page like a mirror.

**Negative/Positive reversal:** You can reverse the black-and-white of a page.

### ■ Trimming / Masking

You can select the desired area of an original and copy only the selected area (trimming). You can also mask the desired area of an original and copy only the unmasked area (masking). On both functions you can select up to 4 areas on 1 original. The selected area should be in a rectangle.




#### Tips

- Only standard size originals are applicable.
- Note that the entire image of the selected area may not be copied if you do not select proper sizes for the original and copy paper.


### 1 Place paper in the drawer(s).

When using bypass copying, be sure to set the paper size.

### 2 Press [EDITING] on the EDIT menu.




### 3 Press [TRIM] or [MASK].



### 4 Place the original on the original glass with its face up.

Place it with its bottom toward you. Match its top left corner against that of the original glass so that the original will be aligned with the original scales.



#### ⚠ CAUTION

Do not place any heavy objects (4 kg (9 lb.) or over) on the original glass and do not press on it with force.

Breaking the glass could injure you.

### 5 Read the following 4 values to specify the area using the left and top scales on the original glass.


**X1:** From the top left to the left edge of the selected area

**X2:** From the top left to the right edge of the selected area

**Y1:** From the top left to the upper edge of the selected area


**Y2:** From the top left to the lower edge of the selected area

Note that the marks of the original scales have a 2 mm (0.08") pitch.




## 6 Key in the read values.

- 1) Press [X1], [X2], [Y1] and [Y2], and then key in the read values correspondingly.
- 2) You can specify up to 4 areas on 1 page. When you want to specify more than one area, press  $\wedge$  or  $\vee$  to switch the area, and then key in the values correspondingly.
- 3) Press [OK] after you have specified all the areas.



## 7 Place the original again on the original glass with its face down.

Place it with its bottom toward you. Match its top left corner against that of the original glass.




## 8 Select other copy modes as required, and then press the [START] button on the control panel.

## ■ Mirror image / Negative/Positive reversal


You can reverse a page like a mirror (mirror image), or you can reverse the black-and-white of a page (negative/positive reversal).



- 1 Place paper in the drawer(s).**  
When using bypass copying, be sure to set the paper size.
- 2 Place the original(s).**
- 3 Press [EDITING] on the EDIT menu.**



- 4 Press [MIRROR] or [NEG/POS].**




- 5 Select other copy modes as required, and then press the [START] button on the control panel.**



## XY Zoom


You can change the reproduction ratio in both vertical and horizontal directions separately. This function is called “XY zoom”.



### Note


The reproduction ratio is changeable from 25 to 400%. However when the original is placed on the RADF (Reversing Automatic Document Feeder), this range is 25 to 200%.

- 1 Place paper in the drawer(s).**  
When using bypass copying, be sure to set the paper size.
- 2 Place the original(s).**
- 3 Press [XY ZOOM] on the EDIT menu.**



### 4 Set the reproduction ratio in both vertical and horizontal directions.

- 1) Press [X], and then press either [▼ 25%] or [▲ 400%] for a horizontal direction.
- 2) Press [Y], and then press either [▼ 25%] or [▲ 400%] for a vertical direction.
- 3) Press [OK].




- 5 Select other copy modes as required, and then press the [START] button on the control panel.**


## Cover Sheet

You can add a special type of paper such as colored paper as a front cover sheet or a back cover sheet. This function is called "cover sheet". The cover sheet mode has the following 4 types:


**TOP BLANK:** Adds a blank sheet as a front cover.




**TOP COPIED:** Adds a copied sheet as a front cover.



**BOTH BLANK:** Adds 2 blank sheets as a front cover and a back cover.



**TOP COPIED BACK BLANK:** Adds a copied sheet as a front cover and a blank sheet as a back cover.




### 1 Place the paper for the cover sheets.

Place it on the bypass tray or in a drawer previously set for cover sheets. The paper for the cover sheets must be placed in a different paper source than normal paper.



#### **When the Inserter (optional) is installed in the equipment**

For using [TOP BLANK] or [BOTH BLANK] in the cover sheet modes, paper for cover sheets can be set on the Inserter.

You can use [TOP BLANK] or [BOTH BLANK] with a function for inserting a back cover sheet turned down, using the [INSERTER] function.

 P.130 "Inserter"

## Notes


- When placing paper for cover sheets in a drawer, set the paper type (“COVER”), size and thickness for the drawer.  
 P.18 “Setting paper type”
- When placing paper for cover sheets on the bypass tray, set the size and thickness.  
 P.36 “Bypass Copying”
- Place the paper for cover sheets of the same size as normal paper in the same direction.

## 2 Place the normal paper in the drawer(s).


## 3 Place the original(s).

When placing them on the original glass, they must be placed from the first page.

## 4 Press [COVER SHEET] on the EDIT menu.



## 5 Select the desired cover sheet mode.




## Tip

When you select [TOP COPIED] or [TOP COPIED BACK BLANK] and [1->2 DUPLEX] (duplex copying) together, the front cover will be a 1-sided copy.

**6 Press the [BASIC] tab to display the BASIC menu. Then select a drawer in which normal paper is placed (not the one for the cover sheets).**

You must place the normal paper of the same size and direction as that for the cover sheets in advance.



**7 Select other copy modes as required, and then press the [START] button on the control panel.**

When the originals are placed on the RADF, scanning and copying start.  
When they are placed on the original glass, follow steps 8 and 9.

**8 Place the next original, and then press the [START] button on the control panel.**

Scanning of the next original starts. The scanning also starts when you press [YES] on the touch panel and then press the [START] button on the control panel. Repeat this procedure until the scanning of all the originals is finished.


**9 When the scanning of all the originals is finished, press [FINISHED] on the touch panel.**

Copying starts.


## Sheet Insertion

You can insert a special type of paper such as colored paper at the desired page. This function is called “sheet insertion”. You can insert up to 2 types of sheets for a total of 50 pages. The sheet insertion mode has the following 2 types:

**COPIED:** Inserts a copied sheet, replacing the specified page.



**BLANK:** Inserts a blank sheet before the specified page.



### 1 Place the paper for sheet insertion.

Place it on the bypass tray or in a drawer previously set for insertion sheets. The paper for the insertion sheets must be placed in a different paper source than normal paper.

#### When the Inserter (optional) is installed in the equipment

For using [BLANK] in the sheet insertion modes, paper for sheet insertion can be set also on the Inserter. You can use [BLANK] in combination with a function for inserting front and back cover sheets with the [INSERTER] function.

📖 P.130 “Inserter”

#### Notes


- When placing paper for insertion sheets in a drawer, set the paper type (“INSERT 1” or “INSERT 2”), size and thickness for the drawer.  
📖 P.18 “Setting paper type”
- When placing paper for insertion sheets on the bypass tray, set the size and thickness.  
📖 P.36 “Bypass Copying”
- Place the paper for insertion sheets of the same size as normal paper in the same direction.

### 2 Place the normal paper in the drawer(s).


### 3 Place the original(s).

When placing them on the original glass, they must be placed from the first page.

#### 4 Press [SHEET INSERTION] on the EDIT menu.




#### 5 Press either [COPIED] or [BLANK].



#### 6 Select the page where the insertion sheets will be inserted.

- 1) Select the type of the insertion sheets ([INSERT SOURCE 1] or [INSERT SOURCE 2]).
- 2) Key in page numbers (1 to 2000) where the insertion sheets will be inserted, and then press [SET]. Repeat steps 1) and 2) if you want to insert sheets at more than one page.
- 3) Press [OK] after you have keyed in the page numbers.




#### Tips

- If you selected [COPIED] in step 5, the selected page will be replaced with a copied insertion sheet. If you selected [BLANK], a blank insertion sheet will be inserted before the selected page.
- Up to 50 pages in total can be selected for [INSERT SOURCE 1] and [INSERT SOURCE 2].

**7 Press the [BASIC] tab to display the BASIC menu. Then select the drawer in which normal paper is placed (not the one for sheet insertion).**

You must place the normal paper of the same size and direction as that for the insertion sheets in advance.



4

**8 Select other copy modes as required, and then press the [START] button on the control panel.**

When the originals are placed on the RADF, scanning and copying start.  
When they are placed on the original glass, follow steps 9 and 10.

**9 Place the next original, and then press the [START] button on the control panel.**


Scanning of the next original starts. The scanning also starts when you press [YES] on the touch panel and then the [START] button on the control panel. Repeat this procedure until the scanning of all the originals is finished.

**10 When the scanning of all the originals is finished, press [FINISHED] on the touch panel.**  
Copying starts.

## Time Stamp

You can add the date and time on the copied paper.


Printed at the bottom  
of a portrait copy




Printed at the top  
of a landscape copy



- 1** Place paper in the drawer(s).
- 2** Place the original(s).
- 3** Press [TIME STAMP] on the EDIT menu.



- 4** Select the direction and position of the time stamp.
  - 1) Select the direction ([SHORT EDGE] or [LONG EDGE]).
  - 2) Select the position ([UPPER] or [LOWER]).
  - 3) Press [OK].




- 5** Select other copy modes as required, and then press the [START] button on the control panel.




## Page Number

You can add a page number on the copied paper.




- 1 Place paper in the drawer(s).
- 2 Place the original(s).
- 3 Press [PAGE NUMBER] on the EDIT menu.




### 4 Select the direction and position of a page number.

- 1) Select the direction ([SHORT EDGE] or [LONG EDGE]).
- 2) Select the position ([TOP LEFT], [TOP CENTER], etc.).
- 3) If you want to specify the page number to start with, press  and go to step 5. Otherwise, press [OK] and go to step 6.



## 5 Specify the page number you want to start with.


- 1) Key in the page number.
- 2) Press [OK].



## 6 Select other copy modes as required, and then press the [START] button on the control panel.

## Job Build

You can scan several stacks of originals whose settings are individually different, and then copy or store them in one operation. This function is called "job build". For example, news clips (in the TEXT mode) and photographs in magazines (in the PHOTO mode) in A3 size and photographs in A4 size can be scanned in the optimal settings for each, and copied in one operation.




4

### Notes


- Up to 2000 pages of originals can be copied in one operation. There is no limit for the number of jobs.
- Some settings are not available for job build, and some settings for the first job will be applied to all of the other jobs. See the table below before setting job build.

Settings not available	Settings applied for all jobs	Settings changeable for each job
Automatic Paper Selection BOOK -> 2 (Book-type original -> 2-sided copy) Editing XY zoom Cover sheet Sheet insertion Magazine sort Magazine sort & saddle stitch 2IN1 / 4IN1 Tab paper Inserter	e-Filing / File Mixed-size originals Copy paper size Finishing mode Image shift Book center erase Time stamp Page number Image direction Book - tablet	Reproduction ratio Automatic Magnification Selection (Default setting for job build) Original size Original mode Simplex/Duplex copying settings other than Book-type original -> 2-sided copy (1->1 SIMPLEX, 2->1 SPLIT, 1->2 DUPLEX, 2->2 DUPLEX) Background adjustment Sharpness Edge erase Dual page Document feeder (Feeding mode)


### 1 Press [JOB BUILD] on the EDIT menu.



## 2 Press [OK].



Job build is now set and the message below appears.



## 3 Place the first stack of originals, and then select settings.

### Tips


- When placing the original on the original glass, remember that 1 page is equal to 1 job.
- When placing mixed-size originals on the RADF, see the following page:  
 P.50 "Copying mixed-size originals in one operation"
- If you want to use a particular drawer, select it.

### Notes

- Press [SETTINGS] on the touch panel to confirm the current settings.
- If you want to change the settings, press the [FUNCTION CLEAR] button on the control panel, and then restart the procedure from step 1.

#### 4 Press the [START] button on the control panel.

Scanning starts. When the scanning of all the originals is finished, the message below appears.




#### 5 Place the next stack of originals, and then select the settings.

Repeat steps 4 and 5 until all the desired pages have been scanned.

##### Note

If you do not change any settings, those for the last job will be applied.

#### 6 When the scanning of all the originals is finished, change the number of copy sets as required. Then press [JOB FINISH] on the touch panel.




Copying starts. If any storing function is set, storing also starts.


## Image Direction

When you make 1-sided portrait originals to 2-sided copy by placing them in a landscape direction, normally the copied pages are “open to top”. With this function you can make them “open to left”. This function is called “image direction”. When you make 2-sided “open to left” portrait originals to 1-sided copy, normally the copied pages exit in a different direction alternately. With this function, you can make them all exit in the same direction.


### 1-sided portrait original (placed in a landscape direction) -> 2-sided copy



### 2-sided “open to left” portrait original -> 1-sided copy



- 1** Place paper in the drawer(s).
- 2** Place the original(s).
- 3** Set duplex copying setting.  
 P.72 “Duplex Copying”
- 4** Press [IMAGE DIRECTION] on the EDIT menu.



## 5 Press [OK].





Image direction is now set.


## 6 Select other copy modes as required, and then press the [START] button on the control panel.

## Book - Tablet


As for the directions of originals or copied images, “open to left” is called “book” and “open to top” is called “tablet”. With this function you can make 2-sided originals to 2-sided copy, rotating only the back side of the copied page by 180 degrees, namely, you can copy “book” originals to “tablet” copy, or vice versa.



- 1 Place paper in the drawer(s).
- 2 Place the original(s).
- 3 Press [BOOK <->TABLET] on the EDIT menu.



- 4 Press [OK].



Book - tablet is now set.

- 5 Select other copy modes as required, and then press the [START] button on the control panel.



## ADF -> SADF

You can switch the feeding mode when the RADF (Reversing Automatic Document Feeder) is used, from “ADF” to “SADF”. The paper feeding mode has 2 types as follows:

**ADF (Continuous feed mode):** Feeds originals continuously when you press the [START] button on the control panel while originals are being placed on the RADF. This is useful when you make more than one copy in one operation. (Default setting)


**SADF (Single feed mode):** Feeds originals one by one automatically. This is useful when you usually only have 1 original.

### Note


When the single feed mode (SADF) is set, place originals one sheet at a time. If you place more than one original, the copied image may be skewed or the originals may jam.

4

- 1 Place paper in the drawer(s).
- 2 Press [ADF -> SADF] on the EDIT menu.



- 3 Press [OK].




The feeding mode is now set at “single feed mode”.

- 4 Select other copy modes as required.

## 5 Place the original(s) on the RADF one sheet at a time.

The original is pulled into the RADF automatically, and then the menu below appears.




Repeat step 5 if you have another original. The placed original will be pulled into the RADF automatically even if you do not press [YES] on the touch panel.

## 6 When the scanning of all the originals is finished, press [FINISHED].

### Tip

Even if you do not press [FINISHED], copying will start when the current operation is cleared by means of the automatic function clear.

 P.47 "Clearing the set functions"

## Tab Paper

Copying on the tab of tab paper and inserting tab paper in copying can be performed. There are the following 3 modes:

**COPY ON TAB:** Copying on the tab on the tab paper

**BLANK TAB INSERT:** Inserting blank tab paper at a specified page


**COPIED TAB INSERT:** Copying on the tab paper and inserting the copied tab paper at the specified pages



4

### ■ Preparing an original to copy on the tab paper

Prepare an original for making a copy on tab paper using [COPY ON TAB] or [COPIED TAB INSERT]. The index of the original is copied on the tab of tab paper by having the printing position shifted as follows. Use an A4/LT-original.



### ■ Setting tab paper

Set tab paper in a drawer other than the External Large Capacity Feeder or the bypass tray (the second drawer is recommended).


The setting order of tab paper is different between when setting it in the drawer and when setting it on the bypass tray.

#### Notes


- Only A4 and LT-size tab paper can be used.
- When an optional finisher is installed, use 5-tab or 8-tab paper.

#### □ Setting tab paper in a drawer


- 1 Pull out the drawer.
- 2 Insert the tab paper back guide into the slit of A4-TAB (LT-TAB) in the drawer.



### 3 Match the order of the tab paper with that of the originals.



### 4 Place the tab paper with its face down in the drawer.




### 5 Close the drawer.

### 6 Set [TAB] for the paper type of the drawer.


P.18 "Setting paper type"

## □ Setting tab paper on the bypass tray

### 1 Match the order of the tab paper with that of the originals.



### 2 Place the tab paper with its face on the bypass tray.




### 3 Set [TAB PAPER] for the paper type of the bypass tray.

P.37 "Bypass copying on standard size paper"


## TAB EXTENSION

Set the tab width and shift width of tab paper. These must be set before performing [COPY ON TAB], [BLANK TAB INSERT] or [COPIED TAB INSERT].

### 1 Press [TAB PAPER] on the EDIT menu.




### 2 Press [TAB EXTENSION].



### 3 Adjust the tab width and shift width.

- 1) Press [DRAWER] for setting tab paper in the drawer or [BYPASS FEED] for setting it on the bypass tray.
- 2) Press [TAB EXTENSION] to adjust the tab width using ▼ or ▲.
- 3) Press [SHIFT MARGIN] to adjust the shift width using ▼ or ▲.
- 4) Press [OK].



#### Tip

Though the initial value is set to 13 mm (0.5") for both the tab width and shift width, this can be changed. For details, refer to the *MFP Management Guide*.

**Range of the tab width and shift width**

The tab width and shift width can be set in the following ranges. They are different when the tab paper is set in the drawer and on the bypass tray.


	Tab width	Shift width
<b>Drawer</b>	12 - 17 mm (0.4" - 0.6")	0 - 30 mm (0 - 1.1")
<b>Bypass tray</b>	10 - 20 mm (0.4" - 0.7")	0 - 30 mm (0 - 1.1")

**Measuring the tab width and shift width on the original glass**


The tab width and shift width can be measured by the scale on the left and rear side of the original glass. The marks of the original scale have a 2 mm (0.08") pitch.

**Measuring the tab width**

Place tab paper on the original glass to measure the tab width.

**Measuring the shift width**

Place the original on the original glass to measure the shift width.

**■ COPY ON TAB**

The original is copied on the tab paper.

**Note**

Set the tab width and shift width using [TAB EXTENSION] in advance.

**1 Prepare and place the original to copy on the tab paper.**


📖 P.121 "Preparing an original to copy on the tab paper"

📖 P.121 "Setting tab paper"

**2 Place tab paper.**


📖 P.121 "Setting tab paper"

### 3 Press [TAB PAPER] on the EDIT menu.




4


### 4 Press [COPY ON TAB].



### 5 Press [OK].



## 6 Press [OK].



## 7 Select other copy modes as required, and then press the [START] button on the control panel.

### ■ BLANK TAB INSERT

Blank tab paper is inserted at the specified pages. Copying is not performed on the tab paper.

#### Note


Set the tab width using [TAB EXTENSION] in advance.

### 1 Place tab paper.

📖 P.121 "Setting tab paper"


### 2 Place the original(s).

### 3 Press [TAB PAPER] on the EDIT menu.






## 4 Press [BLANK TAB INSERT].



4

## 5 Set the pages to insert tab paper.


- 1) Key in the page number (1 to 2000) for inserting the tab paper, and then press [SET]. If more than one sheet of tab paper is inserted, repeat this procedure.
- 2) After the page number has finished being keyed in, press [OK].



### Tip

In [BLANK TAB INSERT], blank tab paper is inserted at the specified pages. Up to 50 sheets of tab paper can be inserted.

## 6 Press [OK].



- 7 Select other copy modes as required, and then press the [START] button on the control panel.

## ■ COPIED TAB INSERT

Tab paper is inserted at the specified pages and copying is performed also on the Tab paper.

### Note

Set the tab width and shift width using [TAB EXTENSION] in advance.

### 1 Prepare the original to copy on the tab paper.

📖 P.121 “Preparing an original to copy on the tab paper”


### 2 Place tab paper.

📖 P.121 “Setting tab paper”


### 3 Place the original(s).

Insert the original for the tab paper prepared in step 1 at the desired page of the other originals and place them.

### 4 Press [TAB PAPER] on the EDIT menu.




### 5 Press [COPIED TAB INSERT].



## 6 Set the pages to insert tab paper.


- 1) Key in the page number (1 to 2000) for inserting the tab paper, and then press [SET]. If more than one sheet of tab paper is inserted, repeat this procedure.
- 2) After the page number has finished being keyed in, press [OK].



### Tips

- In [COPIED TAB INSERT], a copy is made on tab paper and it is inserted at the specified pages. Up to 50 sheets of tab paper can be inserted.
- Check that the page number corresponds to the inserted page for tab paper in step 3.

## 7 Press [OK].



- 8 Select other copy modes as required, and then press the [START] button on the control panel.

## Inserter

You can insert the paper placed on the Inserter (optional) as a front or back cover sheet, or insert the paper at the specified pages. There are 3 types of sheet insertion as follows.

**FRONT COVER:** Inserting paper as a front cover sheet

**FRONT & BACK COVER:** Inserting paper as front and back cover sheets

**SHEET INSERT:** Inserting paper at the specified pages

### Tips


- [FRONT COVER] or [FRONT & BACK COVER] can be used in combination with [SHEET INSERT].
- In the [FRONT & BACK COVER], the sheet for the back cover can be inserted with its back side facing up. Refer to the *MFP Management Guide* for details.
- The inserted sheets are not copied in this function. If you want to make copies on them, use the cover sheet mode or sheet insertion mode. In that case, place them in the drawer or on the bypass tray of the equipment.
  - 📖 P.104 "Cover Sheet"
  - 📖 P.107 "Sheet Insertion"

### 1 Place paper for the insertion sheet on the Inserter.


📖 P.70 "Placing paper on the Inserter"

### 2 Place plain paper in the drawer.

### 3 Press [INSERTER] on the EDIT menu.




### 4 Press [PAPER TYPE].



### Tip


If [MEDIA TYPE] and [PAPER SIZE] are not displayed, place the paper on the Inserter correctly.

## 5 Select and press the type corresponding to the paper placed on the Inserter.




4

## 6 Press [PAPER SIZE].




## 7 Select and press the size corresponding to the paper placed on the Inserter.



## 8 Set the sheet insertion type.

- 1) Press [FRONT COVER], [FRONT & BACK COVER] or [SHEET INSERT].
- 2) If [SHEET INSERT] is selected, key in the desired page number (1 to 2000). To specify more than one page, press  $\uparrow$  or  $\downarrow$  to switch the sheet and repeat this procedure.
- 3) After you have finished the setting, press [OK].



### Tips

- [FRONT COVER] or [FRONT & BACK COVER] can be used in combination with [SHEET INSERT].
- In [SHEET INSERT], a blank sheet is inserted before the page specified. Up to 50 pages can be specified.

## 9 Select other copy modes as required, and then press the [START] button on the control panel.



# IMAGE ADJUSTMENT

This chapter describes the image adjustment functions of this equipment.

<b>Displaying IMAGE Menu .....</b>	<b>134</b>
<b>Using Image Adjustment Functions .....</b>	<b>135</b>
Background adjustment.....	135
Sharpness .....	136

## Displaying IMAGE Menu

You can display the IMAGE menu by pressing the [IMAGE] tab on the touch panel when you want to use various image adjustment functions.






## Using Image Adjustment Functions

### ■ Background adjustment

This function allows you to adjust the density of the original's background. It avoids the back side of a 2-sided original becoming visible on its front side.




#### Note


This mode cannot be used with the automatic density adjustment function.

📖 P.53 "Density Adjustment"

### 1 Press [BACKGROUND ADJUSTMENT] in the IMAGE menu.



### 2 Press [LIGHT] or [DARK] to adjust the density, and then press [OK].




#### Canceling background adjustment


- Move the indicator to the middle, and then press [OK].
- Press [RESET] and then [OK].

## Sharpness

This function allows you to emphasize or blur the outline of the image.




### 1 Press [SHARPNESS] in the IMAGE menu.



### 2 Press [SOFT] or [SHARP] to adjust the sharpness, and then press [OK].

When the sharpness level is adjusted to the [SOFT] side, the moire fringes on the printed photos, etc. are softened. If it is adjusted to the [SHARP] side, the letters and fine lines become sharper.



#### Canceling sharpness adjustment

- Move the indicator to the middle, and then press [OK].
- Press [RESET] and then [OK].

# TEMPLATES

This chapter describes how to use templates.


<b>Templates</b> .....	<b>138</b>
Displaying template menu .....	138
Using “Useful templates” .....	139
<b>Registering Templates</b> .....	<b>141</b>
Registering templates into the public template group .....	141
Creating a new private group .....	144
Registering templates into a private group .....	145
<b>Recalling Templates</b> .....	<b>147</b>
<b>Changing Data</b> .....	<b>150</b>
Changing private group data .....	150
Changing template data .....	151
<b>Deleting Groups or Templates</b> .....	<b>153</b>
Deleting private groups .....	153
Deleting templates .....	155

## Templates

You can create a template with several functions that are frequently used so that they can be employed whenever you want by recalling the template, thus eliminating the need to perform complicated settings every time. Templates can be used in copying, scanning and sending a fax.



### Note

Fax functions are available only when the Fax Unit (optional) is installed.



## ■ Displaying template menu

You can display the template menu by pressing [TEMPLATE] on the touch panel when you want to register or recall templates.



## ■ Using “Useful templates”






This equipment has 12 default templates that can be used immediately. They are registered to the group number 001 “Useful templates”. For how to recall them, see the following page:

📖 P.147 “Recalling Templates”






6





### Templates with copying functions

Button	Function *1
 IDcard Copy	Original size: 2-sided small originals, such as business cards Paper size: A4 (equipment for the A/B format), LT (equipment for the LT format) 2IN1 / 4IN1: 2IN1 (Place the original on the original glass before recalling the template since the automatic start is enabled in this template. After scanning the front side and then the back of the 2-sided original, press [FINISHED] to start copying.)
 2in1 D-D Staple	2IN1 / 4IN1: 2IN1 Simplex/Duplex: 2 -> 2 DUPLEX Staple: FRONT STAPLE *2
 APS Staple Mixed Org	Original size: Mixed-size Paper selection: Automatic Paper Selection Staple: FRONT STAPLE *2
 AMS Staple Mixed Org	Original size: Mixed-size Paper selection: Automatic Magnification Selection Paper source: 1st drawer Staple: FRONT STAPLE *2
 Booklet CoverInsert	Original size: 1-sided Finishing mode: Magazine sort & saddle stitch Editing method: Cover sheet (Top blank) *2, *3 (Place the paper in the 1st drawer and the paper for the cover sheet on the inserter. Both of them must be the same size and direction. If you are using a landscape original, place it vertically.)

### Templates with scanning functions

Button	Function *1
 StoF D Gray 200dpi PDF	Original: 2-sided Original mode: Image smoothing Resolution: 200 dpi Storing method: Stored in a shared folder as a PDF file (multi) *4
 StoB S Gray 300dpi	Original: 1-sided Original mode: Image smoothing Resolution: 300 dpi Storing method: Stored in the e-Filing box (public box) *4
 StoF S Gray 200dpi PDF	Original: 1-sided Original mode: Image smoothing Resolution: 200 dpi Storing method: Stored in a shared folder as a PDF file (multi) *4

### Templates with e-Filing functions

Button	Function *1
	Original mode: TEXT/PHOTO Simplex/Duplex: 1 -> 1 SIMPLEX Storing method: Stored in the e-Filing box (public box)
	Original mode: TEXT/PHOTO Simplex/Duplex: 2 -> 1 SPLIT Storing method: Stored in the e-Filing box (public box)
	Original mode: TEXT/PHOTO Simplex/Duplex: 1 -> 2 DUPLEX Storing method: Stored in the e-Filing box (public box)
	Original mode: TEXT/PHOTO Simplex/Duplex: 1 -> 1 SIMPLEX Editing function: Dual page Storing method: Stored in the e-Filing box (public box) (The dual page function is available only for A4, LT and B5 sizes.)

\*1 Functions other than those noted here are in their default settings.

\*2 An optional finisher is required for stapling and saddle stitching. If a finisher is not installed, the printed paper is only sorted.

\*3 The Inserter (optional) is required.

\*4 The Scanner Kit (optional) or Printer/Scanner Kit (optional) is required.

## Registering Templates

Templates must be registered to either the “public template group” or “private groups”. You can set a password to restrict the use of registered templates.

### Public template group:

Provided by default. Templates in this group can be used by everyone. It is useful to register several combinations of functions frequently used in the entire office or department. Up to 60 templates can be registered to the public group. The Admin (administrator) Password is required when you wish to register, delete or change templates in the public template group.

### Private group:


You can create up to 200 private groups. These are useful for each department, section or user. Up to 60 templates can be registered per group. You can set a password to restrict the use of the registered templates. “Useful templates” are registered under the group 001 by default.

## ■ Registering templates into the public template group

### 1 Set all the required functions.

Example: Editing function – image shift, reproduction ratio – 90%, number of copy sets –10


### 2 Press [TEMPLATE] on the touch panel.




The template menu appears.

### 3 Select the public template group.

- 1) Press the [REGISTRATION] tab.
- 2) Press [PUBLIC TEMPLATE GROUP].
- 3) Press [OPEN].



#### 4 Press [PASSWORD].




The on-screen keyboard appears.

#### 5 Enter the Admin Password using the on-screen keyboard or the digital keys. Then press [OK].


##### Note

When you enter the wrong Admin Password 3 times consecutively, this equipment will be locked for 30 seconds. In this case, wait until it is unlocked and then enter the correct password.



#### 6 Select a template.

- 1) Press a blank button.
- 2) Press [SAVE].



To switch the menu

Press  or .



## 7 Enter the necessary information about the template.

★ TEMPLATE ?

PUBLIC TEMPLATE GROUP

NAME1 COPY MODE

NAME2 001

USER NAME User01

PASSWORD \*\*\*\*\*

AUTOMATIC START

ENABLE DISABLE

This icon is indicated when an automatic start is enabled.

CANCEL SAVE

JOB ST.

**NAME 1 & 2:** Enter the name of the template. NAME 1 appears above the template button and NAME 2 appears below. Be sure to enter at least one of them. When you press either of them, the on-screen keyboard appears. Enter within 11 letters.

### Note

The symbols below cannot be used.  
 ; : / \ " = | \* < > ? + [ ] , .

**USER NAME:** Enter the name of the template owner as required. When you press it, the on-screen keyboard appears. Enter within 30 letters.

**PASSWORD:** Key in a password here, if you want to require a password to recall the template. When you press it, the on-screen keyboard appears. Key in following the procedure below.

- 1) Press [PASSWORD], and then key in a 5-digit password.  
The letters keyed in appear as asterisks (\*).
- 2) Press [RETYPE PASSWORD], and then key in the password again.
- 3) Press [OK].

★ TEMPLATE ?

PUBLIC TEMPLATE GROUP  
(PASSWORD : 5-digit)

PASSWORD \*\*\*\*\*

RETYPE PASSWORD \*\*\*\*\*

CANCEL OK

JOB ST.

### Tip

Press the [CLEAR] button on the control panel to delete the letter keyed in.

**AUTOMATIC START:** Press [ENABLE] if you want the operation of set functions to start immediately after pressing a button for the corresponding template. Press [DISABLE] if you do not want it to start until you press the [START] button on the control panel.

**Note**

Even when the automatic start function is enabled, you need to enter the user name and password when recalling the template in the following cases. For details of the User Authentication for Scan to E-mail and the user management function, ask your administrator.


- When the User Authentication for Scan to E-mail is enabled and the user management function is disabled
- When both the User Authentication for Scan to E-mail and the user management function are enabled, but the user names and passwords are different

When you have entered all the necessary items, press [SAVE].

The template is now registered and the menu returns to the one immediately before registration.

## ■ Creating a new private group


### 1 Press [TEMPLATE] on the touch panel.



The template menu appears.

### 2 Select a group.

- 1) Press the [REGISTRATION] tab.
- 2) Press a blank button.
- 3) Press [OPEN].



To switch the menu

- Press  $\uparrow$  or  $\downarrow$ .
- Key in the group number (3 digits).

### 3 Enter the necessary information about the group.

**NAME:** Enter the name of the group. When you press it, the on-screen keyboard appears. Enter within 20 letters. Be sure to enter it.

**USER NAME:** Enter the name of the group owner as required. When you press it, the on-screen keyboard appears. Enter within 30 letters.

**PASSWORD:** Key in a password here, if you want to require a password to view the group or register templates into the group. When you press it, the on-screen keyboard appears. Key in following the procedure below.

- 1) Press [PASSWORD], and then key in a 5-digit password.  
The letters keyed in appear as asterisks (\*).
- 2) Press [RETYPE PASSWORD], and then key in the password again.
- 3) Press [OK].

#### Tip

Press the [CLEAR] button on the control panel to delete a letter keyed in.

When you have entered all the necessary items, press [OK].  
The new group is now registered and the menu moves to the one for registering templates.

### 4 Press the [FUNCTION CLEAR] button on the control panel.


The menu returns to the BASIC menu.

## ■ Registering templates into a private group

### 1 Set all the required functions.

Example: Editing function – image shift, reproduction ratio – 90%, number of copy sets – 10


## 2 Press [TEMPLATE] on the touch panel.



The template menu appears.

## 3 Select the desired group.

- 1) Press the [REGISTRATION] tab.
- 2) Press the button of the desired group.
- 3) Press [OPEN].




To switch the menu

- Press  or .
- Key in the group number (3 digits).

## 4 Key in the password for the selected group. (If no password is set, go to step 5.)

- 1) Key in the password.
- 2) Press [OK].




## 5 Register a template following steps 6 and 7 on [P.141](#) “Registering templates into the public template group”.

## Recalling Templates


When you recall a template, the functions set in the template will be available automatically. If automatic start function is enabled, this equipment will automatically start the operation of each function when you press the button for the corresponding template.

- 1 Place paper in the drawer(s).
- 2 Place the original(s).
- 3 Press [TEMPLATE] on the touch panel.



The template menu appears.

- 4 Press the button for the group to which the desired template is registered.




To switch the menu


- Press  or .
- Key in the group number (3 digits).

## 5 Key in the password when you have selected the private group. (If no password is set, go to step 6.)

- 1) Key in the password.
- 2) Press [OK].




## 6 Press the button for the desired template.




### To switch the menu

Press  or .

Templates with the automatic start function enabled can be identified with . If this mark is displayed, you can press it to immediately start the operation of the functions set in the template.

## 7 Key in the password for the selected template. (If no password is set, go to step 8.)

- 1) Key in the password.
- 2) Press [OK].



- 8** Confirm that “Updated the template setting” is displayed on the touch panel.  
The message is displayed for approx. 3 seconds.



- 9** Select other copy modes as required, and then press the [START] button on the control panel.

## Changing Data

You can change the data of templates or private groups that are already registered, such as the template name, user name, password and setting of the automatic start function.


### Note

The data of the public template group can be changed from the TopAccess menu but this cannot be done from the control panel. For how to change them from the TopAccess menu, refer to the **TopAccess Guide**.

## ■ Changing private group data

### 1 In the template menu, select the desired group.

- 1) Press the [REGISTRATION] tab.
- 2) Press the button for the desired group.
- 3) Press [EDIT].




#### To switch the menu

- Press  or .
- Key in the group number (3 digits).

### 2 Key in the password for the selected group. (If no password is set, go to step 3.)

- 1) Key in the password.
- 2) Press [OK].



### 3 Change the data following step 3 on [P.144](#) “Creating a new private group”.

### 4 Press the [FUNCTION CLEAR] button on the control panel.


The menu returns to the BASIC menu.



## ■ Changing template data

### 1 In the template menu, select the group to which the desired template is registered.

- 1) Press the [REGISTRATION] tab.
- 2) Press the button for the desired group.
- 3) Press [OPEN].




#### To switch the menu

- Press  or .
- Key in the group number (3 digits).

### 2 Enter the password as follows and then press [OK].

**When the public template group is selected:** Press [PASSWORD] and then enter the Admin Password (6 to 10 digits) with the buttons on the touch panel or the digital keys on the control panel.

**When a private group is selected:** Key in a 5-digit password set for the selected group. If no password is set, go to step 3.




#### Note

When you enter the wrong Admin Password 3 times consecutively, this equipment will be locked for 30 seconds. In this case, wait until it is unlocked and then enter the correct password.

### 3 Select the desired template.

- 1) Press the button for the corresponding template.
- 2) Press [EDIT].




To switch the menu

Press  or .

### 4 Key in the password for the selected template. (If no password is set, go to step 5.)

- 1) Key in the password.
- 2) Press [OK].



### 5 Change the data following step 7 on [P.141](#) “Registering templates into the public template group”.

## Deleting Groups or Templates

You can delete private groups or templates no longer needed. If a private group is deleted, all the templates in the private group are also deleted.


### Note

The public template group cannot be deleted.

### ■ Deleting private groups

#### 1 In the template menu, select the desired private group.

- 1) Press the [REGISTRATION] tab.
- 2) Press the button for the desired group.
- 3) Press [DELETE].




#### To switch the menu


- Press  or .
- Key in the group number (3 digits).

#### 2 Key in the password for the selected group. (If no password is set, go to step 3.)

- 1) Key in the password.
- 2) Press [OK].



### 3 Press [DELETE].




The private group is now deleted.

## ■ Deleting templates

### 1 In the template menu, select the group to which the desired template is registered.

- 1) Press the [REGISTRATION] tab.
- 2) Press the button for the desired group.
- 3) Press [OPEN].




#### To switch the menu

- Press  or .
- Key in the group number (3 digits).

### 2 Enter the password as follows and then press [OK].

**When the public template group is selected:** Press [PASSWORD] and then enter the Admin Password (6 to 10 digits) with the buttons on the touch panel or the digital keys on the control panel.

**When a private group is selected:** Key in a 5-digit password set for the selected group. If no password is set, go to step 3.




#### Note

When you enter the wrong Admin Password 3 times consecutively, this equipment will be locked for 30 seconds. In this case, wait until it is unlocked and then enter the correct password.

### 3 Select the desired template.

- 1) Press the button for the desired template.
- 2) Press [DELETE].




To switch the menu


- Press  or .
- Key in the group number (3 digits).

### 4 Key in the password for the selected template. (If no password is set, go to step 5.)

- 1) Key in the password.
- 2) Press [OK].



### 5 Press [DELETE].



The template is now deleted.

# CONFIRMING JOB STATUS

This chapter describes how to confirm the processing status and the history of copy jobs performed.


<b>Confirming Copy Job Status</b> .....	<b>158</b>
Confirming jobs in progress or ones in waiting .....	158
Confirming copy job history .....	162
Confirming drawers .....	163

## Confirming Copy Job Status

You can confirm jobs in progress or ones in waiting, on the touch panel. Also you can delete, pause or resume jobs in waiting, and change their order. You can also confirm the history of copy jobs performed and the status of the drawers.

### ■ Confirming jobs in progress or ones in waiting


You can confirm the jobs in progress or the ones in waiting, on the touch panel. To view them, press [JOB STATUS] on the touch panel.





#### Note

If this equipment is managed under the user management function, you need to enter user information, such as a user name or a password in the user authentication menu.

The print job list appears. (Press the [JOBS] tab if another tab menu is displayed.) Copy jobs appear on the print job list as well as print jobs.



On the print job list, you can confirm the name of the user who sent the job, the date and time the job was sent, the paper size, the number of pages and copy sets and the processing status. 5 jobs appear on 1 page of the print job list. When you press  or  on the touch panel, the menu will be changed to the previous one or the next one, so that you can view up to 1000 jobs.


Press [CLOSE] when you finish the confirmation. The menu returns to the one shown before you pressed [JOB STATUS].




## □ Deleting jobs

You can delete jobs that you no longer need to print.

- 1 Select the desired job on the print job list, and then press [DELETE].



- 2 Press [DELETE].



The job is now deleted.


## □ Pausing jobs

You can pause jobs in waiting.

### Note

Only the 11th and later jobs (counted from the job in progress) can be paused.


Select the desired job on the print job list, and then press [PAUSE].



The job is now paused. The paused job is not printed even when its turn comes. Printing of the next job starts.

## Resuming the paused job

Select the desired job, and then press [RESUME].



## □ Moving jobs

You can change the order of the jobs in waiting by moving them within the list.

### Note

Only the 11th and later jobs (counted from the job in progress) can be moved. They can be moved to 11th and later.

### 1 Select the desired job on the print job list, and then press [MOVE].

**JOB STATUS** ?

Printing 1  
Press JOB STATUS to return A4

PRINT FAX SCAN

User Name	Date,Time	Paper	Pages	Sets	Status
User 02	21.10:28	A4	10	3	Wait
COPY:	21.10:29	A4	7	5	Wait
User 03	21.10:29	A4	3	2	Wait
COPY:	21.10:35	A4	14	1	Wait
User 01	21.10:38	A4	5	1	Wait

DELETE PAUSE MOVE PRINT CLOSE

JOB LOG SUPPLY

PRINTING JOB STATUS

### 2 Select the position that you want the job to move to. (It will come under the selected job.)

**JOB STATUS** ?

Select the destination you want to move 1  
A4

PRINT FAX SCAN

User Name	Date,Time	Paper	Pages	Sets	Status
User 02	21.10:28	A4	10	3	Wait
COPY:	21.10:29	A4	7	5	Wait
User 03	21.10:29	A4	3	2	Wait
COPY:	21.10:35	A4	14	1	Wait
User 01	21.10:38	A4	5	1	Wait

DELETE PAUSE MOVE PRINT CLOSE

JOB LOG SUPPLY

PRINTING JOB STATUS



**JOB STATUS** ?

Printing 1  
Press JOB STATUS to return A4

PRINT FAX SCAN

User Name	Date,Time	Paper	Pages	Sets	Status
User 02	21.10:28	A4	10	3	Wait
COPY:	21.10:35	A4	14	1	Wait
COPY:	21.10:29	A4	7	5	Wait
User 03	21.10:29	A4	3	2	Wait
User 01	21.10:38	A4	5	1	Wait

DELETE PAUSE MOVE PRINT CLOSE


JOB LOG SUPPLY

PRINTING JOB STATUS


## ■ Confirming copy job history

You can confirm the history of copy jobs performed on the touch panel.


- 1 Press [JOB STATUS] on the touch panel.
- 2 Press the [LOG] tab.



- 3 Press [PRINT].



The print log list appears. Copy jobs appear on the print log list as well as print jobs.



On the print log list, you can confirm the name of the user who performed the job, the date and time the job was printed, the paper size and the number of pages or copy sets. 5 jobs appear on 1 page of the print log list. When you press or on the touch panel, the menu will be changed to the previous one or the next one, so that you can view up to 120 jobs.


When you finish the confirmation, press [RETURN] so that the menu returns to the one in step 3, and then press [CLOSE]. The menu returns to the one shown before you pressed [JOB STATUS].

## ■ Confirming drawers

You can confirm the size and type-setting of the paper or the amount remaining in the drawers. During printing you can confirm which drawer is feeding paper.

**1** Press [JOB STATUS] on the touch panel.

**2** Press the [SUPPLY] tab.




During printing, the button for the drawer from which the paper is fed is highlighted.

Press [CLOSE] when you finish the confirmation. The menu returns to the one shown before you pressed [JOB STATUS].

When the paper in the drawer has run out during printing, [JOB STATUS] on the touch panel blinks. In this case, press [JOB STATUS] so that the menu for displaying the printing status will appear and the button for the drawer whose paper has run out will blink on this menu. Printing resumes when you add paper to this drawer.

📖 P.11 “Placing Paper”





## OTHER INFORMATION

<b>Continuous Copying Speed .....</b>	<b>166</b>
<b>Copying Function Combination Matrix .....</b>	<b>168</b>
Combination matrix 1/2 .....	168
Combination matrix 2/2 .....	169

## Continuous Copying Speed

Copy speeds under the condition in which originals are placed on the original glass and single-side copies are made continuously with 100% reproduction ratio in the non-sort mode (unit: sheet/minute).

### e-STUDIO555

Paper size	Feeder	Paper type							
		PLAIN		THICK1		THICK2		THICK3	
		Face up	Face down	Face up	Face down	Face up	Face down	Face up	Face down
A4, A5-R, B5, LT, ST-R, 8.5"SQ	Drawer	55	55	55	55	55	55	52	52
	Tandem LCF *1	55	55	55	55	55	55	52	52
	Bypass tray	45	45	45	45	45	45	45	45
A4-R, B5-R, LT-R	Drawer	44	44	44	44	44	44	42	42
	Bypass tray	37	37	37	37	37	37	37	37
B4, FOLIO, LG, COMP, 13"LG	Drawer	38	38	38	38	38	38	37	37
	Bypass tray	32	32	32	32	32	32	32	32
A3, LD	Drawer	34	32	34	32	34	32	33	31
	Bypass tray	28	28	28	28	28	28	28	28

### e-STUDIO655

Paper size	Feeder	Paper type							
		PLAIN		THICK1		THICK2		THICK3	
		Face up	Face down	Face up	Face down	Face up	Face down	Face up	Face down
A4, A5-R, B5, LT, ST-R, 8.5"SQ	Drawer	65	65	65	65	65	65	60	60
	Tandem LCF *1	65	65	65	65	65	65	60	60
	Bypass tray	46	46	46	46	46	46	46	46
A4-R, B5-R, LT-R	Drawer	48	48	48	48	48	48	46	46
	Bypass tray	38	38	38	38	38	38	38	38
B4, FOLIO, LG, COMP, 13"LG	Drawer	42	40	42	40	42	40	41	38
	Bypass tray	34	34	34	34	34	34	34	34
A3, LD	Drawer	37	33	37	33	37	33	36	32
	Bypass tray	30	30	30	30	30	30	30	30

### e-STUDIO755

Paper size	Feeder	Paper type							
		PLAIN		THICK1		THICK2		THICK3	
		Face up	Face down	Face up	Face down	Face up	Face down	Face up	Face down
A4, A5-R, B5, LT, ST-R, 8.5"SQ	Drawer	75	75	75	75	75	75	65	65
	Tandem LCF *1	75	75	75	75	75	75	65	65
	Bypass tray	46	46	46	46	46	46	46	46
A4-R, B5-R, LT-R	Drawer	55	52	55	52	55	52	50	48
	Bypass tray	38	38	38	38	38	38	38	38
B4, FOLIO, LG, COMP, 13"LG	Drawer	47	43	47	43	47	43	43	40
	Bypass tray	34	34	34	34	34	34	34	34
A3, LD	Drawer	40	35	40	35	40	35	37	34
	Bypass tray	30	30	30	30	30	30	30	30



## e-STUDIO855

Paper size	Feeder	Paper type							
		PLAIN		THICK1		THICK2		THICK3	
		Face up	Face down	Face up	Face down	Face up	Face down	Face up	Face down
A4, A5-R, B5, LT, ST-R, 8.5"SQ	Drawer	85	85	85	85	85	85	72	72
	Tandem LCF *1	85	85	85	85	85	85	72	72
	Bypass tray	50	50	50	50	50	50	46	46
A4-R, B5-R, LT-R	Drawer	61	56	61	56	61	56	52	50
	Bypass tray	42	42	42	42	42	42	38	38
B4, FOLIO, LG, COMP, 13"LG	Drawer	52	45	52	45	52	45	44	41
	Bypass tray	38	38	38	38	38	38	34	34
A3, LD	Drawer	43	37	43	37	43	37	37	34
	Bypass tray	34	34	34	34	34	34	30	30

\*1 Only A4 and LT-sized paper can be set in the tandem large capacity feeder (Tandem LCF).

- "Face up" and "Face down" in the table mean how the paper exits.
- The bypass copying speed when the paper size is specified is as listed above.
- TOSHIBA-recommended paper is used for the values of the specifications above.
- These specifications vary depending on the copying conditions and the environment.

# Copying Function Combination Matrix

## Combination matrix 1/2

	Store to e- Filing	Copy & File	Sharpness adjustment	Sheet insert	Insert Front & Back cover	Copied tab insert	Tab paper Blank tab insert	ADF -> SADF	Book -> TABLET	Image detection	Job build number	Time stamp	Blank Copied	Sheet insertion	Top copied back blank	Both blank Top copied	Cover sheet Top blank	Top blank	XY zoom	NegaPos	Mirror	Mask	Trim
Bypass copy	*1	Yes	Yes	Yes	Yes	*3	*3	Yes	*1	Yes	*4	*1	*3	*3	*3	*3	*3	Yes	Yes	*1	*1	*1	*1
Mixed original sizes	Yes	Yes	Yes	No	No	No	No	No	Yes	Yes	*4	No	No	No	No	No	No	No	No	No	No	No	No
Text / Photo	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Text	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Photo	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
1 - 1 Simplex	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
1 - 2 Duplex	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
2 - 1 Split	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
2 - 2 Duplex	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Book - 2	Yes	Yes	Yes	No	No	No	No	No	No	Yes	No	Yes	No	No	No	No	No	No	No	No	No	No	No
Non-sort / Non-staple	*3	Yes	Yes	*3	*3	Yes	Yes	Yes	Yes	Yes	*4	Yes	*3	*3	*3	*3	*3	*3	Yes	Yes	Yes	Yes	Yes
Sort	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Group	Yes	Yes	Yes	No	No	No	No	*3	Yes	Yes	*4	Yes	No	No	No	No	No	No	No	Yes	Yes	Yes	Yes
Staple sort	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Magazine sort	No	No	Yes	No	No	Yes	No	Yes	No	Yes	*4	Yes	No	No	No	No	No	No	No	No	No	No	No
Magazine sort & Saddle stitch	No	No	Yes	No	No	Yes	No	Yes	No	Yes	No	Yes	No	No	No	No	No	No	No	No	No	No	No
Hole punch	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Saddle stitch	Yes	Yes	Yes	No	No	Yes	No	Yes	No	Yes	*4	Yes	No	No	No	No	No	No	No	No	No	No	No
Rotate sort 16	Yes	Yes	Yes	No	No	No	No	Yes	Yes	Yes	*4	Yes	No	No	No	No	No	No	No	Yes	Yes	Yes	Yes
Image shift	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Edge erase	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Book center erase	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Dual page	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	No	Yes	*4	Yes	No	No	No	No	No	No	No	No	No	No	No
ZIN1 / AIN1	*3	*3	Yes	Yes	Yes	No	No	Yes	No	Yes	*4	Yes	No	No	No	No	No	No	No	No	No	No	No
Trim	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Mask	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Mirror	Yes	Yes	Yes	Yes	Yes	Yes	No	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
NegaPos	Yes	Yes	No	Yes	Yes	Yes	No	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
XY zoom	Yes	Yes	Yes	No	No	No	No	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Top blank	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Top copied	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Both blank	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Top copied back blank	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Copied	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Blank	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Time stamp	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Page number	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Job build	*4	*4	Yes	Yes	Yes	No	No	No	No	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Image detection	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Book -> TABLET	Yes	Yes	Yes	Yes	Yes	Yes	No	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
ADF -> SADF	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Copy on tab	*3	*3	Yes	No	No	No	No	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Blank tab insert	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Copied tab insert	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Front cover	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Front & Back cover	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	*4	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Sheet insert	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Background adjustment	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Sharpness	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Copy & File	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Store to e-Filing	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No

\*1 Size selection is required.  
 \*2 Size selection is required for [DOUBLE STAPLE] and [REAR STAPLE].  
 \*3 The function set later will be valid.  
 \*4 The setting cannot be changed from 2nd job or later.  
 \*5 Bookbinding margin is not available.  
 \*6 Valid only for the equipment without an optional finisher.

# Combination matrix 2/2

	2IN1 / 4IN1	Dual page	Book center erase	Edge erase	Image shift	Rotate sort %	Saddle stitch	Hole punch	Magazine sort & Saddle stitch	Magazine sort	Staple sort (Group)	Sort	Non-sort / Non-staple	2-sided			Original Mode		Mixed original sizes	Bypass copy	
														1-1 Simplex	1-2 Duplex	2-1 Split	1-1 Photo	Text			
Bypass copy	*3	*1	*1	*1	*1	*1	*1	*1	*1	*1	*2	Yes	Yes	Yes	1-1 Simplex	1-2 Duplex	2-1 Split	Photo	Text	Mixed original sizes	Bypass copy
Mixed original sizes	No	No	No	No	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Original Mode																					
Text / Photo	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Text	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Photo	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
1-1 Simplex	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
1-2 Duplex	*3	No	No	Yes	Yes	Yes	Yes	Yes	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
2-1 Split	*3	No	No	Yes	Yes	Yes	Yes	Yes	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
2-2 Duplex	*3	No	No	Yes	Yes	Yes	Yes	Yes	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Book - 2	No	No	No	Yes	Yes	Yes	No	Yes	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Non-sort / Non-staple	Yes	Yes	Yes	Yes	Yes	Yes	*3	Yes	*3	*3	*3	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Sort	Yes	Yes	Yes	Yes	Yes	Yes	*3	Yes	*3	*3	*3	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Group	Yes	Yes	Yes	Yes	Yes	Yes	*3	Yes	*3	*3	*3	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Staple sort	Yes	Yes	Yes	Yes	Yes	Yes	*3	Yes	*3	*3	*3	*3	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Magazine sort	No	No	No	Yes	Yes	No	*3	No	*3	No	*3	No	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Magazine sort & Saddle stitch	No	No	No	Yes	No	Yes	*3	No	*3	No	*3	No	*3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Hole punch	Yes	Yes	Yes	Yes	Yes	Yes	No	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Saddle stitch	Yes	Yes	Yes	Yes	Yes	Yes	No	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Rotate sort %	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Image shift	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Edge erase	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Book center erase	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Dual page	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
2IN1 / 4IN1	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
Trim																					
Mask																					
Editing																					
Mirror																					
NegaPos																					
XY zoom																					
Cover sheet																					
Top copied																					
Both blank																					
Top copied back blank																					
Sheet insertion																					
Copied																					
Blank																					
Time stamp																					
Page number																					
Job build																					
Image direction																					
Book <-> TABLET																					
ADF -> SADF																					
Copy on tab																					
Tab paper																					
Blank tab insert																					
Copied tab insert																					
Front cover																					
Front & Back cover																					
Sheet insert																					
Background adjustment																					
Sharpness																					
Copy & File																					
Store to e-File																					

\*1 Size selection is required.  
 \*2 Size selection is required for [DOUBLE STAPLE] and [REAR STAPLE].  
 \*3 The function set later will be valid.  
 \*4 The setting cannot be changed from 2nd job or later.  
 \*5 Bookbinding margin is not available.  
 \*6 Valid only for the equipment without an optional finisher.



# INDEX

## Numerics

2IN1 / 4IN1 .....	94
[2-SIDED] .....	8

## A

A/B format .....	11
ADF .....	119
ADF -> SADF .....	119
Alert message indication area .....	8
AMS (Automatic Magnification Selection) .....	54
[APS] .....	8, 48
APS (Automatic Paper Selection) .....	48
Auto job start .....	31
Automatic function clear .....	36
Automatic Magnification Selection (AMS) .....	54
Automatic Paper Selection (APS) .....	48

## B

BACKGROUND ADJUSTMENT .....	135
BASIC menu .....	8
[BASIC] tab .....	8
BOOK - TABLET .....	118
BOOK CENTER ERASE .....	90
Bypass copying	
bypass copying .....	36
non-standard size paper .....	42
standard size paper .....	37
[BYPASS FEED] .....	10
Bypass tray .....	12, 36, 37, 42

## C

Clearing the set functions .....	47
Confirmation screen .....	46
Continuous feed mode .....	26
COPY & FILE .....	78
Copy quantity .....	46
Copying	
auto job start .....	31
basic procedure .....	28
book-type originals .....	24, 75
bypass copying .....	36
continuous copying speed .....	166
copy & file .....	78
copy quantity .....	46
duplex copying .....	72
interrupting .....	32
making copies .....	28
mixed-size originals .....	50
non-standard size paper .....	42
number of copies .....	28
proof copy .....	33
reproduction ratio .....	46, 54
restarting .....	30
stopping .....	30
Copying function combination matrix .....	168
Copying functions	
before using copying functions .....	46
clearing the set functions .....	47
confirming the set functions .....	46
COVER SHEET .....	104

## D

Date and time .....	8
Default settings .....	46
Density adjustment .....	46, 53
Density adjustment buttons .....	9

Department management function .....	8
Drawer buttons .....	10
Drawers .....	11, 13, 163
DUAL PAGE .....	92
Duplex copying	
1-sided original -> 1-sided copy .....	72
1-sided original -> 2-sided copy .....	72
2-sided original -> 1-sided copy .....	72
2-sided original -> 2-sided copy .....	72
book-type original -> 2-sided copy .....	72
simplex/duplex setting .....	72

## E

EDGE ERASE .....	89
EDIT menu .....	84
[EDIT] tab .....	8
EDITING .....	99
masking .....	99
mirror image .....	102
negative/positive reversal .....	102
trimming .....	99
Editing functions .....	83
2IN1 / 4IN1 .....	94
ADF -> SADF .....	119
BOOK - TABLET .....	118
BOOK CENTER ERASE .....	90
COVER SHEET .....	104
DUAL PAGE .....	92
EDGE ERASE .....	89
EDITING .....	99
IMAGE DIRECTION .....	116
IMAGE SHIFT .....	85
INSERTER .....	130
JOB BUILD .....	113
MAGAZINE SORT .....	97
PAGE NUMBER .....	111
SHEET INSERTION .....	107
TAB PAPER .....	121
TIME STAMP .....	110
XY ZOOM .....	103
End guide .....	13
Equipment status indication area .....	8, 10
[EXIT TRAY] .....	10
External Large Capacity Feeder .....	11, 20

## F

Feeding mode .....	26
Finisher	
Finisher .....	60
name of each part .....	61
Saddle Stitch Finisher .....	60
[FINISHING] .....	8
Finishing mode	
finishing mode .....	46
group .....	60, 62
hole punch .....	60, 69
inserter mode .....	60, 70
magazine sort .....	60, 67
magazine sort & saddle stitch .....	60, 67
non-sort non-staple .....	60
rotate sort .....	60, 64
saddle stitch .....	60, 67
selecting .....	60
sort .....	60, 62
staple sort .....	60, 65
FTP .....	80

[FUNCTION CLEAR] button .....	36, 46, 47	Original mode	
<b>G</b>		original mode .....	46, 52
Group .....	60, 62	PHOTO .....	52
<b>H</b>		TEXT .....	52
Help button .....	9	TEXT/PHOTO .....	52
Hole punch .....	60, 69	Original stopper .....	26
Hole Punch Unit .....	60	Originals	
<b>I</b>		acceptable originals .....	22
Image adjustment functions		maximum number of sheets for one scanning .....	22
BACKGROUND ADJUSTMENT .....	135	mixed-size originals .....	50
image adjustment functions .....	133	placing .....	22
SHARPNESS .....	136	using the RADF .....	25
IMAGE DIRECTION .....	116	<b>P</b>	
IMAGE menu .....	134	PAGE NUMBER .....	111
IMAGE SHIFT .....	85	Paper	
[IMAGE] tab .....	8, 134	acceptable copy paper .....	11
INSERTER		amount of paper remaining .....	10
FRONT & BACK COVER .....	130	out of paper .....	29
FRONT COVER .....	130	paper type setting .....	18, 38, 41
INSERTER .....	130	placing .....	11, 13, 16, 20
SHEET INSERT .....	130	precautions for storing copy paper .....	12
Inserter .....	60	registering paper size .....	17
Inserter mode .....	60, 70	unacceptable copy paper .....	12
[INTERRUPT] button .....	32	Paper holder .....	36
Interrupting copying .....	32	Paper selection .....	46, 48
<b>J</b>		Paper size indicator .....	14
JOB BUILD .....	113	Paper type on the bypass tray .....	10
Job history .....	162	Paper type setting .....	18, 38, 41
[JOB STATUS] .....	8	PHOTO .....	52
Job status .....	158	Plain paper .....	11
Job status menu .....	158	Private group	
Jobs		changing private group data .....	150
confirming .....	158	creating .....	144
deleting .....	159	deleting .....	153
moving .....	161	private group .....	141
pausing / resuming .....	160	registering templates .....	145
<b>K</b>		[PROOF COPY] .....	9
K format .....	11	Proof copy .....	33
<b>L</b>		Public template group .....	141
Log .....	162	<b>R</b>	
LT format .....	11	RADF (Reversing Automatic Document Feeder)	
<b>M</b>		precautions .....	25
MAGAZINE SORT .....	97	unacceptable originals .....	25
Magazine sort .....	60, 67	using the RADF .....	25
Magazine sort & saddle stitch .....	60, 67	Receiving tray indication .....	10
Message indication area .....	8	Receiving tray selection .....	35
<b>N</b>		Recommended paper .....	11
NetWare IPX/SPX .....	81	Registering paper size .....	17
NetWare TCP/IP .....	81	Reproduction ratio .....	46, 54
Non-sort Non-staple .....	60	Reversing Automatic Document Feeder (RADF)	
Number of copies .....	9, 28	precautions .....	25
Number of remaining copy sets .....	9	unacceptable originals .....	25
<b>O</b>		using the RADF .....	25
OHP film .....	12, 36, 39	Rotate sort .....	60, 64
Original glass .....	23	<b>S</b>	
[ORIGINAL MODE] .....	8, 52	Saddle stitch .....	60, 67
		SADF .....	119
		[SETTINGS] .....	9
		Share folder .....	80
		SHARPNESS .....	136
		SHEET INSERTION .....	107
		Side guide lock .....	13
		Side guides of the bypass tray .....	37, 42

---

Side guides of the drawer .....	13
Side guides of the RADF (Reversing Automatic Document Feeder) .....	26, 27
Simplex/duplex setting .....	46
Single feed mode .....	27
SMB .....	80
Sort .....	60, 62
Staple sort .....	60, 65
[START] button .....	29
Sticker labels .....	12, 36
[STOP] button .....	30
[STORAGE] .....	9

## T

TAB PAPER	
BLANK TAB INSERT .....	121
COPIED TAB INSERT .....	121
COPY ON TAB .....	121
TAB PAPER .....	121
Tab paper .....	12, 39
Tandem large capacity feeder .....	11, 16
[TEMPLATE] .....	9, 138
Template menu .....	138
Templates	
changing data .....	150, 151
deleting .....	153, 155
recalling .....	147
registering .....	141, 145
templates .....	138
useful templates .....	139
TEXT .....	52
TEXT/PHOTO .....	52
Thick paper .....	11
TIME STAMP .....	110
TopAccess .....	150
Touch panel .....	8
Tracing paper .....	12

## U

Useful templates .....	139
[USER FUNCTIONS] button .....	17
User management function .....	8

## X

XY ZOOM .....	103
---------------	-----

## Z

[ZOOM] .....	8, 54
--------------	-------







MULTIFUNCTIONAL DIGITAL SYSTEMS

Copying Guide

**e-STUDIO555/655/755/855**

**TOSHIBA TEC CORPORATION**

2-17-2, HIGASHIGOTANDA, SHINAGAWA-KU, TOKYO, 141-8664, JAPAN



R081120G8001-TTEC  
Ver01 2009-12

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>