



Owner's Manual – DrizAir Dehumidifiers

DrizAir 80, DrizAir 1200, DrizAir 2000 LG, DrizAir 2400 LG
115-volt models

DRI-EAZ PRODUCTS, INC.

15180 Josh Wilson Road, Burlington, WA USA 98233
Fax: (360) 757-7950 Phone: (360) 757-7776 www.dri-eaz.com

DrizAir Dehumidifiers are commercial refrigerant dehumidifiers, designed for drying building structures and contents. They are designed for high performance water removal, as well as durability and ease of use.

Read And Save These Instructions



Safety Information

Keep Children Away: Do not allow children to play with or around the unit, which could result in injury. Be sure the unit is inaccessible to children when not attended.

Keep Unit Grounded: Always operate the unit with a grounding plug and a grounded electrical outlet. A grounding plug is an essential safety feature that helps reduce the risk of shock or fire.

Protect Power Cord from Damage: Never operate a unit with a damaged power cord, as this may lead to electrical or fire hazards. If the power supply cord is damaged, it must be replaced by a cord of the same type and amperage rating.

Extension Cords: Extension cords must be grounded and able to deliver the appropriate voltage to the unit.

Handle With Care: Do not drop or throw the unit. Rough treatment can damage the components or wiring and create a hazardous condition.

Run on Stable Surface: Always operate the unit on a stable, level surface, like the floor or a strong counter, so it cannot fall and cause injury.

Secure During Transport: When transporting in a vehicle, secure the unit to prevent sliding and possible injury to vehicle occupants.

Keep Out of Water: Never operate the unit in pooled or standing water, as this may create a risk of injury from electrical shock. Do not store or operate outdoors. If electrical wiring or components become wet, thoroughly dry them before using the unit.

Keep Air Intakes Clear: Do not clog or block air intakes, as may occur if operated too close to draperies or similar materials. This may cause the unit to overheat and result in a fire or electrical hazard.

Keep Filter Clean: Always use a clean air filter. Do not allow any material to clog the filter, as this may cause the dehumidifier to overheat. Do not allow oil, grease, or other contaminants to be drawn into the dehumidifier.

Keep Electrical Components Dry: Never allow water inside the dehumidifier's electrical components. If these areas become wet for any reason, thoroughly dry them before using the dehumidifier.

Allow Repair Only by Qualified Person: Do not attempt to disassemble or repair the unit if you are not qualified to do so. You may handle some maintenance and troubleshooting, but make sure that more complex problems are handled by an authorized

service technician. For information about authorized repair, call Dri-Eaz at (360) 757-7776.

HOW TO USE DEHUMIDIFIERS

DrizAir Dehumidifiers are designed to reduce water vapor or high humidity in a building or part of a building. The purpose is to prevent humidity damage, and to dry out wet materials such as carpet, carpet cushion, floors, walls, furniture, contents, lumber, and structural materials.

To speed up the rate of evaporation, and dry out materials faster, use Dri-Eaz TurboDryer airmovers. The DrizAir Dehumidifier will be needed to remove the additional water evaporated by the TurboDryers.

Positioning Dehumidifiers

The dehumidifier must be operated in an enclosed area to achieve best efficiency. Close all openings to other areas of the building, like windows and doors, to prevent moist air from mixing with the air in the drying area. Keep traffic through doors at a minimum. This forms a closed drying chamber.

Inside the drying chamber, air should circulate freely. Open interior doors and operate TurboDryer airmovers to maintain good airflow to all areas.

Place the dehumidifier where there is no restriction to air flowing through either the inlet or the outlet. Keep away from loose materials like curtains and drapes.

Under normal circumstances, place the dehumidifier in the center of the room. To dry a specific area, place the dehumidifier so the outlet air points at the wet area and the warm, dry air passes across it. The duct should never be closer than three feet from the wall.

The DrizAir Dehumidifier warms the air as it removes its moisture. In smaller rooms this can raise the temperature substantially. Room temperatures of about 68° to 80° F (20° to 27° C) are usually a good condition for drying. Never allow the room temperature to exceed 100° F (38° C), because this could damage the dehumidifier or building contents.

OPERATING INSTRUCTIONS

1. Operate the DrizAir Dehumidifier only in the upright position. If it has been in a horizontal position for any time over a few minutes, let it sit in the upright position for at least 30 minutes before starting. This allows oil to drain back into the compressor, increasing its life.
2. Plug in to a standard outlet with the correct voltage and amperage for the unit. Push the ON switch. Listen for proper operation of fan and compressor before leaving the unit unattended.

3. **Allow five minutes before restarting** after the unit shuts off for any reason. This will avoid damaging the compressor.
4. If your unit has a pump, run the pump drain hose into a sink, toilet, drain, or bucket. Make sure the hose is not kinked. If using a bucket, check and empty the bucket frequently to prevent overflow.
5. Before moving the unit, make sure the pump is empty of water. To do this, let the unit sit while OFF for 10 minutes, while water drains from the coils into the pump. Then push the **PURGE** switch. When using the DrizAir 80, tip the unit backward to about a 30-degree angle; this will cause the pump impeller to run and empty the collection pan.
6. **CAUTION: Check dehumidifier daily** for correct operation. **Protect floor surfaces** from leakage.

Water Removal Rate

With all dehumidifiers, the rate of water removal varies with humidity and temperature. If possible, judge the performance of the dehumidifier by how much the humidity drops, rather than by the volume of water being removed and deposited in the bucket. You can roughly guess the humidity by its "feel" on your skin, but to be accurate use a thermo-hygrometer.

To estimate how many dehumidifiers to place, see the Specifications below.

How the Machine Works

DrizAir units are refrigerant dehumidifiers. They operate by blowing moisture-laden air from the room across a cold evaporator coil. Moisture in the air condenses on the coil, drips off, and then is removed through a drain hose or pump. Now warmer and drier, the air passes back into the room to continue its work of carrying water vapor.


When a DrizAir Dehumidifier is operating at a room temperature below about 68° F (20° C), frost will normally form on the evaporator coil. Water removal will stop temporarily. When an automatic control built into the unit senses the ice temperature, it initiates a defrost cycle. During this time, considerable quantities of water drain from the unit. As soon as the ice has melted, normal operation resumes.


How to Use the Touchpad Controller (DrizAir 1200, 2000, 2400 only)

The Touchpad Controller used on DrizAir dehumidifiers has one display and four keys. The normal display messages are:

DEHUMIDIFIER OFF	CMPRSR DELAY 00
DEHUMIDIFIER ON	PUMP PURGING
TOTAL HRS=00000	DEFROST ON
JOB HRS=00000	GET SERVICE ER01

Control Keys

 **ON-OFF.** When the unit is first plugged in, the display cycles through three messages: DEHUMIDIFIER OFF, TOTAL HOURS , and JOB HOURS. Press the ON-OFF key to turn the unit on. The display often reads CMPRSR DELAY 00, with the numeral counting down from a maximum of 60 seconds to 0. At that point the unit begins to operate and the display reads DEHUMIDIFIER ON. (The delay prevents damage from accidental power interruptions, where power to the compressor stops and then starts again when pressure in the system is still high.)

 **PURGE.** Push this key to run the purge before tipping the unit. This empties water from the pump reservoir to prevent leakage. If the unit has been operating, turn the power OFF but leave the cord plugged in for about 10 minutes while water drips from the coil; then press PURGE to remove residual water. The purge also runs automatically every six minutes during operation, and

whenever the reservoir is full. While the purge is running, the display reads PUMP PURGING.



DISPLAY. Press the DISPLAY key to stop the display at DEHUMIDIFIER ON or OFF, TOTAL HOURS, or JOB HOURS, when it is cycling. Press again to make the display cycle again.



CLEAR. To clear the JOB HOURS reading, first press the DISPLAY key to make the display read JOB HRS steadily. Then press the CLEAR key to re-set the numerals to 00000. NOTE: the TOTAL HOURS reading cannot be re-set.

Defrost On

The display will read DEFROST ON whenever the unit is in a defrost cycle. During normal operation, frost forming on the coils is detected by the temperature sensor, causing a defrost cycle to start. Dehumidification is suspended as hot gas flows through the coils and melts the frost. At the end of the defrost cycle, the display returns to its normal condition.

Changing Language Shown on Display

The default language is English. To change to another language, follow these steps. (1) The unit must be unplugged from the power outlet. Hold down the DISPLAY key while plugging the unit in. The display now reads "ENGLISH." (2) Press the DISPLAY key or the CLEAR key to adjust the reading to FRANCAIS, DEUTSCH, or ESPANOL. (3) Then unplug the unit from the power outlet, which sets the language.

CAUTION: While in the change-language mode, pressing other keys can change operating parameters of the unit. Do NOT press other keys or change parameters, except when following guidelines from the Dri-Eaz Service Department.

Error Messages

In case of certain problems, the display may show the error message "GET SERVICE," followed by "ER01" or another numeral. Follow these steps:

1. First, unplug the unit and then plug it back in. This may re-set the electronics.
2. If that does not fix the problem, try the solution if one is listed in the table below.
3. If that does not fix the problem, contact the Dri-Eaz Service Department (contact information above).

ER 1-2-3-5-6	Problem with the electronic control panel. Contact Service.
ER4	Problem with temperature sensor or cable.
ER8	Problem with a touchpad key. Press and release each key several times.
ER9	Check for obstructions in pump or drain hose, or that pump wiring is correct.

ELECTRICAL CONNECTIONS

DrizAir Dehumidifiers are designed to operate on a 115V/60 Hz electrical connection. Make sure that the electrical outlet is grounded and that all safety precautions are taken.

MAINTENANCE

Always turn off the power before performing maintenance procedures. All the service procedures below are to be executed with the unit unplugged. Perform before each use or as needed.

INSPECT ELECTRICAL SYSTEM: Inspect the electrical cord for damage at regular intervals. Periodically, remove the housing and inspect internal wiring for bare wires, insecure fasteners, and discoloration. Remove and repair any damaged wiring as needed. Failure to do so may lead to electrical shock or a fire hazard.

PUMP TUBE: Make sure the pump tube is completely unwrapped and not kinked. Failure to do so can cause water to back up in the pump and leak out. The control panel may signal this problem by displaying "ER9."

KEEP OUT DUST. Keep dust from drywall, demolition, and other sources out of the coils. Failure to do so can cause the unit to overheat, leading to compressor failure or other problems. Do not run the unit during sanding, painting or other operations producing airborne particulate. When dust is present, use the optional pleated paper filter to keep more dust out of the unit; also, inspect and clean the coils as required.

USE A CLEAN FILTER. Keep a clean filter in the unit at all times to keep out dust. When using a foam filter, clean with a vacuum, or wash with water and mild detergent and allow it to dry. When using paper filters, discard the filter when visibly dirty and insert a clean one.

SHINE EXTERIOR: Use a sponge and mild detergent for regular cleaning. Do not pour or run water onto the unit or allow water to soak the touchpad control. Bring back the original shine with a vinyl cleaner-polish.

Periodic Maintenance (as needed)

Make sure unit is unplugged. Remove housing as needed to permit access to interior parts.

KEEP COILS CLEAN. Dirty coils do not remove water efficiently. Inspect them regularly, especially if operating in dusty environments. Clean if they are visibly dirty.

First make sure coils are dry, then blow them clean with direct compressed air from both sides of the coil. Do NOT hold too close to the coils, as high-pressure air may fold the fins.

If sticky or oily residue remain, do a wet cleaning. Use a squirt bottle to flush the coil with water and a little detergent. Do NOT run a hose or pressure washer on the coils, or permit water to enter the electrical compartment.

Remove dirt buildup with an aluminum evaporator coil cleaner available from a refrigeration supply outlet. Follow product directions carefully.

When cleaning coils, also make sure that the drain tray, drain hose, and filter cover are free of dirt.

PUMP SYSTEM: Inspect and clean the pump system regularly to maintain effective operation. Remove the four screws holding down the pump cover. Clean the catch basin. Make sure the float shaft operates smoothly and does not stick in the OFF position. Use a pipe cleaner to clean the gravity drain hose.

WARRANTY

FILL OUT WARRANTY CARD: Please stop before proceeding and fill out the warranty card.

INSPECT ON ARRIVAL: When your Dri-Eaz product arrives, check immediately for signs of shipping damage. If you notice damage, save the shipping carton for claim purposes, and immediately report the problem to your supplier and the shipping company. Also, save the carton for shipping in case your product ever needs repair at a remote location.

Dri-Eaz promises, to the original purchaser, to perform the following as needed to correct defects in materials and workmanship:

7 Years on Housing: Repair or replace the housing of a Dri-Eaz Airmover or Dehumidifier, for seven years from date of purchase. (United States and Canada only.)

4 Years on Compressor, Coils and Rotor: Repair or replace the compressor and/or coil of a DriAir Dehumidifier, or the desiccant rotor of a DriTec Dehumidifier, for four years from the date of purchase. (United States and Canada only.)

1 Year on Parts and Labor: Cover parts and labor costs for the repair of a Dri-Eaz Airmover, Dehumidifier, Instrument, Accessory, and other product except Marketing Products, for a period of one year from the date of purchase.

90 Days on Shipping: Cover shipping costs for the repair of a Dri-Eaz Airmover, Dehumidifier, Instrument, Accessory, or other product except Marketing Products, both to and from the Service Center, for a period of 90 days from the date of purchase.

LIMITATIONS: This warranty shall not extend to any products showing effects of misuse, accident damage, disassembly, alteration, lack of proper maintenance, corrosive chemicals, improper voltage, unauthorized repairs, use of other than genuine parts and materials, fire, flood, normal wear and tear, or any other causes beyond Dri-Eaz Products' control. The warranty obligation extends only to the repairs or replacement of parts found, upon Dri-Eaz Products' examination, to be defective. The foregoing constitutes the entire warranty and no other warranty, liability, contingency or responsibility, direct, indirect, consequential or in any way connected with the sale or operation of products is expressed or implied.

TO RECEIVE WARRANTY SERVICE: You must write or call for a Return Authorization. You must have the serial number available. The Dri-Eaz Service Department must authorize all costs, including shipping, for any Service Centers worldwide. Please direct questions to an authorized distributor, or to Dri-Eaz at (360) 757-7776, extension 238.

SPECIFICATIONS

Model	DRIZAIR 80 and 80 DX		DRIZAIR 1200		DRIZAIR 2000 LG		DRIZAIR 2400 LG	
Water Removal, maximum	80 pints (10 gallons)	38 liters	123 pints (15 gall.)	58 liters	198 pints (25 gallons)	94 liters	240 pints (30 gallons)	114 liters
Water Removal, AHAM	40 pints (5 gallons)	19 liters	64 pints (8 gallons)	30 liters	110 pints (14 gall)	52 liters	148 pints (18.5 gall.)	70 liters
Airflow	200 cfm	360 cmh	225 cfm	385 cmh	365 cfm	700 cmh	365 cfm	600 cmh
Use Weight	62 lb (76 DX)	31 kg (39 DX)	80 lbs	36 kg	132 lbs	60 kg	160 lbs	73 kg
Dimensions	21x14x16 in 34x19x20 (DX)	53x36x41 cm 86x48x51 (DX)	32x20x20 in	83x50x50 cm	41x24x23 in	103x61x57 cm	47x24x27 in	120x61x6 9 cm
Operating range	55° - 95° F	13° - 35° C	33° - 100° F	0° - 38° C	33° - 100° F	0° - 38° C	33° - 100° F	0° - 38° C
Safety Listings	UL, C-UL		UL, C-UL		UL, C-UL		UL, C-UL	
Filter	Foam		Foam or Paper		Foam or Paper		Foam or Paper	
Defrost	Thermostat – Fan Defrost		Hot Gas Bypass		Hot Gas Bypass		Hot Gas Bypass	
Pump	Centrifugal (DX only)		Centrifugal		Centrifugal		Centrifugal	
Refrigerant	R-134A		R-22		R-22		R-22	
Compressor	3,926 BTU Reciprocating		6,670 BTU Rotary		10,120 BTU Rotary		13,315 BTU Rotary	
One dehumidifier will dry the air in APPROXIMATELY the size of the following drying chamber or room(s) with a standard ceiling.								
Soaking wet	200 sq ft	20 sq meters	350 sq ft	30 sq m	550 sq ft	50 sq m	750 sq ft	70 sq m
Moderately wet	300 sq ft	30 sq meters	500 sq ft	45 sq m	825 sq ft	75 sq m	1,100 sq ft	100 sq m
Mostly dry	600 sq ft	60 sq meters	1,000 sq ft	90 sq m	1650 sq ft	150 sq m	2,200 sq ft	200 sq m

Specifications are subject to change without notice. Some values are approximate.

TROUBLESHOOTING

In COLUMN 3, "FS" or **Field Solutions** can be handled by the technician in the field. Others solutions should be handled by a repair technician – an "AST" or **Authorized Service Technician**.

WARNING: All the service procedures below should be executed with the power turned off, i.e. unplugged.

PROBLEM	CAUSE	See above	SOLUTION
Unit does not operate	No power to machine Switch not turned on	FS FS	Plug in the unit; check power at outlet Turn on the switch
Compressor will not start	Unit needs 5 minutes before re-start Overload preventing start up Faulty or broken wire Defective relay Compressor not running	FS FS AST AST AST	Switch off unit, wait 5 minutes before starting Reduce room temperature below 100° F (38° C) Replace or repair broken/loose wire Check relay with volt/amp meter Contact distributor or Dri-Eaz Products
Blower wheel not turning	Obstructed blower Loose blower wheel set screw Loose or broken wire Burned out fan motor	FS FS AST AST	Remove obstruction Tighten set screw Replace broken wire Replace fan motor
Dehumidifier operating but room not dry	Not enough time to dry Poor air movement Excessive air infiltration	FS FS FS	Allow more time for drying Increase air movement with TurboDryers Reduce airflow into the area being dried
Only partial frost or moisture on coils	Possible leak in system Low charge in system	AST AST	Check for leak with gas leak detector Repair and recharge system
No moisture or frost on coils	Possible leak in system Capillary tubing damaged Compressor not running	AST AST AST	Check for leak with gas leak detector Look for damage, replace tubing Contact distributor or Dri-Eaz Products
Unit continuously in defrost	Room temperature too low Defective control assembly Defective bypass relay valve	FS AST AST	Increase room temperature Replace control assembly Replace bypass valve
Unit does not defrost (heavy frost or ice persists over several hours)	Defective sensor Defective control assembly Defective bypass relay valve	AST AST AST	Replace sensor Replace control assembly Replace bypass valve
Unit collects little water	Room air too dry Room temperature too low Airflow through unit restricted	FS FS FS	Check humidity with a hygrometer Increase the room temperature Increase airflow; clean filter and coils
Pump does not function	Stuck float valve	FS	Clean float valve shaft

FOR PARTS AND SERVICE CALL YOUR LOCAL DISTRIBUTOR, or the Dri-Eaz Service Department at (360) 757-7776

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>