

Cuisinart®

INSTRUCTION & RECIPE BOOKLET



Cuisinart® Breakfast Central™

WAF-300 Series

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

IMPORTANT SAFEGUARDS

When using an electrical appliance, basic safety precautions should always be taken, including the following:

1. **READ ALL INSTRUCTIONS.**
2. Do not touch hot surfaces. Use handles and dials.
3. To protect against fire, electric shock, and injury to persons, **DO NOT IMMERSER CORD, PLUG, OR UNIT** in water or other liquids.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest Cuisinart Authorized Service Facility for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by Cuisinart may result in fire, electric shock, or injury to persons.
8. Do not use outdoors.
9. Do not let power cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Do not use appliance for other than intended use.
12. Always unplug the unit when finished baking waffles.
13. To safely disconnect power at any time, remove the plug from the outlet.
14. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
15. **WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, REPAIR SHOULD BE DONE ONLY BY AUTHORIZED PERSONNEL. NO USER-SERVICEABLE PARTS ARE INSIDE.**

16. Do not operate your appliance in an appliance garage or under a wall cabinet. **When storing in an appliance garage always unplug the unit from the electrical outlet.** Not doing so could create a risk of fire, especially if the appliance touches the walls of the garage or the door touches the unit as it closes.

SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

SPECIAL CORD SET INSTRUCTIONS

A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.

Extension cords may be used if care is exercised in their use.

If an extension cord is used, the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance, and the longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or animals, or tripped over.

NOTICE

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

CONTENTS

Important Safeguards	2
Parts and Features	3
Before the First Use	3
Assembly Instructions	4
Operating Instructions	4
Cleaning and Care	4
Storage	5
Tips to Make Perfect Waffles	5
Warranty	5
Cooking Chart	7
Recipes	7

PARTS AND FEATURES

- Housing** – Elegant brushed stainless steel with embossed Cuisinart logo.
- Lid Handle** – Durable, easy-lift handle that stays cool to the touch.
- Nonstick Removable Dishwasher-Safe Plates** –
 - Waffle: One set of 4-slice Belgian waffle plates.
 - Pancake: One 4-slot pancake plate.
- Temperature Knob** – Six adjustable settings.
- Indicator Lights** – Red indicator light signals power ON; green indicator light signals when ready to cook and when ready to eat.


- Audible Signal (not shown)** – Signals when ready to cook and when waffles are cooked and ready to eat.
- Cord Storage (not shown)** – Cord wraps around the back of the unit. Unit stands upright for compact storage.
- Rubber Feet** – Feet keep unit steady and won't mark countertop.
- Tongs** – for flipping and easy removal of cooked foods.
- BPA Free (not shown)**– All materials that come in contact with food are BPA free.

BEFORE THE FIRST USE

Remove all packaging and any promotional labels or stickers from your unit. Be sure that all parts (listed above, **Parts and Features**) have been included before discarding any packaging materials. You may want to keep the box and packing materials for use at a later date.

Before using your Cuisinart® Breakfast Central™ for the first time, wipe housing and plates with a damp cloth to remove any dust from the warehouse or shipping.

Note: The Cuisinart® Breakfast Central™ plates have been treated with a special nonstick coating. Before the first use, we suggest you season the grids with cooking spray or flavorless vegetable oil. If using oil, apply oil with a paper towel or pastry brush. You may find it helpful to repeat this process before each use.



ASSEMBLY INSTRUCTIONS

To insert plates

1. Place the closed unit on a clean, flat surface where you intend to use it.
2. Lift lid by grasping the handle and pushing up in one fluid motion. Lid will stay open at a 105° position until you lower it.
3. Insert one plate at a time.



Waffle plates: Each plate is designed to fit in either the upper housing or the lower housing of the waffle maker. The word LOWER or UPPER is embossed on the right side of each plate.



Pancake plate: The 4-slot plate is designed to fit in the lower housing only. The word LOWER is embossed on the right side of the plate. The flat plate is designed to fit in the upper housing only. The word UPPER is embossed on the right side of the plate.

4. Locate the two holes at the back of the housing. Tilt the back end of the plate and line up the pegs at the back of the plate with the holes at the housing. Slide the plate underneath the holes and push down the front end of the plate. It will snap into place.

To remove plates

1. Locate the plate release buttons on the right side of the unit. Press firmly on button and the plate will pop up slightly from the base.
2. Grasp the plate with two hands, slide it out from the holes at the housing, and lift it out of the base.
3. Press on the other plate release button to remove the second plate in the same manner.



OPERATING INSTRUCTIONS

1. Plug the power cord into a standard electrical outlet.
2. Adjust the temperature knob to the desired browning setting.
3. The red indicator light will turn on to signal that the power is on and the unit will begin to heat. We recommend preheating in the closed position. When the unit has reached desired temperature, the green indicator light will turn on and the audible tone will sound. You are now ready to begin.



Note: The first time you use your unit it may have a slight odor and may smoke a bit. This is normal, and common to appliances with a nonstick surface.

4. Please refer to the Cooking Chart on pg. 7 for further details on preparing foods.

CLEANING AND CARE

When you are finished cooking, turn the temperature knob to Off and unplug the power cord from the wall outlet. Allow the unit to cool down completely before handling.

Press the plate release buttons to remove plates from the housing. Be sure that the plates have cooled completely before handling (at least 30 minutes). The plates can be washed in the dishwasher. Do not use metallic objects such as knives or forks for cleaning. Do not use a scouring pad for cleaning. The nonstick coating can be damaged.


To clean exterior, wipe with a soft dry cloth. Never use an abrasive cleanser or harsh pad.

NEVER IMMERSIVE CORD, PLUG OR UNIT IN WATER OR OTHER LIQUIDS.

Any other servicing should be performed by an authorized service representative.

STORAGE

Store with plates inserted and cord wrapped securely around the back of the unit. For compact storage, stand the unit on its back end with the control panel facing up.



TIPS TO MAKE PERFECT WAFFLES

- Setting #1 will produce the lightest color waffles. Setting #6 will produce the darkest color waffles. Experiment to determine which setting produces the best waffle color for you. We recommend setting #4 or #5 for golden brown waffles.
- We recommend using a heaping 1½ cups of batter to fill the lower grid. Be careful not to over-mix the batter – this will produce dense, chewy waffles.
- For evenly filled waffles, pour the batter onto the center of the lower grid and spread it out evenly to the edges with a heat-proof spatula. The entire lower grid should be filled.
- Waffles are best when made to order, but baked waffles may be kept warm in a 200°F oven. Place them in a baking pan or cover loosely with foil while in the oven. Waffles wrapped in foil may lose their crispiness.
- Allow to cool completely. Use waxed paper to keep waffles separated, and place in plastic food storage bag and reheat in a toaster or toaster oven.

WARRANTY

Limited Three-Year Warranty

This warranty is available to consumers only. You are a consumer if you own a Cuisinart® Breakfast Central™ that was purchased at retail for personal, family or household use. Except as otherwise required under applicable law, this warranty is not available to retailers or other commercial purchasers or owners.

We warrant that your Cuisinart® Breakfast Central™ will be free of defects in materials and workmanship under normal home use for 3 years from the date of original

purchase.

We recommend that you visit our website, www.cuisinart.com for a fast, efficient way to complete your product registration. However, product registration does not eliminate the need for the consumer to maintain the original proof of purchase in order to obtain the warranty benefits. In the event that you do not have proof of purchase date, the purchase date for purposes of this warranty will be the date of manufacture.

If your Cuisinart® Breakfast Central™ should prove to be defective within the warranty period, we will repair it, or if we think necessary, replace it. To obtain warranty service, simply call our toll-free number, 1-800-726-0190, for additional information from our Customer Service Representatives, or send the defective product to Customer Service at Cuisinart, 7475 North Glen Harbor Blvd., Glendale, AZ 85307.

To facilitate the speed and accuracy of your return, please enclose \$10.00 for shipping and handling of the product. Please pay by check or money order (California residents need only supply proof of purchase and should call 1-800-726-0190 for shipping instructions).

NOTE: For added protection and secure handling of any Cuisinart product that is being returned, we recommend you use a traceable, insured delivery service. Cuisinart cannot be held responsible for in-transit damage or for packages that are not delivered to us. Lost and/or damaged products are not covered under warranty. Please be sure to include your return address, daytime phone number, description of the product defect, product model number (located on bottom of product), original date of purchase, and any other information pertinent to the product's return.

Your Cuisinart® Breakfast Central™ has been manufactured to the strictest specifications and has been designed for use only in 120-volt outlets with the authorized accessories and replacement parts.

This warranty expressly excludes any defects or damages caused by attempted use of this unit with a converter, accessories, replacement parts, or repair service other than those that have been authorized by Cuisinart.

This warranty does not cover any damage caused by accident, misuse, shipment or other than ordinary household use.

This warranty excludes all incidental or consequential damages. Some states do not allow the exclusion or limitation of these damages, so these exclusions may not apply to you.

CALIFORNIA RESIDENTS ONLY:

California law provides that for In-Warranty Service, California residents have the option of returning a nonconforming product (A) to the store where it was purchased or (B) to another retail store that sells Cuisinart products of the same type.

The retail store shall then, at its discretion, either repair the product, refer the consumer to an independent repair facility, replace the product, or refund the purchase price less the amount directly attributable to the consumer's prior usage of the product. If the above two options do not result in the appropriate relief to the consumer, the consumer may then take the product to an independent repair facility if service or repair can be economically accomplished. Cuisinart and not the consumer will be responsible for the reasonable cost of such service, repair, replacement, or refund for nonconforming products under warranty.

California residents may also, according to their preference, return nonconforming products directly to Cuisinart for repair, or if necessary, replacement, by calling our Consumer Service Center toll-free at 1-800-726-0190.

Cuisinart will be responsible for the cost of the repair, replacement, and shipping and handling for such products under warranty.

BEFORE RETURNING YOUR CUISINART PRODUCT

If you are experiencing problems with your Cuisinart product, we suggest that you call our Consumer Service Center at 1-800-726-0190 before returning the product to be serviced. If servicing is needed, a representative can confirm whether the product is under warranty and direct you to the nearest service location.

Important: If the nonconforming product is to be serviced by someone other than Cuisinart's Authorized Service Center, please remind the servicer to call our Consumer Service Center at 1-800-726-0190 to ensure that the problem is properly diagnosed, the product serviced with the correct parts, and the product is still under warranty.

COOKING CHART

Food	Plate	quantity	setting	time
waffle	waffle	1-1/2 cups	preference	
pancake	pancake	1/4 cup per pancake	4	2 to 3 minutes per side
eggs- sunny side up	pancake	1 large egg per compartment	4	2 to 3:30 minutes
eggs - scrambled	pancake	2 large eggs plus 2T liquid (e.g. cream, milk) per four compartments	4	2 minutes
Canadian bacon	pancake	1 slice per compartment	5	2 minutes per side
cooked sausage (patty, link)	pancake	1 cooked patty per compartment	5	2 to 3 minutes per side

RECIPES

Waffle Mix	7
Waffle Mix Waffles	8
Buttermilk Waffles	8
Overnight Yeasted Waffles	8
Multigrain Waffles	9
Buckwheat Waffles	9
Lemon Ginger Waffles	10
Gluten-Free Waffles	10
Banana Walnut Waffles	11
Chocolate Brownie Waffles	11
Cinnamon-Sugar Waffles	12
Maple Bacon Waffles	12
Savory Cheddar-Chive Waffles	13
Chicken and Waffles	13
Strawberry Shortcake Waffles	14
Blueberry Maple Syrup	14
Traditional Pancakes	15
Blueberry Sour Cream Pancakes	15
Multigrain Pancakes	15
Breakfast Sandwiches	16

Waffle Mix

Having a batch of this mix at the ready will allow you to make one batch of four waffles at a time. Just prepare as much or as little as you need. Our version is much healthier than purchased mixes.

Makes about 7½ cups of mix, enough to make 24 waffles

- 5½ cups unbleached, all-purpose flour**
- 1 cup wheat germ**
- 1 cup buttermilk powder***
- 3 tablespoons granulated sugar**
- 3 tablespoons baking powder**
- 2¼ teaspoons kosher salt**
- 1½ teaspoons baking soda**
- ¾ teaspoon cream of tartar**

1. Using a whisk, combine all ingredients thoroughly in a large mixing bowl.
2. Store in an airtight container in a cool, dry place for up to 6 months. You can store in the refrigerator, or freeze, for ultimate freshness.

*Buttermilk powder is available in most grocery stores. If you cannot find it, substituting nonfat dry milk is acceptable, but the results will not be as moist.

Waffle Mix Waffles

The recipe makes enough for two batches of waffles, but increase it for however many mouths you need to feed. The waffles freeze well and can be reheated quickly in a toaster oven.

Makes 8 waffles

- 2½ cups Waffle Mix (previous recipe)**
- 1¾ cups buttermilk**
- 1 large egg, lightly beaten**
- 1½ tablespoons grapeseed or vegetable oil**

1. Put all the ingredients into a medium mixing bowl. Whisk until just smooth. Let batter rest 5 minutes before using.
2. Preheat the Cuisinart® Breakfast Central™ to desired setting (a tone will sound when preheated).
3. Pour half of the batter (about 1½ heaping cups) onto the center of the lower grid of the preheated waffle maker; spread batter evenly using a heatproof spatula. Close lid of waffle maker. When tone sounds, waffles are ready. Open lid and carefully remove baked waffles. Repeat with remaining batter. For best results, serve immediately with desired toppings.

Nutritional information per waffle:

Calories 206 (22% from fat) • carb. 32g • pro. 9g • fat 5g
• sat. fat 1g • chol. 30mg • sod. 543mg
• calc. 236mg • fiber 1g

Buttermilk Waffles

Fresh, homemade waffles make breakfast a special occasion. Freeze the extras to use when time is short.

Makes 12 waffles

- 3 cups unbleached, all-purpose flour**
- 3 tablespoons yellow cornmeal**
- 3 tablespoons granulated sugar**
- 1 teaspoon baking soda**
- ¾ teaspoon kosher salt**
- 2½ cups buttermilk**
- 3 large eggs, lightly beaten**

- 1 teaspoon pure vanilla extract**
- ⅓ cup grapeseed or vegetable oil**

1. Combine all dry ingredients in a large mixing bowl; whisk until well blended. Add the liquid ingredients and whisk until just smooth. Let batter rest 5 minutes before using.
2. Preheat the Cuisinart® Breakfast Central™ to desired setting (a tone will sound when preheated).
3. Pour 1½ heaping cups of batter onto the center of the lower grid of the preheated waffle maker; spread batter evenly using a heatproof spatula. Close lid of waffle maker. When tone sounds, waffles are ready. Open lid and carefully remove baked waffles. Repeat with remaining batter. For best results, serve immediately.

Nutritional information per waffle:

Calories 269 (47% from fat) • carb. 29g • pro. 7g • fat 14g
• sat. fat 2g • chol. 50mg • sod. 291mg
• calc. 70mg • fiber 1g

Overnight Yeasted Waffles

This is the more authentic way of preparing waffles. The flavor cannot be matched!

Makes 8 waffles

- 1½ cups reduced-fat milk**
- ½ cup (1 stick) unsalted butter**
- 2 cups unbleached, all-purpose flour**
- 1½ teaspoons active, dry yeast**
- 2 tablespoons granulated sugar**
- 1 teaspoon kosher salt**
- 2 large eggs, lightly beaten**
- 1 teaspoon pure vanilla extract**

1. Put the milk and butter in a small saucepan set over medium-low heat. Once butter has melted, remove and cool until just warm. While the milk and butter are heating, whisk the flour, yeast, sugar and salt together in a large mixing bowl. Gradually add the warm milk/butter mixture and whisk until smooth. Add the eggs and vanilla and whisk until

combined. Cover with plastic and refrigerate at least 12 hours and up to 24 hours.

2. Preheat the Cuisinart® Breakfast Central™ to desired setting (a tone will sound when preheated).
3. Whisk batter to combine again (batter will deflate). Pour 1½ heaping cups of batter onto the center of the lower grid of the preheated waffle maker; spread batter evenly using a heatproof spatula. Close lid of waffle maker. When tone sounds, waffles are ready. Open lid and carefully remove baked waffles. Repeat with remaining batter. For best results, serve immediately.

Nutritional information per waffle:

Calories 255 (46% from fat) • carb. 28g • pro. 6g • fat 13g
• sat. fat 8g • chol. 80mg • sod. 323mg
• calc. 58mg • fiber 1g

Multigrain Waffles

A great mix of whole grains, healthy oils and nuts. Skip the sugary syrups and top with fresh fruit.

Makes 12 waffles

- 1 cup whole wheat flour
- 1 cup unbleached, all-purpose flour
- ½ cup rolled oats (not quick)
- 1 teaspoon baking powder
- ¼ teaspoon baking soda
- ½ teaspoon kosher salt
- ½ teaspoon ground cinnamon
- 1½ cups dairy-free milk (may substitute skim or lowfat)
- 2 large eggs, lightly beaten
- 2 tablespoons pure maple syrup
- 1 teaspoon pure vanilla extract
- ⅓ cup grapeseed or vegetable oil
- 2 tablespoons flaxseed oil
- 1 cup plain yogurt (preferably lowfat)
- ½ cup finely chopped pecans or walnuts (optional)

1. Combine the flours, oats, baking powder, baking soda, salt and cinnamon in a large mixing bowl; whisk until well blended. Add the milk, eggs, syrup and vanilla. Whisk until smooth. Stir in the oils and yogurt and whisk again until combined. Fold in the nuts, if using. Let batter rest 5 minutes before using.

2. Preheat the Cuisinart® Breakfast Central™ to desired setting (a tone will sound when preheated).

3. Pour 1½ heaping cups of batter onto the center of the lower grid of the preheated waffle maker; spread batter evenly using a heatproof spatula. Close lid of waffle maker. When tone sounds, waffles are ready. Open lid and carefully remove baked waffles. Repeat with remaining batter. For best results, serve immediately.

Nutritional information per waffle:

Calories 228 (50% from fat) • carb. 23g • pro. 6g • fat 13g
• sat. fat 2g • chol. 33mg • sod. 187mg
• calc. 83mg • fiber 2g

Buckwheat Waffles

Buckwheat imparts a nutty flavor to these waffles – they pair great with our Blueberry Maple syrup on page 14.

Makes 16 waffles

- 2 cups unbleached, all-purpose flour
- 1 cup buckwheat flour
- 3 tablespoons yellow cornmeal
- 3 tablespoons granulated sugar
- 1 teaspoon baking soda
- ¾ teaspoon kosher salt
- 3 cups buttermilk
- 3 large eggs, lightly beaten
- 1 teaspoon pure vanilla extract
- ⅓ cup grapeseed or vegetable oil

1. Combine the flours, cornmeal, sugar, baking soda and salt; whisk until well blended. Add the buttermilk, eggs and vanilla. Whisk until smooth. Stir in the oil and whisk again until combined. Let batter rest 5 minutes before using.

- Preheat the Cuisinart® Breakfast Central™ to desired setting (a tone will sound when preheated).
- Pour 1½ heaping cups of batter onto the center of the lower grid of the preheated waffle maker; spread batter evenly using a heatproof spatula. Close lid of waffle maker. When tone sounds, waffles are ready. Open lid and carefully remove baked waffles. Repeat with remaining batter. For best results, serve immediately.

Nutritional information per waffle:

*Calories 211 (46% from fat) • carb. 23g • pro. 6g • fat 11g
• sat. fat 2g • chol. 23mg • sod. 221mg
• calc. 65mg • fiber 1g*

Lemon Ginger Waffles

These waffles are simply our Buttermilk Waffles with a few added ingredients. They are fresh and sweet – perfect when paired with warm maple syrup.

Makes 16 waffles

- 3½ cups unbleached, all-purpose flour**
- 3 tablespoons yellow cornmeal**
- 3 tablespoons granulated sugar**
- 1 teaspoon baking soda**
- ¾ teaspoon kosher salt**
- ¼ teaspoon ground ginger**
- 1 tablespoon lemon zest**
- ½ cup finely chopped candied/crystallized ginger**
- 3 cups buttermilk**
- 3 large eggs, lightly beaten**
- 1 teaspoon pure vanilla extract**
- ⅔ cup grapeseed or vegetable oil**

- Combine the flour, cornmeal, sugar, baking soda, salt and ground ginger in a large mixing bowl; whisk until well blended. Stir in the zest and candied ginger. Add the liquid ingredients and whisk until just smooth. Let batter rest 5 minutes before using.
- Preheat the Cuisinart® Breakfast Central™ to desired setting (a tone will sound when preheated).

- Pour 1½ heaping cups of batter onto the center of the lower grid of the preheated waffle maker; spread batter evenly using a heatproof spatula. Close lid of waffle maker. When tone sounds, waffles are ready. Open lid and carefully remove baked waffles. Repeat with remaining batter. For best results, serve immediately.

Nutritional information per waffle:

*Calories 221 (43% from fat) • carb. 26g • pro. 6g • fat 11g
• sat. fat 2g • chol. 38mg • sod. 195mg
• calc. 63mg • fiber 1g*

Gluten-Free Waffles

Just like our buttermilk waffles, but without the gluten, these are light and crispy. They are extra-decadent when served with fresh fruit.

Makes 12 waffles

- 3½ cups rice flour**
- ½ cup tapioca starch (flour)**
- ¼ cup milk powder**
- ¼ cup granulated sugar**
- 1 tablespoon baking powder**
- 1½ teaspoons kosher salt**
- 2½ cups buttermilk**
- 2 large eggs, lightly beaten**
- 1 tablespoon pure vanilla extract**
- ½ cup grapeseed or vegetable oil**

- Combine the dry ingredients; whisk until well blended. Add the remaining ingredients and whisk until just combined. Let batter rest 5 minutes before using.
- Preheat the Cuisinart® Breakfast Central™ to desired setting (a tone will sound when preheated).
- Pour 1½ heaping cups of batter onto the center of the lower grid of the preheated waffle maker; spread batter evenly using a heatproof spatula. Close lid of waffle maker. When tone sounds, waffles are ready. Open lid and carefully remove baked waffles. Repeat with remaining batter. For best results, serve immediately.

Nutritional information per waffle:

*Calories 292 (36% from fat) • carb. 40g • pro. 7g • fat 12g
• sat. fat 2g • chol. 25mg • sod. 409mg
• calc. 99mg • fiber 1g*

Banana Walnut Waffles

Classic waffle for a weekend brunch.

Makes 12 waffles

- 2 cups unbleached, all-purpose flour**
- 2 tablespoons granulated sugar**
- 1 teaspoon baking powder**
- ½ teaspoon baking soda**
- ½ teaspoon kosher salt**
- 2 large eggs, lightly beaten**
- ⅓ cup grapeseed or vegetable oil**
- 1 cup low-fat vanilla yogurt (or you can use plain yogurt – if doing so, stir 1 teaspoon pure vanilla extract into the yogurt)**
- ¾ cup buttermilk**
- 1 cup mashed banana (about 2 medium bananas)**
- ½ cup toasted, chopped walnuts**

1. Using a whisk, combine the flour, sugar, baking powder, baking soda and salt in a large mixing bowl. Add the eggs and oil and whisk until blended. Stir in the yogurt and then the buttermilk, and whisk until mixture is smooth. Stir in banana and walnuts until incorporated. Let batter rest 5 minutes before using.
2. Preheat the Cuisinart® Breakfast Central™ to desired setting (a tone will sound when preheated).
3. Pour 1½ heaping cups of batter onto the center of the lower grid of the preheated waffle maker; spread evenly using a heatproof spatula. Close cover of waffle maker. When tone sounds, waffles are ready. Open cover and carefully remove baked waffles. Repeat with remaining batter. For best results, serve immediately.

Nutritional information per waffle:

Calories 213 (42% from fat) • carb. 26g • pro. 6g • fat 10g
• sat. fat 1g • chol. 32mg • sod. 217mg
• calc. 73mg • fiber 1g

Chocolate Brownie Waffles

Kids will love having chocolate for breakfast, but these waffles also make a delicious dessert when topped with whipped cream or ice cream and berries.

Makes 12 waffles

- 2 cups unbleached, all-purpose flour**
- ¾ cup granulated sugar**
- ⅓ cup unsweetened cocoa powder, sifted**
- 1 tablespoon baking powder**
- ½ teaspoon baking soda**
- ½ teaspoon kosher salt**
- ½ teaspoon ground cinnamon**
- 2 cups reduced-fat milk**
- 2 large eggs, lightly beaten**
- 1 teaspoon pure vanilla extract**
- ¼ cup (½ stick) unsalted butter, melted, cooled slightly**
- ⅓ cup semisweet mini chocolate morsels**
- ½ cup finely chopped walnuts or pecans**

1. Combine the flour, sugar, cocoa powder, baking powder, baking soda, salt, and cinnamon in a large mixing bowl; whisk to blend. Add the milk, eggs and vanilla. Whisk until well blended and smooth. Stir in melted butter until completely combined. Fold in morsels and nuts. Let batter rest 5 minutes.
2. Preheat the Cuisinart® Breakfast Central™ to desired setting (a tone will sound when preheated).
3. Pour 1½ heaping cups of batter onto the center of the lower grid of the preheated waffle maker; spread evenly using a heatproof spatula. Close cover of waffle maker. When tone sounds, waffles are ready. Open cover and carefully remove baked waffles. Repeat with remaining batter. For best results, serve immediately.

Nutritional information per waffle:

Calories 296 (36% from fat) • carb. 41g • pro. 7g • fat 12g
• sat. fat 5g • chol. 44mg • sod. 248mg
• calc. 58mg • fiber 2g

Cinnamon Sugar Waffles

The aroma of sweet cinnamon that fills your kitchen while these are baking is reason enough to whip up a batch of these delicious waffles!

Makes 12 waffles

- 3 cups unbleached, all-purpose flour**
- 3 tablespoons yellow cornmeal**
- ¼ cup packed light or dark brown sugar**
- 1 teaspoon baking soda**
- ¾ teaspoon kosher salt**
- 1 tablespoon ground cinnamon**
- 2½ cups buttermilk**
- 3 large eggs, lightly beaten**
- 1 teaspoon pure vanilla extract**
- ⅔ cup grapeseed or vegetable oil**

1. Combine the flour, cornmeal, sugar, baking soda, salt and cinnamon in a large mixing bowl; whisk to blend. Add the buttermilk, eggs, vanilla and the oil. Whisk until well blended and smooth. Let batter rest 5 minutes.
2. Preheat the Cuisinart® Breakfast Central™ to desired setting (a tone will sound when preheated).
3. Pour 1½ heaping cups of batter onto the center of the lower grid of the preheated waffle maker; spread evenly using a heatproof spatula. Close cover of waffle maker. When tone sounds, waffles are ready. Open cover and carefully remove baked waffles. Repeat with remaining batter. For best results, serve immediately.

Nutritional information per waffle:

Calories 274 (46% from fat) • carb. 30g • pro. 7g • fat 14g
• sat. fat 2g • chol. 50mg • sod. 286mg
• calc. 74mg • fiber 1g

Maple Bacon Waffles

When making the bacon for these waffles, be sure to save the bacon grease to incorporate into the batter – it gives the waffles a tasty smoky flavor. If that is too intense, vegetable oil can be used in its place.

Makes about 16 waffles

- 3½ cups unbleached, all-purpose flour**
- 3 tablespoons yellow cornmeal**
- 1 teaspoon baking soda**
- ¾ teaspoon kosher salt**
- 8 to 10 slices cooked bacon, crumbled (about ¼ cup once crumbled)**
- ¾ cups buttermilk**
- ⅓ cup pure maple syrup**
- 3 large eggs, lightly beaten**
- 1 teaspoon pure vanilla extract**
- ⅔ cup bacon grease and/or grapeseed or vegetable oil (the two can be mixed to reach ⅔ cup)**

1. Combine the flour, cornmeal, baking soda and salt in a large mixing bowl; whisk to blend. Stir in the bacon to coat. Add the buttermilk, syrup, eggs, vanilla and the grease/oil. Whisk until well blended and smooth. Let batter rest 5 minutes.
2. Preheat the Cuisinart® Breakfast Central™ to desired setting (a tone will sound when preheated).
3. Pour 1½ heaping cups of batter onto the center of the lower grid of the preheated waffle maker; spread evenly using a heatproof spatula. Close cover of waffle maker. When tone sounds, waffles are ready. Open cover and carefully remove baked waffles. Repeat with remaining batter. For best results, serve immediately.

Nutritional information per waffle:

Calories 235 (44% from fat) • carb. 26g • pro. 6g • fat 12g
• sat. fat 2g • chol. 40mg • sod. 262mg
• calc. 73mg • fiber 0g

Savory Cheddar-Chive Waffles

These crispy, savory waffles are good to serve with soup or your favorite chili in place of corn muffins. You may also try them with scrambled eggs and bacon for brunch or supper.

Makes 16 waffles

- 3½ cups unbleached, all-purpose flour**
- 3 tablespoons yellow cornmeal**
- 2 tablespoons granulated sugar**
- 1 teaspoon baking soda**
- 1 teaspoon kosher salt**
- 3 cups buttermilk**
- 3 large eggs, lightly beaten**
- ⅔ cup grapeseed or vegetable oil**
- ¼ cup chopped fresh chives**
- 1 cup shredded, extra-sharp Cheddar**

1. Combine the flour, cornmeal, sugar, baking soda and salt in a large mixing bowl; whisk to combine. Add the buttermilk, eggs and oil; whisk until just combined. Stir in the chives and Cheddar. Let batter rest 5 minutes before using.
2. Preheat the Cuisinart® Breakfast Central™ to desired setting (a tone will sound when preheated).
3. Pour 1½ heaping cups of batter onto the center of the lower grid of the preheated waffle maker; spread evenly using a heatproof spatula. Close cover of waffle maker. When tone sounds, waffles are ready. Open cover and carefully remove baked waffles. Repeat with remaining batter. For best results, serve immediately.

Nutritional information per waffle:

Calories 243 (48% from fat) • carb. 24g • pro. 7g • fat 13g
• sat. fat 3g • chol. 45mg • sod. 274mg
• calc. 113mg • fiber 1g

Chicken and Waffles

This is a Southern staple in many households that you can easily make for your family. The chicken is best when marinated overnight, but if you are in a hurry you can have it marinate for a minimum of 3 hours.

Makes 8 servings

Fried Chicken:

- 2 cups buttermilk**
- 1 tablespoon hot sauce**
- 1 tablespoon Dijon mustard**
- 1½ teaspoons kosher salt, divided**
- 1½ teaspoons freshly ground black pepper, divided**
- 8 thin chicken cutlets (about 1½ pounds)**
- 2 cups unbleached all-purpose flour**
- 1½ teaspoons baking powder**
- 1 teaspoon paprika**
- oil for frying (such as vegetable, canola or grapeseed)**
- 4 prepared Savory Cheddar-Chive Waffles (see previous recipe), kept warm**

1. In a medium nonreactive bowl stir together the buttermilk, hot sauce, mustard, 1 teaspoon salt and 1 teaspoon pepper. Add the chicken pieces and coat well with buttermilk mixture. (This can also be stored in a large resealable bag if preferred.) Refrigerate overnight.
2. Mix together the flour, baking powder, paprika and remaining salt and pepper.
3. Preheat a Cuisinart® Compact Deep Fryer to 375°F*. While the oil is heating, line a baking pan with paper towels and insert a cooling rack inside the pan; reserve.
4. While oil is heating, remove chicken from buttermilk, letting excess liquid drop back into bowl or bag.
5. Dredge each chicken piece in the flour mixture, tapping away any excess.
6. Fry chicken in batches, about 3 minutes per side. Internal temperature of chicken should

register 165°F. Transfer to prepared cooling rack.

7. To serve, halve the waffles on the diagonal and serve half with one piece of fried chicken and maple syrup on the side.

*If you do not have a deep fryer, the chicken can easily be fried on the stovetop. In a large sauté pan, add no more than 1 inch of oil and set the pan over medium-high heat. Using a deep fat thermometer, bring oil to 375°F. Fry the chicken in batches, about 2 pieces at a time. You do not want to crowd the pan or the oil will cool down too much and not fry well. Fry, flipping once, until chicken is nicely browned, about 4 to 5 minutes per side. Chicken should have an internal temperature of 165°F. Transfer chicken to the prepared cooling rack.

Nutritional information per serving:

Calories 382 (54% from fat) • carb. 20g • pro. 24g • fat 23g
• sat. fat 4g • chol. 79mg • sod. 521mg
• calc. 99mg • fiber 0g

Strawberry Shortcake Waffles

For a more classic presentation, use the Buttermilk Waffle recipe on page 8. If you are in the mood for a bit more of an indulgence, use the Chocolate Brownie Waffle, page 11, for those chocolate lovers.

Makes 8 servings

- 1 **quart fresh strawberries, hulled and sliced**
- 3 **tablespoons granulated sugar**
pinch kosher salt
- 1 **cup heavy cream**
- 3 **tablespoons confectioners' sugar, plus more for serving (if desired)**
pinch kosher salt
- ½ **teaspoon pure vanilla extract**
- 4 **prepared waffles**

1. In a medium mixing bowl, stir the strawberries, granulated sugar and pinch of salt together. Let sit to macerate until ready to serve.

2. In a large mixing bowl combine the heavy cream, confectioners' sugar, salt and vanilla. Using a Cuisinart hand mixer fitted with the whisk attachment, whisk until medium-soft peaks are achieved. Reserve.
3. To serve, halve each waffle. Top with whipped cream, then some of the macerated strawberries. Drizzle a bit of the juice from the strawberries (collected at the bottom of the mixing bowl) over the strawberries. Dust with confectioners' sugar if desired. Per waffle you should only need about ⅓ cup of the whipped cream and ⅓ cup of the strawberries.

Nutritional information per serving:

Calories 560 (27% from fat) • carb. 99g • pro. 4g • fat 17g
• sat. fat 9g • chol. 65mg • sod. 193mg
• calc. 47mg • fiber 2

Blueberry Maple Syrup

A great change-up from regular maple syrup – the color of the syrup adds nice color to any breakfast plate.

Makes about 2 cups (1½ cups if strained)

- 1 **cup pure maple syrup**
- 1½ **cups fresh blueberries**
pinch kosher salt
pinch orange zest (optional)

1. Put all ingredients in a small saucepan set over medium heat. Bring to a boil and then reduce heat to maintain a strong simmer to allow the mixture to thicken slightly, about 5 minutes.
2. Strain, if desired, and serve.

Nutritional information per serving (2 tablespoons):

Calories 60 (1% from fat) • carb. 15g • pro. 0g • fat 0g
• sat. fat 0g • chol. 0mg • sod. 11mg
• calc. 21mg • fiber 0g

Traditional Pancakes

Great basic go-to pancake recipe.

Makes about 16 pancakes

- 1¼ cups unbleached, all-purpose flour**
- 1 tablespoon granulated sugar**
- 1 tablespoon baking powder**
- ½ teaspoon table salt**
- 2 large eggs**
- 1 cup reduced-fat milk**
- ½ teaspoon pure vanilla extract**
- 2 tablespoons unsalted butter, melted**

1. In a medium bowl, whisk together the flour, sugar, baking powder and salt; reserve. In a separate small bowl, whisk together the eggs, milk and vanilla.
2. Gently whisk the wet ingredients into the dry ingredients until just combined. Gently whisk in the butter.
3. Fit the Cuisinart® Breakfast Central™ with the pancake plates. Adjust the temperature setting to 4. Once preheated, pour ¼ cup of batter in each pancake mold. Cook for about 2 to 2½ minutes each side.
4. Serve immediately.

Nutritional information per serving (1 pancake):

*Calories 64 (32% from fat) • carb. 9g • pro. 2g • fat 6g
• sat. fat 1g • chol. 28mg • sod. 181mg
• calc. 74mg • fiber 0g*

Blueberry Sour Cream Pancakes

Sweet and light, these pancakes are a favorite.

Makes 12 pancakes

- 1¼ cups unbleached, all-purpose flour**
- 3 tablespoons granulated sugar**
- 2 teaspoons baking powder**
- ¼ teaspoon baking soda**
- ¾ teaspoon table salt**

- ⅓ cup sour cream**
- ¾ cup reduced-fat milk**
- 1 large egg**
- 1 teaspoon pure vanilla extract**
- 2 tablespoons unsalted butter, melted and cooled slightly**
- 1 cup fresh blueberries**

1. In a medium bowl, whisk together the flour, sugar, baking powder, baking soda and salt; reserve. In a separate small bowl, whisk together the sour cream, milk, egg and vanilla.
2. Gently whisk the wet ingredients into the dry ingredients until just combined. Carefully fold in the butter and blueberries.
3. Fit the Cuisinart® Breakfast Central™ with the pancake plates. Adjust the temperature setting to 4. Once preheated, pour ¼ cup of batter in each pancake mold. Cook in the closed position for about 2½ to 3 minutes each side.
4. Serve immediately.

Nutritional information per serving (1 pancake):

*Calories 101 (36% from fat) • carb. 14g • pro. 2g • fat 4g
• sat. fat 2g • chol. 25mg • sod. 272mg
• calc. 76mg • fiber 1g*

Multigrain Pancakes

These pancakes have a pleasant texture and taste – multigrains never tasted so good!

Makes 12 pancakes

- ¾ cup whole wheat flour**
- ¼ cup unbleached, all-purpose flour**
- ¼ cup rolled oats**
- 2 tablespoons wheat germ**
- 1 tablespoon light brown sugar**
- ¾ teaspoon baking soda**
- ¾ teaspoon baking powder**
- ½ teaspoon kosher salt**
- 2 large eggs**
- 1 cup whole-milk yogurt**
- 2 tablespoons flax oil**
- 1 teaspoon pure vanilla extract**

1. In a medium bowl, whisk together the flours, oats, wheat germ, sugar, baking soda, baking powder and salt; reserve. In a separate small bowl, whisk together the eggs, yogurt, oil and vanilla.
2. Gently whisk the wet ingredients into the dry ingredients until just combined. Fit the Cuisinart® Breakfast Central™ with the pancake plates. Adjust the temperature setting to 4. Once preheated, pour ¼ cup of batter in each pancake mold. Cook for about 2 to 2½ minutes each side.
3. Serve immediately.
2. While the bacon is cooking, whisk the eggs, cream, salt and pepper together in a liquid measuring cup. After the bacon is finished cooking, pour equal amounts of the egg mixture in each compartment. Cook in the closed position for about 1½ to 2 minutes. Place the cheese in equal amounts on each egg. Close and cook for an additional 30 seconds to melt.
3. If desired, butter the English muffins. Place the bacon and then the egg on each open toasted English muffin. Serve immediately.

Nutritional information per serving (1 sandwich):

*Calories 263 (34% from fat) • carb. 26g • pro. 16g • fat 10g
 • sat. fat 5g • chol. 126mg • sod. 751mg
 • calc. 84mg • fiber 3g*

Nutritional information per serving (1 pancake):

*Calories 80 (34% from fat) • carb. 11g • pro. 2g • fat 3g
 • sat. fat 1g • chol. 3mg • sod. 207mg
 • calc. 31mg • fiber 1g*

Breakfast Sandwiches

The pancake plates make perfectly shaped eggs for this delicious and simple breakfast sandwich.

Makes 4 sandwiches

- 4 slices Canadian bacon**
- 2 large eggs**
- 2 tablespoons heavy cream or milk**
- ¼ teaspoon kosher salt**
- ⅛ teaspoon freshly ground pepper**
- ¼ cup shredded cheese (Cheddar, Swiss, Havarti etc)**
- 4 toasted English muffins**
- Unsalted butter, optional**

1. Fit the Cuisinart® Breakfast Central™ with the pancake plates. Adjust the temperature setting to 5. Once the unit is preheated, place a slice of bacon in each compartment. Cook in the closed position, about 2 minutes per side. Remove and reserve.

Any other trademarks or service marks referred to herein are the trademarks or service marks of their respective owners.

©2013 Cuisinart
 150 Milford Road
 East Windsor, NJ 08520
 Printed in China
 13CE138414

IB-12015-ESP

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>