

EQUIPMENT APPROVAL INFORMATION

Your telephone equipment is approved for connection to the Public Switched Telephone Network and is in compliance with parts 15 and 68, FCC Rules and Regulations and the Technical Requirements for Telephone Terminal Equipment published by ACTA.

Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the US number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

- This equipment may not be used on coin service provided by the telephone company
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local
- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line
- If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer

Model 27977 55925250 (Rev. 1 DOM E) Printed in China

ATLINKS USA, Inc. 101 West 103rd Street Indianapolis, IN 46290 © 2004 ATLINKS USA, Inc. Marca(s) ® Registrada(s)

2 Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinu (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you

HEARING AID COMPATIBILITY (HAC)

This telephone system meets FCC standards for Hearing Aid Compatibility

US NUMBER IS LOCATED ON THE CABINET BOTTOM
REN NUMBER IS LOCATED ON THE CABINET BOTTOM

INTRODUCTION



CAUTION: When using telephone equipment there are basic safety instructions that should always be followed. Refer to the IMPORTANT SAFETY INSTRUCTIONS provided with this product and save them for future reference.

Your Caller ID phone stores and displays specific information provided by your local telephone company, to subscribers of Caller ID or similar caller identification services

Your Call Waiting Caller ID phone enables you to:

- Identify callers before you answer the phone.
- View the time and date of each incoming call.
- Record up to 40 Caller ID messages sequentially.
- Know who called while you were away.


To get the most from your new phone, we suggest that you take a few minutes right now to read through this user's guide.

IMPORTANT: In order to use all of the features of this phone, you must subscribe to either the standard Name/Number Caller ID Service or Call Waiting Caller ID Service. To know who is calling while you are on the phone, you must subscribe to Call Waiting Caller ID Service.

IMPORTANT: Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home

| WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSETHIS PRODUCT TO RAIN | THE LIGHTNING FLASH AND ARROW HEAD WITHIN THE TRIANGE IS A WARNING SIGN ALERTING YOU OF "DANGEROUS VOLTAGE" INSIDE THE PRODUCT. | CAUTION: RISKOFELECTRIC SHOCK DONOTOPEN CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK), NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO UDIALIFIED SERVICE PERSONNEL | THE EXCLAMAN POINT WITHIN TRIANGLE IS A WARNING SIG! ALERTING YOU IMPORTANT INSTRUCTIONS ACCOMPANYIN THE PRODUCT. | |
|--|---|---|---|--|
| OR MOISTURE. | SEE MARKING ON BOTTOM / BACK OF PRODUCT | | | |
| | | | | |

DIALING PAD AND BASE LAYOUT



BEFORE YOU BEGIN

PARTS CHECKLIST

Make sure your package includes the items shown here.









TELEPHONE JACK REQUIREMENTS

To use this phone, you need an RJ11C type modular telephone jack, which night look like the one pictured here. installed in your home. If you don't have a modular jack, call your local phone company to find out how to get



Installation

AC power supply



- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch non-insulated telephone wires or terminals, unless the telephone line has been disconnected at the network interface.
- · Use caution when installing or modifying telephone lines.
- Temporarily disconnect any equipment connected to the phone such as faxes, other phones, or modems

IMPORTANT INSTALLATION GUIDELINES

- Install telephone near both a telephone (modular) jack and an electrical power outlet.
- Avoid sources of noise, such as a window by a busy street, and electrical noise, such motors, microwave ovens, and fluorescent lighting.
- Avoid heat sources, such as heating air ducts, heating appliances, radiators, and direct sunlight
- Avoid areas of excessive moisture or extremely
- Avoid dusty locations.
- · Avoid other cordless telephones or personal computers.

INSTALLATION NOTE: Some cordless telephones operate at frequencies that may cause interference to nearby TVs, microwave ovens, and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV microwave ovens or VCR If such interference ontinues, move the cordless telephone farther away

DIGITAL SECURITY SYSTEM

Your cordless phone uses a digital security system to provide protection against false ringing, unauthorized access, and charges to your phone line.

When you place the dialing pad in the base, the unit verifies its security code. After a power outage or battery replacement, you should place the dialing pad in the base for about 20 seconds to reset the code.

CONNECTING THE BATTERY

- 1. Plug the battery cord into the jack located inside the battery compartment of the dial pad.
- 2. Put the battery compartment door on to the dial pad.

PRIOR TO USE



CHARGE FOR 12 HOURS

BELT CLIP

Attach the belt clip by inserting the sides of the belt clip into the slots on each side of the dialing pad. Snap the ends of the belt



CONNECTING THE HEADSET TO THE DIALING PAD

- 1. For hands free conversation connect the headset to the **HEADSET** jack as shown.
- 2. Adjust the headset to rest comfortably at the back of your head and over your ears. Move the crophone to approximately 2 to 3 inches from your mouth

CAUTION

- L. Do not twist the headset cord. Handle the headset properly and carefully.
- 2. Always have the headset plugged into the dialing pad.
- 3. Whenever you make or receive a call, the headset should be plugged into the dialing pad, and you must use the headset to listen and talk.
- 4. Place the dialing pad on the base

NOTE: The phone will ring while the dialing pad is in the charge cradle, but you cannot answer a call

TIP: To order a new headset, please refer to the accessory order form at the end of this user's guide

CONNECTING THE AC (ELECTRICAL) POWER

NOTE: The dialing pad is charged facing up only

Plug the power supply into the power lack on the back of base and the other end into an electrical outlet. The CHARGE/IN USE indicator turns on, verifying the battery is charging. If the dialing pad is not in the cradle, the CHARGE/IN USE indicator is not lit.



CAUTION: Use only the ATLINKS USA, Inc. 5-2639 power supply that came with this time.
Using other power supplies may damage the unit. 5-2639 power supply that came with this unit

Allow the phone to charge for 12 hours prior to first use. If you don't properly charge the phone, battery performance is compromised.

NOTE: DO NOT connect the telephone line to the modular jack until the phone has charged for 12 hours.

CONNECTING THE TELEPHONE LINE

- 1. Plug the telephone line cord into the TEL LINE jack on the bottom of the base and into a modular jack.
- 2. Set the RINGER switch, on the dialing pad, to ON and place the dialing pad in the base.

NOTE: The phone automatically defaults to touchtone dialing. To change to pulse (rotary) dialing, see "Tone/Pulse Dialing Selection." If you don't know which type of service you have, check with your local telephone company

Installing the INTERCHANGEABLE COVER

This phone comes with interchangeable colored covers for the handset, headset and base. Choose among four color sets (one set installed) to suit your personal preference

CHANGING THE HANDSET COVER

- 1. Carefully remove the existing handset cover by prying up the notch at the bottom of the cover.
- 2. Reattach new cover by snapping the upper portion of the cover into position first, and then snap the lower portion into place.

CHANGING THE BASE COVER 3. Press flash/program to confirm. TELEPHONE OPERATION

- 1. Carefully remove the existing base cover by prying up the notch at the top back edge of the cover.
- 2. Align the new base cover, and snap it securely into place

CHANGING THE HEADSET COVER

- 1. Carefully remove the existing headset cover by prying up the notch on the cover.
- 2. Align the new headset cover, and snap it securely

NOTE: The phone automatically defaults to touch-tone dialing. To change to pulse (rotary) dialing, see "Tone, Pulse Dialing." If you don't know which type of service you have, check with your local telephone company.

SET UP

There are eight programmable menus available: Language, Area Code, Tone/Pulse, Set Animation, Animation Select, Dancing Keypad, Ringer Tone and Default Setting.

LANGUAGE SETTING SELECTION

- 1. Press the flash/program button until >ENG FRA ESP shows in the display. ENG (English) is the default setting.
- Use the ▼ or ▲ button to scroll to your selection.

3. Press flash/program to store selection. AREA CODE SELECTION

- 1. Press the flash/program button until AREA CODE --- shows in the display. - - - is the default setting.
- 2. Use the number pad to enter your three digit area code.

NOTE: If you make a mistake, press the ch/delete button to erase the wrong area code and repeat step 2.

3. Press flash/program to store selection.

Tone/Pulse Dialing Selection

- 1. Press the flash/program button until >TONE PULSE shows in the display. TONE is the default setting.
- 2. Use the ▼ or ▲ button to move the arrow to TONE
- 3. Press flash/program to store selection.

ANIMATION

This setting lets you choose the animation that shows in the display when the handset rings. Choices are: KNOWN CALLERS (refer to Storing a Name and Number in Memory for selection), ALL CALLS and OFF.

- 1. Press the flash/program button until SETUP ANIMATION shows in the display. KNOWN CALLERS is the default setting.
- 2. Use the ▼ or ▲ button to select KNOWN CALLERS, ALL CALLS or OFF
- 3. Press flash/program to save.

Animation Selection

This setting lets you select one of five display animations. 1. Press the flash/program button until ANIMATION shows in

the display, ANIMATION 1 is the default setting.

- 2. Use the ▼ or ▲ button or the touch tone pad to make your selection. The current animation is displayed on the first line of the display.
- 3. Press flash/program to save.

DANCING KEYPAD

Your touch tone pad is pre-programmed to "dance" when alert

- 1. Press the flash/program button until DANCING KEYPAD shows in the display. ON is the default setting. 2. Use the ▼ or ▲ button to choose ON or OFF
- 3. Press flash/program to save

RINGERTONE SELECTION

- 1. Press the flash/program button until RINGERTONE shows in the display. RINGERTONE 1 is the default setting.
- Use the ▼ or ▲ button or the touch tone to choose a
- 3. Press flash/program to save

DEFAULT SETTING SELECTION FINDING THE DIALING PAD

This feature helps to locate a misplaced dialing pad. Press the page button on the base. The dialing pad beeps continuously for about two minutes or until you press any button on the dialing pad. You may also press page to cancel.

NOTE: The ringer does not have to be ON for this featur

The RINGER switch must be ON for the dialing pad to ring during incoming calls.

VOLUME

While the phone is ON, press the ▲ or ▼ buttons to control the headset volume. There are four volume levels. Press the - button to increase the volume level, and press the volume level shows in the

CALL TIMER

While you are talking on the phone, the total talk time is

CALLER ID (CID) FEATURES



This unit receives and displays Caller ID information transmitted by your local phone company. This information may include the phone number, date, and time; or the name, phone number, date, and time. The unit stores up to 40 calls for later review.

Provided you subscribe to Call Waiting Caller ID service from your phone company, you may see in the display who is calling when you hear the call waiting beep. The caller identification information appears in the display after you

IMPORTANT: In order to use all of the features of this unit, you must subscribe to either the standard Name/Number Caller ID Service or Call Waiting Caller ID Service To know who is calling while you are on the phone, you must subscribe to Call Waiting Caller ID Service.

RECEIVING AND STORING CID RECORDS

When you receive a call, the information is transmitted by the phone company to your Caller ID telephone between the first

When the units Caller ID memory is full, a new call record

automatically replaces the oldest call record in memory NEW

appears in the display for calls received that have not been

reviewed. REPT indicates that a new call from the same number was received more than once.

name service availability

As calls are received and stored, the display is updated to let

- Press the ▼ button to scroll through the call records from the most recent to the oldest.
- the oldest to the newest

TO MEMORY

You may transfer a Caller ID record to your phone's memory.

re-format CID records stored in memory.

Use the ▼ or ▲ button to scroll to the desired record.

1. Press the flash/program button until DEFAULT shows in the display. NO is the default setting.

MAKING OR ANSWERING CALLS

• The dialing pad is disabled when it is in the base

from the base to make or answer a call.

· Always keep the headset plugged into the

You must use the headset to listen and talk

tone, to answer a call, or to hang up. Or dial the teleph

number first, and then press the TALK/CALLBACK button

call hangs up the phone

dialing pad.

shows in the display.

return to your phone conversation.

MUTE

REDIAL

FLASH

your local phone company

up the phone

tone dialing.

(rotary) dialing mode

you need.

EXIT

vou initiated.

charging cradle. You must remove the dialing pad

Placing the dialing pad in the base during a phone

Press the TALK/CALLBACK button on the dialing pad to get a dial

To have a private, off-line conversation use the mute feature

The party on the telephone line will not hear you, but you can

1. Press the format/mute button on the handset. MUTE ON

2 Press the format/mute button again to cancel mute and

While the phone is on, press the redial button to redial the

last number you dialed (up to 32 digits). If you get a busy

again (you don't have to turn the phone off and back on).

signal, and want to keep dialing the number, just press redial

Use the flash/program button to activate custom calling services

such as call waiting or call transfer, which are available through

TIP: Don't use the TALK/CALLBACK button to activate

The CHARGE/IN USE indicator is lit when the dialing pad is

flashes when you receive an incoming call, when the PAGE

button is pressed, or if the battery is not installed in the

charging in the cradle on the base or when the phone is ON. It

While talking, you might need to manually change the channel

n order to get rid of static. Press and release the ch/delete

This feature is useful only if you use pulse dialing service.

Temporary tone dialing enables pulse (rotary) service phone

users to access touch-tone services offered by banks, credit

temporary tone feature allows you to temporarily switch to

card companies, etc. For example, when you call your bank

you may need to enter your account number. Using the

touch tone mode so you can enter and send your number.

2. When your call is answered, press the *tone/exit button on

3. Follow the automated instructions to get the information

4. To hang up, press the TALK/CALLBACK button on the

Press the *tone/exit button to cancel any command

the dialing pad to temporarily change from pulse dialing to

dialing pad, and the phone automatically returns to pulse

1. Dial the telephone number and wait for the line

IN USE INDICATOR LIGHT

battery compartment of the dial pad.

button to advance to the next channel.

TEMPORARY TONE DIALING

CHANNEL BUTTON

custom calling services such as call waiting, or you'll hang

YES, the unit resets to the factory default.

2. Use the ▼ or ▲ button or the number pad to move the arrow to >NO or YES. If you choose NO, the current settings remain. If you choose

RINGER SWITCH

display. VOL 1 is the lowest level and VOL 4 is the loudest.



CALL WAITING CALLER ID

• Press the flash/program button to put the current person on hold so that you can answer the incoming call.

and second ring.

NOTE: Check with your local phone company regarding

REVIEWING CID RECORDS

you know how many calls have been received.

• Press the A button to scroll through the call records from

TRANSFERRING CID RECORDS

NOTE: It is important that you format CID records correctly before storing in memory. It is not possible to

- 2. Press the memory button
- 3. Press the desired memory location. Example, press the number 1 key to store the record in memory location 1
- 4. The display shows RINGTONE.
- 5. Use the ▼ or ▲ button or the touch tone pad to select one of six ring tones.

NOTE: The selected ring tone is generated if the Caller ID information matches the memory location.

- 6. Press memory to save the number, and the display shows
- 7. Use ▼ or ▲ button or the touch tone pad to select one of five animations or to turn off the animation. The current animation shows on the first line of the display
- 8. Press memory to save the selected animation for this memory location. You will hear a confirmation tone.

To replace a CID record stored in a memory location with a new CID record:

- 1. Repeat steps 1 through 3.
- 2. Press the memory button and REPLACE MEMO? shows in the display.
- 3. Press *tone/exit to exit, or press memory again and the new CID record replaces the old CID record in that memory location. You will hear a confirmation tone.

DELETING THE CURRENT CID RECORD

2. Use the ▼ or ▲ button to display the desired CID record

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 3. Press ch/delete. The display shows DELETE?
- 4. Press *tone/exit to exit, or press ch/delete again to erase the record. You will hear a confirmation tone. The display shows DELETED. Then the next CID record shows in the display.

DELETING ALL RECORDS

- 1. Make sure the phone is **OFF** (not in TALK mode).
- Use the ▼ or ▲ button to display any CID record.
- 3. Press and hold ch/delete button until the unit beens and DELETE ALL? shows in the display
- 4. Press *tone/exit to exit, or press ch/delete again to erase all records. You will hear a confirmation tone, and the display shows NO CALLS.

DIALING A CALLER ID NUMBER

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Use the ▼ or ▲ button to display the desired CID record.
- 3. PressTALK/CALLBACK button. The number dials automatically.

CHANGING THE CID Number Format

The format button lets you change the format of the displayed CID number. The available formats are as follows

7-digit telephone number. 7-digit

10-digit 3-digit area code + 7-digit telephone number

long distance code "1" + 3-digit area 11-digit code + 7-digit telephone number

- Use the ▼ or ▲ button to scroll to the number you want to call back.
- 2. If the number will not dial as shown, press the format button. Repeat if necessary, until the correct number of
- 3. PressTALK/CALLBACK button. The number dials automatically.

MEMORY

Store up to 10 24-digit numbers in memory for quick dialing. This memory feature is in addition to the 40 Caller ID records that can be stored in the Caller ID memory log.

STORING A NAME AND NUMBER IN **MEMORY**

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Press the memory button.
- 3. Press the desired memory location (0 through 9).
- 4. Press the memory button again. The display shows ENTER NAME (up to 15 characters)

NOTE: If you don't want to enter the name, skip step 5.

5. Use the number pad to enter the name (up to 15 characters). For example, to enter the name Bill Smith, press the two key twice for the letter B, press the four key three times for the letter I, and press the five key three times for the letter L. After one second, press the five key three times again for the second letter L and press the one key to insert a space between the letter L and S. Press the seven key four times for the letter S, press the six key once for the letter M, press the four key three times for the letter I, press the eight key once for the letter T, and press the four key twice for the letter H.

NOTE: If you enter a wrong letter, press ch/delete button to backspace.

- 6. Press the memory button to save the name. The display shows ENTER TEL NUMBR.
- 7. Use the number pad to enter the telephone number you want to store (up to 24 digits). 8. Press memory to save the number, and the display shows
- 9. Use the ▼ or ▲ button or the touch tone pad to select one of six ring tones.

RINGTONE >1

NOTE: The selected ring tone is generated if the Caller ID information matches the memory location, which must be a 10-digit number (including area code). This usually occurs after the first ring. The current ring tone is

- 10. Press memory to save the number, and the display shows
- 11. Use the ▼ or ▲ button or the touch tone pad to select one of five animations or to turn off the animation. The current animation shows on the first line of the display.

NOTE: Remember to press flash/program set animation as KNOWN CALLERS or ALL CALLS, and the selected nimation will show in the display if the Caller ID number exactly matches the memory location

12. Press memory to save the selected animation for this memory location. You will hear a confirmation tone

CHANGING A STORED NUMBER

- 1. Repeat steps 1 through 10 in Storing a Name and Number
- 2. Press the memory button and REPLACE MEMO? shows in the display.
- 3. Press *tone/exit to exit, or press the memory button to store the number. You will hear a confirmation tone.

STORING A REDIAL NUMBER

- 1. Repeat steps 1 through 6 in Storing a Name and Number in Memory.
- 2. Press the redial button
- 3. Repeat steps 8 through 12 in Storing a Name and Number

To replace an old redial number with a new redial number

- 1. Repeat steps 1 through 6 in Storing a Name and mber in Memor
- 2. Press the redial button and the redial number will be shown on the display.
- 3. Repeat steps 8 through 11 in Storing a Name and Number in Memory.
- the display. 5. Press *tone/exit to exit, or press the memory button again and the new redial number replaces the old redial number in that memory location. You will hear a

4. Press the memory button and REPLACE MEMO? shows in

DIALING A STORED NUMBER

- 1. Make sure the phone is ON by pressing the TALK/
- 2. Press memory button.

confirmation tone

3. Press the number (0-9) for the desired memory location The number dials automatically.

- OR

- 1. Make sure the phone is OFF (not in TALK mode).
- Press memory button.
- 3. Use the ▼ or ▲ button to scroll through the numbers
- stored in memory until the desired number is shown. 4. PressTALK/CALLBACK. The numbers dial automatically.

IMPORTANT: If you make test calls to emergency numbers stored in memory, remain on the line and briefly explain the reason for the call to the dispatcher. Also, it's a good idea to make these calls in off-peak hours, such as arly morning or late evening.

INSERTING A PAUSE IN THE DIALING SEQUENCE

When storing information in memory, press the # pause button twice within one second to insert a delay in the dialing sequence of a stored telephone number when a pause is needed to wait for a dial tone (for example after you dial 9 for an outside line, or to wait for a computer access tone). PAUSE shows on the display as a "P." Each pause counts as 1 digit in the dialing sequence.

REVIEWING AND DELETING STORED NUMBERS

- 1. Press memory, then use the ▼ or ▲ button to view the entry.
- 2. While the entry is displayed, press the ch/delete button to delete the entry. The display shows DELETE?
- 3. Press *tone/exit to exit, or press ch/delete again to delete the entry DFLETED shows in the display

CHAIN DIALING FROM MEMORY

Use this feature to make calls which require a sequence of numbers such as using a calling card for a frequently called long distance number. Each part of the sequence is dialed from memory. The following example shows how you can use chain dialing to make a call through a long distance service:

| The Number For | Memory Location | |
|--|-----------------|---|
| Long distance access number | | 7 |
| Authorization code | | 8 |
| Frequently called long distance number | | 9 |

- 1. Make sure the phone is ON.
- 2. Press memory, and then press 7.
- 3. When you hear the access tone, press memory again and then press 8.
- 4. At the next access tone, press memory and then 9.

TIP: Wait for the access tones between pressing the memory button, or your call might not go through.

CHANGING THE BATTERY

Make sure the telephone is **OFF** before you replace battery.

- Remove the battery compartment door.
- 2. Disconnect the battery plug from the jack in the dialing pad and remove the battery pack.
- 3. Insert the new battery pack and connect the cord into the jack inside the dialing pad.
- 4. Put the battery compartment door back on.

5. Place dialing pad in the base to charge. Allow the battery to properly charge (for 12 hours) prior to first use or when you install a new battery pack. If you do not properly charge the phone, battery performance will be compromised



CAUTION: To reduce the risk of fire or personal

BATTERY SAFETY PRECAUTIONS

- Do not burn, disassemble, mutilate, or puncture. Like other batteries of this type, toxic materials could be released which can cause injury.
- To reduce the risk of fire or personal injury, use only the battery listed in the User's Guide
- Keep batteries out of the reach of children.
- Remove batteries if storing over 30 days.

GENERAL PRODUCT CARE

To keep your telephone working and looking good, follow

- these guidelines: Avoid putting the phone near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping and other rough treatment to the phone.
- · Clean with a soft cloth.
- Never use a strong cleaning agent or abrasive powder because this will damage the finish
- . Retain the original packaging in case you need to ship the phone at a later date

Causes of Poor Reception

- Aluminum sidina.
- Foil backing on insulation
- Heating ducts and other metal construction can shield radio signals You're too close to appliances such as microwaves.
- stoves, computers, etc. Atmospheric conditions, such as strong storms.
- Base is installed in the basement or lower floor of the house
- . Base is plugged into an AC outlet with other electronic devices. Baby monitor is using the same frequency.
- Battery is low.
- · You're out of range of the base
- The headset is not plugged in correctly

DISPLAY MESSAGES

The following indicators show the status of a message or of

INCOMPLETE DATA Caller information has been

interrupted during transmission or the phone line is excessively noisy. ENTER NAME Prompt telling you to ente the name for one of the 10

ENTERTEL NUMBR Prompt telling you to enter the telephone number for one of the

memory locations.

10 memory locations. DELETE? Prompt asking if you want to erase Caller ID records or one of the 10 numbers stored in the

phone's outgoing memory. **DELETE ALL?** Prompt asking if you want to erase all Caller ID records DELETED Prompt confirming the Caller ID /

Memory record is erased END OF LIST Indicates that there is no additional information in Caller ID memory.

MUTE ON

RFPT

NO CALLS

NEW Indicates call or calls have not been reviewed.

> Indicates that the mute function is activated, the far end party cannot hear your voice, but you can hear his/her. Press format/mute button again to deactivate the mute.

> > Repeat call message, Indicates that

Indicates no CID records have

(DDN) that can not be formatted.

LINKNOWN NAME/ The incoming call is from CALLER/NUMBER an area not serviced by Caller ID or the information was not sent.

PAGING Someone has pressed the page button on the base BLOCKED CALL The person is calling from a

number that has been blocked from transmission BLOCKED NAME The person's name is blocked

a new call from the same number was received more than once. NO DATA No Caller ID information

FMPTY Indicates a memory location

been stored. MESSAGE WAITING Indicates a message is available. MSG WAITING OFF Indicates a message

PRESS TALK KEY Prompt indicating the Caller ID number is a direct dial numbe

UNABLE TO DIAL Indicates the Calling number is incomplete and can not be

DIALING PAD SOUND SIGNALS

| BIRTH OF THE SCOTTE STOTTES | | | | |
|---------------------------------------|--------------------------|--|--|--|
| Signal | Meaning | | | |
| A long warbling tone (with ringer on) | Signals an incoming cal | | | |
| Two long beeps | Confirmation Tone | | | |
| One short and one long beep | Page signal | | | |
| One short beep every seven seconds | Low battery warning | | | |
| Three short beeps | Error Tone | | | |

TROUBLESHOOTING TIPS

CALLER ID SOLUTIONS

- No Display • Ensure the battery is fully charged. Try replacing the battery. Make sure the battery is properly installed and connected
- If you are using AC power, make sure that the outlet. Disconnect the unit from the plug and plug it in again.
- You must subscribe to Call Waiting Caller ID service to receive Caller ID information.

Caller ID Error Message

· The unit displays this message if it detects anything other than valid Caller ID information during the silent period after the first ring. This message indicates the presence of

TELEPHONE SOLUTIONS

No dial tone

Check installation:

Make sure the base power cord connected to a working outlet.

unit and the wall iack • Ensure the headset is correctly plugged into the dialing pad.

 The dialing pad may be out of range of the base. Move closer to the base

Make sure the telephone line cord connected to the base

- Disconnect the base from the wall lack and connect another phone to the same lack. If there is no dial tone in the second phone, the problem might be your wiring or local service.
- Make sure the battery is properly charged (12 hours).
- · Make sure the battery pack installed correctly.
- Did the dialing pad beep when you pressed the TALK/ CALLBACK button? Did the display indicator turn on? The battery may need to be charged.

Dial tone is OK, but can't dial out

· Make sure the tone/pulse setting is programmed correctly. Unit does not ring

- Make sure the RINGER switch on the dialing pad is turned to ON.
- You may have too many extension phones on your line Try unplugging some phones.

• See solutions for "No dial tone."

- Change channels The dialing pad may be out of range of the base. Move closer to the base
- Relocate the base Charge battery.

Ensure the headset is correctly plugged into the

You experience static, noise, or fading in and out

dialing pad. Make sure base is not plugged into an outlet with another

household appliance. Unit beens

- Place dialing pad in base for 20 seconds to reset the security code. If that doesn't work, charge battery for 12 hours.
- · Clean charging contacts on dialing pad and base with a
- See solutions for "No dial tone." · Replace the battery.
- Memory Dialing
- Did you program the memory location keys correctly?
- Did you follow proper dialing sequence? Make sure the tone/pulse setting is programmed correctly Did you reprogram numbers into memory after power

outage or battery replacement?

- The CHARGE/IN USE indicator on the base flashes
- Make sure the battery is installed correctly in dial pad. Provided your phone company offers voice messaging service and you subscribe to it. the CHARGE/IN USF indicator on the base flashes when the phone is not in use to indicate there is a message waiting. It stops flashing

after the message has been reviewed. SERVICE

If trouble is experienced with this equipment, for repair or warranty information, please contact customer service at 1-800-448-0329. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

This product may be serviced only by the manufacturer or its authorized service agents. Changes or modifications not expressly approved by ATLINKS USA, Inc. could void the user's authority to operate this product. For instructions on how to obtain service, refer to the warranty included in this guide or call customer service at 1-800-448-0329.

Or refer inquiries to: ATLINKS USA, Inc. Manager, Consumer Relations P O Box 1976

Indianapolis, IN 46206

Purchase date

Name of store

Attach your sales receipt to the booklet for future reference or jot down the date this product was purchased or received as a gift. This information will be valuable if service should be required during the warranty period.

Interference Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any nterference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply wit the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

the interference by one or more of the following measures: Reorient or relocate the receiving antenna (that is the antenna for radio or television that is "receiving"

- the interference) Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected

• Consult the dealer or an experienced radio/TV technician

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/televisio technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet. "HowTo Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock

number 004-000-00345-4 when ordering copies. LIMITED WARRANTY

What your warranty covers:

whichever comes first)

Defects in materials or workmanship.

For how long after your purchase: · One year, from date of purchase (The warranty period for rental units begins with the first ental or 45 days from date of shipment to the rental firm,

What we will do: Provide you with a new or, at our option, a refurbished

unit. The exchange unit is under warranty for the remainder of the original product's warranty period. How you get service: • Properly pack your unit. Include any cables, etc., which were originally provided with the product. We

recommend using the original carton and packing materials. • "Proof of purchase in the form of a bill of sale or receipted invoice which is evidence that the product is within the warranty period, must be presented to obtain warranty service." For rental firms, proof of first rental is also required. Also print your name and address and a description of the

- 11721 B Alameda Ave • Pay any charges billed to you by the Exchange Center for
- service not covered by the warranty Insure your shipment for loss or damage, ATLINKS accepts no liability in case of damage or loss

defect. Send via standard UPS or its equivalent to:

ATLINKS USA, Inc.

 A new or refurbished unit will be shipped to you freight prepaid.

• Customer instruction. (Your Owner's Manual provides

information regarding operating instructions and user

- controls. Any additional information, should be obtained from your dealer.)
- Installation and setup service adjustments Batteries.

Product Registration:

· Damage from misuse or neglect

What your warranty does not cover

- Products which have been modified or incorporated into other products. Products purchased or serviced outside the USA.
- Acts of nature, such as but not limited to lightning damage.

required for warranty coverage.

 Please complete and mail the Product Registration Card packed with your unit. It will make it easier to contact you should it ever be necessary. The return of the card is not

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct

How state law relates to this warranty:

warranty information.

Limitation of Warranty

THIS WARRANTY.

. Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations or exclusions may not apply to you.

• THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY

EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED

APPLICABLE TO THIS PRODUCT ALL OTHER WARRANTIES

WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A

PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED, NO

VERBAL OR WRITTEN INFORMATION GIVEN BY ATLINKS

LISA INC. ITS AGENTS OR EMPLOYEES SHALL CREATE

A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF

CONSUMER. ATLINKS USA, INC. SHALL NOT BE LIABLE

DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY

REPAIR OR REPLACEMENT AS PROVIDED UNDERTHIS

FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

RESULTING FROM THE USE OF THIS PRODUCT OF

IMPLIED WARRANTY ON THIS PRODUCT. THIS

ARE GOVERNED BY THE LAWS OF THE STATE OF

APPLICABLE LAW, ANY IMPLIED WARRANTY OF

PURPOSE ON THIS PRODUCT IS LIMITED TO THE

INDIANA. EXCEPT TO THE EXTENT PROHIBITED BY

MERCHANTARILITY OR FITNESS FOR A PARTICULAR

APPLICABLE WARRANTY PERIOD SET FORTH ABOVE

ARISING OUT OF ANY BREACH OF ANY EXPRESS OF

WARRANTY IS THE EXCLUSIVE REMEDY OF THE

• This warranty gives you specific legal rights, and you also may have other rights that vary from state to state If you purchased your product outside the USA:

• This warranty does not apply. Contact your dealer for

Accessory Information

| DESCRIPTION | MODEL NO. | PRICE* |
|----------------------------------|-----------|--------|
| Belt Clip | 5- 2641 | ** |
| Headset | 5- 2642 | ** |
| Replacement battery | 5- 2522 | ** |
| Power Supply | 5- 2639 | ** |
| Interchangeable color cover pack | | |
| (Red) | 52643R | ** |
| (Silver) | 52643S | ** |
| (Yellow) | 52643Y | ** |
| (Purple) | 52643P | ** |

To place order, have your Visa, MasterCard, or

Discover Card ready and call toll-free 1-800-338-0376.

A shipping and handling fee will be charged upon We are required by law to collect appropriate sales tax for each individual state, country,

and locality to which the merchandise is being sent Items are subject to availability. *Prices are subject to change without notice

Download from Www.Somanuals.com, All Manuals Search And Download

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com