
# FB601/610

# KETTLER

Trainings- und Bedienungsanleitung	deutsch	2-11
Training and Operating Instructions	english	12-21
Mode d'emploi et instructions d'entraînement	française	22-31
Trainings- en bedieningshandleiding	nederlands	32-41
Instrucciones de entrenamiento y manejo	español	42-51
Istruzioni per l'allenamento e per l'uso	italiano	52-61
Instrukcja treningowa i instrukcja obsługi	polski	62-71
Návod k obsluze a tréninku	cestina	72-81
Instruções de treino e utilização	português	82-91
Trænings – og betjeningsvejledning	dansk	92-101
Navodilo za trening in upravljanje	slovensko	102-11
Tréning és használati útmutató	magyarul	112-12
Uputstvo za trening i rukovanje	srpski	122-13
Рекомендации по проведению тренировок и	русский	132-14
руковолство по эксплуатации		

GOLF M UNIX M/MX





# Training and Operating Instructions



Table of contents					
Safety instructions	12				
Service	12				
Your safety					
Description	13-15				
• Function range / Buttons	13				
<ul> <li>Indicating range / Display</li> </ul>	14-15				
Settings	16				
• Time	16				
Metric / Imperial	16				
<ul> <li>Memory P1/P2</li> </ul>	16				
Training	17				
without presetting/pulse monitoring	j 17				
with presetting	17				
• Time	17				
• Distance	17				

Energy (KJoule/kcal)	17
• Age (10-99)	17
<ul> <li>Set warning signal (yes/no)</li> </ul>	17
<ul> <li>Selection of target pulse (FA 65% 75%)</li> </ul>	%/FI 1 <i>7</i>
• Entry of target pulse (40-199)	17
<ul> <li>Interruption/end of training</li> </ul>	18
<ul> <li>Resumption of training</li> </ul>	18
<ul> <li>Recovery (recovery pulse measurement)</li> </ul>	re- 19
Display of previous training	19
General instructions	20
<ul> <li>System signals</li> </ul>	20
<ul> <li>Recovery</li> </ul>	20
<ul> <li>Calculation of average value</li> </ul>	20
<ul> <li>Notes on pulse measurement With ear dip</li> </ul>	20 20

	With chest belt With hand pulse	20 20
•	Changing the batteries	20
	Brake level display	20
Tr	aining instructions	20
4	Stamina training	20
•	Strain intensity	20
•	Duration of strain	21
G	lossary	21



This sign in the instructions refers to the glossary, where the respective term will be explained. 13

# Safety instructions

# Please observe the following instructions for your own safety:

- The training device must be set up on an appropriate and firm surface.
- Inspect the connections for firm fitting before initial operation and additionally after approximately six operation days.
- In order to prevent injuries caused by wrong stress or overstress, the training device may only be used in accordance with the instructions.
- It is not recommended to permanently set up the device in humid rooms due to the resulting corrosion development.
- Assure yourself regularly that the training device functions properly and that it is in duly condition.
- The operator is responsible for the safety controls, which have to be carried out on a regular and proper basis.
- Defective or damaged parts must be exchanged immediately.
   Only use original KETTLER spare parts.
- The device may not be used until after repairs are completed.
- The safety level of the device can only be maintained provided that it is regularly inspected for damage and wear and tear.

For your safety:

Please clarify with your general practitioner before you start
with the training, whether or not your health condition allows
you to train with this device. The diagnostic findings should be
the basis for the determination of your training programme.
Wrong or excessive training can cause damage to your health.

# Description

The electronics assembly has the following functions:

- 2 personal memories for:
   Training kilometres and time
   Training presettings
   Display of last training with average and maximum values
- KJoule/km/h or kcal/m/h settings
- Calculation of energy consumption depending on speed and braking level

## **Function range**

The five buttons will be described in short below.

## DISP-SET (press shortly)

- · Switches from time display to ready for training.
- Switches to next input or display.
   Settings or values will be accepted.

Settings or values will be accepted.

## **DISP-SET** (press longer) RESET

 Deletes display for a reset. Only possible in standstill.

## Minus - / Plus +

With these function buttons, you can change the values in the different input data before the start of the training

- Press longer > fast run through the values
- Press "Plus" and "Minus" together: input data will be reset)

## Minus - (press shortly when time is displayed)

 Display of last training data (MEM) and total kilometres (ODO)

## Minus - (press longer when time is displayed)

- Set fime (TIME)
- Switch from ME to IM (SETTINGS)
   ME = [24h], [KJoule], [kitometres] -display
   IM = [12h], [Kcal], [miles] -display
- · Activate Save training presettings.

## REC (recovery pulse with fitness mark)

By pressing this function button, the recovery pulse function is started and a fitness grade is calculated.

## Persons

- Display of training kilometres and time of person 1 or person 2.
- Display of previous training data.

## Measuring the pulse

The measurement of the pulse can be carried out by means of 3 sources:


- 1. Ear dip The plug is put into the socket.
- Chest strap without plug-in. In this electronic unit, the receiver is built in behind the display. A plugged-in ear clip must be removed. The Polar chest strap is available as an accessory (item no. 67002000).
- 3. Hand pulse The connection is situated at the back of the display;

  Download from Www.Somanuals.com. All Manuals Search And Download

FB601/610 KETTLER G

# Training and Operating Instructions Indicating range / Display

The display provides information on different functions.




Value 0 - 99,9

# **Energy consumption**

(KJOULE) or (KCAL)



# Time (EX.TIME)



# Brake level (BRAKE)

Display of average value



# Battery charge



Battery power too low for pulse measurement.
Change battery.

# Display values

The example displays show the operation as home trainer. If the revolutions per minute correspond to the example displays the values for speed and distance are lower for cross trainers.

At 60 min-1 (RPM)

Home trainers: = 21,3 km/h Cross trainers: = 9,5 km/h

# Training and Operating Instructions 12:26 KM /N 161 FH DISTANCE. **a** 1 USER **a** } USER STORE 22 USER USER

STORE

12:26

# **Settings**

## Time

- Minus (press longer when time is displayed)
  Hours flash
- Press Minus / Plus + Set hour
- Press DISP SET Minutes flash
- Press Minus / Plus +
   Set minutes
- DISP SET
- Press Minus / Plus +
   Set to IM or ME
   ME = [24h], [KJoule], [kilometres] -display
   or
   IM = [12h], [Kcal], [miles] -display
- Press DISP SET
   Activate presetting memory for person 1
- Press Minus / Plus +
   Activate memory for person 1. [STORE]
   As soon as STORE is activated, the training presettings time, distance, energy and pulse monitoring are stored and displayed for each new training.
- Press DISP-SET
  Activate presetting memory for person 2
- Press Minus / Plus +
   Activate memory for person 2. [STORE]
   As soon as STORE is activated, the training presettings time, distance, energy and pulse monitoring are stored and displayed for each new training.
- Press DISP-SET
   Time is displayed

# **Training**

# 1. Training without presetting / Pulse measurement / Readiness for training

Press DISP button
Person 1 is displayed.
The readiness for training is displayed with 0 values.
A pulse value is displayed as soon as a pulse signal is identified on the ear clip, hand pulse or plug recipient.
A braking level is indicated.

and / or

Pedalling
 "EX.TIME" Exercise time, "DISTANCE", energy consumption and speed are displayed in increasing order.
 Pedal revolutions are displayed.
 Animation wheel is active.

# 2. Training with presettings/pulse monitoring

It is possible to enter time, distance and energy presettings. When the training is started, these values count down in reverse. If zero is reached, the display flashes and a signal is emitted. Then the presetting value counts up.

When the pulse function is activated, pulse can be monitored displaying a pulse range with deviations of +/- 10 beats as well as a maximum pulse deviation which is signalled by a warning signal.

Selection of persons

The electronic system has 2 personal memories which allow for 2 exercising persons to enter different training presettings. This makes sense if the training shall always be carried out using the same presettings. Thus it is not necessary any more to enter the presettings before starting the training.

The total training time and kilometres are also stored under person 1 and 2.

For activation you must press Adivate [STORE] presettings/memory for person

- Press "persons": selection of persons
- Display: "Person 1 flashes, total training time and kilome-
- · Switch person pressing "Plus" or "Minus"
- Confirm person with "DISP/SET"

Time presettings (EX.TIME)

Enter values using "Plus" or "Minus" (e.g. 30:00)
 Confirm with "DISP/SET".

Display: next menu "DISTANCE"

Distance presettings (DISTANCE)


Enter values using "Plus" or "Minus" (e.g. 7.50)
 Confirm with "DISP/SET"

Display: next menu "Age"


Energy presettings (KJOULE/KCAL)

- Enter values using "Plus" or "Minus" (e.g. 780)
   Confirm with "DISP/SET".
- Select kJoule or kcal unit using "Plus" or "Minus".
   Confirm "DISP/SET".


Display: next menu "Age"



# Training and Operating Instructions











Age entry (AGE)

Entering the age allows for the determination and monitoring of the maximum pulse (MAX symbol, warning signal, if activated).

Enter values using "Plus" or "Minus" (e.g. 50).
This will result in a maximum pulse of 170 when entering the relation (220 - age).
Confirm with "DISP/SET".

Display: next menu "Warning signal"

Warning signal when maximum pulse is exceeded.

 Select function with symbol using "Plus" or "Minus" Confirm with "DISP/SET".

Display: next menu target pulse selection "FA 65%"

# Target pulse monitoring FA 65% / FI 75%

Select using "Plus" or "Minus"

 Fat burning 65%, fitness 75% of maximum pulse Confirm with "DISP/SET" (presetting mode completed)

Display: Readiness for exercise using the presettings

or

Target pulse entry

Entering the values 40 – 199 allows for the determination and monitoring of the training pulse irrespective of age (HI symbol, warning signal if activated, no maximum pulse monitoring).

For this purpose, age entry must be switched to "OFF".

 Deselect maximum pulse monitoring using "Plus" and "Minus". Display: "AGE OFF" Confirm with "DISP/SET"

Display: next presetting "Target pulse"

Enter value using "Plus" or "Minus" (e.g. 130)
 Confirm with "DISP/SET" (presetting mode completed)

Display: Readiness for training using presettings

Pedalling
 The presettings are counted in decreasing order.

# Training interruption/end of training

With less than 10 pedal rotations per minute, the electronics assembly of the training device identifies a training interruption. The animation wheel is displayed empty. The achieved training data are displayed.

Rotations, pulse, speed and brake level are displayed as average value using the  $\varnothing$  symbol.

The training data are displayed for 4 minutes. If you do not press any button nor train during this period of time, time electronics assembly of the training device switches to standy-by mode and displays the time.

# Resumption of training

If you resume training within 4 minutes, the last values continue to be counted up or down.

# **RECOVERY function**

# Recovery pulse measurement

Press "RECOVERY" at the end of training Display: REC

The pulse value is stored (P1).

The current pulse is still displayed

The electronics assembly of the training device measures your pulse 60 seconds in reverse.

The pulse value after 60 seconds (P2) is stored.

The pulse difference (P1-P2) is displayed

From this value, a fitness mark (F 4.8 for this example) is determined.

The display is completed after 20 second

"RECOVERY" interrupts the recovery pulse function or the fitness mark display.

If no pulse is measured in the beginning or at the end of the reverse counting, the error message "Err" is displayed


# Display of previous training with average and maximum values

- · Press "Persons": selection of persons
- Display: "Person 1 flashes, total training time and kilome-
- · Switch persons using "Plus" or "Minus"
- Press "Persons" once more:
- Display: Average values of pulse, % pulse, RPM, km/h and brake level of the previous training are displayed with the [Ø] symbol.
- Press "DISP/SET"
- Display: Average values of pulse, % pulse, RPM, km/h and brake level of the previous training are displayed with the [MAX] symbol.
- Press "DISP/SET"

Display: Readiness for training with or without presettings.

## Comment:

The last training values only refer to the previous training unit. The values are stored by "RESET" or by the activation of the stand-by mode with time display deleting previous



# Training and Operating Instructions

# General instructions

# System signals

## Activation of the device

If you activate the device, a signal is emitted during the segment test.

## Presetting

A short signal is emitted, if you reach a presetting such as time, distance and KJoule/kcal.

## Maximum pulse exceeding

If the preset maximum pulse is exceeded by one pulse beat, 2 short signals are emitted for the time.

## Recovery

Calculation of the fitness mark (F):

mark (F) = 
$$6.0 - \left(\frac{10 \times (P1 - P2)}{P1}\right)^2$$

P1 stress pulse

P2 = recovery pulse

Grade 1 = very good

Grade 6 = insufficient

# Calculation of average value

The calculations of the average values refer to training units in the past until a reset or the stand-by mode.

# Instructions for pulse measurement

The pulse measurement starts as soon as the heart in the display blinks in time with your pulse beat.

## With ear clip

The pulse sensor works with infrared light and measures the variations in translucence in your skin, which are produced by your pulse beat. Rub your ear ten times strongly to activate the blood circulation before attaching the pulse sensor to your earlobe.

Avoid disturbing pulses.

- Attach the ear clip properly to your earlobe and look for the best point for the measurement (heart symbol blinks without interruption).
- Do not train directly under strong incidence of light, e.g. neon light, halogen light, spotlights, sun light.
- Completely eliminate any shocks or bounces of the ear sensor and the cable. Always attach the cable with a clip at your clothing or, even better, at your headband.

## With breast clip

Please observe the corresponding instructions.

## With hand pulse

An extra-low voltage caused by the contractions of your heart is registered by the hand sensors and evaluated by the electronics assembly of the device

- Always grab the contact faces with both hands
- Avoid jerky grasping
- Hold your hands calmly and avoid contractions and rubbing on the contact faces.

### Comment:

Only one way of pulse measurement is possible: either with ear dip or with hand pulse or with breast belt. If no ear dip or plug recipient is located in the pulse plug, hand pulse measurement is activated. If you insert an ear dip or a plug recipient in the pulse plug, hand pulse measurement is automatically deactivated. It is not necessary to disconnect the plug of the hand pulse measurement.

# Battery change

If the battery symbol occurs in the display, battery power is too low for pulse measurement. Training kilometres and time as well as all presettings will get lost. Time must be reset.

# Brake level display

Brake setting is classified in level 1-10. If this classification is disturbed or lost, you must restore it as follows:

- Check whether the 3-pole connecting cable is plugged in at the back of the display.
- Insert batteries and press the "DISP/SET" button until the segment test is completed.
- Turn back hand lever to minimum setting and press the "DISP/SET" button when 0%, BRAKE 0 is displayed.
- Preturn hand lever to maximum setting and press the "DISP/SET" button when 100%, BRAKE 10 is displayed.

The process is completed

# **Training instructions**

Sports medicine and training science use cycle ergometry, among other things, for the examination of the functional capability of heart, circulation and respiratory system.

You can find out whether or not you have achieved the desired effect from your training after several weeks using the following method:

- You manage a particular endurance performance with less heart / circulation performance than previously
- You sustain a particular endurance performance with the same heart / circulation performance over a longer period.
- 3. You recover more quickly than previously after a particular heart / circulation performance.

# Guide values for the endurance training


Maximalpulse: maximum strain means the reaching of the individual maximum pulse. The maximum achievable heart rate is dependent on age.

Here the following empirical formula applies: the maximum heart rate per minute corresponds to 220 heart beats minus age in years

Example: age 50 years  $\rightarrow$  220 - 50 = 170 pulse/min.

# Load intensity

**Load pulse:** the optimum intensity of load is reached at 65-75% (see also diagram) of the maximum pulse. This value changes depending on age.



## Extent of load

Duration of a training unit and its frequency per week:

The optimum extent of load is attained, if 65–75 % of the individual heart / circulation performance is achieved over a longer period.

Training frequency	Duration of training	
daily	10	minutes
2–3 times a week	20-30	minutes
1–2 times a week	30-60	minutes

Beginners should not begin with training units of 30-60 minutes. The beginner's training can be planned as follows in the first 4 weeks:

Training frequency	Extent of training session
	1st week
3 times a week	2 minutes of training Break of 1 minute for physical exercises 2 minutes of training Break of 1 minute for physical exercises 2 minutes of training
	2nd week
3 times a week	3 minutes of training Break of 1 minute for physical exercises 3 minutes of training Break of 1 minute for physical exercises 2 minutes of training
	3rd week
3 times a week	4 minutes of training Break of 1 minute for physical exercises 4 minutes of training Break of 1 minute for physical exercises 3 minutes of training
	4th week
3 times a week	5 minutes of training Break of 1 minute for physical exercises 4 minutes of training Break of 1 minute for physical exercises 4 minutes of training
and the control of th	

It is recommended that you perform approx. 5 minutes of exercises before and after every training unit, in order to warm up and cool down. There should be a training-free day between each two consecutive training units, if you prefer training sessions of 20-30 minutes 3 times a week later on in your training. Otherwise, there is no reason why you should not train daily.

# Glossary

## Age

Entry for the calculation of the maximum pulse.

## Dimension

Units for the display of km/h or mi/h, kJoule or kcal.

## Fat burning pulse

Calculated value of 65% max, pulse

### Fitness pulse

Calculated value of 75% max. pulse

## Glossary

A collection of attempted explanations.

## HI symbol

If "HI" is displayed, the target pulse is exceeded by 11 beats. If "HI" flashes, the maximum pulse is exceeded. "HI" monitoring is always activated.

#### LO symbo

If "LO" is displayed, the target pulse is fallen below by 11 beats "LO" monitoring is activated if the target pulse has been achieved in training.

## MaxPulse(s)

Value calculated from 220 minus age

#### Menu

Display where values must be entered or selected.

#### Pulse

Registration of heart beats per minute

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com