



K00047 ADAPTER KIT

Installation Instructions

1. The K047 adapter kit is used for installing an E-0200, E-0400, or G-0600 ice machine on an SH-500 bin. The bin must be leveled before proceeding to step 2.
2. **INSTALLATION OF ASAPTER:**
 - A. Remove four screws from bin used to hold hinges.
 - B. Locate right-hand and left-hand adapter panels.
 - C. Remove foam tape, which is under the adapter panels.
 - D. Using panels as template, drill four holes, 5/32" diameter, in back of bin.
 - E. Secure panels in place.
 - F. Apply foam tape, as shown in Illustration 1.
3. **INSTALLATION OF ICE MACHINE:**
 - A. Remove two screws from bottom of ice machine that are 16 1/2" from the back of the machine.
 - B. Position ice machine on bin.
 - C. From inside the bin, reinstall the two screws removed in Step 3A.
 - D. Proceed to service manual for electrical and water hook-up and start-up procedures.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>