

VMAC-1

ViewSonic® Macintosh® Adapter User's Guide

Quick Start Installation

- 1 With the monitor and computer turned OFF, open the shielding door of the adapter.
- 2 Make sure all dip switches are set to default settings as shown in the illustration to the right. (Resolution = 832 x 624 and Sync Mode = "Separate + Composite")
- 3 Close the shielding door.
- 4 Connect the male side of the adapter to the monitor port on the back of the computer.

Tighten the two adapter thumb screws until snug. **DO NOT OVER-TIGHTEN.**

- 5 Connect the video cable to the female side of the adapter, then connect the other end of the cable to the back of your monitor. Tighten the thumb screws at both ends of the video cable until snug. **DO NOT OVER-TIGHTEN.**

- 6 Turn on the computer and the monitor.

NOTE: To set the adapter to the highest resolution your Macintosh computer can use, follow the **Advanced Settings** procedure to the right.

To reach ViewSonic Customer Support call (800) 888-8583 or (909) 444-8800

TopView with shielding door open

CAUTION: Be careful not to bend the video connector pins.

VMAC-1 Dip Switch Settings

■ = Switch ON □ = Switch OFF

Resolution & Refresh Rate	DIP Switch No.					
	1	2	3	4	5	6
640 x 480 @ 67 Hz	■	□	□	■	□	□
640 x 870 @ 75 Hz	□	■	□	■	□	□
832 x 624 @ 75 Hz*	■	□	■	□	□	□
1024 x 768 @ 75 Hz	■	■	□	□	□	□
1152 x 870 @ 75 Hz	■	■	■	■	□	□
Macintosh G3 Multi-res (Up to 1600 x 1200)	□	□	□	■	■	■
Multi-res (up to 1600 x 1200)	■	□	□	■	■	□

Sync Mode	DIP Switch No.			
	7	8	9	10
Separate	□	□	■	■
Composite	□	■	■	□
Separate + Composite*	■	■	■	■
Sync on Green	□	□	□	□

*default settings

Advanced Settings

- 1 With the monitor and computer turned OFF, open the shielding door of the adapter.
- 2 Check your monitor's user guide for the maximum resolutions the monitor will support and then select the appropriate resolution from the Dip Switch Settings chart (to the left).

NOTE: Your Macintosh computer may not support the maximum resolutions of your monitor.

- 3 Using the tip of a pen, set each numbered dip switch on the adapter to ON or OFF according to the resolution you selected from the Dip Switch Settings chart.
- 4 Close the shielding door.
- 5 Turn on the computer and the monitor.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>