

[™]*Protector*

U.S. Patent Nos. 6069415 and 6690208

Robotic Collision Sensor

SR-61, 81, 101, 131, 176, and 221

Installation Instructions for Coolant Protection Boot



Document #9610-60-1008-04 November 2007

Engineered Products for Robotic Productivity Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com



CAUTION: This manual describes the function, application and safety considerations of this product. This manual must be read and understood before any attempt is made to install or operate the product, otherwise damage to the product or unsafe conditions may occur.

Information contained in this document is the property of ATI Industrial Automation, Inc. (ATI) and shall not be reproduced in whole or in part without prior written approval of ATI. The information herein is subject to change without notice. This manual is periodically revised to reflect and incorporate changes made to the product.

The information contained herein is **CONFIDENTIAL** and reserved exclusively for the customers and authorized agents of ATI Industrial Automation and may not be divulged to any third party without prior written consent from ATI. No warranty including implied warranties is made with regard to accuracy of this document or fitness of this device for a particular application. ATI Industrial Automation shall not be liable for any errors contained in this document or for any incidental or consequential damages caused thereby. ATI Industrial Automation also reserves the right to make changes to this manual at any time without prior notice.

ATI assumes no responsibility for any errors or omissions in this document. Users' critical evaluation of this document is welcomed.

©Copyright by ATI Industrial Automation. All rights reserved.

How to Reach Us

Sales, Service and Information about other ATI products:

ATI Industrial Automation 1031 Goodworth Drive Apex, NC 27539 USA www.ati-ia.com Tel: 919.772.0115 Fax: 919.772.8259 E-mail: info@ati-ia.com

Technical support and questions:

Application Engineering

Tel: 919.772.0115, Option 2, then option 2 Fax: 919.772.8259 E-mail: mech_support@ati-ia.com

Table of Contents


	Page
1.	Installation of Coolant Protection Boot5
	1.1 Attach Interface Plate to Robot5
	1.2 Attach the Collision Protection Device (CPD) to the Robot Interface Plate 5
	1.3 Attach the Stem Side Interface Plate to the Stem of the CPD
	1.4 Apply 10–20 psi to CPD to Raise the Stem. This step is not required for spring-loaded units
	1.5 Stretch (1) Garter Spring of the CPD Assembly as Shown
	1.6 Slide (1) Coolant Sealant Boot over the Stem Side Interface Plate onto the CPD Cover
	1.7 Secure the Coolant Sealant Boot to the CPD by Positioning the Garter Springs in the Spring Grooves on the Boot
2.	Design/Procurement of Interface Plates9
3.	Drawings for Replacement Parts & Interface Plates
	3.1 SR-61
	3.2 SR-81
	3.3 SR-101
	3.4 SR-131
	3.5 SR-176
	3.6 SR-221
4.	Terms and Conditions of Sale

Glossary of Terms

Term	Definition
Body	Cylindrical aluminum housing and air pressure chamber. An interface plate to the user's robot is usually attached here.
Collision	The accidental impact between the end of arm tooling and some obstruction in its path.
Cover Plate	Disk-shaped aluminum cover for Protector [™] Body.
Crash	The result of a disturbance that displaces the Protector TM components from their standard, working position.
Interface Plate	Optional component used to adapt the Protector TM Body or Stem to the user's robot or tooling.
Piston	The component which, together with the Body, creates a pressure chamber. Varying the pressure in this chamber varies the load required to move the piston.
Stem	Round tapered post containing tapped holes and a dowel pin hole. An interface plate to the user's tooling is usually attached here.


1. Installation of Coolant Protection Boot

1.1 Attach Interface Plate to Robot




NOTE: A Robot Interface Plate is required. The Robot Interface Plate can be purchased from ATI or manufactured by the customer using ATI approved drawings. The use of Robot Interface Plates supplied by ATI is strongly recommended.


1.2 Attach the Collision Protection Device (CPD) to the Robot Interface Plate




1.3 Attach the Stem Side Interface Plate to the Stem of the CPD




1.4 Apply 10–20 psi to CPD to Raise the Stem. This step is not required for spring-loaded units.



1.5 Stretch (1) Garter Spring of the CPD Assembly as Shown





1.6 Slide (1) Coolant Sealant Boot over the Stem Side Interface Plate onto the CPD Cover



Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com

1.7 Secure the Coolant Sealant Boot to the CPD by Positioning the Garter Springs in the Spring Grooves on the Boot





2. Design/Procurement of Interface Plates

This sealing system utilizes a bellows style boot attached to the cover and stem side interface plate and a molded wire channel gasket. In order to insure proper sealing the following items are necessary:

- The unit must have been purchased from the factory with the coolant sealant boot. (This is necessary since the cover must contain the groove for the garter spring and be sealed to the body.)
- 2) Purchase Custom collision sensor interface plates from ATI. Provide the robot and tooling interface patterns to ATI and we will design and manufacture custom interface plates for your application.

or

Purchase blank collision sensor interface plates and modify them as follows: <u>Tooling to Collision Sensor Stem Interface Plate</u>

a) The tooling mounting holes in the collision sensor stem to tooling interface plate must be surrounded with o-rings installed in properly sized counterbores.


Robot to Collision Sensor Body Interface Plate

- a) The robot mounting holes and dowel hole(s) in the collision sensor body to robot interface plate must be oriented so that they do not cross the molded wire channel gasket.
- **Note:** See drawings in section 3 for interface plate part numbers and examples of properly modified interface plates.


Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com

3. Drawings for Replacement Parts & Interface Plates






Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com




Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com






Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com




Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com

3.3 SR-101




Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com




Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com






Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com




Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com



3.5 SR-176


Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com

Protector Installation & Operation Manual Document #9610-60-1008-04




Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com

3.6 SR-221



Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com



Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com

4. Terms and Conditions of Sale

The following Terms and Conditions are a supplement to and include a portion of ATI's Standard Terms and Conditions, which are on file at ATI and available upon request.

ATI warrants to Purchaser that Protector[™] products purchased hereunder will be free from defects in material and workmanship under normal use for a period of one (1) years from the date of shipment. This warranty does not cover components subject to wear and tear under normal usage or those requiring periodic replacement. ATI will have no liability under this warranty unless: (a) ATI is given written notice of the claimed defect and a description thereof within thirty (30) days after Purchaser discovers the defect and in any event not later than the last day of the warranty period; and (b) the defective item is received by ATI not later ten (10) days after the last day of the warranty period. ATI's entire liability and Purchaser's sole remedy under this warranty is limited to repair or replacement, at ATI's election, of the defective part or item or, at ATI's election, refund of the price paid for the item. The foregoing warranty does not apply to any defect or failure resulting from improper installation, operation, maintenance or repair by anyone other than ATI.

ATI will in no event be liable for incidental, consequential or special damages of any kind, even if ATI has been advised of the possibility of such damages. ATI's aggregate liability will in no event exceed the amount paid by purchaser for the item which is the subject of claim or dispute. ATI will have no liability of any kind for failure of any equipment or other items not supplied by ATI.

No action against ATI, regardless of form, arising out of or in any way connected with products or services supplied hereunder may be brought more than one (1) year after the cause of action occurred.

No representation or agreement varying or extending the warranty and limitation of remedy provisions contained herein is authorized by ATI, and may not be relied upon as having been authorized by ATI, unless in writing and signed by an executive officer of ATI.

Unless otherwise agreed in writing by ATI, all designs, drawings, data, inventions, software and other technology made or developed by ATI in the course of providing products and services hereunder, and all rights therein under any patent, copyright or other law protecting intellectual property, shall be and remain ATI's property. The sale of products or services hereunder does not convey any express or implied license under any patent, copyright or other intellectual property right owned or controlled by ATI, whether relating to the products sold or any other matter, except for the license expressly granted below.

In the course of supplying products and services hereunder, ATI may provide or disclose to Purchaser confidential and proprietary information of ATI relating to the design, operation or other aspects of ATI's products. As between ATI and Purchaser, ownership of such information, including without limitation any computer software provided to Purchaser by ATI, shall remain in ATI and such information is licensed to Purchaser only for Purchaser's use in operating the products supplied by ATI hereunder in Purchaser's internal business operations.

Without ATI's prior written permission, Purchaser will not use such information for any other purpose or provide or otherwise make such information available to any third party. Purchaser agrees to take all reasonable precautions to prevent any unauthorized use or disclosure of such information.

Purchaser will not be liable hereunder with respect to disclosure or use of information which: (a) is in the public domain when received from ATI; (b) is thereafter published or otherwise enters the public domain through no fault of Purchaser; (c) is in Purchaser's possession prior to receipt from ATI; (d) is lawfully obtained by Purchaser from a third party entitled to disclose it; or (f) is required to be disclosed by judicial order or other governmental authority, provided that, with respect to such required disclosures, Purchaser gives ATI prior notice thereof and uses all legally available means to maintain the confidentiality of such information.

Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 • Tel: 919.772.0115 • Fax: 919.772.8259 • www.ati-ia.com • Email: info@ati-ia.com

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com