Instructions



Mixer Manifold

307400P

3000 psi (21.0 MPa, 210 bar) Maximum Working Pressure

Model 215625 Series C

Low Volume Mixer: 1/4 npt fluid outlet; for use in low volume applications, such as air spray urethanes.

Model 215626 Series C

High Volume Mixer: 1/2 npt fluid outlet; for use in high volume applications, such as airless spray or high solids epoxy.

Model 241692 Series A

Includes Model 215626 and a static pipe mixer.

Ball Valve Kit 218413


Updates the handle and ball valve of Series A, Model 215625, Low Volume Mixer. See page 10.

Ball Valve Kit 218414

Updates the handle and ball valve of Series A, Model 215626, High Volume Mixer. See page 10.



Read warnings and instructions. See page 2 for **Table of Contents**.



PROVEN Q	UALITY.	LEADING	TECHN	OLOGY
----------	---------	---------	-------	-------

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441 Copyright 1980, Graco Inc. is registered to I.S. EN ISO 9001

Table of Contents

Varnings	2	Parts	10
nstallation	5	Technical Data	13
Operation	6	Dimensions	14
Froubleshooting	8	Graco Warranty	16
Service	g	Graco Information	16

Symbols

Warning Symbol

WARNING

This symbol alerts you to the possibility of serious injury or death if you do not follow the instructions.

Caution Symbol

A CAUTION

This symbol alerts you to the possibility of damage to or destruction of equipment if you do not follow the instructions.

⚠ WARNING



EQUIPMENT MISUSE HAZARD

Equipment misuse can cause the equipment to rupture or malfunction and result in serious injury.

- This equipment is for professional use only.
- Read all instruction manuals, tags, and labels before operating the equipment.
- Use the equipment only for its intended purpose. If you are not sure, call your Graco distributor.
- Do not alter or modify this equipment.
- Check equipment daily. Repair or replace worn or damaged parts immediately.
- Do not exceed the maximum working pressure of the lowest rated system component. Refer to the **Technical Data** on page 13 for the maximum working pressure of this equipment.
- Use fluids and solvents which are compatible with the equipment wetted parts. Refer to the **Technical Data** section of all equipment manuals. Read the fluid and solvent manufacturer's warnings.
- Handle hoses carefully. Do not pull on hoses to move equipment.
- Route hoses away from traffic areas, sharp edges, moving parts, and hot surfaces. Do not expose Graco hoses to temperatures above 66°C (150°F) or below –40°C (–40°F).
- Wear hearing protection when operating this equipment.
- Do not move or lift pressurized equipment.
- Comply with all applicable local, state, and national fire, electrical, and safety regulations.

▲ WARNING



INJECTION HAZARD

Spray from the gun, leaks or ruptured components can inject fluid into your body and cause extremely serious injury, including the need for amputation. Fluid splashed in the eyes or on the skin can also cause serious injury.

- Fluid injected into the skin is a serious injury. The injury may look like just a cut, but it is a serious injury. Get immediate medical attention.
- Do not stop or deflect leaks with your hand, body, glove or rag.
- Always have the tip guard and the trigger guard on the gun when spraying.
- Do not "blow back" fluid; this is not an air spray system.
- Check the gun diffuser operation weekly. Refer to the gun manual.
- Be sure the gun trigger safety operates before spraying.
- Lock the gun trigger safety when you stop spraying.
- Follow the **Pressure Relief Procedure** on page 8 if the spray tip clogs and before cleaning, checking or servicing the equipment.
- Tighten all fluid connections before operating the equipment.
- Check the hoses, tubes, and couplings daily. Replace worn or damaged parts immediately. Do not repair high pressure couplings; you must replace the entire hose.



MOVING PARTS HAZARD

Moving parts can pinch or amputate your fingers.

- Keep clear of all moving parts when starting or operating the pump.
- Before checking or servicing the equipment, follow the Pressure Relief Procedure on page 8 to prevent the equipment from starting unexpectedly.

▲ WARNING



FIRE AND EXPLOSION HAZARD



Improper grounding, poor ventilation, open flames or sparks can cause a hazardous condition and result in a fire or explosion and serious injury.

- Ground the equipment and the object being sprayed. Follow the grounding instructions on page 5.
- If there is any static sparking or you feel an electric shock while using this equipment, stop spraying immediately. Do not use the equipment until you identify and correct the problem.
- Provide fresh air ventilation to avoid the buildup of flammable fumes from solvents or the fluid being sprayed.
- Keep the spray area free of debris, including solvent, rags, and gasoline.
- Before operating this equipment, electrically disconnect all equipment in the spray area.
- Before operating this equipment, extinguish all open flames or pilot lights in the spray area.
- Do not smoke in the spray area.
- Do not turn on or off any light switch in the spray area while spraying or while operating if fumes are present.
- Do not operate a gasoline engine in the spray area.



TOXIC FLUID HAZARD

Hazardous fluid or toxic fumes can cause serious injury or death if splashed in the eyes or on the skin, inhaled, or swallowed.

- Know the specific hazards of the fluid you are using.
- Store hazardous fluid in an approved container. Dispose of hazardous fluid according to all local, state and national guidelines.
- Always wear protective eyewear, gloves, clothing and respirator as recommended by the fluid and solvent manufacturer.



REACTIVE CHEMICALS HAZARD

Graco Inc. does not manufacture or supply any of the reactive chemical components that are used in this equipment, and is not responsible for their effects. Because of the vast number of chemicals that could be used, and their varying chemical reactions, the buyer and user of this equipment should determine all facts relating to the materials used, including any of the potential hazards involved. Particular inquiry and investigation should be made into potential dangers relating to toxic fumes, fires, explosions, reaction times, and exposure of human beings to the individual components or their resultant mixtures. Graco assumes no responsibility for loss, damage, expense, or claims for bodily injury or property damage, direct or consequential, arising from use of such chemical components.

Installation

Grounding

Proper grounding is an essential part of maintaining a safe system.

To reduce the risk of static sparking, ground the pump. Check your local electrical code for detailed grounding instructions for your area and type of equipment. Be sure to ground all of this equipment:

- 1. *Pump:* use a ground wire and clamp as instructed in your pump instruction manual.
- 2. Fluid hoses: Use only grounded hoses with a maximum of 500 feet (150 m) combined hose length to ensure grounding continuity.
- 3. Spray gun, manifold, or dispensing valve: obtain grounding through connection to a properly grounded connection to a properly grounded fluid hose and sprayer.
- 4. Object being sprayed: according to local code.
- 5. Supply Containers: according to local code.

- All solvent pails used when flushing, according to local code. Use only metal pails, which are conductive. Do not place the pail on a nonconductive surface, such as paper or cardboard, which interrupts the grounding continuity.
- To maintain grounding continuity when flushing or relieving pressure, always hold a metal part of the gun firmly to the side of a grounded metal pail, then trigger the gun.


Installation (See Fig. 1)

For assistance in setting up a plural component system, contact your Graco distributor. This will help assure that you select the proper type and size equipment for your job.

Use the spacer (40), screws (37), nuts (38) and lockwashers (39) provided to mount the manifold.

Connect the supply lines from your pump to the manifold inlets (R & Q).

Connect your static mixer or hose to the material outlet (S). Model 215626 has a 1/2 npt(m) outlet, and model 215625 has a 1/4 npt(m) outlet. Model 241692 includes a static mixer with a 3/8 npt(m) outlet.



Model 215626 Shown

Fig. 1

05764

Operation

Start-up

The mixer manifold was tested in oil, which was left in to protect the manifold. Before operating, thoroughly flush the manifold to prevent contamination of the fluids.

Flushing Procedure

A CAUTION


Be sure to label all fluid path parts "component A" or "component B" when disassembling them. Doing so prevents interchanging A and B parts during reassembly, which will contaminate the materials and the fluid path through the equipment.

Color-coded chemically resistant tape may be used to label the parts. Use blue for component A, green for component B, white for solvent, and red for mixed material.

Place the handle in the UP, or closed, position. Turn on the solvent supply pump. Open one of the solvent valves. Release the spray gun safety latch. Hold the gun firmly to the side of a grounded metal pail, then trigger the gun to flush. Flush until all contaminants and oil are removed. Release the trigger, engage the safety latch, and close the solvent valve. Repeat for the other solvent valve.

Any ratio check valves on the manifold output side must be flushed. Place a container under both valves to catch the waste solvent. Flush the valves after triggering the gun, one side at a time. Solvent may channel through viscous fluids and leave a coating of mixed fluid on the inner tube of your hose.

Fig 2 shows the handle in the UP, or closed, position and the right solvent valve open with solvent flowing through the right fluid chamber and out through the mixing chamber.



Operation

Be sure all fluid is thoroughly flushed from the hose after each use.

Disassemble all other dispensing equipment, as necessary, and clean thoroughly.

A CAUTION

To prevent fluid from setting up in the dispensing equipment, flush the system frequently. Be sure there is adequate solvent in the solvent supply before starting to spray.

Dispensing

To dispense the resin and hardener, turn on the supply pumps. Then push the handle forward (DOWN) to the open position. To stop the flow, move the handle to the UP or closed position.

Fig 3 shows the handle in the DOWN, or open, position, solvent valve closed, and resin and hardener flowing through the manifold.




Fig. 3 _____

Operation

Pressure Relief Procedure

WARNING



INJECTION HAZARD

The system pressure must be manually relieved to prevent the system from starting or spraying accidentally. Fluid

under high pressure can be injected through the skin and cause serious injury. To reduce the risk of an injury from injection, splashing fluid, or moving parts, follow the **Pressure Relief Procedure** whenever you:

- are instructed to relieve the pressure,
- stop spraying,
- check or service any of the system equipment,
- or install or clean the spray tip.

- 1. Close the mixer fluid valves.
- 2. Flush the dispensing equipment as described in the **Flushing Procedure** on page 6.
- 3. Shut off the fluid and solvent pumps.
- 4. Hold a metal part of the spray gun firmly to a grounded metal pail, and trigger the gun to relieve pressure.
- 5. Engage the gun safety latch
- 6. Open any drain valves, and leave them open until you are ready to spray again.
- 7. If fluid has hardened in the hose or mixer, close the fluid valve, shut off the fluid and solvent pumps, and *slowly* loosen the fluid inlet hose(s) to relieve pressure, then remove the dispensing hose.

Troubleshooting

▲ WARNING

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** above.

- Relieve the pressure before you check or service any system equipment.
- Check all possible causes and solutions in the Troubleshooting Chart before disassembling the manifold.

Problem	Cause	Solution
Little or no resin (A) output	The fluid inlet is plugged.	Clean the inlet, remove the obstruction.
	The fluid supply container is empty.	Refill the fluid supply.
Little or no hardener (B) output	The fluid inlet is plugged.	Clean the inlet, remove the obstruction.
	The fluid supply container is empty.	Refill the fluid supply.
The mixed fluid will not flush out	There is hardened fluid in the mixing chamber.	Clean the chamber with a compatible solvent; service it as necessary.
	The solvent supply container is empty.	Refill the solvent supply.
	The solvent is not compatible with the fluid.	Change to a compatible solvent.

Service

Manifold Repair (See Page 10.)

A WARNING

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 8.

Note: Repair kits are available for the manifold. Parts included in the kits are indicated with a †, for example (9†) See page 11.

- 1. Relieve the Pressure.
- Remove the twelve socket-head screws (2) to separate the two valve housings (8) from the manifold housing (7). Remove all parts from the housings.
- Clean all parts thoroughly in a compatible solvent.
 Use a soft bristle brush to clean the manifold passageways.
- 4. Install the two check valve assemblies (9†) and valve seats (6†) in the manifold housing (7).
- 5. Install the needle valve (12), back-up ring (4**), and seal (3†) in each of the valve housings (8).
- Install six socket-head screws (2) through one valve housing (8) and into the manifold housing (7), so the distance between the housings is 0.060 in. (1.5 mm).

- 7. Tighten the needle valve slightly, so that the tapered end centers in the seat (6) and holds its position.
- Turn the six socket screws (2) oppositely and evenly to 60–70 in-lbs (6.7–7.9 N•m). Back off the needle valve (12) slightly.
- 9. Repeat step 8 as the torque will relax.

A CAUTION

Be sure to tighten the six socket screws (2) evenly. The upper four screws, which surround the needle valve assembly (12), are critical in ensuring that the needle seats properly. If the bottom two screws are over-tightened, they will throw off the alignment.


10. Repeat the procedure from step 9 on the other valve housing (8).

Ball Valve Repair (See Page 10.)

Note: Repair Kit 217560 is available for the ball valves. Parts included in the kit are indicated with an asterisk, for example (18*). See page 11.

When reassembling a ball valve (13 or 24), install the ball (18* or 29*) so that the round hole aligns with the main passageway of the valve body and the square hole aligns with the stem (21 or 32) passageway.

Parts



10

Parts

Models 215625 and 215626, Series C

Ref				Ref No.	Part No.	Description (Qty.
No.	Part No.	Description	Qty.			<u>-</u>	χιy.
1	100721	PLUG, internal hex; 1/4; 1/4 np	t 2	20	165964	. NUT, packing	1
2	104472	CAPSCREW, hex hd;	. –	21	178745	. STEM	1
_	.0	10–32 x 1–1/2	12	22*	172094	. SEAT, ball; Nylatron®	2
3†	105694	SEAL, shaft; SST and PTFE	2	23	178743	. HOUSING	1
4†	177019	RING, back-up; Delrin®	2	24	215623	VALVE, ball;	
5	177021	NIPPLE, pipe, hex; 1/4 npt	1			used in model 215626 Series B	
6†	177022	SEAT, valve; Delrin®	2			includes items 25–34	2
7	.,, 022	HOUSING, manifold;	_	25	102310	. NUT	1
•	181116	used in model 215625	1	26*	104892	. O-RING; PTFE	2
	181115	used in model 215626	1	27*	104893	. O-RING; PTFE	1
8		HOUSING, valve;	•	28*	164900	. WASHER, back-up; Delrin [®]	2
· ·	177029	used in model 215625	2	29*	178746	. BALL	1
	177030	used in model 215626	2	30	165599	. STUD; 3/8 npt	2
9†		CHECK VALVE Assy	_	31	165964	. NUT, packing	1
• 1	215619	used in model 215625	2	32	178745	. STEM	1
	215618	used in model 215626	2	33*	172094	. SEAT, ball; Nylatron [®]	2
11	217562	HANDLE	2	34	178743	. HOUSING, valve	1
12	215621	NEEDLE VALVE Assy	2	37‡	104429	CAPSCREW, hex hd; 1/4 x 2.25"	
13	215622	VALVE, ball;				(not shown)	2
		used in model 215625		38‡	100015	NUT, hex, mscr; 1/4 (not shown)	2
		Series B Includes items 14–23	2	39‡	100016	LOCKWASHER; 1/4" (not shown) 2
14	102310	. NUT	1	40‡	178928	SPACER (not shown)	1
15*	104892	. O-RING; PTFE	2	41	188732	LABEL, instruction	1
16*	104893	O-RING; PTFE	1	* Su	pplied in Rep	air Kit 217560.	
17*	164900	. WASHER, back-up; Delrin®	2				IV:1
18*	178746	. BALL	1	-		pair Kit 215913 or 215914. Order Repai Not 215626, and Ropair Kit 215014 for	r Kit
10	16527/	STUD: 1/4 npt	2	21	39131011000	del 215626, and Repair Kit 215914 for	

2

Kits for Series A Manifolds

Ball Valve Kit 218413

165274

Updates the handle (11) and ball valve (13) of Series A 215625 Low Volume Mixer. Includes:

. STUD; 1/4 npt

Ref

19

No.	Part No.	Description	Qty.
11	217562	HANDLE	1
13	215622	VALVE, ball; used in model 215625	
		Series B Includes items 14–23	2

Ball Valve Kit 218414

Model 215625.

Updates the handle (11) and ball valve (24) of Series A 215626 High Volume Mixer. Includes:


Ref

NO.	Part No.	Description	Qty.
11	217562	HANDLE	1
24	215623	VALVE, ball;	
		used in model 215626 Series B	
		includes items 25–34	2

[‡] One spacer (40), two screws (37), nuts (38) and lockwashers (39) are included for mounting the manifold.

Parts

Model 241692 Series A




Ref No.	Part No.	Description	Qty.	Ref No.	Part No.	Description	Qty.
1	215626	MANIFOLD, mixer; see full parts	S	5	156823	UNION, swivel	2
		and listing on pages 10 and 11	1	6	108233	VALVE, needle	2
2	157676	UNION, swivel, 90°	1	7	502265	BUSHING, reducer, pipe	1
3	155699	ELBOW, street	2	8	512506	MIXER, static, pipe	1
4	161037	FITTING, union, adapter	2	9	158581	COUPLING, hex	1

Technical Data


Maximum working pressure
Fluid port size
Model 215625
Model 241692
Model 215626
Solvent port size
Model 215625
Model 215626 and 241692
Fluid outlet size
Model 215625
Model 241692
Model 215626
Mix chamber volume
Model 215625 0.10 fluid oz. (3.1 ml)
Model 215626 and 241692 0.32 fluid oz. (10 ml)
Wetted parts Chrome Alloy, High Carbon, Nickel
Plated and Zinc Plated Steels; 303,
316*, and 416 stainless steels; Delrin [®] ,
Nylon, PTFE, Plastics and Nylatron®
*316 Stainless Steel only used in 216626.
Delrin [®] is a registered trademarks of the DuPont Company.
Nylatron® is a registered trademark of the Polymer Corporation.
Typian of the a region of the resignation.

Dimensions

	Model	Model	Model
	215625	215626	241692
A	5.0 in	5.5 in	5.5 in
Overall Length	(127 mm)	(140 mm)	(140 mm)
B	5.375 in.	6.25 in	19.85 in
Overall Height	(136 mm)	(159 mm)	(504 mm)
C	1.375 in	1.25 in	1.25 in
Overall Width	(35 mm)	(32 mm)	(32 mm)
D Fluid Inlets	1/4 npt(m)	3/8 npt(m)	3/8 npt(m)
E Solvent Inlet	1/4 npt(m)	1/4 npt(m)	1/4 npt(m)
F Material Outlet	1/4 npt(m)	1/2 npt(m)	3/8 npt(m)



Notes



Graco Standard Warranty

Graco warrants all equipment manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale by an authorized Graco distributor to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

Graco makes no warranty, and disclaims all implied warranties of merchantability and fitness for a particular purpose in connection with accessories, equipment, materials or components sold but not manufactured by Graco. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés à la suite de ou en rapport, directement ou indirectement, avec les procedures concernées.

Graco Information

TO PLACE AN ORDER, contact your Graco distributor, or call one of the following numbers to identify the distributor closest to you:

1-800-367-4023 Toll Free 612-623-6921 612-378-3505 Fax

All written and visual data contained in this document reflects the latest product information available at the time of publication.

Graco reserves the right to make changes at any time without notice.

Sales Offices: Minneapolis, Detroit International Offices: Belgium, Korea, Hong Kong, Japan

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

www.graco.com

PRINTED IN U.S.A. 307400 09/1980, Revised 10/2002

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com