User's Guide

L1717S

Make sure to read the **Important Precautions** before using the product. Keep the User's Guide(CD) in an accessible place for furture reference. See the label attached on the product and quote this information to your dealer when you require service.



This unit has been engineered and manufactured to ensure your personal safety, however improper use may result in potential eletrical shock or fire hazards. In order to allow the proper operation of all safeguards incorporated in this display, observe the following basic rules for its installation, use, and servicing.

On Safety

Use only the power cord supplied with the unit. In case you use another power cord, make sure that it is certified by the applicable national standards if not being provided by the supplier. If the power cable is faulty in any way, please contact the manufacturer or the nearest authorized repair service provider for a replacement.

The power supply cord is used as the main disconnection device. Ensure that the socket-outlet is easily accessible after installation.

Operate the display only from a power source indicated in the specifications of this manual or listed on the display. If you are not sure what type of power supply you have in your home, consult with your dealer.

Overloaded AC outlets and extension cords are dangerous. So are frayed power cords and broken plugs. They may result in a shock or fire hazard. Call your service technician for replacement.

Do not Open the Display.

- There are no user serviceable components inside.
- There are Dangerous High Voltages inside, even when the power is OFF.
- Contact your dealer if the display is not operating properly.

To Avoid Personal Injury :

- Do not place the display on a sloping shelf unless properly secured.
- Use only a stand recommended by the manufacturer.

To Prevent Fire or Hazards:

- Always turn the display OFF if you leave the room for more than a short period of time. Never leave the display ON when leaving the house.
- Keep children from dropping or pushing objects into the display's cabinet openings. Some internal parts carry hazardous voltages.
- Do not add accessories that have not been designed for this display.
- During a lightning storm or when the display is to be left unattended for an extended period of time, unplug it from the wall outlet.

On Installation

Do not allow anything to rest upon or roll over the power cord, and do not place the display where the power cord is subject to damage.

Do not use this display near water such as near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool. Displays are provided with ventilation openings in the cabinet to allow the release of heat generated during operation. If these openings are blocked, built-up heat can cause failures which may result in a fire hazard. Therefore, NEVER:

- Block the bottom ventilation slots by placing the display on a bed, sofa, rug, etc.
- Place the display in a built-in enclosure unless proper ventilation is provided.
- Cover the openings with cloth or other material.
- Place the display near or over a radiator or heat source.

Do not rub or strike the Active Matrix LCD with anything hard as this may scratch, mar, or damage the Active Matrix LCD permanently.

Do not press the LCD screen with your finger for a long time as this may cause some afterimages.

Some dot defects may appear as Red, Green or Blue spots on the screen. However, this will have no impact or effect on the display performance.

If possible, use the recommended resolution to obtain the best image quality for your LCD display. If used under any mode except the recommended resolution, some scaled or processed images may appear on the screen. However, this is characteristic of the fixed-resolution LCD panel.

On Cleaning

- Unplug the display before cleaning the face of the display screen.
- Use a slightly damp (not wet) cloth. Do not use an aerosol directly on the display screen because over-spraying may cause electrical shock.

On Repacking

 Do not throw away the carton and packing materials. They make an ideal container in which to transport the unit. When shipping the unit to another location, repack it in its original material.

On Disposal

- The fluorescent lamp used in this product contains a small amount of mercury.
- Do not dispose of this product with general household waste.
 Disposal of this product must be carried out in accordance to the regulations of your local authority.



• Before setting up the monitor, ensure that the power to the monitor, the computer system, and other attached devices is turned off.


Unfolding the stand base

1. Place the monitor with its front facing upward on a cushion or soft cloth.

Expand the stand base to its first step degree (70°), pulling it apart with two hands.



2. Place the monitor with its front facing downward and then further expand the stand base fully to 90 degrees. Do not apply excessive force to expand the stand base over 90 degrees as it may damage the monitor.




3. Place the monitor upright and adjust the angle of the stand base as desired. Adjust the stand base angle with two hands, holding the monitor head.



Folding the stand base

1. Face the front of the monitor and push the monitor backwards, following the sequence shown in the picture. Be careful not to squash your hands while you fold the stand base.



This illustration depicts the general model of connection. Your monitor may differ from the items shown in the picture.


 Δ Do not touch or apply force to the monitor screen while expanding or folding the stand base.

Using the Computer

- 1. Connect the signal cable. When attached, tighten the thumbscrews to secure the connection.
- 2. Connect the power cord into a proper power outlet that is easily accessible and close to the display. ②

NOTE

- This is a simplified representation of the rear view.
- This rear view represents a general model; your display may differ from the view as shown.



3. Press button on the front switch panel to turn the power on. When monitor power is turned on, the 'Self Image Setting Function' is executed automatically.

PROCESSING SELF

NOTE

* Self Image Setting Function'? This function provides the user with optimal display settings. When the user connects the monitor for the first time, this function automatically adjusts the display to optimal settings for individual input signals. If you want to adjust the monitor while in use, or wish to manually run this function once again, push the 'AUTO/SET' button on the front panel of the monitor. Otherwise, you may execute the ' Factory reset' option on the OSD adjustment menu. However, be aware that this option initializes all the menu items except 'Language'.



Front Panel Controls

MENI	J – Light	view + AUTO	/SET	Ů	
			3		

Control	Function		
MENU Button	Button Use this button to enter or exit the On Screen Display.		
	OSD LOC	KED/UNLOCKED	
OSD LOCKED OSD UNLOCKED	This function allows you to lock the current control settings, so that they cannot be inadvertently changed. Press and hold the MENU button for 5 seconds. The message "OSD LOCKED" should appear.		
	You can unlock the OSD controls at any time by pushing the MENU button for 5 seconds. The message " OSD UNLOCKED " should appear.		
2 - + Buttons	Use these buttons to select or adjust functions in the On Screen Display.		
	LightViev	w hot key	
DAY TEXT	DAY NIGHT This feature lets you easily select the best of image condition optimized to the environme (ambient illumination, image types etc).		
NIGHT TEXT		 DAY : Bright ambient illumination NIGHT : Dark ambient illumination TEXT : For text images (Word processing etc.) MOVIE : For animation images in videos or movies PHOTO : For pictures or drawings NORMAL : This is under normal operating conditions 	

Control		Function	
Butto	D/SET on	Use this button to enter a selection in the On Screen Display.	
	CESSING AUTO Se adjustment	AUTO IMAGE ADJUSTMENT When adjusting your display settings, always press the AUTO/SET button before entering the On Screer Display(OSD). This will automatically adjust your display image to the ideal settings for the current screen resolution size (display mode). The best display mode is 17 inch monitor : 1280x1024	
4 Powe	r Button	Use this button to turn the display on or off.	
5 Powe	r Indicator	This Indicator lights up green when the display operates normally(On Mode). If the display is in Sleep Mode (Energy Saving), this indicator color changes to amber.	

Screen Adjustment

Making adjustments to the image size, position and operating parameters of the display is quick and easy with the On Screen Display Control system. A short example is given below to familiarize you with the use of the controls. The following section is an outline of the available adjustments and selections you can make using the OSD.

NOTE

• Allow the display to stabilize for at least 30 minutes before making image adjustments.

To make adjustments in the On Screen Display, follow these steps:

$$MENU \rightarrow - + \rightarrow AUTO/SET \rightarrow - + \rightarrow MENU$$

- Press the MENU Button, then the main menu of the OSD appears.
- 2 To access a control, use the or + Buttons. When the icon you want becomes highlighted, press the AUTO/SET Button.
- 3 Use the **-+ Buttons** to adjust the item to the desired level.
- Accept the changes by pressing the MENU Button.
- 5 Exit the OSD by Pressing the MENU Button.

The following table indicates all the On Screen Display control, adjustment, and setting menus.


Main menu	Sub menu			Reference	
PICTURE	BRIGHTNESS			To adjust the brightness, contrast	
	CONTRA	ST		and gamma of the screen	
	GAMMA				
COLOR	PRESET	6500K		To customize the color of the	
		9300K		screen	
	RED				
	GREEN				
	BLUE				
POSITION	HORIZON	NTAL		To adjust the position of the screen	
	VERTICA	L			
TRACKING	CLOCK			To improve the clarity and	
	PHASE			stability of the screen	
SETUP	LANGUAGE			To customize the screen status	
~~~~~	OSD HORIZONTAL			for a user's operating environment	
	POSITION VERTICAL				
	WHITE BALANCE				
	POWER INDICATOR				
	FACTORY RESET				
				Adjustable	

#### NOTE

• The order of icons may differ depending on the model (A9~A12).



You were introduced to the procedure of selecting and adjusting an item using the OSD system. Listed below are the icons, icon names, and icon descriptions of the all items shown on the Menu.




Press the MENU Button, then the main menu of the OSD appears.

#### NOTE

• OSD (On Screen Display) menu languages on the monitor may differ from the manual.

## On Screen Display(OSD) Selection and Adjustment



Main menu	Sub menu	Description
TRACKING		<b>.</b>
TRACKING	CLOCK	To minimize any vertical bars or stripes visible on the screen background.The
		horizontal screen size will also change.
PHASE	PHASE	To adjust the focus of the display. This
፼ ⋳ <b>───</b> ────────────────── 50		item allows you to remove any horizontal noise and clear or sharpen
		the image of characters.
MENU 🖸 – 🖅 + 🕂 SET 🗉		
MENU : Exit		

- : Decrease
- + : Increase

■ SE	I: Selec	t another	sub-menu
------	----------	-----------	----------

	LANGUAGE	To choose the language in which the control names are displayed.	
Construction     Construction	OSD POSITION	To adjust position of the OSD window on the screen.	
	WHITE Balance	If the output of the video card is different the required specifications, the color level may deteriorate due to video signal distortion. Using this function, the signal level is adjusted to fit into the standard output level of the video card in order to provide the optimal image.	
Image: Section 2         FACTORY RESET         ►NO           Image: Section 2         1280 x 1024 60HZ         1280 x 1024 60HZ		Activate this function when white and black colors are present in the screen.	
MENU - E + SET • MENU : Exit • - : Adjust • + : Adjust • SET : Select another sub-men	POWER INDICATOR	Use this function to set the power indicator on the front side of the monitor to <b>ON</b> or <b>OFF</b> . If you set <b>OFF</b> , it will go off. If you set <b>ON</b> at any time, the power indicator will automatically be turned on.	
16 al. :	FACTORY RESET	Restore all factory default settings except "LANGUAGE." Press the ► button to reset immediately.	

If this does not improve the screen image, restore the factory default settings. If necessary, perform the white balance function again. This function will be enabled only when the input signal is an analog signal.

## A12

Check the following before calling for service.

No image appears	
Is the power cord of the display connected?	<ul> <li>Check and see if the power cord is connected properly to the power outlet.</li> </ul>
Is the power indicator light on?	Press the Power button.
Is the power on and the power indicator blue or green?	<ul> <li>Adjust the brightness and the contrast.</li> </ul>
Is the power indicator amber?	<ul> <li>If the display is in power saving mode, try moving the mouse or pressing any key on the keyboard to bring up the screen.</li> <li>Try to turn on the PC.</li> </ul>
Do you see an "OUT OF RANGE" message on the screen?	• This message appears when the signal from the PC (video card) is out of horizontal or vertical frequency range of the display. See the 'Specifications' section of this manual and configure your display again.
Do you see a "CHECK SIGNAL CABLE" message on the screen?	<ul> <li>This message appears when the signal cable between your PC and your display is not connected. Check the signal cable and try again.</li> </ul>

Do you see a "OSD LOCKED" message on the screen?			
Do you see "OSD LOCKED" when you push MENU button?	<ul> <li>You can secure the current control settings, so that they cannot be inadvertently changed. You can unlock the OSD controls at any time by pushing the MENU button for 5 seconds: the message</li> <li>"OSD UNLOCKED" will appear.</li> </ul>		

Display image is incorrect			
Display Position is incorrect.	<ul> <li>Press the AUTO/SET button to automatically adjust your display image to the ideal setting. If the results are unsatisfactory, adjust the image position using the H position and V position icon in the on screen display.</li> <li>Check Control Panel&gt; Display&gt; Settings and see if the frequency or the resolution were changed. If yes, readjust the video card to the recommend resolution.</li> </ul>		
On the screen background, vertical bars or stripes are visible.	• Press the <b>AUTO/SET</b> button to automatically adjust your display image to the ideal setting. If the results are unsatisfactory, decrease the vertical bars or stripes using the <b>CLOCK</b> icon in the on screen display.		
Any horizontal noise appearing in any image or characters are not clearly portrayed.	<ul> <li>Press the AUTO/SET button to automatically adjust your display image to the ideal setting. If the results are unsatisfactory, decrease the horizontal bars using the PHASE icon in the on screen display.</li> <li>Check Control Panel&gt; Display&gt; Settings and adjust the display to the recommended resolution or adjust the display image to the ideal setting. Set the color setting higher than 24 bits (true color).</li> </ul>		
The screen color is mono or abnormal.	<ul> <li>Check if the signal cable is properly connected and use a screwdriver to fasten if necessary.</li> <li>Make sure the video card is properly inserted in the slot.</li> <li>Set the color setting higher than 24 bits (true color) at <b>Control Panel - Settings</b>.</li> </ul>		
The screen blinks.	<ul> <li>Check if the screen is set to interlace mode and if yes, change it to the recommend resolution.</li> <li>Make sure the power voltage is high enough, It has to be higher than AC100-240V 50/60Hz.</li> </ul>		

Have you installed the display driver?			
Have you installed the display driver?	• Be sure to install the display driver from the display driver CD (or diskette) that comes with your display. Or, you can also download the driver from our web site: http://www.lge.com.		
Do you see an "Unrecognized monitor, Plug&Play (VESA DDC) monitor found" message?	<ul> <li>Make sure to check if the video card supports Plug&amp;Play function.</li> </ul>		

Display	Anti-Gla 17 inche	es (43.2cm) re coating es viewable im pixel pito		tive matrix-TFT LCD
Sync Input	Horizon Vertical Input Fo			utomatic) L, Positive/Negative ITL Positive/Negative
Video Input	Signal I Input Fo		15 pin D-Sul RGB Analog	o Connector (0.7Vp-p/75ohm)
Resolution	Max Recom			x 1024@75Hz x 1024@60Hz
Plug&Play	DDC 2B			
Power Consumption	On Moo Sleep M Off Moo	lode	≤ 35W ≤ 1W ≤ 1W	
Dimensions &Weight (with tilt stand)	Width Height Depth Net	38.61 cm / 38.35 cm /	Position 15.20 inches 15.09 inches 7.48 inches 4.4 kg (9.70	Folded Position 38.61cm / 15.20 inches 44.0 cm / 17.32 inches 6.6 cm / 2.55 inches Ibs)
Tilt Range	Tilt		0°~20°	
Power Input	AC 100-	240V~ 50/6	60Hz 1.0A	
Environmental Conditions	Operating ConditionsTemperature10°C to 35 °CHumidity10 % to 80 % non-CondensingStorage Conditions-20°C to 60 °CHumidity5 % to 95 % non-Condensing			
Tilt Stand	Attached( 0 ), Detached ( )			
Signal cable	Attached(), Detached (O)			
Power cord	Wall-outlet type or PC-outlet type			
		/ 1	-71-	

### NOTE

Information in this document is subject to change without notice.



## • PRESET MODE

Display Modes (Resolution)			Horizontal Freq. (kHz)	Vertical Freq. (Hz)
1	VGA	640 x 350	31.469	70
2	VGA	720 x 400	31.468	70
3	VGA	640 x 480	31.469	60
4	VESA	640 x 480	37.500	75
5	VESA	800 x 600	37.879	60
6	VESA	800 x 600	46.875	75
7	MAC	832 x 624	49.725	75
8	VESA	1024 x 768	48.363	60
9	VESA	1024 x 768	60.023	75
10	MAC	1152 x 870	68.681	75
11	VESA	1152 x 900	61.805	65
*12	VESA	1280 x 1024	63.981	60
13	VESA	1280 x 1024	79.976	75

## Indicator


Mode	LED Color
On Mode	Green
Sleep Mode	Amber
Off Mode	Off

*Recommend Mode



#### **VESA** wall mounting

Connected to another object (stand type and wallmounted type. This monitor accepts a VESAcompliant mounting interface pad.- **optional**) For further information, refer to the VESA Wall Mounting Instruction Guide.



Kensington Security Slot- optional Connected to a locking cable that can be purchased separately at most computer stores

# Digitally yours





Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com