## Table of Contents


PrecautionsPrecautions	. 1
Package contents	
Installation instructions	
Assembling the Monitor	
Detaching the Monitor	
Adjusting the Viewing Angle	
Connecting the Devices	
Switching the Power	
Adjusting display settings	
External Controls	
OSD options	
OSD Menu	. 4
Troubleshooting	
General specifications	

### **Precautions**




- The monitor may be damaged if placed too near a source of heat. Be aware of the location of radiators, cookers, open fires etc.
- Do not cover the slots and openings on the back or top of the cabinet as the monitor requires ventilation. The monitor should be located in a wellventilated room to prevent the possibility of overheating.
- Do not allow sharp objects such as knives, pens, or pencils near the screen. If such objects touch the screen, the LCD panel will be permanently scratched.
- When cleaning this monitor, disconnect it from the electric socket to avoid any danger of electrocution. A soft, lint-free cloth should be used to clean the outside of the monitor. A cloth very slightly moistened with a mild detergent solution will clean stubborn stains. Keep liquids away from the display screen, including sprays. Do not spray liquid directly it is best to lightly spray on to a cloth and wipe. If liquid gets inside the monitor it can cause electrical shock and/or damage to the unit.
- If you encounter a problem, please check the "Troubleshooting" section
  first. If this does not resolve the problem do not attempt to repair the
  monitor by yourself; opening or removing covers can lead to injury or
  death through electrocution among other hazards. Please contact a
  qualified engineer if you find the troubleshooting section does not help.

# Package contents



# Installation instructions

## **Assembling the Monitor**



1. Position the monitor on top of the stand.



2. Connect the stand into the neck of the monitor along the track.

## **Detaching the Monitor**

If you need to repackage the monitor, please separate the monitor and base, and restore them to the carton.

To detach the monitor:

- 1. Unplug the AC power cord to make sure the power is off.
- 2. Pull the 4 hooks on bottom side of the base and hold.
- 3. Separate the monitor and base and put them into carton.

#### **Important**

First, find a clean, flat surface to place the monitor after removing it from the stand. Place a clean dry cloth under the monitor to protect it further.

Pull the monitor slightly up and away from the stand.


## **Adjusting the Viewing Angle**

The viewing angle of the monitor ranges from  $-5^{\circ}\sim20^{\circ}$ .

## **Connecting the Devices**

V.

**Caution:** Make sure that the computer and the monitor are both disconnected from the power supply.



①	Power Code	Attach the monitor to the power cord which should then be
		inserted into a properly grounded electric socket.
2	VGA Cable	Connect the signal cable to the VGA output socket of the
	(Attached)	graphics card on the computer. Then tighten the
		thumbscrews on the connector.
3	Audio cable	Connect the audio input socket of the LCD monitor and the
	(Optional)	computer by means of the audio cable.


**WARNING:** The D-Sub 15 pin plug of the VGA cable is trapezoid in shape. Make sure the shape of the plug matches the shape of the socket it is inserted into, and that none of the pins are bent or otherwise damaged.

3

## **Switching the Power**

First, switch the power on to the monitor, then switch the power on to the computer. When you see the LED on the power button go green, this indicates the computer is ready for use. Allow about 10 seconds for the video signal to appear. If you do not see the green light on the power button or a video signal, check the connections.

# Adjusting display settings



### **External Controls**

1.	AUTO	AUTO	If OSD is active, press to exit a selection in OSD. If OSD is inactive, press and the monitor will automatically optimize the position, focus and clock of your display.
2	<	MINUS	If OSD is active, press to select or adjust OSD options. If OSD is inactive, press once, then press the buttons marked < or > to adjust the volume.
3	>	PLUS	If OSD is active, press to select or adjust OSD options. If OSD is inactive, press once, then press the buttons marked < or > to adjust the volume.
4	MENU	OSD Function	Press to view OSD.  Press again to enter a selection in OSD.
5	Φ	POWER	Power on/off Green: power on Orange: in sleep mode

Notice: **0** & **2** are only suitable for models with speakers.

4

# OSD options

Please refer to "External Controls" on Page 4.

To adjust the OSD settings:

- 1. Press the **MENU** button to open the OSD menu. Press again to enter a selection of 10 functions on OSD.
- 2. Use the buttons marked < or >, to highlight a control, then adjust the control to the desired level.
- 3. When you have finished making all selections, press the **AUTO** button to exit the OSD.

#### **OSD Menu**





#### **Contrast:**

This adjusts dark and light shades of color relative to each other to achieve a comfortable contrast.

#### **Brightness:**

This adjusts the brightness of the picture on the screen.





#### Focus:

This removes any horizontal distortion and makes the picture clear and sharp.

#### Clock:

If there are any vertical stripes seen on the background of the screen this renders them less noticeable by minimizing their size. It also changes the size of the horizontal screen.













#### **H-Position:**

This adjusts the horizontal.

#### V-Position:

This adjusts the vertical.



#### **COLOR:**

There are three ways of adjusting color:

Warm (Reddish white)

Cool (Bluish white)

User defined:

You can adjust the colors red, green and blue to the intensity you desire.



#### LANGUAGE:

Select the OSD menu language from English, German, Spanish, Simplified Chinese, Traditional Chinese, French, Italian, and Japanese.



#### **OSD SETTING:**

This changes the position of the OSD window on the screen and staying time.







#### **Auto Config:**

System runs auto-configuration.





#### **INFORMATION:**

This shows brief information on the screen.





#### **Reset:**

Recall to default settings.





Exit:

Exit from OSD.

# Troubleshooting

Problems	Possible Solutions
Power LED is not ON	Check to see if the power switch is in the ON position.
	Ensure that the Power Cord is connected.
No Picture	Check to see if the power switch is in the ON position.
	Ensure that the Power Cord is connected.
	Ensure the video cable is securely connected to the back of the monitor and the computer.
	Move the mouse or press any key on the keyboard to bring the monitor out of "active off" mode.
Picture shows inappropriate colors	See "Color Adjustment" to adjust RGB color or to select color temperature.
Picture bounces or a wave pattern is present in the picture	Move or switch off electrical devices that may be causing interference.
	Inspect the monitor's video cable and ensure that none of the pins are bent.
Image is not sized or centered properly	Press select/auto key and the monitor will automatically optimize the position of your display.
	See "Position adjustment".

Caution: Do not attempt to service the monitor yourself or open the computer yourself. Please refer all servicing to qualified service personnel if the problems cannot be solved in "Troubleshooting" section.

# General specifications

Item	Specification	
LCD Panel	•	
Display	17-inch Flat panel active-matrix TFT LCD	
Max resolution	SXGA 1280×1024 pixels	
Pixel Pitch	0.264 mm	
Color	16.2M	
Brightness	300 cd/m <sup>2</sup> (Typical)	
Contrast Ratio	450:1 (Typical)	
Response Time	4ms +16ms /20ms (Tr+Tf / typical)	
View Angle of Horizontal	75° / 75°	
View Angle of Vertical	65° / 60°	
External Controls		
Power Button	ON/ OFF	
Control Buttons	Auto, <, >, MENU	
OSD Function		
Contrast /Brightness	Contrast / Brightness	
Focus/Clock	Focus/Clock	
Position	Position	
Color	Color	
Language	Language	
OSD setting	OSD Setting	
Auto config	Auto config	
Information	Information	
Reset	Reset	
Exit	Exit	
Video Interface		
Video	Analog 0.7V	
Sync	TTL (+/ -)	
Audio (Optional)	1W x 2	
Plug & Play	DDC2B	
Power		
Power Source	100~240V AC, 50/60 Hz	
Power consumption during normal	< 40W	
operation	< 40 W	
Power consumption during active off	< 1W	
operation	< 1 W	
Dimension and Weight		
Dimension (W×H×D)	$377 \times 396 \times 182$ mm (with stand)	
	$377 \times 396 \times 62 \text{ mm (without stand)}$	
Weight (Net/ Gross)	4.3 Kg/ 5.4Kg	

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com