# **Specifications**

Dimensions: 10½" (26.7cm)L x 24½" (62.2cm)W x 3½" (8.9cm)H

Weight: 13½ lbs. (6.2kg)

Power: 120VAC, 50/60Hz, 840 Watts

Width Capacity: 13½" (34.3cm)

Maximum Thickness: 1/16" (2mm)

Film Thickness: 1.5 mil up to 10 mil (37 micron - 250 micron) each side

#### WARRANTY AND RETURN POLICY

#### Warranty:

Your laminator is warranted to be free of defects in materials and workmanship for a period of one year from the date of purchase. In the event of a defect in material or workmanship, your dealer will (at his/her option) repair or replace the laminator.


No other warranty is implied except as stated above. This warranty does not cover damage as a result of misuse, or any special or consequential damage, whether or not foreseeable.

# **Return policy:**

If your laminator is not operating properly, first review the instructions. If the malfunction cannot be corrected, contact your dealer for instructions. Be sure to have your machine serial number and date of purchase handy.

If the laminator must be returned to the dealer, it is your responsibility to ensure it is packaged properly. Shipping damage as a result of improper packaging is not covered under the terms of this warranty.

# Operating Instructions



Model No.
PL135-4
(120V)

Revised 10/08/98

#### INTRODUCTION

Congratulations on your purchase of our PL135-4 13½" (34.3cm) four roller pouch laminator. This laminator is designed to provide quality lamination of all thicknesses of plastic.

The PL135-4 is designed for cards as well as larger items up to 13½" (34.3cm) wide. A thermostat allows you to adjust the temperature as needed for laminating different materials.

#### **OPERATION**

Before using your laminator, be sure to observe the following precautions:

- To prevent electric shock, do not operate the unit near a sink or other water source.
- Do not immerse the laminator, its cord, or plug in water.
- Do not use the laminator if the power cord is damaged.
- Do not allow the cord to touch hot surfaces or hang over the edge of a cabinet or shelf.
- In case of a malfunction, return the unit to your dealer for service. The laminator does not contain any customer serviceable parts.
- To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.

### To use your pouch laminator follow these steps:

- Place the unit on a table and plug the power cord into a grounded 120VAC outlet.
- 2. Press the HEAT switch to the ON position (the switch will illuminate). The indicator light will come on when the laminator has reached operating temperature and is ready to laminate (about 3 minutes).
- 3. Insert the item to be laminated into a laminating pouch. Next, place the pouch into the paper laminating carrier. The carrier must be at least  $4\frac{1}{2}$ " (11.43cm) long when in the folded position.
- 4. Press the RUN switch to the ON position (the switch will illuminate).

- 5. Slowly feed the carrier, folded end first, into the laminator until it is picked up by the rollers.
- 6. Remove the carrier from the rear of the laminator after it has stopped moving. Leave the pouch inside the carrier for several seconds to cool before removing it.
- 7. Turn the RUN and HEAT switches OFF at the end of the day.

#### **TEMPERATURE ADJUSTMENT**

Your pouch laminator temperature has been factory set to provide high quality lamination under normal conditions. If you use a heavier paper or use a different laminating film, the temperature may be adjusted by turning the temperature control knob on the bottom of the unit.

## To increase the temperature:

- 1. Turn the temperature control knob clockwise one division. Wait until the green indicator light comes on before laminating.
- 2. Repeat step 1 until the laminator produces the desired results.

## To decrease the temperature:

- 1. Turn the temperature control knob counter-clockwise. The green indicator light will remain on. Wait several minutes before laminating.
- 2. Repeat step 1 until the laminator produces the desired results.
- If the pouch does not seal or the lamination is cloudy, the temperature is too low.
- If the lamination contains bubbles or wrinkles, the temperature is too high.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com