

# INSTALLATION INSTRUCTIONS

## IDC ICEMAKER ADAPTER KIT FOR P/N 629088662

1. Place bar into 1st set of pockets inside the ice bin, gasket side up.
2. Hook cross braces over top of bar and back of ice bin such that they fit down inside the outer pockets of the ice bin. Place gasket side up.
3. Place Icemaker Adapter Kit on top of unit.
4. Place icemaker on top of kit. DO NOT slide icemaker into position on the lid.
5. Apply continuous bead of NSF international (NSF) listed silastic sealant (Dow 732 or equivalent), supplied in kit, to seal the icemaker to the top of the adapter kit. All excess sealant must be wiped away immediately.
6. Drill  $9/64$ " diameter holes, using one of the two supplied brackets as a template, into the rear of the icemaker and the rear of the icemaker adapter kit. USE EXTREME CARE NOT TO DRILL INTO ANY ICEMAKER COMPONENTS!!! Secure the icemaker to the adapter using the screws and brackets provided.




FIGURE 1

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>