D-Link **Quick Installation Guide**

This product can be set up using any current web browser, i.e., Internet Explorer 6 or Netscape Navigator 6.2.3.

Before You Begin



DWL-810+ **D-Link AirPlus**[™] Ethernet-to-Wireless Bridge

You must have at least the following:

An Ethernet-enabled device, such as a game console, laptop or desktop computer, network printer or set-top box that will connect to the DWL-810+

Check Your Package Contents



If any of the above items are missing, please contact your reseller.

©2002 D-Link Systems, Inc. All rights reserved. Trademarks or registered trademarks are the property of their respective holders. Software and specifications subject to change without notice. DWL-810+04162003

Connecting the DWL-810+ to your Ethernet-enabled device

- A. First, connect the power adapter to the **receptor** at the back panel of the DWL-810+ and then plug the other end of the power adapter to a wall outlet or power strip. The Power LED will turn **ON** to indicate proper operation.
- B. Insert one end of an Ethernet cable (included) to the Ethernet port on the back panel of the DWL-810+ and connect the other end to the Ethernet port located on the device (e.g., a Set Top Box, Gaming Console, laptop or desktop computer, or network printer.) The LED light will blink when there is data tranfer through the wireless connection. (Note: The Ethernet port on the DWL-810+ is Auto-MDI/MDIX. Meaning you can use a straight-through or crossover-cable to the Ethernet Port.)
- C. The antenna is used by the DWL-810+ to connect to other 802.11b wireless devices.





Connect an Ethernet cable from the DWL-810+ to your Ethernet enabled: Desktop PC, Laptop PC, Set-Top-Box, or Gaming Console.



Setup #2





Before You Begin the Configuration

It's best to use a computer (with an Ethernet adapter) that is connected to a switch for configuring the DWL-810+. (Note: You also have the option of connecting the DWL-810+ directly to the computer that will be used for configuration). The default IP address for the DWL-810+ is 192.168.0.30 with a Subnet Mask of 255.255.255.0. You will need to assign your computer a Static IP address within the same range as the DWL-810+'s IP address for the purpose of configuring the DWL-810+. See the Manual on the CD-ROM if you need assistance in assigning a Static IP address for your network adapter.

Open your Web browser and type "http://192.168.0.30" into the URL address box. Then press the **Enter** or **Return** key.







Step 1 - Set up your new password. You have the option to establish a password.	DWL-810+ Setup Wizard Set Password You may change the admin account password by entering in a new password. Click Next to continue.
	New Password Confirm Password
Click Next	G D Back Next Exit



Step 3 - Encryption

The DWL-810+ is capable of three levels of wireless encryption - 64-bit, 128-bit, and 256-bit. **By default the encryption is disabled.** You can change the encryption settings for more secure wireless communication.



Click Next





You have completed the Configuration of the DWL-810+!

Appendix Xbox Setup

Step 1 - Please refer to Step 4 for configuring and modifying the wireless settings of the DWL-810+



Step 2 - Connect an Ethernet cable from the DWL-810+ to the Ethernet port on the back of your Xbox.

In order to connect to the XBox Live service, you will need to have the proper XBox Live equipment and account.





Appendix PlayStation 2 Setup

Step 1 - Please refer to Step 4 for configuring and modifying the wireless settings of the DWL-810+



Step 2 - Connect an Ethernet cable from the DWL-810+ to the Ethernet port on the back of your PlayStation 2.





Appendix Assigning a Static IP Address in Windows

To assign a Static IP Address to the laptop or computer that you are using to configure the DWL-810+, please do the following:



10

For Apple Macintosh OS X:



Technical Support

You can find software updates and user documentation on the D-Link website.

D-Link provides free technical support for customers within the United States and within Canada for the duration of the warranty period on this product.

U.S. and Canadian customers can contact D-Link technical support through our website, or by phone.

Tech Support for customers within the United States: D-Link Technical Support over the Telephone:

(877) 453-5465 24 hours a day, seven days a week.

D-Link Technical Support over the Internet: http://support.dlink.com email:support@dlink.com

Tech Support for customers within Canada:

D-Link Technical Support over the Telephone:

(800) 361-5265 Monday to Friday 8:30am to 9:00pm EST

D-Link Technical Support over the Internet:

http://support.dlink.ca email:support@dlink.ca



Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com