





Owner's Manual
EM513
WIRELESS HEADPHONES
Bluetooth

Location of controls



- [PREVIOUS] Button - Play previous track
- [CALL] Button - Call / End Call / Play music / Pause music
- [NEXT] Button - Play next track
- USB charging socket
- [VOLUME UP] Button - Increase volume
- [VOLUME DOWN] Button - Decrease volume
- [POWER] On / Off switch
- Microphone


In the box



Headphones




Owner's Manual



USB Charging Cable

Charging the Headphones


- Connect the snakk end of the USB cable to the charging socket of the Headphones.
- Connect the other end of the USB cable to the Computer's USB port.
- The RED LED indicator light turns on while charging.
- The RED LED indicator light shuts off when the Headphones are fully charged (approximately 3 hours).



NOTE: Make sure you charge your Headphones for a full 3 hours before using it for the first time.


Pairing the Headphones

- Make sure the Headphones are turned on (Move the [POWER] On/Off switch to ON position - green)
- Keep your Headphones and mobile phone within 3 feet of each other during the pairing process.
- Press and HOLD the [CALL] button until the LED indicator light turns a steady BLUE. (approx. 8-10 seconds).
- The Headphones are now in Pairing Mode and ready to connect to your mobile phone.




NOTE: To enter the Pairing Mode, you must press and HOLD the [CALL] button for approximately 10 seconds. This must be done while the headphones are powered ON. Pairing mode will last 1 minute. After 1 minute the headset will return to standby mode.


- Set your mobile phone or other Bluetooth enabled device to search for Bluetooth devices.




- When the phone finds the Headphones, confirm by selecting EM513 from the list.



- Select "Pair" to connect the Headphones to your phone.




NOTE: Depending on which model mobile phone you are trying to connect the Headphones to, it may be necessary to enter a passcode and the following message (or similar) may appear on your phone's display:




Enter passcode "0000" if prompted by the phone.

- Your mobile phone will confirm that the pairing is completed, and prompt you to accept the connection. Please respond YES to connect the Headphones to your mobile phone. If the pairing was successful, the Headphones's indicator light flashes blue 2 times quickly every 4 seconds.



- When attempting to reconnect the Headphones to your mobile phone, you may see the message below, and your mobile phone will prompt you to accept the connection request to the EM513 Headphones, and an option not to ask this again. Please accept the connection, and if you select "Don't ask this again", your phone will automatically accept future connection requests from your Headphones.



NOTE: The screenshots above are typical of many Bluetooth enabled phones in the market today, and are used to assist in the explanation of the pairing process. Your mobile phone's interface and interaction with the Headphones may be slightly different from the illustrations above.

Pairing with multiple devices

The Headphones can be paired with up to 8 devices. Once the number of paired devices exceeds 8, the first one will be replaced.

NOTE: It is only possible to use one paired device at a time.

Pairing with SONY Playstation® (PS3™)

To pair the Headphones with a SONY PlayStation 3, follow the instructions below:

- <SET ACCESSORY to BLUETOOTH on PS3>
- Go to the PS3 main menu, scroll to and select "Settings".
 - Scroll to and select "Accessory Settings".
 - Scroll to and select "Manage Bluetooth Devices".
 - The menu will ask: "The Bluetooth device has not been registered. Do you want to register it?", then select "YES".

<REGISTER EM513 to PS3>

Put your Bluetooth Headphones into pairing mode. (See "Pairing the Headphones with a Bluetooth enabled device")

- Select "Start Scanning" from the PS3 menu.
- Once the PS3 has discovered the Headphones, the screen will read "Select the Bluetooth device to register", then select "EM513".
- The PS3 will ask for a passkey. Enter [0000] then select "OK". Now press [O] (the PS3 circle button) to get back to the previous menu.
- Scroll to and select "Audio Device Settings" to change the "Input Device" to "EM513".

NOTE: "Input Device" is the microphone, and determines the method of how how others will hear you speak. By default, the "Output Device" will now switch to "EM513". "Output Device" is the audio, and determines how you will hear the PS3 audio and others speaking.

To test the connection, speak into the Headphones and you will see the bars above the "Microphone Level" moving, if not, repeat the pairing process.

Press "OK" to confirm the new settings. You are now ready to use the Bluetooth Headphones with your PS3 Entertainment System. If you would like to hear the PS3 audio through your TV or Audio System, scroll to "Output Device" and switch to "System Default Device".

For further assistance with Bluetooth settings on your PS3 please refer to your PS3 instruction manual.

Using your Headphones

Powering ON/OFF

- To turn ON, move the [POWER] On/Off switch to the ON position (Green) The BLUE LED Indicator light will flash 2 times quickly every 4 seconds when the Headphones are powered on.
- To turn OFF, move the [POWER] On/Off switch to the OFF position (Red)

- Answering/Ending a call
- To answer a call, press the [CALL] button once.
 - To end a call, press the [CALL] button once.

If the Headphones are powered on and a call comes in, the Headphones will beep to indicate the incoming call.

To make a call
Dial the number and press the send button on your mobile phone, the call is automatically transferred to the Headphones.

Adjusting the volume
Press the [VOLUME UP] or [VOLUME DOWN] button to adjust the volume to the desired level.

NOTE: You may also adjust the volume from your mobile phone's volume control.

Stereo Bluetooth

These Headphones allow you to listen (in full stereo) and control* the music on your Bluetooth enabled mobile phone, gaming console, computer or mp3 player and supports the following Bluetooth profiles:

- A2DP - Advanced Audio Distribution Profile
- AVRCP - Audio/Video Remote Control Profile
- HSP - Headset Profile
- HFP - Handsfree Profile

To use the Headphones to listen/control music, your Bluetooth enabled device must support the A2DP and AVRCP profiles. Please refer to the user guide of your Bluetooth enabled device for more information.

*The Sharper Image Bluetooth stereo wireless Headphones are compatible with any brand of Bluetooth-enabled phone or music device that supports Advanced Audio Distribution Profile (A2DP) and Audio Video Remote Control Profile (AVRCP).

In order for Bluetooth devices to communicate with one another properly, they must utilize the same Bluetooth profile. To determine the profiles supported by your device (mobile phone, gaming console, computer or mp3 player), please refer to the device's user guide.

Certain Bluetooth features including those listed may not be supported by all compatible Bluetooth-enabled devices, and/or the functionality of such features may be limited in certain devices.

Playing Music

To enjoy wireless music on your Headphones, you must open the music player or application on your device, then press the [CALL] button on the Headphones. Once playback has begun, you can control the music or answer phone calls from the control buttons of the Headphones (not all mobile phones support the control of music using Bluetooth).


NOTE: Some phones or bluetooth enabled media players require that you first press the [PLAY/PAUSE] button on your device before you can control the music with the Headphones.

Play/Pause*
Press the [CALL] button to pause the music. To resume music playback, press the [CALL] button again.

Skipping or searching songs*
Press the [PREVIOUS] button to go to the previous song. Press the [NEXT] button to go to the next song.

Adjusting the volume
Press the [VOLUME UP] or [VOLUME DOWN] button to adjust the volume to the desired level.

NOTE: You may also adjust the volume from your mobile phone's volume control.




Safety information

FCC Part 15
This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Do not attempt to repair or modify this equipment. Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Safety information



- Do not use these device while driving.
- Observe all signs in the designated areas where some electronic devices or RF radio products are required to be switched off. These could include airplanes, hospitals, blasting areas, and potentially explosive atmospheres.

Troubleshooting tips

I can pair the Headphones with my Bluetooth device, but I cannot hear any music?

- Make sure your Bluetooth device supports A2DP profile.

I cannot get the Headphones into Pairing Mode.

- Make sure the Headphones are turned off before beginning the pairing process.
- Press and hold the [CALL] button until the LED indicator light BLUE turns steady, this will signal that the Headphones are in Pairing Mode, and ready to connect to your mobile phone.

My mobile phone is not able to pair with the Headphones.

- Make sure that you fully charged the Headphones before pairing.
- Keep your Headphones and mobile phone within 3 feet of each other during the pairing process.
- Check that your phone's Bluetooth feature is turned ON.
- Try repeating the pairing process, see "Pairing the Headphones".

After successfully pairing my mobile phone and Headphones, when I shut my phone and turn it on again, my Headphones did not automatically connect.

- Try turning the Headphones OFF, and then turning them ON again.
- Many mobile phones have an auto reconnect option when first attempting to reconnect to a newly paired Bluetooth device. Make sure you accept this option, so that your Headphones automatically reconnect to your mobile phone (check the user guide of your mobile phone for more information regarding this option).
- Try unpairing the Headphones from your phone, and repeat the pairing procedure.

I hear distortion, and the sound quality is poor.

- Try keeping the Headphones closer to the Bluetooth enabled device.
- Check that the battery is charged enough.

The sound is very low.

- Try adjusting the volume by using the [Volume] buttons on your Headphones; make sure the volume on your mobile phone is turned up as well.

Limited Warranty

1 Year Limited Warranty
In the unlikely event that this product is defective, or does not perform properly, you may within (1) year from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:

- Provide proof of the date of purchase within the package (Dated bill of sale).
- Prepay all shipping costs to the authorized service center, and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

Southern Telecom, Inc.
Attention: Customer Service (2nd Floor)
14-C 53rd Street
Brooklyn, NY 11232

Should you have any questions or problems concerning this product, please contact our customer service department at:

Customer Support:

1-877-768-8483 (Toll Free)
cs@southern telecom.com

Monday - Thursday: 9AM - 5PM (EST)
Friday: 9AM - 3PM (EST)

www.southern telecom.com

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

Limitation of Warranty:

THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY AIT, INC. IT'S AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. AIT, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>