



Bluetooth Headset
User Manual
EM516


Let's Get Started →

In the box



Bluetooth Headset

User Guide



Charging Cable


Location of controls




1. [M] - Play/Pause and Answer/End calls/LED Indicator light
2. Microphone
3. [V+] - Increase volume
4. [V-] - Decrease volume
5. Charging port

Charging the Bluetooth Headset

1. Connect the small end of the charging cable into the charging cable on the side of the Headset.
2. Connect the other end of the charging cable to your computer's USB port.
3. The LED indicator light turns RED when charging.
4. The LED indicator light turns OFF when finishing charging.



1. Make sure the EM516 is turned off.
2. Keep your EM516 and Bluetooth enabled device within 3 feet of each other during the pairing process.
3. Set your mobile phone or other Bluetooth enabled device to search for Bluetooth devices.



On an iPhone

- Go to SETTINGS > GENERAL > BLUETOOTH (Make sure Bluetooth is turned ON)



On a Blackberry

- Go to SETTINGS/OPTIONS > BLUETOOTH
- Enable BLUETOOTH




On an Android Phone

- Go to SETTINGS > BLUETOOTH > MENU > Search for devices (Make sure Bluetooth is turned ON)



On other Cell Phones/Devices

Review the instruction manual that came with your phone/device.



NOTE: The illustrations above are typical of many Bluetooth enabled phones in the market today, and are used to assist in the explanation of the pairing process. Your mobile phone's interface and interaction with the headset may be slightly different from the illustration above.

4. Press and hold the [M] button on the EM516 until the LED Indicator Light flashes RED and BLUE alternately (approximately 6 seconds). The LED Indicator Light will turn BLUE after 3 seconds, but keep holding until the light flashes BLUE and RED.
5. When the Bluetooth enabled device finds the EM516, confirm by selecting EM516 from the list. If asked for a passcode, enter "0000" (four zeroes).
6. After a successful registration, the LED Indicator light will blink BLUE twice quickly every 3 seconds.

Using your Bluetooth Headset

Powering ON/OFF

- To turn ON, press and hold the [M] button (approximately 3 seconds). The LED Light indicator will flash BLUE and the voice prompter will say "Power on."
- To turn OFF, press and hold the [M] button (approximately 3 seconds). The LED Light indicator will flash RED, the voice prompter will say "Power off," and the headset will turn off.

Answering / Ending a call

- To answer a call, quickpress the [M] button.
- To end a call, quickpress the [M] button.

To make a call

Dial the number and press the send button on your mobile phone, the call is automatically transferred to the Headset.



Rejecting calls

To reject an incoming call, press and hold the [M] button for 2 seconds and then release.

NOTE: If you hold too long, the headset will turn off.

Redialing the last number called (Dependent on your phone supporting this feature)
Quickpress the [M] button twice quickly. The last number called will be redialed.

Playing Music

To enjoy wireless music on your Bluetooth Headset, make sure you are connected to a Bluetooth enabled device.

i In order to play the previous or next song, you must use your Bluetooth enabled device's controls.

Adjusting the Volume

- Press the [V+] button to increase the volume.
- Press the [V-] button to decrease the volume.

Play/Pause

- Press the [M] button to pause the music.
- To resume music playback, press the [M] button again.



Answering / Ending Calls

If the Bluetooth enabled device you are using to play music is a mobile phone and you receive a phone call, the music will be interrupted.

1. To accept the call, press the [M] button. If you accept the call, the conversation will be replayed by the Bluetooth Headset. You can speak into the microphone of the Bluetooth Headset during the conversation. After you have ended the call, the devices will remain connected and playback will continue.
2. To reject an incoming call, press and hold the [M] button for 2 seconds and then release. If you reject the call, playback will continue.

***The Emerson Bluetooth Headset is compatible with any brand of Bluetooth-enabled phone or music device that supports Advanced Audio Distribution Profile (A2DP) and Audio Video Remote Control Profile (AVRCP).**

In order for Bluetooth devices to communicate with one another properly, they must utilize the same Bluetooth profile. To determine the profiles supported by your device (mobile phone, gaming console, computer or mp3 player), please refer to the device's user guide.

Certain Bluetooth features including those listed may not be supported by all compatible Bluetooth-enabled devices, and/or the functionality of such features may be limited in certain devices.

Troubleshooting tips

i The Bluetooth Headset won't turn on.

• The battery may be exhausted. Try charging the battery.

i There is no audio signal through the Bluetooth connection.

- If the Bluetooth Headset is turned OFF, then turn it ON.
- The Bluetooth Headset may not be paired to the Bluetooth enabled device. Try checking whether the connection exists. If necessary, try pairing the Bluetooth enabled device to the Bluetooth Headset again.
- The volume level of the Bluetooth enabled device may be too low. Try increasing the volume of the Bluetooth enabled device.

i I can pair the Bluetooth Headset with my Bluetooth enabled device, but I cannot hear any music?

- Make sure your Bluetooth enabled device supports A2DP profile.
- Turn up the volume on your Bluetooth enabled device.
- For some Bluetooth enabled devices, you must open your Bluetooth settings and make sure "media" is turned ON.

i My Bluetooth enabled device is not able to pair with the Bluetooth Headset.

- Make sure the Bluetooth Headset are turned OFF before beginning the pairing process.
- Keep your Bluetooth Headset and Bluetooth enabled device within 3 feet of each other during the pairing process.
- Press and hold the [M] button on the EM516 until the LED Indicator Light flashes RED and BLUE alternately (approximately 6 seconds). The LED Indicator Light will turn BLUE after 3 seconds, but keep holding until the light flashes BLUE and RED.
- Check that your device's Bluetooth feature is turned ON.
- Try repeating the pairing process, see "Pairing the EM516".

FCC Part 15

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Do not attempt to repair or modify this equipment. Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Industry Canada

Operation is subject to the two following conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The term "IC" before the certification/registration number only signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

Legal information

Limited Warranty

In the unlikely event that this product is defective, or does not perform properly, you may within 90 days from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:

- Provide proof of the date of purchase within the package (Dated bill of sale).
- Prepay all shipping costs to the authorized service center, and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product. Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

Southern Telecom, Inc.
ATTN: Customer Service (2nd Floor)
14-C 53rd Street
Brooklyn, NY 11232

Should you have any questions or problems concerning this product, please contact our customer service department at:

1-877-768-8483 (Toll Free)
Monday - Friday: 8AM - 10PM (EST)
or
via e-mail at
cs@southern telecom.com

Limited Warranty

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

Limitation of Warranty:

THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY SOUTHERN TELECOM INC. ITS AGENTS, OR EMPLOYEES SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. SOUTHERN TELECOM INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK, EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

www.emersonphones.com
Distributed by Southern Telecom Inc. Brooklyn, NY 11232 © 2011 Southern Telecom Inc. All rights reserved. Emerson and the G-Clef logo are registered trademarks of Emerson Radio Corp. Parsippany, New Jersey USA. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. SONY PlayStation® & PS3™ are either trademarks or registered trademarks of SONY. All other trademarks are trademarks of their respective owners.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>