

bifinett

KH 6588

Instruction
Manual





KH6588
KH6588

IMPORLANT SAFEGUARDS

Please read these operating instructions through carefully before connecting your device to the mains, in order to avoid damage due to incorrect use. Please pay particular attention to the safety information. If you pass the device on to a third party, these operating must be handed over.

01. Incorrect operation and improper handling can lead to faults on the device and injuries to the user.
02. In the event of improper use or incorrect handling, no liability can be accepted for any damages that may occur.
03. Before you put the plug into the socket, please check that the type of current and mains voltage correspond to the instructions on the nameplate on the underside of the appliance.
04. Keep the base away from damp, and protect from splashes.
05. Do not immerse the unit or mains plug in water or other liquids, there is danger to life due to electric shock! However, if this should occur, remove the mains plug immediately and then have the unit checked by an expert before using it again.
06. Do not operate the device if the mains cable or the mains plug show signs of damage, if the device has fallen on the floor or has been otherwise damaged. In such cases take the device to a specialist for checking and repair, if necessary.
07. Ensure that the main cable does not hang over sharp edges and keep it away from hot objects and open flames. Only pull it out of the socket by the plug, not by the cable.
08. This device is not suitable for commercial use nor for use in the open air.
09. You should never leave the device unattended during use.
10. Children cannot recognize the hazards which attend improper handling of electrical devices. Therefore, children should never use electrical household appliances unsupervised.
11. Use the kettle only with the base supplied, and do not use the base for any other purposes.
12. Do not overfill! Check the level indicator (MAX) inside the main body when filling.
13. **Dangerous:** If the kettle is overfilled, boiling water may be ejected.
14. Never remove the kettle from its base while in operation. Switch the appliance off first.
15. Take care to close the lid properly before switching on. Otherwise, the appliance will not switch off automatically and hot water may overflow.
16. The kettle is for heating water only, and is not to be used for any other fluids.
17. **Caution:** Danger of burn! The kettle becomes very hot during use. So hold it by the handle only.
18. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or similar qualified person in order to avoid a hazard.
19. **Warning:** Do not remove the lid while the water is boiling.
20. Kettle is only to be used with the stand provided.

TECHNICAL DATA:

Voltage: 230V AC
Power: 2200W
Volume: 1.7 L

BEFORE FIRST USE

01. Remove all packaging material!
02. Clean the kettle by filling with clean water and bringing to the boil (see "operation"). Pour away the water then repeat the operation.

OPERATION

01. Wind out the mains cord only as much as necessary. Draw it out through the opening in the base and connect it to a suitable mains socket.
02. Open the lid and pour water of the desired quantity in. While doing so, watch the water level mark. Never go below the minimum (0.5L) or above the maximum (MAX) marks.
03. Close the lid and ensure that the kettle is switched off before setting it on the base.
04. Switch on, the appliance will begin to operate, and the indicator light will come on.
05. When the water boils, the appliance will switch off automatically and the indicator light will go off.
06. If you wish to stop the boiling process or interrupt it temporarily, switch the appliance off by pushing the switch upwards, before removing the kettle from its base.

Note: This appliance has a safety device which automatically switches off the heater element if the appliance is inadvertently switched on when empty, or if it boils dry. In this case, let the appliance cool down completely, before filling with water again.

CLEANING AND CARE

Please also observe the safety advice for this.

01. Always remove the plug from the mains socket before cleaning the base. Let the kettle cool down completely.
02. Clean the outside of the kettle and the base with a soft dry cloth. Do not use scouring materials.
03. Descale at regular intervals. Use a descaling agent, which can be obtained from specialist shops given.

STATEMENT OF CONFORMITY

We, Kompernaß Handelsgesellschaft mbH, Burgstr. 21, D-44867 Bochum, hereby declare that this product conforms with the following EC regulations:

EC low voltage regulations:	73/23 EEC, 93/86 EEC
Electromagnetic Compatibility:	89/336 EEC, 93/86 EEC
Applicable harmonized standards:	EN 60335-1; 1994+A11:1995+A1,A12:1996 +A13,A14:1998+A2,A15:2000+A16:2001 EN60335-2-15:1996+A1;1999+A2:2000+ prA3:2000+prAA:2001

Test report issued by: TÜV Rheinland Safety GmbH

Type: KH 6588

Description of the machinery: Kettle

Bochum, 01.05.2001



Hans Kompernaß
- Managing Director -

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>